



Operating Instructions

Diesel engine
12V4000S11 (T1237K39)

M015284/04E

Engine model	kW/cyl.	Application group
12V4000S11	107.2 kW/cyl.	4C, short time operation

Table 1: Applicability

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to §15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

California Proposition 65

This warning applies only to the State of California, USA, in compliance with Title 27 California Code of Regulations, Article 6, Clear and Reasonable Warnings.

 **WARNING:** Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel.

(→ www.P65warnings.ca.gov/diesel)

Table of Contents

1 Preface		7 Maintenance	
1.1 Preface	7	7.1 Maintenance task reference table [QL 1]	42
2 Safety		8 Troubleshooting	
2.1 Important provisions for all products	8	8.1 Troubleshooting	43
2.2 Intended use of all products	9	8.2 Fault messages from DDEC engine governor	46
2.3 Personnel and organizational requirements	10	9 Task Description	
2.4 Safety regulations for commissioning and operation	11	9.1 Engine	65
2.5 Safety regulations for assembly, maintenance, and repair work	13	9.1.1 Engine – Manual barring	65
2.6 Fire and environmental protection, indirect materials	17	9.1.2 Engine – Cranking on starting system	66
2.7 Standards for warning messages in the text and highlighted information	20	9.2 Cylinder Liner	67
3 Transport		9.2.1 Cylinder liner – Endoscopic inspection	67
3.1 Transport	21	9.2.2 Cylinder liner – Instructions and comments on endoscopic and visual examination	69
3.2 Crankshaft transport locking device	23	9.3 Crankcase Breather	71
4 General Information		9.3.1 Crankcase breather (open-circuit crankcase ventilation) – Filter element cleaning	71
4.1 Engine side and cylinder designations	24	9.3.2 Crankcase breather – Filter element replacement	72
4.2 Engine layout	25	9.4 Valve Drive	74
4.3 Sensors, actuators and injectors – Overview	27	9.4.1 Valve gear – Lubrication	74
4.4 Data acquisition and data transmission	30	9.4.2 Valve clearance – Check and adjustment	75
5 Technical Data		9.4.3 Cylinder head cover – Removal and installation	78
5.1 Engine data 12V4000S	31	9.5 Injection Pump / HP Pump	79
5.2 Firing order	33	9.5.1 HP fuel pump – Relief bore check	79
5.3 Main engine dimensions	34	9.6 Injection Valve / Injector	80
6 Operation		9.6.1 Injector – Replacement	80
6.1 Preparations for putting into operation after extended out-of-service periods (>3 months)	35	9.6.2 Injector – Removal and installation	81
6.2 Putting the engine into operation after scheduled out-of-service period	36	9.7 Fuel System	86
6.3 Engine – Starting in manual mode	37	9.7.1 Fuel system – Venting	86
6.4 Re-starting the engine following an automatic safety shutdown	38	9.8 Fuel Filter	87
6.5 Operational monitoring	39	9.8.1 Fuel filter – Replacement	87
6.6 Engine – Stopping in manual mode	40	9.8.2 Intermediate fuel filter – Replacement	88
6.7 After stopping the engine – Putting the engine out of operation	41	9.8.3 Fuel prefilter – Draining	89
		9.8.4 Fuel prefilter – Filter element replacement	91
		9.9 Charge-Air Cooling General, Left-Hand Side	95
		9.9.1 Intercooler – Checking condensate drain for coolant leakage and obstruction	95
		9.10 Air Intake	96
		9.10.1 Service indicator – Check	96

9.11 Lube Oil System, Lube Oil Circuit	97	9.16 Battery-Charging Generator	123
9.11.1 Engine oil – Change	97	9.16.1 Battery-charging generator drive – Drive belt tension adjustment	123
9.11.2 Engine oil level – Check	98	9.16.2 Battery-charging generator drive – Drive belt condition check	124
9.11.3 Engine oil level – Check	99	9.16.3 Battery-charging generator drive – Drive belt replacement	125
9.11.4 Engine oil – Sample extraction and analysis	100	9.17 Auxiliary PTO	126
9.12 Oil Filtration / Cooling	102	9.17.1 Compressor – Check	126
9.12.1 Engine oil filter – Replacement	102	9.18 Wiring (General) for Engine/Gearbox/Unit	127
9.12.2 Centrifugal oil filter – Cleaning and filter sleeve replacement	103	9.18.1 Engine cabling – Check	127
9.13 Coolant Circuit, General, High-Temperature Circuit	105	9.19 Accessories for (Electronic) Engine Governor / Control System	128
9.13.1 Engine coolant – Filling	105	9.19.1 DDEC and connectors – Cleaning	128
9.13.2 Engine coolant – Draining	107	9.19.2 DDEC – Checking plug-in connections	130
9.13.3 Engine coolant – Change	109		
9.13.4 Engine coolant level – Check	110	10 Appendix A	
9.13.5 Engine coolant pump – Relief bore check	111	10.1 Manufacturer's documentation	131
9.13.6 Engine coolant – Sample extraction and analysis	112	10.2 Contact person / Service partner	132
9.14 Low-Temperature Circuit	114	10.3 Abbreviations	133
9.14.1 Charge-air coolant – Filling	114		
9.14.2 Charge-air coolant – Draining	117	11 Appendix B	
9.14.3 Charge-air coolant – Change	119	11.1 Standard Tools and Special Tools	136
9.14.4 Charge-air coolant level – Check	120	11.2 Index	142
9.14.5 Charge-air coolant pump – Relief bore check	121		
9.15 Belt Drive	122		
9.15.1 Drive belt – Condition check	122		

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer Rolls-Royce Solutions.

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at: <http://www.mtu-solutions.com>

2.2 Intended use of all products

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/Rolls-Royce Solutions contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all safety and warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

2.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.