

Operating Instructions

Diesel engine

8V4000Gx1

12V4000Gx1

16V4000Gx1

M015570/05E



Power. Passion. Partnership.

Engine model	Power	Application group
8V4000G6 1	91.9/93.8 kW/cyl. (3A) 111.9/119.4 kW/cyl. (3B, 3C) 123.1/131.3 kW/cyl. (3D)	3A, continuous operation, unrestricted 3B, continuous operation at variable load 3C, continuous operation, time-limited 3D standby power, fuel stop power, IFN
8V4000G8 1	93.8 kW/cyl. (3A) 125 kW/cyl. (3B) 137.5 kW/cyl. (3D)	3A, continuous operation, unrestricted 3B, continuous operation at variable load 3D standby power, fuel stop power, IFN
12V4000G2 1	100.4/109.2 kW/cyl. (3B, 3C) 110.8/120.4 kW/cyl. (3D)	3B, continuous operation at variable load 3C, continuous operation, time-limited 3D standby power, fuel stop power, IFN
12V4000G4 1	85 kW/cyl. (3A) 112.9 kW/cyl. (3B) 124.2 kW/cyl. (3D)	3A, continuous operation, unrestricted 3B, continuous operation at variable load 3D standby power, fuel stop power, IFN
12V4000G6 1	91.3/93.3 kW/cyl. (3A) 110.8/120.4 kW/cyl. (3B, 3C) 122.1/132.5 kW/cyl. (3D)	3A, continuous operation, unrestricted 3B, continuous operation at variable load 3C, continuous operation, time-limited 3D standby power, fuel stop power, IFN
12V4000G8 1	93.3 kW/cyl. (3A) 124.2 kW/cyl. (3B) 136.7 kW/cyl. (3D)	3A, continuous operation, unrestricted 3B, continuous operation at variable load 3D standby power, fuel stop power, IFN
16V4000G2 1	100/108.4 kW/cyl. (3B, 3C) 110/119.4 kW/cyl. (3D)	3B, continuous operation at variable load 3C, continuous operation, time-limited 3D standby power, fuel stop power, IFN
16V4000G4 1	85 kW/cyl. (3A) 113.1 kW/cyl. (3B) 124.4 kW/cyl. (3D)	3A, continuous operation, unrestricted 3B, continuous operation at variable load 3D standby power, fuel stop power, IFN
16V4000G6 1	90.6/93.4 kW/cyl. (3A) 110/119.4 kW/cyl. (3B, 3C) 121.3/131.3 kW/cyl. (3D)	3A, continuous operation, unrestricted 3B, continuous operation at variable load 3C, continuous operation, time-limited 3D standby power, fuel stop power, IFN
16V4000G8 1	93.4 kW/cyl. (3A) 124.4 kW/cyl. (3B) 136.9 kW/cyl. (3D)	3A, continuous operation, unrestricted 3B, continuous operation at variable load 3D standby power, fuel stop power, IFN

Table 1: Applicability

Table of Contents

1	Safety			
1.1	Important provisions for all products	5		
1.2	Gendrive engines – Intended use	7		
1.3	Personnel and organizational requirements	8		
1.4	Safety regulations for initial start-up and operation	9		
1.5	Safety regulations for assembly, maintenance, and repair work	11		
1.6	Fire and environmental protection, fluids and lubricants	15		
1.7	Standards for warning notices in the text and highlighted information	18		
2	Transport			
2.1	Transport	19		
2.2	Lifting specifications	21		
2.3	Crankshaft transport locking device	22		
3	General Information			
3.1	Engine side and cylinder designations	25		
3.2	Engine layout	26		
3.3	Sensors and actuators – Overview	27		
4	Technical Data			
4.1	8/12/16V 4000 engine data: Standby operation 3D, optimized fuel consumption	31		
4.2	8/12/16V 4000 engine data: Standby operation 3D, optimized exhaust emission (EPA)	35		
4.3	8/12/16V 4000 engine data: Continuous operation, limited 3C, optimized fuel consumption	39		
4.4	8/12/16V 4000 engine data: Continuous operation, limited, 3C, optimized exhaust emission ("TA-Luft")	43		
4.5	8/12/16V 4000 engine data: Continuous operation, variable 3B, optimized fuel consumption	47		
4.6	8/12/16V 4000 engine data: Continuous operation, variable 3B, optimized exhaust emission ("TA-Luft")	51		
4.7	8/12/16V 4000 engine data: Continuous operation, variable 3B, optimized exhaust emission (EPA)	55		
4.8	8/12/16V 4000 engine data: Continuous operation, unlimited 3A, optimized fuel consumption	59		
4.9	8/12/16V 4000G engine data: Continuous operation, unlimited 3A, optimized exhaust emission (EPA)	63		
4.10	Firing order	67		
4.11	Engine – Main dimensions	68		
5	Operation			
5.1	Preparations for putting operation after extended out-of-service periods (>3 months)	69		
5.2	Preparations for putting into operation after scheduled out-of-service-period	70		
5.3	Starting the engine in manual mode (test run)	71		
5.4	Re-starting the engine following an automatic safety shutdown	72		
5.5	Safety system – Override	73		
5.6	Emergency engine start (Override mode)	74		
5.7	Operational checks	75		
5.8	Engine – Stopping in Manual mode (test run)	76		
5.9	Engine – Emergency stop	78		
5.10	After stopping the engine – Engine remains ready for operation	79		
5.11	After stopping the engine – Putting the engine out of operation	80		
5.12	Plant – Cleaning	81		
6	Maintenance			
6.1	Maintenance task reference table [QL1]	82		
7	Troubleshooting			
7.1	Troubleshooting	84		
7.2	Fault messages on engine governor	87		
8	Task Description			
8.1	Engine	98		
8.1.1	Engine – Barrage manually	98		
8.1.2	Engine – Cranking on starting system	99		
8.1.3	Engine – Test run	100		
8.2	Cylinder Liner	101		
8.2.1	Cylinder liner – Endoscopic inspection	101		
8.2.2	Cylinder liner – Instructions and comments on endoscopic and visual examination	103		
8.3	Crankcase Breather	105		
8.3.1	Crankcase breather – Filter element replacement	105		

8.3.2 Crankcase breather - Oil separator replacement, diaphragm check and replacement	106	8.15 Coolant Circuit, General, High-Temperature Circuit	146
8.4 Valve Drive	108	8.15.1 Engine coolant - Level check	146
8.4.1 Valve gear - Lubrication	108	8.15.2 Engine coolant - Change	148
8.4.2 Valve clearance - Check and adjustment	109	8.15.3 Engine coolant - Draining	149
8.4.3 Cylinder head cover - Removal and installation	114	8.15.4 Engine coolant - Filling	150
8.5 Injection Pump / HP Pump	115	8.15.5 Engine coolant pump - Relief bore check	153
8.5.1 HP fuel pump - Relief bore check	115	8.15.6 Engine coolant - Sample extraction and analysis	154
8.6 Injection Valve / Injector	116	8.16 Low-Temperature Circuit	156
8.6.1 Injector - Replacement	116	8.16.1 Charge-air coolant level - Check	156
8.6.2 Injector - Removal and installation	117	8.16.2 Charge-air coolant - Change	158
8.7 Fuel System	122	8.16.3 Charge-air coolant - Draining	159
8.7.1 Fuel system - Venting	122	8.16.4 Charge-air coolant - Filling	161
8.8 Fuel Filter	123	8.16.5 Charge-air coolant pump - Relief bore check	165
8.8.1 Fuel filter - Replacement	123	8.16.6 Charge-air coolant - Sample extraction and analysis	166
8.8.2 Fuel prefilter - Cleaning	124	8.17 Belt Drive	168
8.8.3 Fuel prefilter - Differential pressure gauge check and adjustment	125	8.17.1 Drive belt - Condition check	168
8.8.4 Fuel prefilter - Draining	126	8.18 Battery-Charging Generator	169
8.8.5 Fuel prefilter - Flushing	128	8.18.1 Battery-charging generator drive - Drive belt tension adjustment	169
8.8.6 Fuel prefilter - Filter element replacement	131	8.18.2 Battery-charging generator drive - Drive belt condition check	170
8.9 Charge-Air Cooling	133	8.18.3 Battery-charging generator drive - Drive belt replacement	171
8.9.1 Intercooler - Checking condensate drain for coolant leakage and obstruction	133	8.19 Cabling	172
8.10 Air Filter	134	8.19.1 Engine cabling - Check	172
8.10.1 Air filter - Replacement	134	8.20 Accessories for (Electronic) Engine Governor / Control System	173
8.10.2 Air filter - Removal and installation	135	8.20.1 Engine governor and connectors - Cleaning	173
8.11 Air Intake	136	8.20.2 Engine Control Unit - Plug connection check	174
8.11.1 Contamination indicator - Signal ring position check	136	9 Appendix A	
8.12 Starting Equipment	137	9.1 Abbreviations	175
8.12.1 Air starter - Manual operation	137	9.2 Conversion tables	179
8.13 Lube Oil System, Lube Oil Circuit	138	9.3 MTU Contact/Service Partners	183
8.13.1 Engine oil level - Check	138	10 Appendix B	
8.13.2 Engine oil - Change	139	10.1 Special Tools	184
8.13.3 Engine oil - Sample extraction and analysis	141	10.2 Index	190
8.14 Oil Filtration / Cooling	143		
8.14.1 Engine oil filter - Replacement	143		
8.14.2 Centrifugal oil filter - Cleaning and filter sleeve replacement	144		

1 Safety

1.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by MTU come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emission specifications and emission label

Responsibility for compliance with emission regulations

Modification or removal of any mechanical/electronic components or the installation of additional components including the execution of calibration processes that might affect the emission characteristics of the product are prohibited by emission regulations. Emission-related components must only be serviced, exchanged or repaired if the components used for this purpose are approved by the manufacturer.

Noncompliance with these specifications will invalidate the design type approval or certification issued by the emissions regulation authorities. The manufacturer does not accept any liability for violations of the emission regulations.

The product must be operated over its entire life cycle according to the conditions defined as "Intended use" (→ Page 7).

Emission certification applicable to engines with EPA Nonroad Tier 4 emission certification in accordance with 40 CFR 1039 and with EPA Locomotive emission certification in accordance with 40 CFR 1033

Extract from the standard:

Failing to follow these instructions when installing a certified engine in a piece of nonroad equipment violates federal law (40 CFR 1068.105(b)), subject to fines or other penalties as described in the Clean Air Act.

Extract from the standard:

If you install the engine in a way that makes the engine's emission control information label hard to read during normal engine maintenance, you must place a duplicate label on the equipment, as described in 40 CFR 1068.105.

When fitting the second label, the requirements of 40 CFR 1068.105(c) must be followed and observed. This paragraph describes the process for requesting and fitting the label, the documentation obligations and storage obligations for the required documents.

Replacing components with emission labels

On all MTU engines fitted with emission labels, these labels must remain on the engine throughout its operational life.

Exception: Engines used exclusively in land-based, military applications other than by US government agencies.

Please note the following when replacing components with emission labels:

- The relevant emission labels must be affixed to the spare part.
- Emission labels shall not be transferred from the replaced part to the spare part.
- The emission labels must be removed from the replaced part and destroyed.

1.2 Gendrive engines – Intended use

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the admissible operating parameters in accordance with the (→ technical sales documents – product data – TVU data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/MTU contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and observance of all safety and warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques

The product shall not be operated in explosive atmospheres unless it fulfills the conditions for such use and approval has been granted.

The section below applies to applications deployed in regions under the jurisdiction of the EPA.

- Use of EPA Tier 2 and Tier 3 certified genset engines.
- EPA Tier 2 and Tier 3 certified genset engines may only be used in generator sets for stationary emergency applications. Non-emergency operation is limited to 100 hrs per year.

The engines may be used in fixed speed gensets only. Permanent limitation to a max. engine power of less than 560 kW (e.g. by means of correspondingly low generator power) is not admissible.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to use, ensure that the most recent version is available. The latest version can be found at:

- For drive systems: <http://www.mtu-online.com>
- For power generation: <http://www.mtuonsiteenergy.com>

Modifications or conversions

Unauthorized changes to the product breach the conditions concerning its intended use and compromise safety.

Only modifications or conversions expressly authorized by the manufacturer are regarded as compliant in this sense. The manufacturer shall not be held liable for any damage resulting from unauthorized modifications or conversions.

1.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.

1.4 Safety regulations for initial start-up and operation

Safety regulations for initial start-up

Install the product correctly and carry out acceptance in accordance with the manufacturer's specifications before putting the product into service. All necessary approvals must be granted by the relevant authorities and all requirements for initial startup must be fulfilled.

Whenever the product is subsequently taken into operation ensure that:

- All personnel is clear of the danger zone surrounding moving parts of the machine.
Electrically-actuated linkages may be set in motion when the Engine Control Unit (governor) is switched on.
- All maintenance and repair work has been completed.
- All loose parts have been removed from rotating machine components.
- All safeguards are in place.
- All components must be properly grounded. Ground separately by means of a grounding stake as necessary.
- No persons wearing pacemakers or any other technical body aids are present.
- Adequate ventilation of the operating room must be ensured for any operating status.
- In the first few hours of operation, the product emits gases as a result of smoldering e.g. lacquers or oil. These gases may be hazardous to health. Always wear respiratory protection in the operating room during this period.
- The exhaust system is leak-tight and that the gases are vented to atmosphere.
- The product must be free of any damage, this applies in particular to lines and cabling.
- Protect battery terminals, generator terminals or cables against accidental contact.
- Check that all connections have been correctly allocated e.g. +/- polarity, fuel line/reduction agent line, supply/return.

Immediately after putting the product into operation, make sure that all control and display instruments as well as the monitoring, signaling and alarm systems work properly.

Smoking is prohibited in the area of the product.

Safety regulations during operation

The operator must be familiar with the control and display elements.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be permanently observed with regard to present operating status, violation of limit values and warning or alarm messages.

Malfunctions and emergency stop

Practice emergency procedures, especially emergency stopping, at regular intervals.

Take the following steps if any system malfunctions are detected or signaled by the system:

- Inform supervisor(s) in charge.
- Analyze the message.
- Respond by taking any necessary emergency action, e.g. emergency stop.

After a safety shutdown, the engine must only be started after the cause of the shutdown has been eliminated.

Contact Service if the root cause of the malfunction cannot be clearly identified.

Operation

Do not remain in the operating room when the product is running unless absolutely necessary. Keep your stay as short as possible.

Keep a safe distance away from the product if possible. Do not touch the product unless expressly instructed to do so following a written procedure.

Do not inhale the exhaust gases of the product.

The following requirements must be fulfilled before the product is started:

- Wear ear protectors.
- Mop up any leaked or spilled fluids and lubricants immediately or soak up with a suitable binding agent.

Operation of electrical equipment

When electrical equipment is in operation, certain components of these appliances are electrically live.

Follow the applicable operating and safety instructions when operating the devices and heed warnings at all times.