



Operating Instructions

Diesel Engine
8V4000R41x
12V4000R41x
16V4000R41x

M015575/09E



A Rolls-Royce
solution

Engine model	kW/cyl.	Application group
8V4000R41R	106 kW/cyl.	2A; Continuous operation, unrestricted
8V4000R41	125 kW/cyl.	2A; Continuous operation, unrestricted
8V4000R41L	138 kW/cyl.	2A; Continuous operation, unrestricted
12V4000R41R	115 kW/cyl.	2A; Continuous operation, unrestricted
12V4000R41	125 kW/cyl.	2A; Continuous operation, unrestricted
12V4000R41L	138 kW/cyl.	2A; Continuous operation, unrestricted
16V4000R41R	106 kW/cyl.	2A; Continuous operation, unrestricted
16V4000R41	125 kW/cyl.	2A; Continuous operation, unrestricted
16V4000R41L	138 kW/cyl.	2A; Continuous operation, unrestricted

Table 1: Applicability

California Proposition 65

This warning applies only to the State of California, USA, in compliance with Title 27 California Code of Regulations, Article 6, Clear and Reasonable Warnings.

 **WARNING:** Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel.

(→ www.P65warnings.ca.gov/diesel)

Table of Contents

1 Preface			
1.1 Preface	7		
2 Safety			
2.1 Important provisions for all products	8		
2.2 Intended use of all products	10		
2.3 Personnel and organizational requirements	11		
2.4 Safety regulations for initial start-up and operation	12		
2.5 Safety regulations for assembly, maintenance, and repair work	14		
2.6 Fire and environmental protection, indirect materials	18		
2.7 Standards for warning notices in the text and highlighted information	21		
3 Transport			
3.1 Lifting specifications	22		
3.2 Transport	23		
3.3 Crankshaft transport locking device	24		
4 General Information			
4.1 Engine side and cylinder designations	27		
4.2 Engine layout	28		
4.3 Sensors, actuators and injectors - Overview	30		
5 Technical Data			
5.1 Engine data 8/12/16V400041R	33		
5.2 Engine data 8/12/16V4000R41	37		
5.3 Engine data 8/12/16V4000R41L	41		
5.4 Firing order	45		
5.5 Engine - Main dimensions	46		
6 Operation			
6.1 Preparations for putting into operation after extended out-of-service periods (>3 months)	47	6.9 Preparations for extended out-of-service period	55
6.2 Putting the engine into operation after scheduled out-of-service period	48	6.10 After shutting down engine - Putting engine out of operation	56
6.3 Engine - Starting in manual mode	49	6.11 Plant - Cleaning	57
6.4 Re-starting the engine following an automatic safety shutdown	50		
6.5 Safety system - Override	51	7 Maintenance	
6.6 Operational monitoring	52	7.1 Maintenance task reference table [QL1]	59
6.7 Engine - Stopping in manual mode	53	8 Troubleshooting	
6.8 Engine - Emergency stop	54	8.1 Troubleshooting	60
		8.2 ECU fault messages	63
		9 Task Description	
		9.1 Engine	75
		9.1.1 Engine - Barring manually	75
		9.1.2 Barring engine with starting system	77
		9.1.3 Engine - Performing test run	78
		9.2 Cylinder Liner	79
		9.2.1 Cylinder liner - Endoscopic inspection	79
		9.2.2 Cylinder liner - Instructions and comments on endoscopic and visual examination	81
		9.3 Crankcase Breather	83
		9.3.1 Crankcase breather - Filter element replacement	83
		9.3.2 Crankcase breather - Oil separator check	84
		9.4 Belt Drive	85
		9.4.1 Drive belt - Condition check	85
		9.5 Running Gear	86
		9.5.1 Grounding device - Carbon brush replacement	86
		9.6 Flywheel Housing	87
		9.6.1 Grounding equipment - Carbon brush replacement	87
		9.7 Valve Drive	89
		9.7.1 Valve gear - Lubrication	89
		9.7.2 Valve clearance - Check and adjustment	90
		9.7.3 Cylinder head cover - Removal and installation	94
		9.8 Injection Pump / HP Pump	95
		9.8.1 HP fuel pump - Relief bore check	95
		9.9 Injector	96
		9.9.1 Injector - Replacement	96
		9.9.2 Injector - Removal and installation	97
		9.10 Fuel System	102
		9.10.1 Fuel system - Venting	102

9.11 Fuel Filter	103	9.18.4 Engine coolant - Draining	140
9.11.1 Fuel filter - Replacement	103	9.18.5 Engine coolant - Filling	142
9.11.2 Fuel prefilter - Differential pressure gauge check and adjustment	104	9.18.6 Engine coolant pump - Relief bore check	145
9.11.3 Fuel prefilter - Flushing	105	9.18.7 Engine coolant filter - Replacement	146
9.11.4 Fuel prefilter - Draining	108	9.18.8 Coolant expansion tank - Valve cover replacement	147
9.11.5 Fuel prefilter - Filter element replacement	109	9.19 Low-Temperature Circuit	149
9.12 Exhaust Turbocharger	110	9.19.1 Charge-air coolant level - Check	149
9.12.1 Exhaust turbocharger - Visual inspection	110	9.19.2 Charge-air coolant - Change	151
9.13 Charge-Air Cooling	111	9.19.3 Charge-air coolant - Draining	152
9.13.1 Intercooler - Checking condensate drain for coolant leakage and obstruction	111	9.19.4 Charge-air coolant - Filling	154
9.14 Air Filter	112	9.19.5 Charge-air coolant pump - Relief bore check	158
9.14.1 Air filter element and dust bowl (option) - Cleaning	112	9.20 Battery-Charging Generator	159
9.14.2 Air filter - Replacement	113	9.20.1 Battery-charging generator drive - Coupling condition check	159
9.14.3 Air filter element - Removal and installation (optional)	114	9.20.2 Battery-charging generator drive - Drive belt replacement	160
9.15 Air Intake	115	9.21 Engine Mounting / Support	161
9.15.1 Contamination indicator - Signal ring position check	115	9.21.1 Engine mounting - Checking securing screws for firm seating	161
9.16 Engine Oil System	116	9.21.2 Engine mounting - Checking resilient mounts	162
9.16.1 Engine oil level - Check	116	9.22 Drive Systems, Driving End and Free End (Coupling)	164
9.16.2 Engine oil - Change	117	9.22.1 Torsionally resilient coupling - Check	164
9.16.3 Engine oil - Sample extraction and analysis	119	9.23 Wiring (General) for Engine/Gearbox/Unit	165
9.17 Oil Filtration / Cooling	121	9.23.1 Engine cabling - Check	165
9.17.1 Oil filter element - Overview	121	9.24 Accessories for (Electronic) Engine Governor / Control System	166
9.17.2 Oil filter element - Removal	123	9.24.1 Engine governor and connector - Cleaning	166
9.17.3 Oil filter element - Cleaning	124	9.24.2 Engine governor plug connections - Check	167
9.17.4 Oil filter element - Assembly	125	10 Appendix A	
9.17.5 Centrifugal oil filter - Cleaning and filter-sleeve replacement	129	10.1 Contact person/Service partner	168
9.17.6 Oil indicator filter - Cleaning and check	131	10.2 List of abbreviations	169
9.17.7 Engine oil filter - Replacement	134	11 Appendix B	
9.18 Coolant Circuit, General, High-Temperature Circuit	135	11.1 Special Tools	172
9.18.1 Engine coolant - Sample extraction and analysis	135	11.2 Index	179
9.18.2 Engine coolant - Level check	137		
9.18.3 Engine coolant - Change	139		

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer MTU.

Definition of MTU

MTU refers to Rolls-Royce Power Systems AG and MTU Friedrichshafen GmbH or an affiliated company pursuant to Section § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture).

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by MTU come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations and emissions label

Responsibility for compliance with emissions regulations

Modification or removal of any mechanical/electronic components or the installation of additional components including the execution of calibration processes that might affect the emissions characteristics of the product are prohibited by emissions regulations. Emissions-related components must only be serviced, exchanged or repaired if the components used for this purpose are approved by the manufacturer.

Noncompliance with these specifications will invalidate the design type approval or certification issued by the emissions regulation authorities. The manufacturer does not accept any liability for violations of the emissions regulations.

The product must be operated over its entire life cycle according to the conditions defined as "Intended use" (→ Page 10).

Emissions certification applicable to engines with EPA Nonroad Tier 4 emissions certification in accordance with 40 CFR 1039 and with EPA Locomotive emissions certification in accordance with 40 CFR 1033

Extract from the standard:

Failing to follow these instructions when installing a certified engine in a piece of nonroad equipment violates federal law (40 CFR 1068.105(b)), subject to fines or other penalties as described in the Clean Air Act.

Extract from the standard:

If you install the engine in a way that makes the engine's emission control information label hard to read during normal engine maintenance, you must place a duplicate label on the equipment, as described in 40 CFR 1068.105.

When fitting the second label, the requirements of 40 CFR 1068.105(c) must be followed and observed. This paragraph describes the process for requesting and fitting the label, the documentation obligations and storage obligations for the required documents.

Replacing components with emissions labels

On all engines from MTU fitted with emissions labels, these labels must remain on the engine throughout its operational life.

Exception: Engines used exclusively in land-based, military applications other than by US government agencies.

Please note the following when replacing components with emissions labels:

- The relevant emissions labels must be affixed to the spare part.
- Emissions labels shall not be transferred from the replaced part to the spare part.
- The emissions labels must be removed from the replaced part and destroyed.

2.2 Intended use of all products

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/MTU contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all safety and warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.