

Technical Publication

Gas Engine
12 V 4000 L61
16 V 4000 L61

Operating Instructions
M015635/01E



Printed in Germany

© 2006 Copyright MTU Friedrichshafen GmbH

Diese Veröffentlichung einschließlich aller ihrer Teile ist urheberrechtlich geschützt. Jede Verwertung oder Nutzung bedarf der vorherigen schriftlichen Zustimmung der MTU Friedrichshafen GmbH. Das gilt insbesondere für Vervielfältigung, Verbreitung, Bearbeitung, Übersetzung, Mikroverfilmungen und die Einspeicherung und / oder Verarbeitung in elektronischen Systemen, einschließlich Datenbanken und Online-Diensten. Das Handbuch ist zur Vermeidung von Störungen oder Schäden beim Betrieb zu beachten und daher vom Betreiber dem jeweiligen Wartungs- und Bedienungspersonal zur Verfügung zu stellen. Änderungen bleiben vorbehalten.

Printed in Germany

© 2006 Copyright MTU Friedrichshafen GmbH

This Publication is protected by copyright and may not be used in any way whether in whole or in part without the prior written permission of MTU Friedrichshafen GmbH. This restriction also applies to copyright, distribution, translation, microfilming and storage or processing on electronic systems including data bases and online services.

This handbook is provided for use by maintenance and operating personnel in order to avoid malfunctions or damage during operation.

Subject to alterations and amendments.

Imprimé en Allemagne

© 2006 Copyright MTU Friedrichshafen GmbH

Tout droit réservé pour cet ouvrage dans son intégralité. Toute utilisation ou exploitation requiert au préalable l'accord écrit de MTU Friedrichshafen GmbH. Ceci s'applique notamment à la reproduction, la diffusion, la modification, la traduction, l'archivage sur microfiches, la mémorisation et / ou le traitement sur des systèmes électroniques, y compris les bases de données et les services en ligne.

Le manuel devra être observé en vue d'éviter des incidents ou des endommagements pendant le service. Aussi recommandons-nous à l'exploitant de le mettre à la disposition du personnel chargé de l'entretien et de la conduite.

Modifications réservées.

Impreso en Alemania

© 2006 Copyright MTU Friedrichshafen GmbH

Esta publicación se encuentra protegida, en toda su extensión, por los derechos de autor. Cualquier utilización de la misma, así como su reproducción, difusión, transformación, traducción, microfilmación, grabación y/o procesamiento en sistemas electrónicos, entre los que se incluyen bancos de datos y servicios en línea, precisa de la autorización previa de MTU Friedrichshafen GmbH.

El manual debe tenerse presente para evitar fallos o daños durante el servicio, y, por dicho motivo, el usuario debe ponerlo a disposición del personal de mantenimiento y de servicio.

Nos reservamos el derecho de introducir modificaciones.

Stampato in Germania

© 2006 Copyright MTU Friedrichshafen GmbH

Questa pubblicazione è protetta dal diritto d'autore in tutte le sue parti. Ciascun impiego o utilizzo, con particolare riguardo alla riproduzione, alla diffusione, alla modifica, alla traduzione, all'archiviazione in microfilm e alla memorizzazione o all'elaborazione in sistemi elettronici, comprese banche dati e servizi on line, deve essere espressamente autorizzato per iscritto dalla MTU Friedrichshafen GmbH.

Il manuale va consultato per evitare anomalie o guasti durante il servizio, per cui va messo a disposizione dall'utente al personale addetto alla manutenzione e alla condotta.

Con riserva di modifiche.

Impresso na Alemanha

© 2006 Copyright MTU Friedrichshafen GmbH

A presente publicação, inclusive todas as suas partes, está protegida pelo direito autoral. Qualquer aproveitamento ou uso exige a autorização prévia e por escrito da MTU Friedrichshafen GmbH. Isto diz respeito em particular à reprodução, divulgação, tratamento, tradução, microfilmagem, e a memorização e/ou processamento em sistemas eletrônicos, inclusive bancos de dados e serviços on-line.

Para evitar falhas ou danos durante a operação, os dizeres do manual devem ser respeitados. Quem explora o equipamento economicamente consequentemente deve colocá-lo à disposição do respectivo pessoal da conservação, e à disposição dos operadores.

Salvo alterações.

Wichtig – Important – Importante

Bitte die Karte „Inbetriebnahmemeldung“ abtrennen und ausgefüllt an MTU Friedrichshafen GmbH zurücksenden.

Die Informationen der Inbetriebnahmemeldung sind Grundlage für den vertraglich vereinbarten Logistik-Support (Gewährleistung, Ersatzteile etc.).

Please complete and return the “Commissioning Note” card below to MTU Friedrichshafen GmbH.

The Commissioning Note information serves as a basis for the contractually agreed logistic support (warranty, spare parts, etc.).

Veillez séparer la carte “Signalisation de mise en service” et la renvoyer à la MTU Friedrichshafen GmbH.

Les informations contenues dans la signalisation de mise en service constituent la base pour l'assistance en exploitation contractuelle (garantie, rechanges, etc.).

Rogamos separen la tarjeta “Aviso de puesta en servicio” y la devuelvan rellena a MTU Friedrichshafen GmbH.

Las informaciones respecto al aviso de puesta en servicio constituyen la base para el soporte logístico contractual (garantía, piezas de repuesto, etc.).

Ritagliare “Avviso di messa in servizio” e rispedirlo debitamente compilato alla MTU Friedrichshafen GmbH.

Le informazioni ivi registrate sono la base per il supporto logistico contrattuale (garanzia, ricambi, ecc.).

É gentileza cortar o cartão “Participação da colocação em serviço”, preenchê-lo e devolvê-lo a MTU Friedrichshafen.

Os dados referentes à colocação em serviço representam a base para o suporte logístico (garantia, peças sobressalentes, etc.) estabelecido contratualmente.



Postcard

MTU Friedrichshafen GmbH
Department SCSD
88040 Friedrichshafen
GERMANY

Bitte in Blockschrift ausfüllen!
Please use block capitals!
Prière de remplir en lettres capitales!
¡A rellenar en letras de imprenta!
Scrivere in stampatello!
Favor preencher com letras de forma!



Motornr.: Engine No.: N° du moteur: N° de motor: Motore N.: No. do motor:	Auftragsnr.: MTU works order No.: N° de commande: N° de pedido: N. commessa: No. do pedido:	Inbetriebnahme- meldung Commissioning Note
Motortyp: Engine model: Type du moteur: Tipo de motor: Motore tipo: Tipo do motor:	Inbetriebnahmedatum: Date put into operation: Mise en service le: Fecha de puesta en servicio: Messa in servizio il: Data da colocação em serviço:	Notice de mise en service Aviso de puesta en servicio
Eingebaut in: Installation site: Lieu de montage: Lugar de montaje: Installato: Incorporado em:	Schiffstyp / Schiffshersteller: Vessel/type/class / Shipyard: Type du bateau / Constructeur: Tipo de buque / Constructor: Tipo di barca / Costruttore Tipo de embarcação/estaleiro naval:	Avviso di messa in servizio Participação da colocação em serviço
Endabnehmer/Anschrift: End user's address: Adresse du client final: Dirección del cliente final: Indirizzo del cliente finale: Usuário final/endereço:		
Bemerkung: Remarks: Remarques: Observaciones: Commento: Observações:		

1 Safety

Safety, accident prevention and environmental protection instructions

2 Product Summary

Engine layout, technical data

3 Operation

Task descriptions

4 Maintenance and Servicing

Maintenance schedule

5 Troubleshooting

Malfunctions, causes, measures

6 Task Description

Inspection and maintenance tasks

7 Annex

Abbreviations

Index

1	Safety	03
1.1	General conditions	03
1.2	Personnel and organizational requirements	04
1.3	Transport	05
1.4	Safety requirements for maintenance and repair working on the engine	06
1.5	Auxiliary materials, fire prevention and environmental protection	09
1.6	Standards for warning notices in the publication	11
2	Product Summary	13
2.1	Engine Overview	13
2.1.1	Engine layout	13
2.2	Engine Side and Cylinder Designations	15
2.2.1	Engine side and cylinder designations	15
2.3	Main Engine Dimensions	16
2.3.1	Engine – Main dimensions	16
2.4	Ignition Order	17
2.4.1	Ignition order	17
2.5	Technical Data	18
2.5.1	12/16V 4000 L61 engine data (TAL), optimized fuel consumption	18
2.5.2	12/16V 4000 L61 engine data, optimized exhaust emissions (1/2 TAL)	26
3	Operation	35
3.1	SIAM 4000 – Operating panel	35
3.2	Putting the engine into operation after extended out-of-service periods (>3 months)	37
3.3	Putting the engine into operation after scheduled out-of-service-period	38
3.4	Starting the engine in manual mode	39
3.5	Starting the engine in automatic mode	40
3.6	Operational checks	41
3.7	Stopping the engine in manual mode	42
3.8	Stopping the engine in automatic mode	43
3.9	Emergency stop	44
3.10	After stopping the engine – Engine remains ready for operation	45
3.11	After stopping the engine – Putting the engine out of operation	46
4	Maintenance	47
4.1	Preface	47
4.2	50-hours service	49
4.3	Maintenance schedule matrix	50
4.4	Maintenance tasks	53

5	Task Descriptions	55
5.1	Engine	55
5.1.1	Engine – Baring manually	55
5.1.2	Checking machine room for smell of gas	56
5.2	Ignition System	57
5.2.1	Ignition system – Ignition timing check	57
5.2.2	Spark plug – Replacement	58
5.2.3	Spark plug – Removal and installation	59
5.3	Valve Drive	61
5.3.1	Valve gear – Lubrication	61
5.3.2	Valve clearance – Check and adjustment	62
5.3.3	Cylinder head cover – Removal and installation	64
5.4	Gas System	65
5.4.1	Gas supply – Checking gas lines for leaks	65
5.5	Air Filter	66
5.5.1	Air filter – Replacement	66
5.5.2	Air filter removal and installation	67
5.6	Lube Oil System, Lube Oil Circuit	68
5.6.1	Engine oil – Change	68
5.6.2	Engine oil – Level check	69
5.6.3	Engine-oil – Sample extraction and analysis	70
5.7	Oil Cooling / Filtration	71
5.7.1	Engine oil filter – Replacement	71
5.7.2	Oil separator – Filter element replacement	72
5.8	Coolant Circuit, General, HT Circuit	74
5.8.1	Engine coolant – Filling	74
5.8.2	Engine coolant – Draining	75
5.8.3	Engine coolant – Change	77
5.8.4	Engine coolant – Level check	78
5.9	LT Circuit	79
5.9.1	Mixture coolant – Filling	79
5.9.2	Mixture coolant – Draining	80
5.9.3	Mixture coolant – Change	81
5.9.4	Mixture coolant – Level check	82
5.10	General Cabling for Engine / Gearbox / Unit	83
5.10.1	Engine wiring check	83
6	Special Tools	85
6.1	Special tools	85
7	Annex	91
7.1	Manufacturer's documentation	91
7.2	MTU contact person/service partner	92
7.3	Index	93

1 Safety

1.1 General conditions

General

In addition to the instructions in this publication, the applicable country-specific legislation and other compulsory regulations regarding accident prevention must be observed. This engine is a state-of-the art product and conforms with all applicable specifications and regulations. Nevertheless, persons and property may be at risk in the event of:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Modifications or conversions
- Non-compliance with the Safety Instructions

Correct use

The engine is intended exclusively for the application specified in the contract or defined at the time of delivery. Any other use is considered improper use. The manufacturer will accept no liability for any resultant damage. The responsibility is borne by the user alone.

Correct use also includes observation of and compliance with the maintenance specifications.

Modifications or Conversions

Modifications made by the customer to the engine may affect safety.

MTU will accept no liability or warranty claims for any damage caused by unauthorized modifications or conversions.

Spare parts

Only genuine MTU spare parts must be used to replace components or assemblies. In the event of any damage caused by the use of other spare parts, no liability nor warranty claims vis-à-vis the engine manufacturer will be accepted.

1.2 Personnel and organizational requirements

Personnel

Work on the engine must only be carried out by properly qualified and instructed personnel.

The specified legal minimum age must be observed.

Responsibilities of the operating, maintenance and repair personnel must be specified.

Organization

This publication must be issued to all personnel involved in operation, maintenance, repair or transportation.

It must be kept at hand near the engine and accessible at any time to all personnel involved in operation, maintenance, repair or transportation.

The personnel must be instructed on engine operation and repair by means of this publication, and in particular the safety instructions must be explained.

This is especially important for personnel who work on the engine only on an occasional basis. Such personnel must be given instructions repeatedly.

Working clothes and protective equipment

Wear proper work clothing for all work.

Depending on the kind of work, use additional protective equipment, e.g. protective goggles, gloves, helmet, apron.

Work clothing must be tight fitting so that it does not catch on rotating or projecting components.

Do not wear jewelry (e.g. rings, chains etc.).