

Operating Instructions

Diesel engine
12V4000Gx3x
16V4000Gx3x

M015710/08E



Power. Passion. Partnership.

Engine model	Frequency	Application group *
12V4000G23	50 Hz	3B, 3D, 3E, 3F, 3G
12V4000G23R	50 Hz	3B
12V4000G43	60 Hz	3A, 3B, 3D, 3F, 3G
12V4000G63	50 Hz	3A, 3B, 3D, 3E, 3F, 3G
12V4000G83	60 Hz	3A, 3B, 3D, 3F, 3G
16V4000G23	50 Hz	3B, 3D, 3E, 3F, 3G
16V4000G43	60 Hz	3A, 3B, 3D, 3F, 3G
16V4000G63	50 Hz	3A, 3B, 3D, 3E, 3F, 3G
16V4000G83	60 Hz	3A, 3B, 3D, 3F, 3G
16V4000G83L	60 Hz	3D
* 3A Continuous operation, unrestricted 3B Continuous operation, variable load, ICXN 3D Standby power, fuel stop power, IFN 3E Standby power, overload capability according to ICXN 3F Mains backup mode, unlimited, ICXN 3G Prime power, time-limited, ICXN		

Table 1: Applicability



WARNING: Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information, go to www.P65warnings.ca.gov/diesel

Table of Contents

1	Revision Overview		ORDE and China Nonroad mobile Machinery Stage III	
1.1	Revision - Overview	6	5.7 Product data 12V4000Gx3, standby operation 3D, optimized fuel consumption	69
2	Safety		5.8 Product data 16V4000Gx3x, standby operation 3D, optimized fuel consumption	73
2.1	Important provisions for all products	7	5.9 Product data 12V/16V4000Gx3x, standby operation 3D, EPA Stationary EMERG T2 (40CFR60) and EPA Nonroad T2 Comp (40CFR89)	77
2.2	Correct use of all products	9	5.10 Product data 12V/16V4000Gx3, standby operation 3D, NEA Singapore for ORDE and China Nonroad mobile Machinery Stage III	82
2.3	Personnel and organizational requirements	10	5.11 Product data 12V/16V4000Gx3, standby operation 3E, optimized fuel consumption	86
2.4	Safety regulations for initial start-up and operation	11	5.12 Product data 12V/16V4000Gx3, standby operation 3E, optimized exhaust gas emissions (TA-Luft)	90
2.5	Safety regulations for assembly, maintenance, and repair work	13	5.13 Product data 12V/16V4000Gx3, standby operation 3E, NEA Singapore for ORDE and China Nonroad mobile Machinery Stage III	94
2.6	Fire and environmental protection, fluids and lubricants	17	5.14 Product data 12V4000Gx3, standby power operation 3F, optimized fuel consumption	98
2.7	Standards for warning notices in the text and highlighted information	19	5.15 Product data 16V4000Gx3, standby power operation 3F, optimized fuel consumption	102
3	Transport		5.16 Product data 12V/16V4000Gx3, standby power operation 3F, optimized exhaust gas emissions (TA-Luft)	106
3.1	Transport	20	5.17 Product data 12V/16V4000Gx3, standby power operation 3F, EPA Stationary EMERG T2 (40CFR60) und EPA Nonroad T2 Comp (40CFR89)	110
3.2	Lifting specifications	21	5.18 Product data 12V/16V4000Gx3, standby power operation 3F, NEA Singapore for ORDE and China Nonroad mobile Machinery Stage III	114
3.3	Crankshaft transport locking device	22	5.19 Product data 12V4000Gx3, continuous operation 3G, optimized fuel consumption	118
3.4	Engine mount shipping lock	25	5.20 Product data 16V4000Gx3, continuous operation 3G, optimized fuel consumption	122
4	General Information		5.21 Product data 12V/16V4000Gx3, continuous operation 3G, optimized exhaust gas emissions (TA-Luft)	126
4.1	Tightening specifications for screws, nuts and bolts	26	5.22 Product data 12V/16V4000Gx3, continuous operation 3G, EPA Stationary EMERG T2 (40CFR60) und EPA Nonroad T2 Comp (40CFR89)	130
4.2	Engine side and cylinder designations	39	5.23 Product data 12V/16V4000Gx3, continuous operation 3G, NEA Singapore for ORDE and China Nonroad mobile Machinery Stage III	134
4.3	Engine - Overview	40		
4.4	Sensors and actuators - Overview	41		
5	Technical Data			
5.1	Product data 12V/16V4000Gx3, continuous operation 3A, optimized fuel consumption	44		
5.2	Product data 12V4000Gx3x, continuous operation 3B, optimized fuel consumption	49		
5.3	Product data 16V4000Gx3, continuous operation 3B, optimized fuel consumption	53		
5.4	Product data 12V/16V4000Gx3x, continuous operation 3B, optimized exhaust gas emissions (TA-Luft)	57		
5.5	Product data 12V/16V4000Gx3, continuous operation 3B, EPA Stationary EMERG T2 (40CFR60) und EPA Nonroad T2 Comp (40CFR89)	61		
5.6	Product data 12V/16V4000Gx3x, continuous operation 3B, NEA Singapore for	65		

5.24	Final compression pressure	138	9.4	Valve Drive	222
5.25	Firing order	139	9.4.1	Valve protrusion - Measurement	222
5.26	Main engine dimensions	140	9.4.2	Valve gear - Lubrication	226
			9.4.3	Valve clearance - Check and adjustment	227
6	Operation		9.4.4	Cylinder head cover - Removal and installation	231
6.1	Putting the engine into operation after extended out-of-service periods (>3 months)	141	9.5	Injection Pump / HP Pump	232
6.2	Putting into operation after scheduled out-of-service-period	142	9.5.1	HP fuel pump - Filling with engine oil	232
6.3	Starting the engine in manual mode (test run)	143	9.6	Injector	234
6.4	Re-starting the engine following an automatic safety shutdown	144	9.6.1	Injector - Replacement	234
6.5	Safety system - Override	145	9.6.2	Injector - Removal and installation	235
6.6	Emergency engine start (Override mode)	146	9.7	Fuel System	241
6.7	Operational monitoring	147	9.7.1	Fuel system - Venting	241
6.8	Emission label - Check	148	9.8	Fuel Filter	243
6.9	Engine - Stopping in Manual mode (test run)	149	9.8.1	Fuel filter - Replacement	243
6.10	Engine - Emergency stop	151	9.8.2	Fuel prefilter - Pressure ratios	244
6.11	After stopping the engine - Engine remains ready for operation	152	9.8.3	Fuel prefilter (non-switchable) - Draining	245
6.12	After stopping the engine - Putting the engine out of operation	153	9.8.4	Fuel prefilter (switchable) - Draining	247
6.13	Plant - Cleaning	154	9.8.5	Fuel prefilter (switchable) - Low pressure indicator check	250
7	Troubleshooting		9.8.6	Fuel prefilter (non-switchable) - Filter element replacement	251
7.1	Troubleshooting	155	9.8.7	Fuel prefilter (switchable) - Filter element replacement	253
7.2	Engine Control Unit ADEC (ECU 7) for Series 4000 genset engines - Fault messages	158	9.8.8	Fuel prefilter - Venting	256
8	Maintenance		9.9	Charge-Air Cooling	258
8.1	Maintenance task reference table [QL1]	207	9.9.1	Intercooler - Checking condensate drain for coolant leakage and obstruction	258
9	Task Description		9.10	Air Filter	259
9.1	Engine	209	9.10.1	Air filter - Replacement	259
9.1.1	Engine - Barring manually	209	9.10.2	Air filter - Check	260
9.1.2	Engine - Turning on starting system	211	9.10.3	Air filter - Removal and installation	261
9.1.3	Engine - Test run	212	9.11	Air Intake	262
9.2	Cylinder Liner	213	9.11.1	Contamination indicator - Signal ring position check	262
9.2.1	Cylinder liner - Endoscopic examination	213	9.12	Starting Equipment	263
9.2.2	Cylinder liner - Instructions and comments on endoscopic and visual examination	215	9.12.1	Air starter - Manual operation	263
9.3	Crankcase Breather	217	9.13	Lube Oil System, Lube Oil Circuit	264
9.3.1	Crankcase breather - Oil separator element replacement	217	9.13.1	Engine oil - Change	264
9.3.2	Crankcase breather - Filter element replacement	220	9.13.2	Engine oil level - Check	266
			9.13.3	Engine oil - Sample extraction and analysis	267
			9.13.4	Oil priming pump - Visual inspection	269
			9.14	Oil Filtration / Cooling	270
			9.14.1	Engine oil filter - Replacement	270
			9.14.2	Oil indicator filter - Cleaning and check	271
			9.14.3	Centrifugal oil filter - Cleaning and filter sleeve replacement	274
			9.15	Coolant Circuit, General, High-Temperature Circuit	276
			9.15.1	Engine coolant - Level check	276
			9.15.2	Engine coolant - Change	278

9.15.3	Engine coolant - Draining	279	9.18.2	Battery-charging generator drive - Drive belt replacement	310
9.15.4	Engine coolant - Filling	281			
9.15.5	Engine coolant pump - Relief bore check	284	9.19	Engine Mounting / Support	311
9.15.6	Engine coolant - Sample extraction and analysis	285	9.19.1	Engine mounting - Checking resilient element	311
9.15.7	Preheater - Overview	287	9.20	Wiring (General) for Engine/Gearbox/Unit	312
9.15.8	Preheater - Function and leak check	288	9.20.1	Engine cabling - Check	312
9.15.9	Preheater - Overhaul	289	9.21	Accessories for (Electronic) Engine Governor / Control System	313
9.15.10	Preheater - Solenoid switch replacement	290	9.21.1	Engine governor and connector - Cleaning	313
9.15.11	Preheater - Heating element and housing check	292	9.21.2	Engine governor plug connections - Check	314
9.15.12	Preheater thermostats - Replacement	295	9.21.3	Engine governor ECU 7 - Removal and installation	315
9.15.13	Coolant expansion tank valve cover - Replacement	298			
9.16	Low-Temperature Circuit	299	10	Appendix A	
9.16.1	Charge-air coolant level - Check	299	10.1	Abbreviations	316
9.16.2	Charge-air coolant - Change	301	10.2	MTU Contact/Service Partners	319
9.16.3	Charge-air coolant - Draining	302			
9.16.4	Charge-air coolant - Filling	304	11	Appendix B	
9.16.5	Charge-air coolant pump - Relief bore check	307	11.1	Special Tools	320
9.17	Belt Drive	308	11.2	Index	329
9.17.1	Drive belt - Condition check	308			
9.18	Battery-Charging Generator	309			
9.18.1	Battery-charging generator - Drive belt tension adjustment	309			

1 Revision Overview

1.1 Revision – Overview

Revision overview – General

Chapter	M015710/07	M015710/08
2	Chapter “Safety”.	Chapter updated to the latest status.

Revision overview – Maintenance schedule

Task No.		

Revision overview – Task description

Chapter	M015710/07	M015710/08

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by MTU come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emission specifications and emission label

Responsibility for compliance with emission regulations

Modification or removal of any mechanical/electronic components or the installation of additional components including the execution of calibration processes that might affect the emission characteristics of the product are prohibited by emission regulations. Emission-related components must only be serviced, exchanged or repaired if the components used for this purpose are approved by the manufacturer.

Noncompliance with these specifications will invalidate the design type approval or certification issued by the emissions regulation authorities. The manufacturer does not accept any liability for violations of the emission regulations.

The product must be operated over its entire life cycle according to the conditions defined as "Intended use" (→ Page 9).

Emission certification applicable to engines with EPA Nonroad Tier 4 emission certification in accordance with 40 CFR 1039 and with EPA Locomotive emission certification in accordance with 40 CFR 1033

Extract from the standard:

Failing to follow these instructions when installing a certified engine in a piece of nonroad equipment violates federal law (40 CFR 1068.105(b)), subject to fines or other penalties as described in the Clean Air Act.

Extract from the standard:

If you install the engine in a way that makes the engine's emission control information label hard to read during normal engine maintenance, you must place a duplicate label on the equipment, as described in 40 CFR 1068.105.

When fitting the second label, the requirements of 40 CFR 1068.105(c) must be followed and observed. This paragraph describes the process for requesting and fitting the label, the documentation obligations and storage obligations for the required documents.

Replacing components with emission labels

On all MTU engines fitted with emission labels, these labels must remain on the engine throughout its operational life.

Exception: Engines used exclusively in land-based, military applications other than by US government agencies.

Please note the following when replacing components with emission labels:

- The relevant emission labels must be affixed to the spare part.
- Emission labels shall not be transferred from the replaced part to the spare part.
- The emission labels must be removed from the replaced part and destroyed.