

Operating Instructions

Diesel engine

20 V 4000 G23

20 V 4000 G43

20 V 4000 G63, G63L

20 V 4000 G83, G83L

2 Exhaust turbocharger

M015715/04E



Power. Passion. Partnership.

Engine model	kW/cyl.	Application group
20V4000G23	121.0 kW/cyl.	3D, standby power, fuel stop power, IFN
20V4000G43	137.0 kW/cyl.	3D, standby power, fuel stop power, IFN
20V4000G63	133.5 kW/cyl.	3D, standby power, fuel stop power, IFN
20V4000G63L	142.5 kW/cyl.	3D, standby power, fuel stop power, IFN
20V4000G83	150.5 kW/cyl.	3D, standby power, fuel stop power, IFN
20V4000G83L	174.5 kW/cyl.	3D, standby power, fuel stop power, IFN
20V4000G23	110 kW/cyl.	3B, continuous operation, variable load, ICXN
20V4000G43	125 kW/cyl.	3B, continuous operation, variable load, ICXN
20V4000G63	121 kW/cyl.	3B, continuous operation, variable load, ICXN
20V4000G63L	130 kW/cyl.	3B, continuous operation, variable load, ICXN
20V4000G83	137 kW/cyl.	3B, continuous operation, variable load, ICXN
20V4000G83L	151 kW/cyl.	3B, continuous operation, variable load, ICXN
20V4000G43	95 kW/cyl.	3A, continuous operation, unrestricted
20V4000G63	100 kW/cyl.	3A, continuous operation, unrestricted
20V4000G63L	109 kW/cyl.	3A, continuous operation, unrestricted
20V4000G83	112 kW/cyl.	3A, continuous operation, unrestricted
20V4000G83L	125 kW/cyl.	3A, continuous operation, unrestricted

Table 1: Applicability

Table of Contents

1 Safety

1.1 Important provisions for all products	5
1.2 Correct use of all products	7
1.3 Personnel and organizational requirements	8
1.4 Initial start-up and operation – Safety regulations	9
1.5 Assembly, maintenance, and repair work – Safety regulations	11
1.6 Fire and environmental protection, fluids and lubricants	15
1.7 Standards for warning notices in the text and highlighted information	17

2 Transport

2.1 Transportation	18
2.2 Lifting specifications	19
2.3 Crankshaft transport locking device	20

3 General Information

3.1 Engine side and cylinder designations	23
3.2 Engine layout	24
3.3 Sensors and actuators – Overview	26

4 Technical Data

4.1 20 V 4000 Gx3 engine data: Continuous operation, unrestricted 3A, optimized fuel consumption	29
4.2 20 V 4000 Gx3 engine data: Continuous operation, variable 3B, optimized fuel consumption	34
4.3 20 V 4000 Gx3 engine data: Continuous operation, variable 3B, optimized exhaust emissions (EPA2)	40
4.4 20 V 4000 Gx3 engine data: Continuous operation, variable 3B, optimized exhaust emissions (TA-Luft)	44
4.5 20 V 4000 Gx3 engine data: Standby operation 3D, optimized fuel consumption	48
4.6 20 V 4000 Gx3 engine data: Standby operation 3D, optimized exhaust emissions (EPA stage 2)	54
4.7 Firing order	58
4.8 Engine – Main dimensions	59

5 Operation

5.1 Putting the engine into operation after extended out-of-service periods (>3 months)	60
5.2 Putting the engine into operation after scheduled out-of-service-period	61
5.3 Engine – Starting in manual mode (test run)	62
5.4 Safety system – Override	63
5.5 Starting the engine in emergency situations (override mode)	64
5.6 Operational checks	65
5.7 Engine – Stopping in manual mode (test run)	66
5.8 Engine – Emergency stop	67
5.9 After stopping the engine – Engine remains ready for operation	68
5.10 After stopping the engine – Putting the engine out of operation	69
5.11 Plant – Cleaning	70

6 Maintenance

6.1 Maintenance task reference table [QL1] for application group 3A, 3B	71
6.2 Maintenance task reference table [QL1] for application group 3D	72

7 Troubleshooting

7.1 Troubleshooting	73
7.2 Fault messages on the SAM display (optional)	76
7.3 Engine governor ADEC (ECU 7) for Series 4000 genset engines – Fault messages	77

8 Task Description

8.1 Engine	126
8.1.1 Engine – Barring manually	126
8.1.2 Engine – Turning on starting system	128
8.1.3 Engine – Test run	129
8.2 Cylinder Liner	130
8.2.1 Cylinder liner – Endoscopic examination	130
8.2.2 Cylinder liner – Instructions and comments on endoscopic and visual examination	132
8.3 Crankcase Breather	134
8.3.1 Crankcase breather – Oil mist separator replacement	134
8.4 Valve Drive	135
8.4.1 Valve protrusion – Measurement	135

8.4.2	Valve gear - Lubrication	139	8.15.1	Engine coolant - Level check	179
8.4.3	Valve clearance - Check and adjustment	140	8.15.2	Engine coolant - Change	181
8.4.4	Cylinder head cover - Removal and installation	143	8.15.3	Engine coolant - Draining	182
8.5	Injection Pump / HP Pump	144	8.15.4	Engine coolant - Filling	184
8.5.1	HP fuel pump - Filling with engine oil	144	8.15.5	Engine coolant pump - Relief bore check	187
8.6	Injector	146	8.15.6	Engine coolant - Sample extraction and analysis	188
8.6.1	Injector - Replacement	146	8.15.7	Coolant expansion tank valve cover - Replacement	190
8.6.2	Injector - Removal and installation	147	8.16	Low-Temperature Circuit	191
8.7	Fuel System	153	8.16.1	Charge-air coolant - Level check	191
8.7.1	Fuel system - Venting	153	8.16.2	Charge-air coolant - Change	192
8.8	Fuel Filter	154	8.16.3	Charge-air coolant - Draining	193
8.8.1	Fuel filter - Replacement	154	8.16.4	Charge-air coolant - Filling	195
8.8.2	Fuel prefilter - Cleaning	155	8.16.5	Charge-air coolant pump - Relief bore check	198
8.8.3	Fuel prefilter - Differential pressure gage check and adjustment	156	8.17	Engine Mounting / Support	199
8.8.4	Fuel prefilter - Draining	157	8.17.1	Engine mounting - Check	199
8.8.5	Fuel prefilter - Flushing	159	8.18	Belt Drive	200
8.8.6	Fuel prefilter - Filter element replacement	161	8.18.1	Drive belt - Condition check	200
8.9	Charge-Air Cooling	163	8.19	Battery-Charging Generator	201
8.9.1	Intercooler - Checking condensate drain for coolant leakage and obstruction	163	8.19.1	Battery-charging generator drive - Drive belt replacement	201
8.10	Air Filter	164	8.19.2	Battery-charging generator drive - Drive belt tension adjustment	202
8.10.1	Air filter - Replacement	164	8.20	Wiring (General) for Engine/Gearbox/Unit	203
8.10.2	Air filter - Check	165	8.20.1	Engine cabling - Check	203
8.10.3	Air filter - Removal and installation	166	8.21	Accessories for (Electronic) Engine Governor / Control System	204
8.11	Air Intake	167	8.21.1	Parameters for drift correction (CDC) - Resetting with DiaSys®	204
8.11.1	Service indicator - Signal ring position check	167	8.21.2	Engine governor and connector - Cleaning	205
8.12	Starting Equipment	168	8.21.3	Engine governor plug connections - Check	206
8.12.1	Air starter - Manual operation	168	8.21.4	Engine governor ECU 7 - Removal and installation	207
8.13	Lube Oil System, Lube Oil Circuit	169	9	Appendix A	
8.13.1	Engine oil level - Check	169	9.1	List of abbreviations	208
8.13.2	Engine oil - Change	170	9.2	MTU Contact/Service Partners	211
8.13.3	Engine oil - Sample extraction and analysis	172	10	Appendix B	
8.14	Oil Filtration / Cooling	174	10.1	Special Tools	212
8.14.1	Engine oil filter - Replacement	174	10.2	Index	219
8.14.2	Oil indicator filter - Cleaning and check	175			
8.14.3	Centrifugal oil filter - Cleaning and filter-sleeve replacement	177			
8.15	Coolant Circuit, General, High-Temperature Circuit	179			

1 Safety

1.1 Important provisions for all products

General information

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number and must match with the information on the title page of this manual.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by MTU come with a second nameplate. When operating the machine in the EU: The second nameplate must be affixed in a prominent position as described in the accompanying specifications.

Emission regulations and emission labels

Responsibility for compliance with emission regulations

Modification or removal of any mechanical/electronic components or the installation of additional components including the execution of calibration processes that might affect the emission characteristics of the product are prohibited by emission regulations. Emission-related components must only be serviced, exchanged or repaired if the components used for this purpose are approved by the manufacturer.

Noncompliance with these specifications will invalidate the design type approval or certification issued by the emissions regulation authorities. The manufacturer does not accept any liability for violations of the emission regulations.

The product must be operated over its entire life cycle according to the conditions defined as "Intended use" (→ Page 7).

Emission certification applicable to engines with EPA Nonroad Tier 4 emission certification in accordance with 40 CFR 1039

Extract from the standard:

Failing to follow these instructions when installing a certified engine in a piece of nonroad equipment violates federal law (40 CFR 1068.105(b)), subject to fines or other penalties as described in the Clean Air Act.

Extract from the standard:

If you install the engine in a way that makes the engine's emission control information label hard to read during normal engine maintenance, you must place a duplicate label on the equipment, as described in 40 CFR 1068.105.

When fitting the second label, the requirements of 40 CFR 1068.105(c) must be followed and observed. This paragraph described the process for requesting and fitting the label, the documentation obligations and storage obligations for the required documents.

Replacing components with emission labels

On all MTU engines fitted with emission labels, these labels must remain on the engine throughout its operational life.

Exception: Engines used exclusively in land-based, military applications other than by US government agencies.

Please note the following when replacing components with emission labels:

- The relevant emission labels must be affixed to the spare part.
- Emission labels shall not be transferred from the replaced part to the spare part.
- The emission labels must be removed from the replaced part and destroyed.

1.2 Correct use of all products

Correct use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/MTU contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found on the websites:

- For drive systems: <http://www.mtu-online.com>
- For power generation: <http://www.mtuonsiteenergy.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

1.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the descriptions of the individual activities.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorisation and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.

1.4 Initial start-up and operation – Safety regulations

Safety regulations for initial start-up

Install the product correctly and carry out acceptance in accordance with the manufacturer's specifications before putting the product into service. All necessary approvals must be granted by the relevant authorities and all requirements for initial startup must be fulfilled.

Whenever the product is subsequently taken into operation ensure that:

- All personnel is clear of the danger zone surrounding moving parts of the machine.
Electrically-actuated linkages may be set in motion when the Engine Control Unit (governor) is switched on.
- All maintenance and repair work has been completed.
- All loose parts have been removed from rotating machine components.
- All safety equipment is in place.
- All components must be properly grounded. Ground separately by means of a grounding stake as necessary.
- No persons wearing pacemakers or any other technical body aids are present.
- The service room is adequately ventilated.
- In the first few hours of operation, the product emits gases as a result of smoldering e.g. lacquers or oil. These gases may be hazardous to health. Always wear respiratory protection in the operating room during this period.
- The exhaust system is leak-tight and that the gases are vented to atmosphere.
- The product must be free of any damage, this applies in particular to lines and cabling.
- Protect battery terminals, generator terminals or cables against accidental contact.
- Check that all connections have been correctly allocated e.g. +/- polarity, fuel line/reduction agent line, supply/return.

Immediately after putting the product into operation, make sure that all control and display instruments as well as the monitoring, signaling and alarm systems work properly.

Smoking is prohibited in the area of the product.

Safety regulations during operation

The operator must be familiar with the control and display elements.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be permanently observed with regard to present operating status, violation of limit values and warning or alarm messages.

Malfunctions and emergency stop

Practice emergency procedures, especially emergency stopping, at regular intervals.

Take the following steps if any system malfunctions are detected or signaled by the system:

- inform supervisor(s) in charge,
- analyze the message,
- respond by taking any necessary emergency action, e.g. emergency stop.

Contact Service if the root cause of the malfunction cannot be clearly identified.

Operation

Do not remain in the operating room when the product is running unless absolutely necessary. Keep your stay as short as possible.

Keep a safe distance away from the product if possible. Do not touch the product unless expressly instructed to do so following a written procedure.

Do not inhale the exhaust gases of the product.

The following requirements must be fulfilled before the product is started:

- Wear ear protectors.
- Mop up any leaked or spilled fluids and lubricants immediately or soak up with a suitable binding agent.

Operation of electrical equipment

When electrical equipment is in operation, certain components of these appliances are electrically live.

Follow the applicable operating and safety instructions when operating the devices and heed warnings at all times.