

MTU_ValueService **Technical Documentation**

Gas Engine
8 V 4000 L61

Operating Instructions
M015720/02E



Printed in Germany

© 2009 Copyright MTU Friedrichshafen GmbH

This Publication is protected by copyright and may not be used in any way whether in whole or in part without the prior written permission of MTU Friedrichshafen GmbH. This restriction also applies to copyright, distribution, translation, microfilming and storage or processing on electronic systems including data bases and online services. This handbook is provided for use by maintenance and operating personnel in order to avoid malfunctions or damage during operation.

Subject to alterations and amendments.

Wichtig – Important – Importante

Bitte die Karte „Inbetriebnahmemeldung“ abtrennen und ausgefüllt an MTU Friedrichshafen GmbH zurücksenden.

Die Informationen der Inbetriebnahmemeldung sind Grundlage für den vertraglich vereinbarten Logistik-Support (Gewährleistung, Ersatzteile etc.).

Please complete and return the “Commissioning Note” card below to MTU Friedrichshafen GmbH.

The Commissioning Note information serves as a basis for the contractually agreed logistic support (warranty, spare parts, etc.).

Veillez séparer la carte “Signalisation de mise en service” et la renvoyer à la MTU Friedrichshafen GmbH.

Les informations contenues dans la signalisation de mise en service constituent la base pour l'assistance en exploitation contractuelle (garantie, rechanges, etc.).

Rogamos separen la tarjeta “Aviso de puesta en servicio” y la devuelvan rellena a MTU Friedrichshafen GmbH.

Las informaciones respecto al aviso de puesta en servicio constituyen la base para el soporte logístico contractual (garantía, piezas de repuesto, etc.).

Ritagliare “Avviso di messa in servizio” e rispedirlo debitamente compilato alla MTU Friedrichshafen GmbH.

Le informazioni ivi registrate sono la base per il supporto logistico contrattuale (garanzia, ricambi, ecc.).

É gentileza cortar o cartão “Participação da colocação em serviço”, preenchê-lo e devolvê-lo a MTU Friedrichshafen.

Os dados referentes à colocação em serviço representam a base para o suporte logístico (garantia, peças sobressalentes, etc.) estabelecido contratualmente.



Postcard

MTU Friedrichshafen GmbH
Technical Information Management
88040 Friedrichshafen
GERMANY

Bitte in Blockschrift ausfüllen!
Please use block capitals!
Prière de remplir en lettres capitales!
¡A rellenar en letras de imprenta!
Scrivere in stampatello!
Favor preencher com letras de forma!



Motornr.: Engine No.: N° du moteur: N° de motor: Motore N.: No. do motor:	Auftragsnr.: MTU works order No.: N° de commande: N° de pedido: N. commessa: No. do pedido:	Inbetriebnahme- meldung Commissioning Note
Motortyp: Engine model: Type du moteur: Tipo de motor: Motore tipo: Tipo do motor:	Inbetriebnahmedatum: Date put into operation: Mise en service le: Fecha de puesta en servicio: Messa in servizio il: Data da colocação em serviço:	Notice de mise en service Aviso de puesta en servicio
Eingebaut in: Installation site: Lieu de montage: Lugar de montaje: Installato: Incorporado em:	Schiffstyp / Schiffshersteller: Vessel/type/class / Shipyard: Type du bateau / Constructeur: Tipo de buque / Constructor: Tipo di barca / Costruttore Tipo de embarcação/estaleiro naval:	Avviso di messa in servizio Participação da colocação em serviço
Endabnehmer/Anschrift: End user's address: Adresse du client final: Dirección del cliente final: Indirizzo del cliente finale: Usuário final/endereço:		
Bemerkung: Remarks: Remarques: Observaciones: Commento: Observações:		

1	Safety	05
1.1	General conditions	05
1.2	Personnel and organizational requirements	06
1.3	Transport	07
1.4	Safety requirements for maintenance and repair working on the engine	08
1.5	Auxiliary materials, fire prevention and environmental protection	11
1.6	Standards for warning notices in the publication	13
2	Product Summary	15
2.1	Engine Layout	15
2.1.1	Engine layout	15
2.2	Engine Side and Cylinder Designations	17
2.2.1	Engine side and cylinder designations	17
2.3	Main Engine Dimensions	18
2.3.1	Main engine dimensions	18
2.4	Ignition Sequence	19
2.4.1	Firing order	19
2.5	Technical Data	20
2.5.1	Runtimes at partial load	20
2.5.2	8V 4000 L61 engine data, fuel optimized (TA-Luft)	21
2.5.3	8 V 4000 L61 engine data, exhaust optimized (1/2 TA-Luft)	26
3	Operation	31
3.1	Switchgear cabinet – Overview	31
3.2	Gas engine phase 2 system – Overview	33
3.3	Display – Overview of the screen pages	35
3.4	Display – Operation	43
3.5	Fault displays on display DIS 10 – General information	45
3.6	Fault indication on display DIS 10	46
3.7	Putting the engine into operation after extended out-of-service-periods (>3 months)	80
3.8	Putting the engine into operation after scheduled out-of-service-period	81
3.9	Control, start and stop sequences	82
3.10	Starting the engine in manual mode	83
3.11	Starting the engine in automatic mode	84
3.12	Operational checks	85
3.13	Stopping the engine in manual mode	86
3.14	Stopping the engine in automatic mode	87
3.15	Emergency stop	88

3.16	After stopping the engine – Engine remains ready for operation	89
3.17	After stopping the engine – Putting the engine out of operation	90
4	Maintenance	91
4.1	Preface	91
4.2	50-hours check	93
4.3	Maintenance schedule matrix	94
4.4	Maintenance tasks	97
5	Task Descriptions	99
5.1	Engine	99
5.1.1	Engine – Baring manually	99
5.1.2	Checking machine room for smell of gas	100
5.2	Crankcase Breather	101
5.2.1	Oil separator – Filter element replacement	101
5.3	Ignition System	103
5.3.1	Ignition system – Ignition timing check	103
5.3.2	Spark plug – Replacement	104
5.3.3	Spark plug – Removal and installation	105
5.4	Valve Drive	107
5.4.1	Valve gear – Lubrication	107
5.4.2	Valve clearance – Check and adjustment	108
5.4.3	Measuring valve stem end to cylinder head top distance	110
5.4.4	Cylinder head cover – Removal and installation	113
5.5	Gas System	114
5.5.1	Gas supply – Checking gas lines for leaks	114
5.6	Air Filter	115
5.6.1	Air filter – Replacement	115
5.6.2	Air filter – Removal and installation	116
5.7	Air Intake	117
5.7.1	Service indicator – Signal ring position check	117
5.8	Lube Oil System, Lube Oil Circuit	118
5.8.1	Engine oil level – Check	118
5.8.2	Engine oil – Change	119
5.8.3	Engine oil – Sample extraction and analysis	120
5.9	Oil Filtration/Cooling	121
5.9.1	Engine oil filter – Replacement	121
5.10	Coolant Circuit, General, HT Circuit	122
5.10.1	Engine coolant – Level check	122
5.10.2	Engine coolant – Change	123
5.10.3	Engine coolant – Draining	124
5.10.4	Engine coolant – Filling	126
5.10.5	Vent line of engine coolant circuit – Replacement, 8/12/16 V only	127
5.11	LT Circuit	128

5.11.1	Mixture coolant – Level check	128
5.11.2	Mixture coolant – Change	129
5.11.3	Mixture coolant – Draining	130
5.11.4	Mixture coolant – Filling	131
5.12	Cabling, General for Engine / Gearbox / Unit	132
5.12.1	Engine wiring – Check	132
5.12.2	Sensors – Overview	133
6	Special Tools	137
6.1	Special tools	137
7	Annex	145
7.1	Manufacturer's documentation	145
7.2	MTU Onsite Energy contact / service partner	146
7.3	Abbreviations	147
7.4	Index	151

1 Safety

1.1 General conditions

General

In addition to the instructions in this publication, the applicable country-specific legislation and other compulsory regulations regarding accident prevention must be observed. This engine is a state-of-the art product and conforms with all applicable specifications and regulations. Nevertheless, persons and property may be at risk in the event of:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Modifications or conversions
- Non-compliance with the Safety Instructions

Correct use

The engine is intended exclusively for the application specified in the contract or defined at the time of delivery. Any other use is considered improper use. The manufacturer will accept no liability for any resultant damage. The responsibility is borne by the user alone.

Correct use also includes observation of and compliance with the maintenance specifications.

Modifications or Conversions

Modifications made by the customer to the engine may affect safety.

MTU will accept no liability or warranty claims for any damage caused by unauthorized modifications or conversions.

Spare parts

Only genuine MTU spare parts must be used to replace components or assemblies. In the event of any damage caused by the use of other spare parts, no liability nor warranty claims vis-à-vis the engine manufacturer will be accepted.

1.2 Personnel and organizational requirements

Personnel

Work on the engine must only be carried out by properly qualified and instructed personnel.

The specified legal minimum age must be observed.

Responsibilities of the operating, maintenance and repair personnel must be specified.

Organization

This publication must be issued to all personnel involved in operation, maintenance, repair or transportation.

It must be kept at hand near the engine and accessible at any time to all personnel involved in operation, maintenance, repair or transportation.

The personnel must be instructed on engine operation and repair by means of this publication, and in particular the safety instructions must be explained.

This is especially important for personnel who work on the engine only on an occasional basis. Such personnel must be given instructions repeatedly.

Working clothes and protective equipment

Wear proper work clothing for all work.

Depending on the kind of work, use additional protective equipment, e.g. protective goggles, gloves, helmet, apron.

Work clothing must be tight fitting so that it does not catch on rotating or projecting components.

Do not wear jewelry (e.g. rings, chains etc.).