



Operating Instructions

Diesel engine

12V4000P61, P81

16V4000P61, P81

Application group 3A, 3B, 3C

MS15001/04E

Engine model	kW/cyl.	rpm	Application group
12V4000P61	95 kW/cyl.	1500	3A, continuous operation, unrestricted
	110 kW/cyl.	1500	3B, continuous operation, variable load, ICXN
	110 kW/cyl.	1500	3C, time-limited operation, ICXN
12V4000P81	115 kW/cyl.	1800	3A, continuous operation, unrestricted
	133.3 kW/cyl.	1800	3B, continuous operation, variable load, ICXN
	133.3 kW/cyl.	1800	3C, time-limited operation, ICXN
16V4000P61	95 kW/cyl.	1500	3A, continuous operation, unrestricted
	110 kW/cyl.	1500	3B, continuous operation, variable load, ICXN
	110 kW/cyl.	1500	3C, time-limited operation, ICXN
16V4000P81	115 kW/cyl.	1800	3A, continuous operation, unrestricted
	131.6 kW/cyl.	1800	3B, continuous operation, variable load, ICXN
	131.6 kW/cyl.	1800	3C, time-limited operation, ICXN

Table 1: Applicability

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to §15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

California Proposition 65

This warning applies only to the State of California, USA, in compliance with Title 27 California Code of Regulations, Article 6, Clear and Reasonable Warnings.

 **WARNING:** Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel.

(→ www.P65warnings.ca.gov/diesel)

Table of Contents

1 Preface		6.5 Emergency engine start (Override mode)	58
1.1 Preface	7	6.6 Operational monitoring	59
2 Safety		6.7 Engine – Stopping in manual mode (test run)	60
2.1 Important provisions for all products	8	6.8 Emergency engine stop	62
2.2 Intended use of all products	9	6.9 After stopping the engine – Engine remains ready for operation	63
2.3 Personnel and organizational requirements	10	6.10 After shutting down engine – Putting engine out of operation	64
2.4 Safety regulations for commissioning and operation	11	7 Maintenance	
2.5 Safety regulations for assembly, maintenance, and repair work	13	7.1 Maintenance task reference table [QL1]	65
2.6 Fire and environmental protection, indirect materials	17	8 Troubleshooting	
2.7 Standards for warning messages in the text and highlighted information	20	8.1 Troubleshooting	66
2.8 ATEX (where applicable)	21	8.2 Fault messages on Engine Control Unit ECU 4	69
3 Transport		8.3 Fault display on printed circuit board SAM	80
3.1 Transport	22	9 Task Description	
3.2 Lifting specifications	24	9.1 Engine	89
3.3 Crankshaft transport locking device	25	9.1.1 Cranking engine manually	89
4 General Information		9.1.2 Engine – Cranking with starting system	91
4.1 Engine side and cylinder designations	28	9.1.3 Engine – Test run	92
4.2 Product description	29	9.2 Cylinder Liner	94
4.3 Engine – Overview	35	9.2.1 Cylinder liner – Endoscopic examination	94
4.4 Sensors and actuators – Overview	36	9.2.2 Cylinder liner – Instructions and comments on endoscopic and visual examination	96
4.5 Data acquisition and data transmission	41	9.3 Crankcase Breather	98
5 Technical Data		9.3.1 Crankcase breather – Oil separator element replacement	98
5.1 Product data 12V4000P61, 12V4000P81	42	9.4 Valve Drive	100
5.2 Product data 16V4000P61, 16V4000P81	47	9.4.1 Valve gear – Lubrication	100
5.3 Firing order	52	9.4.2 Valve clearance – Check and adjustment	101
5.4 Engine – Main dimensions	53	9.4.3 Cylinder head cover – Removal and installation	103
6 Operation		9.5 Injection Pump / HP Pump	104
6.1 Preparations for putting into operation after extended out-of-service periods (>3 months)	54	9.5.1 HP fuel pump – Relief bore check	104
6.2 Preparations for startup after scheduled out-of-service-period	55	9.6 Injection Valve / Injector	105
6.3 Starting the engine in manual mode (test run)	56	9.6.1 Injector – Replacement	105
6.4 Re-starting the engine following an automatic safety shutdown	57	9.6.2 Injector – Removal and installation	106
		9.7 Fuel System	111
		9.7.1 Fuel system – Venting	111
		9.8 Fuel Filter	112
		9.8.1 Fuel filter – Replacement	112

9.8.2	Fuel prefilter – Differential pressure gauge check and adjustment	114	9.15.4	Engine coolant level – Check	141
9.8.3	Fuel prefilter – Draining	115	9.15.5	Engine coolant pump – Relief bore check	142
9.8.4	Fuel prefilter – Flushing	117	9.15.6	Engine coolant – Sample extraction and analysis	143
9.8.5	Fuel prefilter – Filter element replacement	120	9.16	Low-Temperature Circuit	145
9.9	Charge-Air Cooling General, Left-Hand Side	122	9.16.1	Charge-air coolant – Filling	145
9.9.1	Intercooler – Checking condensate drain for coolant discharge and obstruction	122	9.16.2	Charge-air coolant – Draining	148
9.10	Air Filter	123	9.16.3	Charge-air coolant – Change	150
9.10.1	Air filter – Replacement	123	9.16.4	Charge-air coolant level – Check	151
9.10.2	Air filter – Removal and installation	124	9.16.5	Charge-air coolant pump – Relief bore check	152
9.11	Air Intake	125	9.17	Battery-Charging Generator	153
9.11.1	Contamination indicator – Signal ring position check	125	9.17.1	Battery-charging generator – Check	153
9.11.2	Emergency air shutoff flaps – Lubrication	126	9.17.2	Battery-charging generator – Cleaning	154
9.11.3	Emergency air-shutoff flaps – Functional check with electric actuation	127	9.18	Engine Mounting / Support	157
9.12	Starting Equipment	128	9.18.1	Engine mounting – Check	157
9.12.1	Air starter – Manual operation	128	9.19	Wiring (General) for Engine/Gearbox/Unit	158
9.13	Lube Oil System, Lube Oil Circuit	129	9.19.1	Engine wiring – Check	158
9.13.1	Engine oil – Change	129	9.20	Accessories for (Electronic) Engine Governor / Control System	159
9.13.2	Engine oil level – Check	131	9.20.1	Engine governor and connectors – Cleaning	159
9.13.3	Engine oil – Sample extraction and analysis	132	9.20.2	Engine governor plug connections – Check	160
9.14	Oil Filtration / Cooling	133	9.20.3	Engine Monitoring Unit and connectors – Cleaning	161
9.14.1	Engine oil filter – Replacement	133	9.20.4	Engine Monitoring Unit – Plug connection check	162
9.14.2	Centrifugal oil filter – Cleaning and filter sleeve replacement	135	10	Appendix A	
9.15	Coolant Circuit, General, High-Temperature Circuit	137	10.1	Abbreviations	163
9.15.1	Engine coolant – Filling	137	10.2	Contact person / Service partner	167
9.15.2	Engine coolant – Draining	139	11	Appendix B	
9.15.3	Engine coolant – Change	140	11.1	Standard Tools and Special Tools	168
			11.2	Index	174

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer Rolls-Royce Solutions.

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at: <http://www.mtu-solutions.com>

2.2 Intended use of all products

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/Rolls-Royce Solutions contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all safety and warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

2.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.