



Operating Instructions

Diesel Engine
12V4000S83
12V4000S83L
16V4000S83
16V4000S83L

MS150026/08E

Engine model	kW/cyl.	Application group
12V4000S83	139,8 kW/cyl.	4D, Frac-operation (continuous operation with low load)
12V4000S83L	155,4 kW/cyl.	4D, Frac-operation (continuous operation with low load)
16V4000S83	139,8 kW/cyl.	4D, Frac-operation (continuous operation with low load)
16V4000S83L	153,8 kW/cyl.	4D, Frac-operation (continuous operation with low load)

Table 1: Applicability

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to §15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

California Proposition 65

This warning applies only to the State of California, USA, in compliance with Title 27 California Code of Regulations, Article 6, Clear and Reasonable Warnings.

 **WARNING:** Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel.

(→ www.P65warnings.ca.gov/diesel)

Table of Contents

1 Preface		6.8 Preparations for extended out-of-service period	47
1.1 Preface	7	6.9 After shutting down engine – Putting engine out of operation	48
2 Safety		6.10 Plant – Cleaning	49
2.1 Important provisions for all products	8	6.11 EPA labels	51
2.2 Intended use of all products	9	7 Maintenance	
2.3 Personnel and organizational requirements	10	7.1 Maintenance task reference table [QL1] for Non-EPA regions	52
2.4 Safety regulations for commissioning and operation	11	7.2 Maintenance task reference table [QL1] for EPA regions	53
2.5 Safety regulations for assembly, maintenance, and repair work	13	8 Troubleshooting	
2.6 Fire and environmental protection, indirect materials	17	8.1 Troubleshooting	54
2.7 Standards for warning messages in the text and highlighted information	20	8.2 Fault messages	57
3 Transport		9 Task Description	
3.1 Lifting specifications	21	9.1 Engine	88
3.2 Transport	22	9.1.1 Engine – Test run	88
3.3 Crankshaft transport locking device	23	9.1.2 Engine – Barring manually	89
4 General Information		9.1.3 Engine – Turning on starting system	91
4.1 Data acquisition and data transmission	26	9.2 Cylinder Liner	92
4.2 Engine side and cylinder designations	27	9.2.1 Cylinder liner – Endoscopic inspection	92
4.3 Engine overview	28	9.2.2 Cylinder liner – Instructions and comments on endoscopic and visual examination	94
4.4 Sensors and actuators – Overview	30	9.3 Crankcase Breather	96
5 Technical Data		9.3.1 Crankcase breather – Oil separator element replacement	96
5.1 Engine data 12/16V4000S83	34	9.4 Valve Drive	98
5.2 Firing order	38	9.4.1 Valve gear – Lubrication	98
5.3 Engine – Main dimensions	39	9.4.2 Valve clearance – Check and adjustment	99
6 Operation		9.4.3 Cylinder head cover – Removal and installation	102
6.1 Preparations for putting into operation after extended out-of-service periods (>3 months)	40	9.4.4 Valve protrusion – Measurement	103
6.2 Putting the engine into operation after scheduled out-of-service period	41	9.5 Injection Pump / HP Pump	107
6.3 Engine – Starting in manual mode	42	9.5.1 HP pump – Filling with engine oil	107
6.4 Re-starting the engine following an automatic safety shutdown	43	9.5.2 HP fuel pump control block connectors – Check	110
6.5 Operational monitoring	44	9.6 Injector	111
6.6 Engine – Stopping in manual mode	45	9.6.1 Injector – Replacement	111
6.7 Engine – Emergency stop	46	9.6.2 Injector – Removal and installation (jacketed fuel system)	112
		9.7 Fuel System	119
		9.7.1 Fuel system – Venting	119

9.8 Fuel Filter	120	9.14.4 Charge-air coolant level – Check	153
9.8.1 Fuel filter – Replacement	120	9.14.5 Charge-air coolant pump – Relief bore check	155
9.8.2 Fuel prefilter with internal electrical priming pump – Filter element replacement	121	9.15 Belt Drive	156
9.8.3 Fuel prefilter with internal electrical priming pump – Draining	124	9.15.1 Drive belt – Condition check	156
9.9 Charge Air Cooler	125	9.16 Battery-Charging Generator	157
9.9.1 Intercooler – Checking condensate drain for coolant leakage and obstruction	125	9.16.1 Battery-charging generator – Cleaning and check	157
9.10 Air Intake	126	9.16.2 Battery-charging generator drive – Drive belt tension adjustment	158
9.10.1 Emergency air-shutoff flaps – Electric control check	126	9.16.3 Battery-charging generator drive – Drive belt replacement	159
9.10.2 Contamination indicator – Signal ring position check	127	9.17 Fan Drive	160
9.11 Engine Oil System	128	9.17.1 Fan drive – Drive belt tension check and adjustment	160
9.11.1 Engine oil level – Check	128	9.17.2 Fan drive – Drive belt replacement	162
9.11.2 Engine oil – Change	129	9.18 Engine Mounting / Support	163
9.11.3 Engine oil – Sample extraction and analysis	131	9.18.1 Engine mounting – Checking resilient element	163
9.12 Oil Filtration / Cooling	133	9.18.2 Engine mounting – Trunnion mount check	164
9.12.1 Engine oil filter – Replacement	133	9.19 Wiring (General) for Engine/Gearbox/Unit	165
9.12.2 Oil indicator filter – Cleaning and check	134	9.19.1 Engine cabling – Check	165
9.12.3 Centrifugal oil filter – Cleaning and filter-sleeve replacement	136	9.20 Accessories for (Electronic) Engine Governor / Control System	166
9.13 Coolant Circuit, General, High-Temperature Circuit	138	9.20.1 CDC parameters – Reset	166
9.13.1 Engine coolant – Level check	138	9.20.2 Engine governor and connectors – Cleaning	167
9.13.2 Engine coolant – Change	140	9.20.3 Engine governor plug connections – Check	168
9.13.3 Engine coolant pump – Relief bore check	141	10 Appendix A	
9.13.4 Draining engine coolant	142	10.1 Tightening specifications for screws, nuts and bolts	169
9.13.5 Engine coolant – Filling	144	10.2 Abbreviations	182
9.13.6 Engine coolant – Sample extraction and analysis	146	10.3 Contact person / Service partner	185
9.14 Low-Temperature Circuit	148	11 Appendix B	
9.14.1 Charge-air coolant – Change	148	11.1 Standard Tools and Special Tools	186
9.14.2 Charge-air coolant – Draining	149	11.2 Index	195
9.14.3 Charge-air coolant – Filling	151		

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer Rolls-Royce Solutions.

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at:<http://www.mtu-solutions.com>

2.2 Intended use of all products

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/Rolls-Royce Solutions contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all safety and warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

2.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.