



Operating Instructions

Diesel engine
12V4000Px3
16V4000Px3
20V4000Px3

MS150050/07E



A Rolls-Royce
solution

Engine model	kW/cyl.	Application group
12V4000P63	112.5 kW/cyl.	3A, continuous operation, unrestricted
12V4000P63	130 kW/cyl.	3B, continuous operation, variable load, ICXN
12V4000P63	130 kW/cyl.	3C, restricted operation, ICXN
16V4000P63	112.5 kW/cyl.	3A, continuous operation, unrestricted
16V4000P63	130 kW/cyl.	3B, continuous operation, variable load, ICXN
16V4000P63	130 kW/cyl.	3C, restricted operation, ICXN
20V4000P63	112.3 kW/cyl.	3A, continuous operation, unrestricted
20V4000P63	130 kW/cyl.	3B, continuous operation, variable load, ICXN
20V4000P63	130 kW/cyl.	3C, restricted operation, ICXN
12V4000P83	121 kW/cyl.	3A, continuous operation, unrestricted
12V4000P83	140 kW/cyl.	3B, continuous operation, variable load, ICXN
12V4000P83	140 kW/cyl.	3C, restricted operation, ICXN
16V4000P83	121 kW/cyl.	3A, continuous operation, unrestricted
16V4000P83	140 kW/cyl.	3B, continuous operation, variable load, ICXN
16V4000P83	140 kW/cyl.	3C, restricted operation, ICXN
20V4000P83	121 kW/cyl.	3A, continuous operation, unrestricted
20V4000P83	140 kW/cyl.	3B, continuous operation, variable load, ICXN
20V4000P83	140 kW/cyl.	3C, restricted operation, ICXN

Table 1: Applicability

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to §15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

California Proposition 65

This warning applies only to the State of California, USA, in compliance with Title 27 California Code of Regulations, Article 6, Clear and Reasonable Warnings.

 **WARNING:** Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel.

(→ www.P65warnings.ca.gov/diesel)

Table of Contents

1 Preface			
1.1 Preface	8		
2 Safety			
2.1 Important provisions for all products	9		
2.2 Intended use of all products	10		
2.3 Intended use of engines and systems in Marine applications	11		
2.4 Personnel and organizational requirements	12		
2.5 Safety regulations for commissioning and operation	13		
2.6 Safety regulations for assembly, maintenance, and repair work	15		
2.7 Fire and environmental protection, indirect materials	19		
2.8 Standards for warning messages in the text and highlighted information	22		
2.9 ATEX (where applicable)	23		
3 Transport			
3.1 Transport	24		
3.2 Lifting specifications	25		
3.3 Crankshaft transportation lock	29		
4 General Information			
4.1 Data acquisition and data transmission	32		
4.2 Engine side and cylinder designations	33		
4.3 Engine – Overview	34		
4.4 Sensors and actuators – Overview	35		
5 Technical Data			
5.1 Product data 12V4000P63, 12V4000P83	40		
5.2 Product data 16V4000P63, 16V4000P83	45		
5.3 Product data 20V4000P63, 20V4000P83	50		
5.4 Firing order	55		
5.5 Engine – Main dimensions	56		
6 Operation			
6.1 Preparations for putting into operation after extended out-of-service periods (>3 months)	57		
6.2 Preparations for putting into operation after scheduled out-of-service-period	58		
6.3 Starting the engine in manual mode (test run)	59		
6.4 Re-starting the engine following an automatic safety shutdown	60		
6.5 Emergency engine start (Override mode)	61		
6.6 Operational monitoring	62		
6.7 Engine – Stopping in manual mode (test run)	63		
6.8 Emergency engine stop	65		
6.9 After shutting down engine – Putting engine out of operation	66		
6.10 Plant – Cleaning	67		
7 Maintenance			
7.1 Maintenance task reference table [QL1]	69		
8 Troubleshooting			
8.1 Troubleshooting	71		
8.2 Fault messages	74		
9 Task Description			
9.1 SOLAS	110		
9.1.1 SOLAS shielding – Installation locations	110		
9.1.2 SOLAS shielding as per MTN 5233 – Installation	115		
9.1.3 Adhesive tape for SOLAS shielding – Application	116		
9.2 Engine	117		
9.2.1 Barring engine manually	117		
9.2.2 Engine – Turning on starting system	118		
9.2.3 Engine – Test run	119		
9.3 Cylinder Liner	120		
9.3.1 Cylinder liner – Endoscopic inspection	120		
9.3.2 Cylinder liner – Instructions and comments on endoscopic and visual examination	122		
9.4 Crankcase Breather	124		
9.4.1 Crankcase breather – Oil separator replacement, diaphragm check and replacement	124		
9.5 Valve Drive	126		
9.5.1 Valve protrusion – Measurement	126		
9.5.2 Valve gear – Lubrication	130		
9.5.3 Valve clearance – Check and adjustment	131		
9.5.4 Cylinder head cover – Removal and installation	135		
9.6 Injection Pump / HP Pump	136		
9.6.1 HP pump – Filling with engine oil	136		
9.6.2 HP pump – Replacement	139		

9.6.3	HP fuel pump control block connectors – Check	145	9.17.5	Engine coolant pump – Relief bore check	206
9.7	Injector	146	9.17.6	Preheater – Function and leak check	207
9.7.1	Injector – Replacement	146	9.17.7	Preheater – Checking heating element(s) (electrical)	208
9.7.2	Injector – Removal and installation (jacketed fuel system)	147	9.17.8	Coolant expansion tank – Valve cover replacement	209
9.8	Fuel System	154	9.18	Low-Temperature Circuit	211
9.8.1	Fuel system – Venting	154	9.18.1	Charge-air coolant level – Check	211
9.8.2	Fuel delivery pump – Replacement	156	9.18.2	Charge-air coolant – Change	213
9.9	Fuel Filter	159	9.18.3	Charge-air coolant – Draining	214
9.9.1	Fuel filter – Replacement	159	9.18.4	Charge-air coolant – Filling	216
9.9.2	Additional fuel filter – Replacement	161	9.18.5	Charge-air coolant pump – Relief bore check	219
9.9.3	Fuel prefilter – Draining	163	9.19	Battery-Charging Generator	220
9.9.4	Fuel prefilter – Filter element replacement	165	9.19.1	Battery-charging generator drive – Drive belt tension adjustment	220
9.10	Exhaust Turbocharger	169	9.19.2	Battery-charging generator drive – Drive belt condition check	221
9.10.1	Exhaust turbocharger – Turbine housing check	169	9.19.3	Drive belt – Condition check	222
9.11	Charge-Air Cooling	174	9.19.4	Battery-charging generator drive – Drive belt replacement	223
9.11.1	Intercooler – Checking condensate drain for coolant leakage and obstruction	174	9.19.5	Battery-charging generator drive – Coupling condition check	224
9.12	Air Filter	175	9.20	Engine Mounting / Support	225
9.12.1	Air filter – Replacement	175	9.20.1	Engine mounting – Checking resilient mounts	225
9.12.2	Air filter – Removal and installation	176	9.20.2	Engine mount – Measuring height of rubber element	227
9.13	Air Intake	177	9.20.3	Engine mounting – Checking securing screws for firm seating	228
9.13.1	Contamination indicator – Signal ring position check	177	9.20.4	Rigid engine mounting – Checking firm seating of securing screws	229
9.13.2	Emergency air shut-off flaps – Functional check with electric actuation	178	9.21	Coupling	230
9.13.3	Emergency shut-off flaps – Lubrication	181	9.21.1	Steel-spring coupling – Check	230
9.14	Starting Equipment	182	9.21.2	Bending-resilient diaphragm coupling – Condition check	231
9.14.1	Air starter – Manual operation	182	9.22	Generator Mounting	232
9.14.2	Starting valve – Check for leaks	183	9.22.1	Generator mounting – Resilient mount check	232
9.15	Lube Oil System, Lube Oil Circuit	184	9.22.2	Generator mounting – Measuring height of rubber element	234
9.15.1	Engine oil level – Check	184	9.22.3	Generator mounting – Checking securing screws for firm seating	235
9.15.2	Engine oil – Change	185	9.23	Fuel Cooler	236
9.15.3	Engine oil – Sample extraction and analysis	187	9.23.1	Fuel cooler – External contamination and leak-tightness check	236
9.15.4	Oil priming pump – Visual inspection	188	9.23.2	Fuel cooler – Cleaning	237
9.16	Oil Filtration / Cooling	189	9.24	Preheater	239
9.16.1	Automatic oil filter – Replacement	189	9.24.1	Preheater – Thermostat replacement	239
9.16.2	Oil indicator filter – Cleaning and check	193	9.25	Wiring (General) for Engine/Gearbox/Unit	241
9.16.3	Centrifugal oil filter – Cleaning and filter sleeve replacement	195	9.25.1	Engine cabling – Check	241
9.17	Coolant Circuit, General, High-Temperature Circuit	198			
9.17.1	Engine coolant – Level check	198			
9.17.2	Engine coolant – Change	200			
9.17.3	Draining engine coolant	201			
9.17.4	Engine coolant – Filling	203			

9.26 Accessories for (Electronic) Engine Governor / Control System	242	10.2 Contact person / Service partner	250
9.26.1 Parameters for drift correction (CDC) – Resetting with DiaSys®	242	11 Appendix B	
9.26.2 Engine governor plug connections – Check	243	11.1 Standard Tools and Special Tools	251
9.26.3 Engine governor and connectors – Cleaning	244	11.2 Index	264
9.26.4 Engine Control Unit – Self-test	245		
10 Appendix A			
10.1 Abbreviations	246		

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer Rolls-Royce Solutions.

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at:<http://www.mtu-solutions.com>

2.2 Intended use of all products

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/Rolls-Royce Solutions contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all safety and warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.