



Operating Instructions

Diesel Engine

12V4000G73

16V4000G73

Application group 3B

MS150054/08E



A Rolls-Royce
solution

Engine model	Power	Application group
12V4000G73	92.1 kW/cyl.	3B, continuous operation, variable load, ICXN
16V4000G73	86.9 kW/cyl.	3B, continuous operation, variable load, ICXN

Table 1: Applicability

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

California Proposition 65

This warning applies only to the State of California, USA, in compliance with Title 27 California Code of Regulations, Article 6, Clear and Reasonable Warnings.

 **WARNING:** Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel.

(→ www.P65warnings.ca.gov/diesel)

Table of Contents

1 Preface		6.7 Engine - Stopping in manual mode (test run)	47
1.1 Preface	7	6.8 Emergency engine stop	49
2 Safety		6.9 After stopping the engine - Engine remains ready for operation	50
2.1 Important provisions for all products	8	6.10 After shutting down engine - Putting engine out of operation	51
2.2 Intended use of all products	9	7 Maintenance	
2.3 Personnel and organizational requirements	10	7.1 Maintenance task reference table [QL1]	52
2.4 Safety regulations for commissioning and operation	11	8 Troubleshooting	
2.5 Safety regulations for assembly, maintenance, and repair work	13	8.1 Troubleshooting	53
2.6 Fire and environmental protection, indirect materials	17	8.2 Fault messages on SAM display (optional)	56
2.7 Standards for warning messages in the text and highlighted information	20	8.3 Fault messages of Engine Control Unit ADEC (ECU 7) for Series 4000, application: oil & gas	57
3 Transport		9 Task Description	
3.1 Transport	21	9.1 Engine	98
3.2 Lifting specifications	22	9.1.1 Cranking engine manually	98
3.3 Engine mounting transportation lock	24	9.1.2 Engine - Turning on starting system	100
3.4 Transport locking device for crankshaft	26	9.1.3 Engine - Test run	101
4 General Information		9.2 Cylinder Liner	102
4.1 Engine side and cylinder designations	29	9.2.1 Cylinder liner - Endoscopic examination	102
4.2 Engine - Overview	30	9.2.2 Cylinder liner - Instructions and comments on endoscopic and visual examination	104
4.3 Sensors and actuators - Overview	31	9.3 Crankcase Breather	106
4.4 Data acquisition and data transmission	35	9.3.1 Crankcase breather - Oil separator replacement, diaphragm check and replacement	106
5 Technical Data		9.4 Valve Drive	108
5.1 12/16V4000G73 engine data, emissions-optimized (EPA - Tier 2)	36	9.4.1 Valve protrusion - Measurement	108
5.2 Firing order	39	9.4.2 Valve gear - Lubrication	112
5.3 Engine - Main dimensions	40	9.4.3 Valve clearance - Check and adjustment	113
6 Operation		9.4.4 Cylinder head cover - Removal and installation	117
6.1 Preparations for putting into operation after extended out-of-service periods (>3 months)	41	9.5 Injection Pump / HP Pump	118
6.2 Preparations for putting into operation after scheduled out-of-service-period	42	9.5.1 HP pump - Filling with engine oil	118
6.3 Engine - Starting in manual mode (test run)	43	9.6 Injector	121
6.4 Re-starting the engine following an automatic safety shutdown	44	9.6.1 Injector - Replacement	121
6.5 Emergency engine start (Override mode)	45	9.6.2 Injector - Removal and installation	122
6.6 Operational monitoring	46	9.7 Fuel System	128
		9.7.1 Fuel system - Venting	128
		9.8 Fuel Filter	130
		9.8.1 Fuel filter - Replacement	130

9.8.2	Fuel prefilter - Differential pressure gauge check and adjustment	131	9.15.5	Charge-air coolant pump - Relief bore check	174
9.8.3	Fuel prefilter - Draining	132	9.16	Belt Drive	175
9.8.4	Fuel prefilter - Flushing	134	9.16.1	Drive belt - Condition check	175
9.8.5	Fuel prefilter - Filter element replacement	137	9.17	Battery-Charging Generator	176
9.9	Charge-Air Cooling	139	9.17.1	Battery-charging generator - Cleaning and check	176
9.9.1	Intercooler - Checking condensate drain for coolant leakage and obstruction	139	9.17.2	Battery-charging generator - Drive belt tension adjustment	177
9.10	Air Filter	140	9.17.3	Battery-charging generator drive - Drive belt replacement	178
9.10.1	Air filter - Replacement	140	9.18	Fan Drive	179
9.10.2	Air filter - Removal and installation	141	9.18.1	Fan drive - Drive belt tension check / adjustment	179
9.11	Air Intake	142	9.18.2	Fan drive - Drive belt replacement	181
9.11.1	Contamination indicator - Signal ring position check	142	9.19	Engine Mounting / Support	182
9.11.2	Emergency air-shutoff flaps - Electric control check	143	9.19.1	Engine mounting - Check	182
9.11.3	Emergency shut-off flaps - Lubrication	144	9.19.2	Engine mounting - Check	183
9.12	Lube Oil System, Lube Oil Circuit	145	9.20	Wiring (General) for Engine/Gearbox/Unit	184
9.12.1	Engine oil - Change	145	9.20.1	Engine cabling - Check	184
9.12.2	Engine oil - Level check	147	9.21	Accessories for (Electronic) Engine Governor / Control System	185
9.13	Oil Filtration / Cooling	148	9.21.1	Parameters for drift correction (CDC) - Resetting with DiaSys®	185
9.13.1	Engine oil filter - Replacement	148	9.21.2	Engine governor and connectors - Cleaning	186
9.13.2	Oil indicator filter - Cleaning and check	149	9.21.3	EMU and connectors - Cleaning	187
9.13.3	Centrifugal oil filter - Cleaning and filter sleeve replacement	151	9.21.4	Engine governor plug connections - Check	188
9.14	Coolant Circuit, General, High-Temperature Circuit	155	9.21.5	EMU - Checking plug-in connections	189
9.14.1	Engine coolant - Level check	155	9.21.6	Engine governor ECU 7 - Removal and installation	190
9.14.2	Engine coolant - Change	157	9.21.7	EMU 7 - Removal and installation	191
9.14.3	Engine coolant - Draining	158	10	Appendix A	
9.14.4	Engine coolant - Filling	160	10.1	Abbreviations	192
9.14.5	Engine coolant pump - Relief bore check	163	10.2	Contact person/Service partner	196
9.14.6	Engine coolant - Sample extraction and analysis	164	11	Appendix B	
9.15	Low-Temperature Circuit	166	11.1	Standard Tools and Special Tools	197
9.15.1	Charge-air coolant level - Check	166	11.2	Index	208
9.15.2	Charge-air coolant - Change	168			
9.15.3	Charge-air coolant - Draining	169			
9.15.4	Charge-air coolant - Filling	171			

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer Rolls-Royce Solutions.

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at: <http://www.mtu-solutions.com>

2.2 Intended use of all products

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/Rolls-Royce Solutions contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all safety and warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

2.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.