

Operating Instructions

Diesel engine

12 V 4000 G21R

12 V 4000 G41R

MS150064/02E



Power. Passion. Partnership.

© 2019 Copyright MTU Friedrichshafen GmbH

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of MTU Friedrichshafen GmbH. This particularly applies to its reproduction, distribution, editing, translation, micro-filming and storage or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. MTU Friedrichshafen GmbH reserves the right to change, delete or supplement the information provided as and when required.

Commissioning Note

Important

Please complete and return the “Commissioning Note” card below to MTU Friedrichshafen GmbH.

The Commissioning Note information serves as a basis for the contractually agreed logistic support (warranty, spare parts, etc.).



Postcard


MTU Friedrichshafen GmbH

Technical Information Management

Dept. VOT

88040 Friedrichshafen

GERMANY



Engine No.:

MTU works order no.:

Engine model:

Date put into operation:

Application: *
☐ Marine ☐ Rail
☐ Genset ☐

Type:
Manufacturer:

End user's address:

Remarks:

Table of Contents

1	Safety		5.4	Re-starting the engine following an automatic safety shutdown	49
1.1	Important provisions for all products	7	5.5	Emergency engine start (Override mode)	50
1.2	Correct use of all products	9	5.6	Operational monitoring	51
1.3	Personnel and organizational requirements	10	5.7	Engine - Stopping in Manual mode (test run)	52
1.4	Safety regulations for initial start-up and operation	11	5.8	Engine - Emergency stop	54
1.5	Safety regulations for assembly, maintenance, and repair work	13	5.9	After stopping the engine - Engine remains ready for operation	55
1.6	Fire and environmental protection, fluids and lubricants	17	5.10	After stopping the engine - Putting the engine out of operation	56
1.7	Standards for warning notices in the text and highlighted information	20	5.11	Plant - Cleaning	57
2	Transport		6	Maintenance	
2.1	Transport	21	6.1	Maintenance task reference table [QL1]	58
2.2	Lifting instructions	22	7	Troubleshooting	
2.3	Engine mount shipping lock	23	7.1	Troubleshooting	59
2.4	Crankshaft transport locking device	24	7.2	Fault messages on engine governor	62
3	General Information		8	Task Description	
3.1	Engine side and cylinder designations	27	8.1	Engine	73
3.2	Engine layout	28	8.1.1	Engine - Barring manually	73
3.3	Sensors and actuators - Overview	29	8.1.2	Barring engine with starting system	75
4	Technical Data		8.1.3	Engine - Test run	76
4.1	12V 4000 engine data, continuous operation, variable 3B, optimized fuel consumption	32	8.2	Cylinder Liner	77
4.2	12V 4000 engine data, continuous operation, variable 3B, emissions optimized w/o certificate	36	8.2.1	Cylinder liner - Endoscopic examination	77
4.3	12V 4000 engine data, continuous operation, variable 3B, emissions optimized (TA-Luft)	40	8.2.2	Cylinder liner - Instructions and comments on endoscopic and visual examination	79
4.4	Firing order	43	8.3	Crankcase Breather	81
4.5	Final compression pressure	44	8.3.1	Crankcase breather - Oil separator element replacement	81
4.6	Engine - Main dimensions	45	8.4	Valve Drive	84
5	Operation		8.4.1	Valve protrusion - Measurement	84
5.1	Preparations for putting operation after extended out-of-service periods (>3 months)	46	8.4.2	Valve gear - Lubrication	88
5.2	Preparations for putting into operation after scheduled out-of-service-period	47	8.4.3	Valve clearance - Check and adjustment	89
5.3	Starting the engine in manual mode (test run)	48	8.4.4	Cylinder head cover - Removal and installation	91
			8.5	Injection Pump / HP Pump	92
			8.5.1	HP fuel pump - Filling with engine oil	92
			8.5.2	HP fuel pump - Relief bore check	95
			8.6	Injection Valve / Injector	96
			8.6.1	Injector - Replacement	96
			8.6.2	Injector - Removal and installation	97
			8.7	Fuel System	102
			8.7.1	Fuel system - Venting	102

8.8 Fuel Filter	103	8.15.6 Engine coolant - Sample extraction and analysis	135
8.8.1 Fuel filter - Replacement	103	8.16 Low-Temperature Circuit	137
8.8.2 Fuel prefilter - Cleaning	104	8.16.1 Charge-air coolant level - Check	137
8.8.3 Fuel prefilter - Differential pressure gauge check and adjustment	105	8.16.2 Charge-air coolant - Change	139
8.8.4 Fuel prefilter - Draining	106	8.16.3 Charge-air coolant - Draining	140
8.8.5 Fuel prefilter - Flushing	108	8.16.4 Charge-air coolant - Filling	142
8.8.6 Fuel prefilter - Filter element replacement	111	8.16.5 Charge-air coolant - Sample extraction and analysis	146
8.9 Charge-Air Cooling	113	8.16.6 Charge-air coolant pump - Relief bore check	148
8.9.1 Intercooler - Checking condensate drain for coolant leakage and obstruction	113	8.17 Belt Drive	149
8.10 Air Filter	114	8.17.1 Drive belt - Condition check	149
8.10.1 Air filter - Replacement	114	8.18 Battery-Charging Generator	150
8.10.2 Air filter - Removal and installation	115	8.18.1 Battery-charging generator drive - Drive belt condition check	150
8.11 Air Intake	116	8.18.2 Battery-charging generator drive - Drive belt tension adjustment	151
8.11.1 Contamination indicator - Signal ring position check	116	8.18.3 Battery-charging generator drive - Drive belt replacement	152
8.12 Starting Equipment	117	8.19 Wiring (General) for Engine/Gearbox/Unit	153
8.12.1 Air starter - Manual operation	117	8.19.1 Engine cabling - Check	153
8.12.2 Starter - Condition check	118	8.20 Accessories for (Electronic) Engine Governor / Control System	154
8.13 Lube Oil System, Lube Oil Circuit	119	8.20.1 Engine governor and connectors - Cleaning	154
8.13.1 Engine oil level - Check	119	8.20.2 Engine Control Unit - Plug connection check	155
8.13.2 Engine oil - Change	120		
8.13.3 Engine oil - Sample extraction and analysis	122		
8.14 Oil Filtration / Cooling	123		
8.14.1 Engine oil filter - Replacement	123		
8.14.2 Centrifugal oil filter - Cleaning and filter-sleeve replacement	124		
8.15 Coolant Circuit, General, High-Temperature Circuit	126		
8.15.1 Engine coolant - Level check	126		
8.15.2 Engine coolant - Change	128		
8.15.3 Engine coolant - Draining	129		
8.15.4 Engine coolant - Filling	130		
8.15.5 Engine coolant pump - Relief bore check	134		
		9 Appendix A	
		9.1 Abbreviations	156
		9.2 MTU Contact/Service Partners	159
		10 Appendix B	
		10.1 Special Tools	160
		10.2 Index	168

1 Safety

1.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by MTU come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emission specifications and emission label

Responsibility for compliance with emission regulations

Modification or removal of any mechanical/electronic components or the installation of additional components including the execution of calibration processes that might affect the emission characteristics of the product are prohibited by emission regulations. Emission-related components must only be serviced, exchanged or repaired if the components used for this purpose are approved by the manufacturer.

Noncompliance with these specifications will invalidate the design type approval or certification issued by the emissions regulation authorities. The manufacturer does not accept any liability for violations of the emission regulations.

The product must be operated over its entire life cycle according to the conditions defined as "Intended use" (→ Page 9).

Emission certification applicable to engines with EPA Nonroad Tier 4 emission certification in accordance with 40 CFR 1039 and with EPA Locomotive emission certification in accordance with 40 CFR 1033

Extract from the standard:

Failing to follow these instructions when installing a certified engine in a piece of nonroad equipment violates federal law (40 CFR 1068.105(b)), subject to fines or other penalties as described in the Clean Air Act.

Extract from the standard:

If you install the engine in a way that makes the engine's emission control information label hard to read during normal engine maintenance, you must place a duplicate label on the equipment, as described in 40 CFR 1068.105.

When fitting the second label, the requirements of 40 CFR 1068.105(c) must be followed and observed. This paragraph describes the process for requesting and fitting the label, the documentation obligations and storage obligations for the required documents.

Replacing components with emission labels

On all MTU engines fitted with emission labels, these labels must remain on the engine throughout its operational life.

Exception: Engines used exclusively in land-based, military applications other than by US government agencies.

Please note the following when replacing components with emission labels:

- The relevant emission labels must be affixed to the spare part.
- Emission labels shall not be transferred from the replaced part to the spare part.
- The emission labels must be removed from the replaced part and destroyed.

1.2 Correct use of all products

Correct use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/MTU contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found on the websites:

- For drive systems: <http://www.mtu-online.com>
- For power generation: <http://www.mtuonsiteenergy.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

1.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.