



Operating Instructions

Diesel engine
12V4000T94x

MS150096/07E

Engine model	kW/cyl.	Application group
12V4000T94	140.0 kW/cyl.	4D, Frac operation (continuous operation at low load)
12V4000T94L	155.4 kW/cyl.	4D, Frac operation (continuous operation at low load)

Table 1: Applicability

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

California Proposition 65

This warning applies only to the State of California, USA, in compliance with Title 27 California Code of Regulations, Article 6, Clear and Reasonable Warnings.

 **WARNING:** Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel.

(→ www.P65warnings.ca.gov/diesel)

Table of Contents

1 Safety		6 Maintenance	
1.1 Important provisions for all products	7	6.1 Maintenance task reference table [QL1] for MS50080/09	50
1.2 Intended use of engines of the applications Oil&Gas Onshore, Mining, Rail	8	6.2 Maintenance task reference table [QL1] for MSE50080/04, EPA regions	52
1.3 Personnel and organizational requirements	9		
1.4 Safety regulations for commissioning and operation	10	7 Troubleshooting	
1.5 Safety regulations for assembly, maintenance, and repair work	12	7.1 Troubleshooting	54
1.6 Fire and environmental protection, indirect materials	16	7.2 Engine Control Unit ECU9 – Fault messages	58
1.7 Standards for warning messages in the text and highlighted information	19		
2 Transport		8 Task Description	
2.1 Transport	20	8.1 Engine	86
2.2 Transport locking device – Crankshaft	21	8.1.1 Cranking engine manually	86
		8.1.2 Engine – Cranking on starting system	88
		8.1.3 Engine – Test run	89
3 General Information		8.2 Cylinder Liner	90
3.1 Engine side and cylinder designations	25	8.2.1 Cylinder liner – Endoscopic inspection	90
3.2 Data acquisition and data transmission	26	8.2.2 Cylinder liner – Instructions and comments on endoscopic and visual examination	92
3.3 Engine – Overview	27	8.3 Crankcase Breather	94
3.4 Back Pack – Overview	29	8.3.1 Oil mist fine separator – Replacement	94
3.5 Sensors, actuators and injectors – Overview	30	8.4 Valve Drive	96
4 Technical Data		8.4.1 Valve protrusion – Measurement	96
4.1 12V4000T94/T94L engine data	34	8.4.2 Valve-spring retainers – Check	100
4.2 Firing order	38	8.4.3 Valve gear – Lubrication	104
4.3 Engine – Main dimensions	39	8.4.4 Valve clearance – Check and adjustment	105
5 Operation		8.4.5 Valve drive – Removal and installation	108
5.1 Preparations for putting into operation after extended out-of-service periods (>3 months)	40	8.4.6 Cylinder head cover – Removal and installation	111
5.2 Putting the engine into operation after scheduled out-of-service period	41	8.5 Injection Pump / HP Pump	112
5.3 Re-starting the engine following an automatic safety shutdown	42	8.5.1 HP fuel pump – Filling with engine oil	112
5.4 Operational checks	43	8.6 Injector	114
5.5 Engine – Starting in manual mode	44	8.6.1 Injector – Removal and installation	114
5.6 Engine – Stopping in manual mode	45	8.7 Fuel System	120
5.7 After stopping the engine – Putting the engine out of operation	46	8.7.1 Fuel system – Venting	120
5.8 Plant – Cleaning	47	8.8 Fuel Filter	122
5.9 Emission label – Check	49	8.8.1 Fuel filter – Replacement	122
		8.8.2 Additional fuel filter – Replacement	123
		8.8.3 Fuel prefilter with internal electrical priming pump – Draining	124
		8.8.4 Fuel prefilter with internal electrical priming pump – Filter element replacement	125
		8.9 Exhaust Turbocharger	128
		8.9.1 Exhaust turbocharger (LP) – Turbine housing check	128
		8.9.2 Exhaust turbocharger (HP) – Turbine housing check	136

8.10	Charge-Air Cooling	142	8.19	Belt Drive	185
8.10.1	Intercooler - Check for coolant discharge	142	8.19.1	Drive belt - Condition check	185
8.11	Air Filter	143	8.20	Battery-Charging Generator	186
8.11.1	Air filter - Replacement	143	8.20.1	Battery-charging generator - Check and cleaning	186
8.12	Air Intake	144	8.20.2	Battery-charging generator drive - Drive belt tension adjustment	187
8.12.1	Emergency-air shutoff flaps - Overview	144	8.20.3	Battery-charging generator drive - Drive belt replacement	188
8.12.2	Contamination indicator - Signal ring position check	147	8.21	Engine Mounting / Support	189
8.12.3	Emergency air shut-off flaps - Functional check with electric actuation	148	8.21.1	Engine mounting - Check	189
8.13	Exhaust Gas Recirculation	150	8.22	Coupling	190
8.13.1	Exhaust flaps - Overview	150	8.22.1	Torsionally rigid diaphragm coupling - Condition check	190
8.13.2	Exhaust flaps - Checking operation of actuators	152	8.23	Wiring (General) for Engine/Gearbox/Unit	191
8.14	Starting Equipment	153	8.23.1	Engine cabling - Check	191
8.14.1	Starter - Condition check	153	8.24	Accessories for (Electronic) Engine Governor / Control System	192
8.15	Lube Oil System, Lube Oil Circuit	154	8.24.1	Engine governor and connectors - Cleaning	192
8.15.1	Engine oil level - Check at sight glass	154	8.24.2	Engine governor plug connections - Check	193
8.15.2	Engine oil - Level check with oil dipstick	155	8.24.3	NOx sensor - Replacement	194
8.15.3	Engine oil - Change	156	8.24.4	Lambda sensor - Replacement	196
8.15.4	Engine oil - Sample extraction and analysis	158	8.25	Exhaust System	198
8.16	Oil Filtration / Cooling	160	8.25.1	Exhaust silencer - Condensate drain check	198
8.16.1	Engine oil filter - Replacement	160	8.25.2	Back Pack - Visual inspection of securing screws	199
8.16.2	Centrifugal oil filter - Cleaning and filter sleeve replacement	162	8.25.3	Back Pack - Checking securing screws for firm seating	200
8.17	High-Temperature Circuit	164	9	Appendix A	
8.17.1	Engine coolant - Level check	164	9.1	Tightening specifications for screws, nuts and bolts	202
8.17.2	Engine coolant - Change	166	9.2	Abbreviations	216
8.17.3	Engine coolant - Draining	167	9.3	Contact person/Service partner	219
8.17.4	Engine coolant - Filling	169	10	Appendix B	
8.17.5	Engine coolant pump - Relief bore check	172	10.1	Standard Tools and Special Tools	220
8.17.6	Coolant expansion tank - Valve cover replacement	173	10.2	Index	231
8.18	Low-Temperature Circuit	175			
8.18.1	Charge-air coolant level - Check	175			
8.18.2	Charge-air coolant - Change	177			
8.18.3	Charge-air coolant - Draining	178			
8.18.4	Charge-air coolant - Filling	181			
8.18.5	Charge-air coolant pump - Relief bore check	184			

1 Safety

1.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at: <http://www.mtu-solutions.com>

1.2 Intended use of engines of the applications Oil&Gas Onshore, Mining, Rail

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/Rolls-Royce Solutions contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all safety and warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair
- By contracting only workshops authorized by the manufacturer to carry out repair and overhaul

The engine is not designed and configured for environments that require explosion protection as per ATEX or comparable technical specifications. The usage, application and operation in the above-mentioned environment is not permitted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Notice for engines with EPA Nonroad Tier 4 emissions certification in accordance with 40 CFR 1039

The following requirements must be taken into account for engines with EPA Nonroad Tier 4 emissions certification:

- Permanent power limitation of the plant (constrained operation) to <560 kW is not allowed.
- These engines must not be used in engine-generator sets.

Notice for Series 4000R54 engines

The certification of Series 4000R54 engines applies exclusively to line haul applications. Permanent power limitation of the plant (constrained operation) to <1715 kW is therefore not allowed.

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

1.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.

1.4 Safety regulations for commissioning and operation

Safety regulations for commissioning

Install the product correctly and carry out acceptance in accordance with the manufacturer's specifications before commissioning the product. All necessary approvals must be granted by the relevant authorities and all requirements for commissioning must be fulfilled.

Whenever the product is subsequently put into operation ensure that:

- All personnel is clear of the danger zone surrounding moving parts of the machine.
Electrically-actuated linkages may be set in motion when the Engine Control Unit (governor) is switched on.
- All maintenance and repair work has been completed.
- All loose parts have been removed from rotating machine components.
- All protective devices are in place.
- All lines bearing media are ready for operation.
- The walkways in the operating room are unobstructed and safe.
- No persons wearing pacemakers or any other technical body aids are present.
- Adequate ventilation of the operating room is ensured for any operating status.
- In the first few hours of operation, the product emits gases as a result of smoldering e.g. lacquers or oil. These gases may be hazardous to health. Always wear respiratory protection in the operating room during this period.
- The exhaust system is leak-tight and the gases are vented to atmosphere.
- The product is free of any damage, this applies in particular to lines and cabling.
- All components are properly grounded. Ground separately by means of a grounding stake as necessary.
- The power supply (mains plug) is always freely accessible to facilitate disconnecting the device or system from the power supply at any time.
- Battery terminals, generator terminals or cables are protected against accidental contact.
- All connections have been correctly allocated e.g. +/- polarity, fuel line/reducing agent line, supply/return.

Immediately after putting the product into operation, make sure that all control and display instruments as well as the monitoring, signaling and alarm systems work properly.

Smoking is prohibited in the area of the product.

Safety regulations during operation

The operator must be familiar with the control and display elements.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be observed with regard to present operating status, violation of limit values and warning or alarm messages.

Malfunctions and emergency stop

Practice emergency procedures, especially emergency stopping, at regular intervals.

Take the following steps if any system malfunctions are detected or signaled by the system:

- Inform supervisor(s) in charge.
- Analyze the message.
- Respond by taking any necessary emergency action, e.g. emergency stop.

After a safety shutdown, the engine may only be started after the cause of the shutdown has been eliminated.

Contact Service if the root cause of the malfunction cannot be clearly identified.

Operation

Do not remain in the operating room when the product is running unless absolutely necessary. Keep your stay as short as possible.