



Operating Instructions

Gas engine
12V4000L62FB
16V4000L62FB

MS150098/04E

Engine model	kW/cyl.	Application group
12V4000L62FB	100 kW/cyl.	3A, continuous operation, unrestricted
16V4000L62FB	100 kW/cyl.	3A, continuous operation, unrestricted

Table 1: Applicability

Table of Contents

1 Preface		5.3 Engine - Main dimensions	45
1.1 Preface	5	6 Operation	
2 Safety		6.1 Runtimes at partial load	46
2.1 Important provisions for all products	6	6.2 Preparations for putting into operation after extended out-of-service periods (>3 months)	47
2.2 Intended use of all products	8	6.3 Putting the engine into operation after scheduled out-of-service-period	48
2.3 Personnel and organizational requirements	9	6.4 Re-starting the engine following an automatic safety shutdown	49
2.4 Safety regulations for initial start-up and operation	10	6.5 Control, starting and stopping sequences	50
2.5 Safety regulations for commissioning and operation, specific information for gaseous fuel supply or and dual fuel applications	12	6.6 Engine - Start	52
2.6 Safety regulations for assembly, maintenance, and repair work	14	6.7 Operational checks	53
2.7 Safety regulations for assembly, maintenance and servicing work, specific information for gaseous fuel and dual fuel supply or applications	18	6.8 Emission values - Check	54
2.8 Fire and environmental protection, indirect materials	19	6.9 Engine - Shutdown	55
2.9 Fire prevention and environmental protection, fluids and lubricants, auxiliary materials, specific information for gaseous fuel supply in gaseous-fuel or dual-fuel applications	22	6.10 Engine - Emergency shutdown	56
2.10 Standards for warning notices in the text and highlighted information	23	6.11 After stopping the engine - Engine remains ready for operation	57
3 Transport		6.12 After shutdown - Putting engine out of operation	58
3.1 Transport	24	7 Maintenance	
3.2 Lifting specifications	25	7.1 50-hours check	59
3.3 Crankshaft transport locking device	26	7.2 Maintenance task reference table [QL1]	60
4 General Information		8 Troubleshooting	
4.1 Engine side and cylinder designations	29	8.1 Fault messages - Key	61
4.2 Engine - Overview	30	8.2 Fault messages in genset control system log	63
4.3 Monitoring, Control and Regulation Equipment	32	8.3 Engine Control Unit - Fault messages	102
4.3.1 Gas engine phase 3 system - Overview	32	9 Task Description	
4.3.2 Purpose of the units	34	9.1 Engine	138
4.3.3 Sensors - Overview	36	9.1.1 Engine - Barring manually	138
5 Technical Data		9.1.2 Operating room - Check for smell of gas	139
5.1 12V 4000 L62FB, 16V 4000 L62FB engine data, fuel-optimized (TA-Luft)	40	9.2 Crankcase Breather	140
5.2 Firing order	44	9.2.1 Oil separator - Filter replacement	140
		9.2.2 Crankcase breather - Pressure control check and adjustment	142
		9.3 Ignition System	143
		9.3.1 Spark plug - Replacement	143
		9.3.2 Spark plug - Removal	144
		9.3.3 Spark plug - Installation	145
		9.3.4 Spark plug connector - Replacement	147
		9.3.5 Spark plug connector - Removal	148
		9.3.6 Spark plug connector - Installation	150
		9.3.7 Ignition system - Ignition timing check	153
		9.4 Valve Drive	154

9.4.1	Valve clearance - Check and adjustment	154	9.11.1	Engine coolant level - Check	185
9.4.2	Valve protrusion - Measurement	157	9.11.2	Engine coolant - Change	186
9.4.3	Valve gear - Lubrication	160	9.11.3	Engine coolant - Draining	187
9.4.4	Cylinder head cover - Removal	161	9.11.4	Engine coolant - Filling	189
9.4.5	Cylinder head cover - Installation	162	9.11.5	Coolant vent line (engine coolant circuit) - Replacement	190
9.5	Exhaust Turbocharger	163	9.12	Low-Temperature Circuit	191
9.5.1	Exhaust turbocharger - Cleaning	163	9.12.1	Mixture coolant level - Check	191
9.6	Gas System	175	9.12.2	Mixture coolant - Change	192
9.6.1	Gas supply - Checking gas lines for leaks	175	9.12.3	Mixture coolant - Draining	193
9.7	Air Filter	176	9.12.4	Mixture coolant - Filling	194
9.7.1	Air filter - Replacement	176	9.13	Wiring (General) for Engine/Gearbox/Unit	195
9.7.2	Air filter - Removal and installation	177	9.13.1	Engine cabling - Check	195
9.8	Starting System	178			
9.8.1	Starter - Replacement	178	10	Appendix A	
9.9	Lube Oil System, Lube Oil Circuit	181	10.1	Abbreviations	196
9.9.1	Engine oil level - Check	181	10.2	Contact person/Service partner	198
9.9.2	Engine oil - Change	182			
9.9.3	Engine oil - Sample extraction and analysis	183	11	Appendix B	
9.10	Oil Filtration / Cooling	184	11.1	Special Tools	199
9.10.1	Engine oil filter - Replacement	184	11.2	Index	205
9.11	Coolant Circuit, General, High-Temperature Circuit	185			

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer MTU.

Definition of MTU

MTU refers to Rolls-Royce Power Systems AG and MTU Friedrichshafen GmbH or an affiliated company pursuant to Section § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture).

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by MTU come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations and emissions label

Responsibility for compliance with emissions regulations

Modification or removal of any mechanical/electronic components or the installation of additional components including the execution of calibration processes that might affect the emissions characteristics of the product are prohibited by emissions regulations. Emissions-related components must only be serviced, exchanged or repaired if the components used for this purpose are approved by the manufacturer.

Noncompliance with these specifications will invalidate the design type approval or certification issued by the emissions regulation authorities. The manufacturer does not accept any liability for violations of the emissions regulations.

The product must be operated over its entire life cycle according to the conditions defined as "Intended use" (→ Page 8).

Emissions certification applicable to engines with EPA Nonroad Tier 4 emissions certification in accordance with 40 CFR 1039 and with EPA Locomotive emissions certification in accordance with 40 CFR 1033

Extract from the standard:

Failing to follow these instructions when installing a certified engine in a piece of nonroad equipment violates federal law (40 CFR 1068.105(b)), subject to fines or other penalties as described in the Clean Air Act.

Extract from the standard:

If you install the engine in a way that makes the engine's emission control information label hard to read during normal engine maintenance, you must place a duplicate label on the equipment, as described in 40 CFR 1068.105.

When fitting the second label, the requirements of 40 CFR 1068.105(c) must be followed and observed. This paragraph describes the process for requesting and fitting the label, the documentation obligations and storage obligations for the required documents.

Replacing components with emissions labels

On all engines from MTU fitted with emissions labels, these labels must remain on the engine throughout its operational life.

Exception: Engines used exclusively in land-based, military applications other than by US government agencies.

Please note the following when replacing components with emissions labels:

- The relevant emissions labels must be affixed to the spare part.
- Emissions labels shall not be transferred from the replaced part to the spare part.
- The emissions labels must be removed from the replaced part and destroyed.

2.2 Intended use of all products

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/MTU contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all safety and warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

2.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.

2.4 Safety regulations for initial start-up and operation

Safety regulations for initial start-up

Install the product correctly and carry out acceptance in accordance with the manufacturer's specifications before putting the product into service. All necessary approvals must be granted by the relevant authorities and all requirements for initial startup must be fulfilled.

Whenever the product is subsequently taken into operation ensure that:

- All personnel is clear of the danger zone surrounding moving parts of the machine.
Electrically-actuated linkages may be set in motion when the Engine Control Unit (governor) is switched on.
- All maintenance and repair work has been completed.
- All loose parts have been removed from rotating machine components.
- All safeguards are in place.
- All components must be properly grounded. Ground separately by means of a grounding stake as necessary.
- No persons wearing pacemakers or any other technical body aids are present.
- Adequate ventilation of the operating room must be ensured for any operating status.
- In the first few hours of operation, the product emits gases as a result of smoldering e.g. lacquers or oil. These gases may be hazardous to health. Always wear respiratory protection in the operating room during this period.
- The exhaust system is leak-tight and that the gases are vented to atmosphere.
- The product must be free of any damage, this applies in particular to lines and cabling.
- Protect battery terminals, generator terminals or cables against accidental contact.
- Check that all connections have been correctly allocated e.g. +/- polarity, fuel line/reduction agent line, supply/return.

Immediately after putting the product into operation, make sure that all control and display instruments as well as the monitoring, signaling and alarm systems work properly.

Smoking is prohibited in the area of the product.

Safety regulations during operation

The operator must be familiar with the control and display elements.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be permanently observed with regard to present operating status, violation of limit values and warning or alarm messages.

Malfunctions and emergency stop

Practice emergency procedures, especially emergency stopping, at regular intervals.

Take the following steps if any system malfunctions are detected or signaled by the system:

- Inform supervisor(s) in charge.
- Analyze the message.
- Respond by taking any necessary emergency action, e.g. emergency stop.

After a safety shutdown, the engine must only be started after the cause of the shutdown has been eliminated.

Contact Service if the root cause of the malfunction cannot be clearly identified.

Operation

Do not remain in the operating room when the product is running unless absolutely necessary. Keep your stay as short as possible.

Keep a safe distance away from the product if possible. Do not touch the product unless expressly instructed to do so following a written procedure.