



Operating Instructions

Gas engine
12V4000L32FB
16V4000L32FB

MS150115/07E



A Rolls-Royce
solution

Engine model	kW/cyl.	Application group
12V4000L32FB	100 kW/cyl.	3A, continuous operation, unrestricted
16V4000L32FB	100 kW/cyl.	3A, continuous operation, unrestricted

Table 1: Applicability

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

Table of Contents

1 Preface			
1.1 Preface	5		
2 Safety			
2.1 Important provisions for all products	6		
2.2 Intended use of all products	7		
2.3 Personnel and organizational requirements	8		
2.4 Safety regulations for commissioning and operation	9		
2.5 Safety regulations for commissioning and operation, specific information for gaseous fuel supply or and dual fuel applications	11		
2.6 Safety regulations for assembly, maintenance, and repair work	13		
2.7 Safety regulations for assembly, maintenance and servicing work, specific information for gaseous fuel and dual fuel supply or applications	17		
2.8 Fire and environmental protection, indirect materials	18		
2.9 Fire prevention and environmental protection, fluids and lubricants, auxiliary materials, specific information for gaseous fuel supply in gaseous-fuel or dual-fuel applications	21		
2.10 Standards for warning notices in the text and highlighted information	22		
3 Transport			
3.1 Transport	23		
3.2 Lifting specifications	24		
3.3 Crankshaft transport locking device	25		
4 General Information			
4.1 Engine side and cylinder designations	28		
4.2 Engine - Overview	29		
4.3 Monitoring, Control and Regulation Equipment	31		
4.3.1 Gas engine phase 4 system - Overview	31		
4.3.2 Purpose of the units	33		
4.3.3 Sensors - Overview	35		
5 Technical Data			
5.1 Engine data 12V4000L32FB, 16V4000L32FB, fuel-optimized (TA-Luft)	39		
5.2 Engine data 12V4000L32FB, 16V4000L32FB, tropical application (TA-Luft)			44
5.3 Firing order			49
5.4 Engine - Main dimensions			50
6 Operation			
6.1 Runtimes at partial load			51
6.2 Preparations for putting into operation after extended out-of-service periods (>3 months)			52
6.3 Putting the engine into operation after scheduled out-of-service-period			53
6.4 Re-starting the engine following an automatic safety shutdown			54
6.5 Control, starting and stopping sequences			55
6.6 Starting the engine			57
6.7 Operational monitoring			58
6.8 Checking emission values			59
6.9 Engine - Shutdown			60
6.10 Engine - Emergency shutdown			61
6.11 After stopping the engine - Engine remains ready for operation			63
6.12 After shutdown - Putting engine out of operation			64
7 Maintenance			
7.1 50-hours check			65
7.2 Maintenance task reference table [QL1]			66
8 Troubleshooting			
8.1 Fault messages - Key			67
8.2 Fault messages in engine-generator set controller log			69
8.3 Engine Control Unit - Fault messages			135
9 Task Description			
9.1 Engine			177
9.1.1 Engine - Barring manually			177
9.1.2 Operating room - Check for smell of gas			178
9.1.3 Engine - Test run			179
9.1.4 Operating data check after 3000 hours			180
9.2 Crankcase Breather			182
9.2.1 Oil separator - Filter replacement			182
9.2.2 Crankcase breather - Pressure regulator check and adjustment			184
9.3 Ignition System			185
9.3.1 Spark plug - Replacement			185

9.3.2 Spark plug - Removal	186	9.10.1 Engine oil filter - Replacement	218
9.3.3 Spark plug - Installation	187	9.11 Coolant Circuit, General, High-Temperature Circuit	219
9.3.4 Spark plug connector - Replacement	189	9.11.1 Engine coolant level - Check	219
9.3.5 Spark plug connector - Removal	190	9.11.2 Engine coolant - Change	220
9.3.6 Spark plug connector - Cleaning and check	191	9.11.3 Engine coolant - Draining	221
9.3.7 Spark plug connector - Installation	192	9.11.4 Engine coolant - Filling	223
9.3.8 Ignition system - Ignition timing check	194	9.11.5 Coolant vent line (engine coolant circuit) - Replacement	224
9.4 Valve Drive	195	9.11.6 Coolant pipework - O-ring replacement	225
9.4.1 Valve clearance - Check and adjustment	195	9.11.7 Rubber bellows for HT circuit - Replacement	226
9.4.2 Valve protrusion - Measurement	198	9.12 Low-Temperature Circuit	227
9.4.3 Valve gear - Lubrication	201	9.12.1 Mixture coolant level - Check	227
9.4.4 Cylinder head cover - Removal	202	9.12.2 Mixture coolant - Change	228
9.4.5 Cylinder head cover - Installation	203	9.12.3 Mixture coolant - Draining	229
9.5 Gas System	204	9.12.4 Mixture coolant - Filling	230
9.5.1 Gas supply - Checking gas lines for leaks	204	9.13 Engine Mounting / Support	231
9.6 Air Filter	205	9.13.1 Engine mounting - Checking securing screws for firm seating	231
9.6.1 Air filter - Check	205	9.14 Wiring (General) for Engine/Gearbox/Unit	232
9.6.2 Air filter - Replacement	206	9.14.1 Engine cabling - Check	232
9.6.3 Air filter - Removal and installation	207	9.14.2 NOx sensor - Replacement	233
9.6.4 Prefilter - Replacement	208	10 Appendix A	
9.7 Exhaust Pipework	209	10.1 Abbreviations	235
9.7.1 Exhaust pipe bellows - Check	209	10.2 Contact person/Service partner	237
9.7.2 Exhaust pipe bellows - Replacement	210	11 Appendix B	
9.8 Starting System	211	11.1 Standard Tools and Special Tools	238
9.8.1 Starter - Replacement	211	11.2 Index	244
9.9 Lube Oil System, Lube Oil Circuit	215		
9.9.1 Engine oil level - Check	215		
9.9.2 Engine oil - Change	216		
9.9.3 Engine oil - Sample extraction and analysis	217		
9.10 Oil Filtration / Cooling	218		

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer Rolls-Royce Solutions.

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at: <http://www.mtu-solutions.com>

2.2 Intended use of all products

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/Rolls-Royce Solutions contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all safety and warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

2.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.

2.4 Safety regulations for commissioning and operation

Safety regulations for commissioning

Install the product correctly and carry out acceptance in accordance with the manufacturer's specifications before putting the product into service. All necessary approvals must be granted by the relevant authorities and all requirements for initial startup must be fulfilled.

Whenever the product is subsequently put into operation ensure that:

- All personnel is clear of the danger zone surrounding moving parts of the machine.
Electrically-actuated linkages may be set in motion when the Engine Control Unit (governor) is switched on.
- All maintenance and repair work has been completed.
- All loose parts have been removed from rotating machine components.
- All protective devices are in place.
- All lines bearing media are ready for operation.
- No persons wearing pacemakers or any other active implanted medical devices (AIMD) are present.
- Adequate ventilation of the operating room must be ensured for any operating status.
- In the first few hours of operation, the product emits gases as a result of smoldering e.g. lacquers or oil. These gases may be hazardous to health. Always wear respiratory protection in the operating room during this period.
- The exhaust pipework is leak-tight and that the gases are vented to atmosphere.
- The product must be free of any damage, this applies in particular to lines and cabling.
- All components are properly grounded. Ground separately by means of a grounding stake as necessary.
- The power supply (mains plug) must always be freely accessible to facilitate disconnecting the device or system from the power supply at any time.
- Protect battery terminals, generator terminals or cables against accidental contact.
- Check that all connections have been correctly allocated e.g. +/- polarity, fuel line/reduction agent line, supply/return.

Immediately after putting the product into operation, make sure that all control and display instruments as well as the monitoring, signaling and alarm systems work properly.

Smoking is prohibited in the area of the product.

Safety regulations during operation

The operator must be familiar with the control and display elements.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be observed with regard to present operating status, violation of limit values and warning or alarm messages.

Malfunctions and emergency stop

Practice emergency procedures, especially emergency stopping, at regular intervals.

Take the following steps if any system malfunctions are detected or signaled by the system:

- Inform supervisor(s) in charge.
- Analyze the message.
- Respond by taking any necessary emergency action, e.g. emergency stop.

After a safety shutdown, the engine may only be started after the cause of the shutdown has been eliminated.

Contact Service if the root cause of the malfunction cannot be clearly identified.

Operation

Do not remain in the operating room when the product is running unless absolutely necessary. Keep your stay as short as possible.

Keep a safe distance away from the product if possible. Do not touch the product unless expressly instructed to do so following a written procedure.

Do not inhale the exhaust gases of the product.

The following requirements must be fulfilled before the product is started:

- Wear hearing protection.
- Mop up any leaked or spilled fluids and lubricants immediately or soak up with a suitable binding agent.

Operation of electrical equipment

When electrical equipment is in operation, certain components of these appliances are electrically live.

Follow the applicable operating and safety instructions when operating the devices and heed warnings at all times.