



Operating Instructions

Diesel Engine
12V4000T25L
12V4000T95x
16V4000T95

MS150120/05E

Engine model	Power	Application group
12V4000T25L	114 kW/cyl.	3B, continuous service, variable load, ICXN
12V4000T95	155 kW/cyl.	4D, Frac operation (continuous operation with low load)
12V4000T95L	162 kW/cyl.	4D, Frac operation (continuous operation with low load)
12V4000T95R	140 kW/cyl.	4D, Frac operation (continuous operation with low load)
16V4000T95	140 kW/cyl.	4D, Frac operation (continuous operation with low load)

Table 1: Applicability

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

California Proposition 65

This warning applies only to the State of California, USA, in compliance with Title 27 California Code of Regulations, Article 6, Clear and Reasonable Warnings.

 **WARNING:** Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel.

(→ www.P65warnings.ca.gov/diesel)

Table of Contents

1 Preface		6.6 Emission label – Check	58
1.1 Preface	7	6.7 Engine – Starting in manual mode	59
2 Safety		6.8 Engine – Stopping in manual mode	60
2.1 Important provisions for all products	8	6.9 Emergency engine stop	61
2.2 Intended use of all products	9	6.10 After stopping the engine – Putting the engine out of operation	62
2.3 Personnel and organizational requirements	10	6.11 Plant – Cleaning	63
2.4 Safety regulations for commissioning and operation	11	7 Maintenance	
2.5 Safety regulations for assembly, maintenance, and repair work	13	7.1 Maintenance task reference table [QL1]	65
2.6 Fire and environmental protection, indirect materials	17	7.2 Maintenance task reference table [QL1] for Non-EPA regions	67
2.7 Standards for warning messages in the text and highlighted information	20	8 Troubleshooting	
3 Transport		8.1 Troubleshooting	68
3.1 Transport	21	8.2 Fault messages	72
3.2 Lifting requirements	22	9 Task Description	
3.3 Transport locking device for crankshaft	23	9.1 Engine	153
4 General Information		9.1.1 Cranking engine manually	153
4.1 Engine side and cylinder designations	27	9.1.2 Engine – Cranking on starting system	155
4.2 Engine – Overview	28	9.1.3 Engine – Test run	156
4.3 Back Pack – Overview	32	9.2 Cylinder Liner	157
4.4 Safety Function System (SFS) (optional) – Overview	33	9.2.1 Cylinder liner – Endoscopic inspection	157
4.5 Sensors and actuators – Overview	36	9.2.2 Cylinder liner – Instructions and comments on endoscopic and visual examination	159
5 Technical Data		9.3 Crankcase Breather	161
5.1 Product data 12V4000T95R 12V4000T95 12V4000T95L 16V4000T95	42	9.3.1 Oil mist fine separator – Replacement	161
5.2 Firing order	47	9.4 Valve Drive	163
5.3 Engine – Main dimensions	48	9.4.1 Valve gear – Lubrication	163
6 Operation		9.4.2 Valve protrusion – Measurement	164
6.1 Preparations for putting into operation after extended out-of-service periods (>3 months)	49	9.4.3 Valve clearance – Check and adjustment	168
6.2 Putting the engine into operation after scheduled out-of-service period	50	9.4.4 Cylinder head cover – Removal and installation	171
6.3 Re-starting the engine following an automatic safety shutdown	51	9.5 Injection Pump / HP Pump	173
6.4 Operational monitoring	52	9.5.1 HP fuel pump – Filling with engine oil	173
6.5 Safety Function System (SFS) – Operating states	53	9.6 Injector	175
		9.6.1 Injector – Replacement	175
		9.6.2 Injector – Removal and installation	176
		9.7 Fuel System	183
		9.7.1 Fuel system – Venting	183
		9.8 Fuel Filter	185
		9.8.1 Fuel filter – Replacement	185
		9.8.2 Additional fuel filter – Replacement	186
		9.8.3 Fuel prefilter with internal electrical priming pump – Draining	187

9.8.4	Fuel prefilter with internal electrical priming pump - Filter element replacement	188	9.18	Low-Temperature Circuit	244
9.9	Exhaust Turbocharger	191	9.18.1	Charge-air coolant level - Check	244
9.9.1	Exhaust turbocharger - Turbine housing check	191	9.18.2	Charge-air coolant - Change	246
9.9.2	Exhaust turbocharger (HP) - Turbine housing check	192	9.18.3	Charge-air coolant - Draining	247
9.9.3	Exhaust turbocharger (LP) - Turbine housing check	198	9.18.4	Charge-air coolant - Filling	250
9.10	Charge-Air Cooling	203	9.18.5	Charge-air coolant pump - Relief bore check	253
9.10.1	Intercooler - Check for coolant discharge	203	9.19	Belt Drive	254
9.11	Air Filter	204	9.19.1	Drive belt - Condition check	254
9.11.1	Air filter - Replacement	204	9.20	Battery-Charging Generator	255
9.12	Air Intake	205	9.20.1	Battery-charging generator - Check	255
9.12.1	Service indicator - Signal ring position check	205	9.20.2	Battery-charging generator drive - Drive belt replacement	256
9.12.2	Overspeed test - Emergency air-shutoff flap functional check	206	9.20.3	Battery-charging generator - Drive belt tension adjustment	257
9.12.3	Emergency air-shutoff flaps - Manual opening	209	9.21	Engine Mounting / Support	258
9.13	Exhaust Gas Recirculation	210	9.21.1	Engine mounting - Check	258
9.13.1	Exhaust flaps - Overview	210	9.22	Wiring (General) for Engine/Gearbox/Unit	259
9.13.2	Exhaust flaps - Checking coupling rod clearance and function	213	9.22.1	Engine cabling - Check	259
9.13.3	Exhaust flaps - Coupling rod replacement	215	9.23	Accessories for (Electronic) Engine Governor / Control System	260
9.14	Starting Equipment	218	9.23.1	Resetting CDC parameter and entering IIG with DiaSys®	260
9.14.1	Starter - Condition check	218	9.23.2	Actuators - Visual inspection and test	261
9.15	Engine Oil System	219	9.23.3	Engine governor and connectors - Cleaning	263
9.15.1	Engine oil level - Check at sight glass	219	9.23.4	Engine governor plug connections - Check	264
9.15.2	Engine oil - Level check with oil dipstick	220	9.23.5	NOx sensor - Replacement	265
9.15.3	Engine oil - Change	221	9.23.6	Lambda sensor - Replacement	267
9.15.4	Engine oil - Sample extraction and analysis	223	9.24	Exhaust System	269
9.16	Oil Filtration / Cooling	225	9.24.1	Exhaust silencer - Condensate drain check	269
9.16.1	Engine oil filter - Replacement	225	9.24.2	Back Pack - Visual inspection of securing screws	270
9.16.2	Centrifugal oil filter - Cleaning and filter sleeve replacement	227	9.24.3	Back Pack - Checking securing screws for firm seating	271
9.17	High-Temperature Circuit	231	10	Appendix A	
9.17.1	Engine coolant - Level check	231	10.1	Abbreviations	273
9.17.2	Engine coolant - Change	233	10.2	Contact person/Service partner	277
9.17.3	Engine coolant - Draining	234	11	Appendix B	
9.17.4	Engine coolant - Filling	236	11.1	Standard Tools and Special Tools	278
9.17.5	Engine coolant pump - Relief bore check	239	11.2	Index	288
9.17.6	Engine coolant - Sample extraction and analysis	240			
9.17.7	Coolant expansion tank - Valve cover replacement	242			

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer Rolls-Royce Solutions.

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at:<http://www.mtu-solutions.com>

2.2 Intended use of all products

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/Rolls-Royce Solutions contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all safety and warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

2.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.