



Operating Instructions

Diesel engine
12V4000Bx4
12V4000Gx4
12V4000Gx3F
12V4000Gx3S
16V4000Bx4
16V4000Gx4
16V4000Gx3F
16V4000Gx3S

MS15038/06E

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

California Proposition 65

This warning applies only to the State of California, USA, in compliance with Title 27 California Code of Regulations, Article 6, Clear and Reasonable Warnings.

 **WARNING:** Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel.

(→ www.P65warnings.ca.gov/diesel)

Table of Contents

1 Preface		6 Technical Data	
1.1 Preface	8	6.1 Product data 12V4000B14S, application 3A; 12V4000B24F, application 3A; 12V4000B24S, application 3A	61
1.2 Applicability	9	6.2 Product data 12V4000G14F, application group 3B	65
2 Safety		6.3 Product data 12V4000G14F, application 3E	70
2.1 Important provisions for all products	10	6.4 Product data 12V4000G14F, application 3F	74
2.2 Important requirements for Power Generation application products	11	6.5 Product data 12V4000G14F, application 3G	78
2.3 Intended use of gendrive engines	13	6.6 Product data 12V4000G14RF, application 3B	82
2.4 Personnel and organizational requirements	14	6.7 Product data 12V4000G14S, applications 3B, 3F, 3G	87
2.5 Safety regulations for commissioning and operation	15	6.8 Product data 12V4000G14S, application 3E	93
2.6 Safety regulations for assembly, maintenance, and repair work	17	6.9 Product data 12V4000G24F, application 3B	97
2.7 Fire and environmental protection, indirect materials	21	6.10 Product data 12V4000G24F, application 3E	102
2.8 Standards for warning messages in the text and highlighted information	24	6.11 Product data 12V4000G24F, application 3F	107
3 Transport		6.12 Product data 12V4000G24F, application 3G	112
3.1 Transport	25	6.13 Product data 12V4000G24S, applications 3B, 3F, 3G	117
3.2 Lifting specifications	26	6.14 Product data 12V4000G24S, application 3E	123
3.3 Engine mounting transportation lock	27	6.15 Product data 12V4000G74F, application 3D; 12V4000G74S, application 3D	127
3.4 Transport locking device for crankshaft	29	6.16 Product data 12V4000G84F, application 3D; 12V4000G84S, application 3D	133
4 General Information		6.17 Product data 16V4000B24F, application 3A; 16V4000B14S, application 3A; 16V4000B24S, application 3A	139
4.1 Engine side and cylinder designations	32	6.18 Product data 16V4000G14F, application 3B	143
4.2 Data acquisition and data transmission	33	6.19 Product data 16V4000G14F, application 3E	148
5 Functional Description		6.20 Product data 16V4000G14F, application 3F	153
5.1 Engine - Overview	34	6.21 Product data 16V4000G14F, application 3G	158
5.2 Crankcase with oil pan	36	6.22 Product data 16V4000G14S, applications 3B, 3F, 3G	163
5.3 Gear train	38	6.23 Product data 16V4000G14S, application 3E	169
5.4 Running gear	39	6.24 Product data 16V4000G24F, application 3B	173
5.5 Cylinder head with injector	41	6.25 Product data 16V4000G24F, application 3E	178
5.6 Valve gear	43	6.26 Product data 16V4000G24F, application 3F	183
5.7 Fuel system with Common-Rail injection	45	6.27 Product data 16V4000G24F, application 3G	188
5.8 Charge-air and exhaust system	47	6.28 Product data 16V4000G24S, applications 3B, 3F, 3G	193
5.9 Lube oil system	49	6.29 Product data 16V4000G24S, application 3E	199
5.10 Cooling system	51	6.30 Product data 16V4000G74F, application 3D; 16V4000G74S, application 3D	203
5.11 Engine management and monitoring	53	6.31 Product data 16V4000G84F, application 3D; 16V4000G84S, application 3D	209
5.12 Sensors and actuators - Overview	56	6.32 Product data 16V4000G94S, application 3D	215
		6.33 Product data 12V4000G23RF, 12V4000G23F, 12V4000G63F,	219

12V4000G43S, 12V4000G83S, 16V4000G23F, 16V4000G63F, 16V4000G43S, 16V4000G83S, 16V4000G83LS	
6.34 Product data 12V4000B24X, application 3A; 12V4000G14X, application 3B; 12V4000G24X, application 3B; 12V4000G74X, application 3D; 12V4000G84X, application 3D	222
6.35 Product data 16V4000B24X, application 3A; 16V4000G14X, application 3B; 16V4000G24X, application 3B; 16V4000G74X, application 3D; 16V4000G84X, application 3D	223
6.36 Firing order	224
6.37 Main engine dimensions	225
7 Operation	
7.1 Preparations for putting into operation after extended out-of-service periods (>3 months)	226
7.2 Preparations for putting into operation after scheduled out-of-service-period	227
7.3 Starting the engine in manual mode (test run)	228
7.4 Engine - Quick-start function	229
7.5 Re-starting the engine following an automatic safety shutdown	230
7.6 Safety system - Override	231
7.7 Emergency engine start (Override mode)	232
7.8 Operational monitoring	233
7.9 Emission label - Check	234
7.10 Engine - Stopping in manual mode (test run)	235
7.11 Engine - Emergency stop	237
7.12 After stopping the engine - Engine remains ready for operation	238
7.13 After shutting down engine - Putting engine out of operation	239
7.14 Plant - Cleaning	240
8 Troubleshooting	
8.1 Troubleshooting	242
8.2 Fault messages of Engine Control Unit ECU9 for Series 4000, genset applications	245
8.3 Fault conditions of the alarms 1801 to 1840	280
9 Maintenance	
9.1 Maintenance task reference table [QL1]	283

10 Task Description	
10.1 Engine	285
10.1.1 Barring engine manually	285
10.1.2 Engine - Cranking on starting system	287
10.1.3 Engine - Test run	288
10.2 Cylinder Liner	289
10.2.1 Cylinder liner - Endoscopic inspection	289
10.2.2 Cylinder liner - Instructions and comments on endoscopic and visual examination	291
10.3 Crankcase Breather	293
10.3.1 Crankcase breather - Oil separator element replacement	293
10.3.2 Crankcase breather - Oil separator element replacement	295
10.3.3 Crankcase breather - Oil mist separator replacement	297
10.4 Valve Drive	298
10.4.1 Valve protrusion - Measurement	298
10.4.2 Valve gear - Lubrication	302
10.4.3 Valve clearance - Check and adjustment	303
10.4.4 Cylinder head cover - Removal and installation	307
10.5 Injection Pump / HP Pump	308
10.5.1 HP fuel pump - Filling with engine oil	308
10.6 Injector	311
10.6.1 Injector - Replacement	311
10.6.2 Injector - Removal and installation	312
10.7 Fuel System	317
10.7.1 Fuel system - Venting	317
10.7.2 Fuel cooler - External contamination and leak- tightness check	319
10.7.3 Fuel cooler - Cleaning	320
10.8 Fuel Filter	322
10.8.1 Fuel filter - Replacement	322
10.8.2 Fuel prefilter - Pressure ratios	324
10.8.3 Fuel prefilter - Draining	325
10.8.4 Fuel prefilter (non-switchable) - Draining	326
10.8.5 Fuel prefilter (switchable) - Draining	329
10.8.6 Fuel prefilter (switchable) - Low pressure indicator check	332
10.8.7 Fuel prefilter - Filter element replacement	333
10.8.8 Fuel prefilter (non-switchable) - Filter element replacement	334
10.8.9 Fuel prefilter (switchable) - Filter element replacement	336
10.8.10 Fuel prefilter - Venting	339
10.9 Charge-Air Cooling	341
10.9.1 Intercooler - Checking condensate drain for coolant leakage and obstruction	341
10.10 Air Filter	342
10.10.1 Air filter - Replacement	342

10.10.2	Air filter - Check	343	10.16.3	Charge-air coolant - Draining	389
10.10.3	Air filter - Removal and installation	344	10.16.4	Charge-air coolant - Filling	391
10.11	Air Intake	345	10.16.5	Charge-air coolant pump - Relief bore check	394
10.11.1	Contamination indicator - Signal ring position check	345	10.17	Battery-Charging Generator	395
10.12	Starting Equipment	346	10.17.1	Battery-charging generator - Cleaning	395
10.12.1	Air starter - Manual operation	346	10.17.2	Drive belt - Condition check	396
10.13	Lube Oil System, Lube Oil Circuit	347	10.17.3	Battery-charging generator - Drive belt tension adjustment	397
10.13.1	Engine oil - Change	347	10.17.4	Battery-charging generator drive - Drive belt replacement	398
10.13.2	Engine oil - Level check	350	10.18	Storage	399
10.13.3	Engine oil - Sample extraction and analysis	351	10.18.1	Engine mounting - Checking resilient element	399
10.13.4	Oil priming pump - Visual inspection	353	10.18.2	Engine mounting - Checking securing screws for firm seating	400
10.14	Oil Filtration / Cooling	354	10.18.3	Engine mount - Measuring height of rubber element	402
10.14.1	Engine oil filter - Replacement	354	10.18.4	Generator mounting - Check	403
10.14.2	Centrifugal oil filter - Cleaning and filter sleeve replacement	356	10.18.5	Generator mounting - Securing screw firm seating check	404
10.15	Coolant Circuit, General, High-Temperature Circuit	359	10.18.6	Generator mount - Measuring height of rubber element	405
10.15.1	Engine coolant - Level check	359	10.19	Wiring (General) for Engine/Gearbox/Unit	406
10.15.2	Engine coolant - Change	361	10.19.1	Engine cabling - Check	406
10.15.3	Engine coolant - Draining	362	10.20	Accessories for (Electronic) Engine Governor / Control System	407
10.15.4	Engine coolant - Filling	364	10.20.1	Engine governor and connectors - Cleaning	407
10.15.5	Engine coolant pump - Relief bore check	367	10.20.2	Engine Control Unit plug connections - Check	408
10.15.6	Engine coolant - Sample extraction and analysis	368	10.20.3	Engine governor ECU 9 - Removal and installation	409
10.15.7	Preheater - Overview	370	10.20.4	Parameters for drift correction (CDC) - Resetting with DiaSys®	410
10.15.8	Preheater - Function and leak check	371	11	Appendix A	
10.15.9	Preheater - Overhaul	372	11.1	Abbreviations	411
10.15.10	Preheater - Solenoid switch replacement	373	11.2	Contact person/Service partner	415
10.15.11	Preheater - Heating element and housing check	375	12	Appendix B	
10.15.12	Preheater thermostats - Replacement	378	12.1	Standard Tools and Special Tools	416
10.15.13	Preheater - Replacement	381	12.2	Index	426
10.15.14	Preheater - Removal	382			
10.15.15	Preheater - Installation	383			
10.15.16	Coolant expansion tank - Valve cover replacement	384			
10.16	Low-Temperature Circuit	386			
10.16.1	Charge-air coolant level - Check	386			
10.16.2	Charge-air coolant - Change	388			

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer Rolls-Royce Solutions.

1.2 Applicability

Engine model	Frequency	Application *	Engine model	Frequency	Application *
12V4000B14S	60 Hz	3A	16V4000B14S	60 Hz	3A
12V4000B24F	50 Hz	3A	16V4000B24F	50 Hz	3A
12V4000B24S	60 Hz	3A	16V4000B24S	60 Hz	3A
12V4000B24X	50/60 Hz	3A	16V4000B24X	50/60 Hz	3A
12V4000G14F	50 Hz	3B, 3E, 3F, 3G	16V4000G14F	50 Hz	3B, 3E, 3F, 3G
12V4000G14RF	50 Hz	3B	16V4000G14S	60 Hz	3B, 3E, 3F, 3G
12V4000G14S	60 Hz	3B, 3E, 3F, 3G	16V4000G14X	50/60 Hz	3B
12V4000G14X	50/60 Hz	3B	16V4000G24F	50 Hz	3B, 3E, 3F, 3G
12V4000G24F	50 Hz	3B, 3E, 3F, 3G	16V4000G24S	60 Hz	3B, 3E, 3F, 3G
12V4000G24S	60 Hz	3B, 3E, 3F, 3G	16V4000G24X	50/60 Hz	3B
12V4000G24X	50/60 Hz	3B	16V4000G74F	50 Hz	3D
12V4000G74F	50 Hz	3D	16V4000G74S	60 Hz	3D
12V4000G74S	60 Hz	3D	16V4000G74X	50/60 Hz	3D
12V4000G74X	50/60 Hz	3D	16V4000G84F	50 Hz	3D
12V4000G84F	50 Hz	3D	16V4000G84S	60 Hz	3D
12V4000G84S	60 Hz	3D	16V4000G84X	50/60 Hz	3D
12V4000G84X	50/60 Hz	3D	16V4000G94S	60 Hz	3D
12V4000G23F	50 Hz	3B, 3D, 3E, 3F, 3G	16V4000G23F	50 Hz	3B, 3D, 3E, 3F, 3G
12V4000G23RF	50 Hz	3B	16V4000G63F	50 Hz	3A, 3B, 3D, 3E, 3F, 3G
12V4000G63F	50 Hz	3A, 3B, 3D, 3E, 3F, 3G	16V4000G43S	60 Hz	3A, 3B, 3D, 3E, 3F, 3G
12V4000G43S	60 Hz	3A, 3B, 3D, 3E, 3F, 3G	16V4000G83S	60 Hz	3A, 3B, 3D, 3E, 3F, 3G
12V4000G83S	60 Hz	3A, 3B, 3D, 3E, 3F, 3G	16V4000G83LS	60 Hz	3D
* 3A Heavy duty, unrestricted, ICXN 3B Continuous service, variable load, ICXN 3D Emergency standby power, IFN			3E Emergency service, ICXN 3F Heavy duty for DCP, unrestricted, ICXN 3G Heavy duty, intermittent, ICXN		

Table 1: Applicability

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at:<http://www.mtu-solutions.com>