



Operating Instructions

Diesel engine

20V4000Bx4F

20V4000Bx4S

20V4000Gx3F

20V4000Gx3S

20V4000Gx3Lx

20V4000Gx4F

20V4000Gx4S

MS15039/06E



A Rolls-Royce
solution

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

California Proposition 65

This warning applies only to the State of California, USA, in compliance with Title 27 California Code of Regulations, Article 6, Clear and Reasonable Warnings.

 **WARNING:** Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel.

(→ www.P65warnings.ca.gov/diesel)

Table of Contents

1 Preface		6 Technical Data	
1.1 Preface	8	6.1 Product data 20V4000B24F, 20V4000B34F, 20V4000B24S, 20V4000B44S, application group 3A	61
1.2 Applicability	9	6.2 Product data 20V4000G14F, application group 3B	66
2 Safety		6.3 Product data 20V4000G14F, application group 3E	71
2.1 Important provisions for all products	10	6.4 Product data 20V4000G14F, application group 3F	76
2.2 Important requirements for Power Generation application products	11	6.5 Product data 20V4000G14F, application group 3G	81
2.3 Intended use of gendrive engines	13	6.6 Product data 20V4000G24F, application group 3B	86
2.4 Personnel and organizational requirements	14	6.7 Product data 20V4000G24F, application group 3E	91
2.5 Safety regulations for commissioning and operation	15	6.8 Product data 20V4000G24F, application group 3F	96
2.6 Safety regulations for assembly, maintenance, and repair work	17	6.9 Product data 20V4000G24F, application group 3G	101
2.7 Fire and environmental protection, indirect materials	21	6.10 Product data 20V4000G34F, application group 3B	106
2.8 Standards for warning messages in the text and highlighted information	24	6.11 Product data 20V4000G34F, application group 3E	111
3 Transport		6.12 Product data 20V4000G34F, application group 3F	116
3.1 Transport	25	6.13 Product data 20V4000G34F, application group 3G	121
3.2 Lifting specifications	26	6.14 Product data 20V4000G64F, application group 3D	126
3.3 Engine mounting transportation lock	27	6.15 Product data 20V4000G74F, application group 3D	130
3.4 Transport locking device for crankshaft	29	6.16 Product data 20V4000G14S, 20V4000G24S, 20V4000G44S, application group 3B	134
4 General Information		6.17 Product data 20V4000G84F, application group 3D	140
4.1 Engine side and cylinder designations	32	6.18 Product data 20V4000G14S, 20V4000G24S, 20V4000G44S, application 3E	144
4.2 Data acquisition and data transmission	33	6.19 Product data 20V4000G14S, 20V4000G24S, 20V4000G44S, application group 3F	148
5 Functional Description		6.20 Product data 20V4000G14S, 20V4000G24S, 20V4000G44S, application group 3G	154
5.1 Engine - Overview	34	6.21 Product data 20V4000G64S, 20V4000G74S, 20V4000G94S, application group 3D	160
5.2 Crankcase with oil pan	36	6.22 Product data 20V4000G23F, 20V4000G63F, 20V4000G63LF, 20V4000G43S, 20V4000G83S, 20V4000G83LS	166
5.3 Gear train	38	6.23 Firing order	168
5.4 Running gear	39	6.24 Engine - Main dimensions	169
5.5 Cylinder head with injector	41		
5.6 Valve gear	43		
5.7 Fuel system with Common-Rail injection	45		
5.8 Charge-air and exhaust system	47		
5.9 Lube oil system	49		
5.10 Cooling system	51		
5.11 Engine management and monitoring	53		
5.12 Sensors and actuators - Overview	56		

7	Operation			
7.1	Preparations for putting into operation after extended out-of-service periods (>3 months)	170	10.4.1	Valve protrusion - Measurement 242
7.2	Preparations for putting into operation after scheduled out-of-service-period	171	10.4.2	Valve gear - Lubrication 246
7.3	Starting the engine in manual mode (test run)	172	10.4.3	Valve clearance - Check and adjustment 247
7.4	Engine - Quick-start function	173	10.4.4	Cylinder head cover - Removal and installation 250
7.5	Re-starting the engine following an automatic safety shutdown	174	10.5	Injection Pump / HP Pump 251
7.6	Safety system - Override	175	10.5.1	HP fuel pump - Filling with engine oil 251
7.7	Emergency engine start (Override mode)	176	10.6	Injector 253
7.8	Operational monitoring	177	10.6.1	Injector - Replacement 253
7.9	Emission label - Check	178	10.6.2	Injector - Removal and installation 254
7.10	Engine - Stopping in manual mode (test run)	179	10.7	Fuel System 259
7.11	Engine - Emergency stop	181	10.7.1	Fuel system - Venting 259
7.12	After stopping the engine - Engine remains ready for operation	182	10.7.2	Fuel cooler - External contamination and leak-tightness check 261
7.13	After shutting down engine - Putting engine out of operation	183	10.7.3	Fuel cooler - Cleaning 262
7.14	Plant - Cleaning	184	10.8	Fuel Filter 264
8	Troubleshooting		10.8.1	Fuel filter - Replacement 264
8.1	Troubleshooting	186	10.8.2	Fuel prefilter - Pressure ratios 266
8.2	Fault messages of Engine Control Unit ECU9 for Series 4000, genset applications	189	10.8.3	Fuel prefilter - Draining 267
8.3	Fault conditions of the alarms 1801 to 1840	224	10.8.4	Fuel prefilter (non-switchable) - Draining 268
9	Maintenance		10.8.5	Fuel prefilter (switchable) - Draining 271
9.1	Maintenance task reference table [QL1]	227	10.8.6	Fuel prefilter (switchable) - Low pressure indicator check 274
10	Task Description		10.8.7	Fuel prefilter - Filter element replacement 275
10.1	Engine	229	10.8.8	Fuel prefilter (non-switchable) - Filter element replacement 276
10.1.1	Barring engine manually	229	10.8.9	Fuel prefilter (switchable) - Filter element replacement 278
10.1.2	Engine - Cranking on starting system	231	10.8.10	Fuel prefilter - Venting 281
10.1.3	Engine - Test run	232	10.9	Charge-Air Cooling 283
10.2	Cylinder Liner	233	10.9.1	Intercooler - Checking condensate drain for coolant leak and obstruction 283
10.2.1	Cylinder liner - Endoscopic inspection	233	10.10	Air Filter 284
10.2.2	Cylinder liner - Instructions and comments on endoscopic and visual examination	235	10.10.1	Air filter - Check 284
10.3	Crankcase Breather	237	10.10.2	Air filter - Replacement 285
10.3.1	Crankcase breather - Oil separator element replacement	237	10.10.3	Air filter - Removal and installation 286
10.3.2	Crankcase breather - Oil separator element replacement	239	10.11	Air Intake 287
10.3.3	Crankcase breather - Oil mist separator replacement	241	10.11.1	Contamination indicator - Signal ring position check 287
10.4	Valve Drive	242	10.12	Starting Equipment 288
			10.12.1	Air starter - Manual operation 288
			10.13	Lube Oil System, Lube Oil Circuit 289
			10.13.1	Engine oil - Change 289
			10.13.2	Engine oil - Level check 292
			10.13.3	Engine oil - Sample extraction and analysis 293
			10.13.4	Oil priming pump - Visual inspection 295
			10.14	Oil Filtration / Cooling 296
			10.14.1	Engine oil filter - Replacement 296
			10.14.2	Centrifugal oil filter - Cleaning and filter sleeve replacement 298

10.15	Coolant Circuit, General, High-Temperature Circuit	301	10.18	Storage	341
10.15.1	Engine coolant - Level check	301	10.18.1	Engine mounting - Checking resilient element	341
10.15.2	Engine coolant - Change	303	10.18.2	Engine mounting - Checking securing screws for firm seating	342
10.15.3	Engine coolant - Draining	304	10.18.3	Engine mount - Measuring height of rubber element	344
10.15.4	Engine coolant - Filling	306	10.18.4	Generator mounting - Check	345
10.15.5	Engine coolant pump - Relief bore check	309	10.18.5	Generator mounting - Securing screw firm seating check	346
10.15.6	Engine coolant - Sample extraction and analysis	310	10.18.6	Generator mount - Measuring height of rubber element	347
10.15.7	Preheater - Overview	312	10.19	Wiring (General) for Engine/Gearbox/Unit	348
10.15.8	Preheater - Function and leak check	313	10.19.1	Engine cabling - Check	348
10.15.9	Preheater - Overhaul	314	10.20	Accessories for (Electronic) Engine Governor / Control System	349
10.15.10	Preheater - Solenoid switch replacement	315	10.20.1	Engine governor and connectors - Cleaning	349
10.15.11	Preheater - Heating element and housing check	317	10.20.2	Engine Control Unit plug connections - Check	350
10.15.12	Preheater thermostats - Replacement	320	10.20.3	Engine governor ECU 9 - Removal and installation	351
10.15.13	Preheater - Replacement	323	10.20.4	Parameters for drift correction (CDC) - Resetting with DiaSys®	352
10.15.14	Preheater - Removal	324	11	Appendix A	
10.15.15	Preheater - Installation	325	11.1	Abbreviations	353
10.15.16	Coolant expansion tank - Valve cover replacement	326	11.2	Contact person/Service partner	357
10.16	Low-Temperature Circuit	328	12	Appendix B	
10.16.1	Charge-air coolant level - Check	328	12.1	Standard Tools and Special Tools	358
10.16.2	Charge-air coolant - Change	330	12.2	Index	367
10.16.3	Charge-air coolant - Draining	331			
10.16.4	Charge-air coolant - Filling	333			
10.16.5	Charge-air coolant pump - Relief bore check	336			
10.17	Battery-Charging Generator	337			
10.17.1	Battery-charging generator - Cleaning	337			
10.17.2	Drive belt - Condition check	338			
10.17.3	Battery-charging generator drive - Drive belt replacement	339			
10.17.4	Battery-charging generator - Drive belt tension adjustment	340			

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer Rolls-Royce Solutions.

1.2 Applicability

Engine model	Frequency	Application group *
20V4000B24F	50 Hz	3A
20V4000B34F	50 Hz	3A
20V4000G14F	50 Hz	3B, 3G, 3E, 3F
20V4000G24F	50 Hz	3B, 3G, 3E, 3F
20V4000G34F	50 Hz	3B, 3G, 3E, 3F
20V4000G64F	50 Hz	3D
20V4000G74F	50 Hz	3D
20V4000G84F	50 Hz	3D
20V4000B24S	60 Hz	3A
20V4000B44S	60 Hz	3A
20V4000G14S	60 Hz	3B, 3G, 3E, 3F
20V4000G24S	60 Hz	3B, 3G, 3E, 3F
20V4000G44S	60 Hz	3B, 3G, 3E, 3F
20V4000G64S	60 Hz	3D
20V4000G74S	60 Hz	3D
20V4000G94S	60 Hz	3D
20V4000G23F	50 Hz	3B, 3D, 3E, 3F, 3G
20V4000G63F	50 Hz	3A, 3B, 3D, 3E, 3F, 3G
20V4000G63LF	50 Hz	3A, 3B, 3D, 3E, 3F, 3G
20V4000G43S	60 Hz	3B, 3D, 3E, 3F, 3G
20V4000G83S	60 Hz	3A, 3B, 3D, 3E, 3F, 3G
20V4000G83LS	60 Hz	3A, 3B, 3D, 3E, 3F, 3G
* 3A Heavy duty, unrestricted, ICXN 3B Continuous service, variable load, ICXN 3D Emergency standby power, IFN 3E Emergency service, ICXN 3F Heavy duty for DCP, unrestricted, ICXN 3G Heavy duty, intermittent, ICXN		

Table 1: Applicability

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at: <http://www.mtu-solutions.com>