



Operating Instructions

Diesel Engine
8V4000Rx3x
12V4000Rx3x
16V4000Rx3x
20V4000Rx3x

MS15042/07E



A Rolls-Royce
solution

Engine model	kW/cyl.	Application group
8V4000R43	125 kW/cyl.	2A continuous operation, unrestricted
12V4000R43	125 kW/cyl.	2A continuous operation, unrestricted
16V4000R43	137.5 kW/cyl.	2A continuous operation, unrestricted
20V4000R43	135 kW/cyl.	2A continuous operation, unrestricted
20V4000R63	150 kW/cyl.	2A continuous operation, unrestricted
8V4000R43L	150 kW/cyl.	2A continuous operation, unrestricted
12V4000R43L	150 kW/cyl.	2A continuous operation, unrestricted
16V4000R43L	150 kW/cyl.	2A continuous operation, unrestricted
20V4000R43L	150 kW/cyl.	2A continuous operation, unrestricted
20V4000R63L	165 kW/cyl.	2A continuous operation, unrestricted
16V4000R43R	125 kW/cyl.	2A continuous operation, unrestricted
20V4000R63R	135 kW/cyl.	2A continuous operation, unrestricted
20V4000R53	157.5 kW/cyl.	2A continuous operation, unrestricted

Table 1: Applicability

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to §15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

Table of Contents

1 Preface		5.4 Firing order	59
1.1 Preface	6	5.5 Engine – Main dimensions	60
2 Safety		6 Operation	
2.1 Important provisions for all products	7	6.1 Preparations for putting into operation after extended out-of-service periods (>3 months)	61
2.2 Intended use of all products	8	6.2 Putting the engine into operation after scheduled out-of-service period	62
2.3 Functional safety, special information for rolling stock	9	6.3 Starting the engine in manual mode	63
2.4 Personnel and organizational requirements	10	6.4 Re-starting the engine following an automatic safety shutdown	64
2.5 Safety regulations for commissioning and operation	11	6.5 Stopping the engine in manual mode	65
2.6 Safety regulations for assembly, maintenance, and repair work	13	6.6 Preparations for extended out-of-service period	66
2.7 Fire and environmental protection, indirect materials	17	6.7 Plant – Check	67
2.8 Standards for warning messages in the text and highlighted information	20	6.8 Plant – Cleaning	68
3 Transport		7 Maintenance	
3.1 Transport	21	7.1 Maintenance task reference table [QL1] – 8V 12V 16V 20V4000R43x R53	70
3.2 Lifting specifications	22	7.2 Maintenance task reference table [QL1] – 20V4000R63x	72
3.3 Transport locking device for crankshaft	23	8 Troubleshooting	
4 General Information		8.1 Troubleshooting	74
4.1 Engine side and cylinder designations	26	8.2 Fault messages on PAU display	77
4.2 Data acquisition and data transmission	27	8.3 Fault messages	78
4.3 Engine layout – 8V	28	9 Task Description	
4.4 Engine overview – 12V 16V	29	9.1 Engine	116
4.5 Engine layout – 20V	31	9.1.1 Engine – Test run	116
4.6 Sensors, actuators and injectors – Overview – 8V	33	9.1.2 Cranking engine manually	117
4.7 Sensors, actuators and injectors – Overview – 12V	36	9.1.3 Cranking engine with starting system	118
4.8 Sensors, actuators and injectors – Overview – 16V	39	9.2 Cylinder Liner	119
4.9 Sensors, actuators and injectors – Overview – 20V	43	9.2.1 Cylinder liner – Endoscopic inspection	119
5 Technical Data		9.2.2 Cylinder liner – Instructions and comments on endoscopic and visual examination	121
5.1 Engine data 8V4000R43 8V4000R43L 12V4000R43 12V4000R43L	47	9.3 Crankcase Breather	123
5.2 Engine data 16V4000R43 16V4000R43L 16V4000R43R	51	9.3.1 Crankcase breather – Replacing filter element of oil separator (only for 20V engines)	123
5.3 Engine data 20V4000R43 20V4000R43L 20V4000R53 20V4000R63 20V4000R63L 20V4000R63R	55	9.3.2 Crankcase breather – Cleaning cyclone element (only for 8, 12 and 16V engines)	125
		9.4 Valve Drive	126
		9.4.1 Valve gear – Lubrication	126
		9.4.2 Valve clearance – Check and adjustment	127

9.4.3	Valve protrusion – Measurement	131	9.15	Coolant Circuit, General, High-Temperature Circuit	182
9.4.4	Cylinder head cover – Removal and installation	135	9.15.1	Engine coolant – Level check	182
9.5	Injection Pump / HP Pump	136	9.15.2	Engine coolant – Change	184
9.5.1	HP pump – Filling with engine oil	136	9.15.3	Engine coolant – Draining	185
9.6	Injector	139	9.15.4	Engine coolant – Filling	187
9.6.1	Injector – Replacement	139	9.15.5	Engine coolant filter – Replacement	190
9.6.2	Injector – Removal and installation (jacketed fuel system)	140	9.15.6	Engine coolant – Sample extraction and analysis	191
9.7	Fuel System	147	9.15.7	Engine coolant pump – Relief bore check	193
9.7.1	Fuel system – Venting	147	9.15.8	Coolant expansion tank – Valve cover (optional) replacement	194
9.8	Fuel Filter	149	9.16	Low-Temperature Circuit	196
9.8.1	Fuel filter – Replacement	149	9.16.1	Charge-air coolant level – Check	196
9.8.2	Additional fuel filter – Replacement	150	9.16.2	Charge-air coolant – Change	198
9.8.3	Fuel prefilter (optional) – Draining	151	9.16.3	Draining charge-air coolant – 8V	199
9.8.4	Fuel prefilter (optional) – Filter element replacement	152	9.16.4	Charge-air coolant – Draining - 12V/16V/20V	200
9.8.5	Fuel prefilter with internal electrical priming pump (optional) – Draining	154	9.16.5	Charge-air coolant – Filling	201
9.8.6	Fuel prefilter with internal electrical priming pump (optional) – Filter element replacement	155	9.16.6	Charge-air coolant pump – Relief bore check	204
9.9	Exhaust Turbocharger	157	9.17	Battery-Charging Generator (Optional)	205
9.9.1	Exhaust turbocharger – Turbine housing check – 8V	157	9.17.1	Battery-charging generator drive – Coupling condition check	205
9.9.2	Exhaust turbocharger – Turbine housing check – 12V 16V 20V	161	9.18	Storage	206
9.10	Charge-Air Cooling	165	9.18.1	Resilient mounts – Condition check	206
9.10.1	Intercooler – Checking condensate drain for coolant leakage and obstruction	165	9.18.2	Resilient mounts – Checking securing screws for firm seating	207
9.11	Air Filter (Optional)	166	9.18.3	Generator mounting (optional) – Checking securing screws for firm seating	208
9.11.1	Air filter element and dust bowl (option) – Cleaning	166	9.18.4	Resilient mounts – Measuring and adjusting buffer clearance	209
9.11.2	Air filter – Replacement	167	9.18.5	Resilient mounts – Measuring height of rubber element	211
9.11.3	Air filter element – Removal and installation (optional)	168	9.19	Coupling	212
9.12	Air Intake (Optional)	169	9.19.1	Steel-spring coupling (optional) – Check	212
9.12.1	Contamination indicator – Signal ring position check	169	9.19.2	Torsionally rigid diaphragm coupling (optional) – Condition check	213
9.13	Engine Oil System	170	9.20	Wiring (General) for Engine/Gearbox/Unit	214
9.13.1	Engine oil level – Check	170	9.20.1	Engine cabling – Check	214
9.13.2	Engine oil – Change	171	9.21	Accessories for (Electronic) Engine Governor / Control System	215
9.13.3	Engine oil – Sample extraction and analysis	173	9.21.1	Resetting CDC parameter and entering IIG with DiaSys®	215
9.13.4	Oil priming pump (optional) – Check	175	9.21.2	Engine governor and connectors – Cleaning	216
9.14	Oil Filtration / Cooling	176	9.21.3	Engine governor plug connections – Check	217
9.14.1	Engine oil filter (optional) – Replacement	176	10	Appendix A	
9.14.2	Oil indicator filter (optional) – Cleaning and check	177	10.1	Tightening specifications for screws, nuts and bolts	218
9.14.3	Centrifugal oil filter – Cleaning and filter sleeve replacement	180	10.2	List of abbreviations	231

10.3 Contact person/Service partner	234	11.2 Index	244
11 Appendix B			
11.1 Standard Tools and Special Tools	235		

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer Rolls-Royce Solutions.

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at:<http://www.mtu-solutions.com>

2.2 Intended use of all products

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/Rolls-Royce Solutions contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all safety and warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

2.3 Functional safety, special information for rolling stock

Consider those functions which are relevant to safety when planning and engineering the project

The user of the vehicle and its systems is responsible for assessing the risks involved in their usage. The vehicle manufacturer is responsible for defining safety objectives for the vehicle when planning to produce rolling stock.

Rolls-Royce Solutions has conducted a hazard & risk analysis for the diesel engine system in accordance with SIRF (Safety Directive for Rolling Stock, SIRF 400 provisions).

This hazard & risk analysis was based neither on a specific vehicle, nor any particular vehicle manufacturer.

The results are based on estimated parameters and are influenced by these to a large extent. These factors depend on the operating environment and the specific architecture of the vehicle concerned.

The following aspects having special relevance to matters of safety have been identified:

- The output signals from the Engine Control Unit (ECU) shall not be used for safety-relevant functions in the plant.
- The retarder function or dynamic brake on diesel-electric and hybrid vehicle systems shall not be used for safety-relevant braking operations due to the increased coolant flow rate this involves.
The vehicle manufacturer must draw up a suitable concept in cases where allowances are to be made for the dynamic brake or retarder.
- These diesel engines release very high levels of kinetic energy. The risk of flying parts cannot be fully avoided in accordance with a corresponding safety integrity level (SIL) by means of diesel engine design alone.

Note: Overspeed monitoring is implemented with Safety Integrity Level 1 (SIL1) when a SafeMon is used by preventing flying parts.

- It may prove necessary to realize the "Safe Engine Stop" (emergency shutdown) functionality based on a safety integrity level (SIL). Select a control device (e.g. emergency stop button) with a suitably low probability of failure.

The emergency shutdown function for the diesel engine is integrated in the Engine Control Unit (ECU). The vehicle manufacturer must therefore ensure that the emergency stop signal is applied throughout the system until the engine has reached a standstill.

An uninterruptible power supply may serve as an alternative. This requires prior consultation with the Rolls-Royce Solutions Application Engineering department responsible for the project.

- Any workplace (e.g. driver's cab) must be equipped with a control which allows some, or all functions of the traction system to be stopped safely in a hazardous situation.
- The emergency stop control must feature a clearly recognizable, easily visible and rapidly accessible actuator. The control unit shall stop the process as quickly as possible without incurring any additional risk.

Project-specific operational environment

The user, vehicle manufacturer or integrator is responsible for verifying these safety-relevant aspects when the diesel engine system is used in a project-specific operational environment and in a particular vehicle.

2.4 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.