



Operating Instructions

Diesel Engine
12V4000G34F
12V4000G94F
16V4000G34F
16V4000G94F

MS15060/06E

Engine model	Power	Frequency	Application group
12V4000G34F	146 kW/cyl.	50 Hz	3E, emergency service, ICXN
12V4000G34F	146 kW/cyl.	50 Hz	3F, mains backup mode, unlimited, ICXN
12V4000G94F	161 kW/cyl.	50 Hz	3D, emergency standby power, IFN
16V4000G34F	136 kW/cyl.	50 Hz	3E, emergency service, ICXN
16V4000G34F	136 kW/cyl.	50 Hz	3F, mains backup mode, unlimited, ICXN
16V4000G94F	149 kW/cyl.	50 Hz	3D, emergency standby power, IFN
Load factor:	$\leq 85\%$ (3D, 3E) $\leq 100\%$ (3F)		
Operating hours:	500 h per year or for the duration of an emergency (3D, 3E) No limit for operating hours (3F)		
Time between major overhauls:	8,000 h or 18 years (3D, 3E, 3F)		

Table 1: Applicability

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to §15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

California Proposition 65

This warning applies only to the State of California, USA, in compliance with Title 27 California Code of Regulations, Article 6, Clear and Reasonable Warnings.

 **WARNING:** Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel.

(→ www.P65warnings.ca.gov/diesel)

Table of Contents

1 Preface		6 Technical Data	
1.1 Preface	8	6.1 Product data 12V4000G34F	64
2 Safety		6.2 Product data 12V4000G94F	69
2.1 Important provisions for all products	9	6.3 Product data 16V4000G34F	73
2.2 Important requirements for Power Generation application products	10	6.4 Product data 16V4000G94F	78
2.3 Intended use of gendrive engines	12	6.5 Firing order	82
2.4 Personnel and organizational requirements	13	6.6 Engine - Main dimensions	83
2.5 Safety regulations for commissioning and operation	14	7 Operation	
2.6 Safety regulations for assembly, maintenance, and repair work	16	7.1 Preparations for putting into operation after extended out-of-service periods (>3 months)	84
2.7 Fire and environmental protection, indirect materials	20	7.2 Preparations for putting into operation after scheduled out-of-service-period	85
2.8 Standards for warning messages in the text and highlighted information	23	7.3 Starting the engine in manual mode (test run)	86
3 Transport		7.4 Engine - Quick-start function	87
3.1 Transport	24	7.5 Re-starting the engine following an automatic safety shutdown	88
3.2 Lifting specifications	25	7.6 Safety system - Override	89
3.3 Transport locking device for crankshaft	26	7.7 Operational monitoring	90
3.4 Engine mounting transportation lock	29	7.8 Emergency engine start (Override mode)	91
4 General Information		7.9 Stopping the engine in manual mode (test run)	92
4.1 Engine side and cylinder designations	31	7.10 Emergency engine stop	93
4.2 Data acquisition and data transmission	32	7.11 After stopping the engine - Engine remains ready for operation	94
5 Functional Description		7.12 After shutting down engine - Putting engine out of operation	95
5.1 Engine models 12/16V4000G34F and 12/16V4000G94F - Overview	33	7.13 Plant - Cleaning	96
5.2 Crankcase with oil pan	36	8 Troubleshooting	
5.3 Gear train	38	8.1 Troubleshooting	98
5.4 Running gear	39	8.2 Fault messages of the Engine Control Unit (ECU 9) for Series 4000 engines, application Genset	101
5.5 Cylinder head with injector	41	8.3 Fault conditions of the alarms 1801 to 1840	142
5.6 Valve gear	43	9 Maintenance	
5.7 Fuel system with Common Rail injection	45	9.1 Maintenance task reference table [QL1]	145
5.8 Charge-air and exhaust system	47	10 Task Description	
5.9 Lube oil system	49	10.1 Engine	147
5.10 Cooling system	51	10.1.1 Barring engine manually	147
5.11 Fuel cooler	54	10.1.2 Engine - Cranking on starting system	149
5.12 Engine management and monitoring	56	10.1.3 Engine - Test run	150
5.13 Sensors and actuators - Overview	59	10.2 Cylinder Liner	151

10.2.1	Cylinder liner - Endoscopic inspection	151	10.12.4	Oil priming pump - Visual inspection	214
10.2.2	Cylinder liner - Instructions and comments on endoscopic and visual examination	153	10.13	Oil Filtration / Cooling	215
10.3	Crankcase Breather	155	10.13.1	Engine oil filter - Replacement	215
10.3.1	Crankcase breather - Oil mist separator replacement	155	10.13.2	Centrifugal oil filter - Cleaning and filter sleeve replacement	217
10.3.2	Crankcase breather - Filter element replacement	156	10.14	Coolant Circuit, General, High-Temperature Circuit	220
10.4	Valve Drive	158	10.14.1	Engine coolant - Level check	220
10.4.1	Valve protrusion - Measurement	158	10.14.2	Engine coolant - Change	222
10.4.2	Valve gear - Lubrication	162	10.14.3	Engine coolant - Draining	223
10.4.3	Valve clearance - Check and adjustment	163	10.14.4	Engine coolant - Filling	225
10.4.4	Cylinder head cover - Removal and installation	167	10.14.5	Engine coolant pump - Relief bore check	229
10.5	Injection Pump / HP Pump	168	10.14.6	Engine coolant - Sample extraction and analysis	230
10.5.1	HP fuel pump - Filling with engine oil	168	10.14.7	Preheater - Overview	232
10.6	Injector	171	10.14.8	Preheater - Function and leak check	233
10.6.1	Injector - Replacement	171	10.14.9	Preheater - Overhaul	234
10.6.2	Injector - Removal and installation	172	10.14.10	Preheater - Heating element and housing check	235
10.7	Fuel System	178	10.14.11	Preheater - Solenoid switch replacement	238
10.7.1	Fuel system - Venting	178	10.14.12	Preheater thermostats - Replacement	240
10.7.2	Fuel cooler - Cleaning	180	10.14.13	Preheater - Replacement	243
10.7.3	Fuel cooler - External contamination and leak-tightness check	182	10.14.14	Preheater - Removal	244
10.8	Fuel Filter	183	10.14.15	Preheater - Installation	245
10.8.1	Fuel filter - Replacement	183	10.14.16	Coolant expansion tank - Valve cover replacement	246
10.8.2	Additional fuel filter - Replacement	185	10.15	Low-Temperature Circuit	248
10.8.3	Fuel prefilter - Pressure ratios	186	10.15.1	Charge-air coolant level - Check	248
10.8.4	Fuel prefilter - Draining	187	10.15.2	Charge-air coolant - Change	250
10.8.5	Fuel prefilter (switchable) - Draining	188	10.15.3	Charge-air coolant - Draining	251
10.8.6	Fuel prefilter (non-switchable) - Draining	191	10.15.4	Charge-air coolant - Filling	253
10.8.7	Fuel prefilter (switchable) - Low pressure indicator check	194	10.15.5	Charge-air coolant pump - Relief bore check	257
10.8.8	Fuel prefilter - Filter element replacement	195	10.16	Battery-Charging Generator	258
10.8.9	Fuel prefilter (switchable) - Filter element replacement	196	10.16.1	Battery-charging generator - Cleaning	258
10.8.10	Fuel prefilter (non-switchable) - Filter element replacement	199	10.16.2	Drive belt - Condition check	259
10.8.11	Fuel prefilter - Venting	201	10.16.3	Battery-charging generator - Drive belt tension adjustment	260
10.9	Charge-Air Cooling	203	10.16.4	Battery-charging generator drive - Drive belt replacement	261
10.9.1	Intercooler - Checking condensate drain for coolant leak and obstruction	203	10.17	Storage	262
10.10	Air Filter	204	10.17.1	Engine mounting - Checking resilient element	262
10.10.1	Air filter - Replacement	204	10.17.2	Engine mounting - Checking securing screws for firm seating	263
10.10.2	Air filter - Check	205	10.17.3	Engine mount - Measuring height of rubber element	265
10.10.3	Air filter - Removal and installation	206	10.17.4	Generator mounting - Check	266
10.11	Air Intake	207	10.17.5	Generator mounting - Securing screw firm seating check	267
10.11.1	Service indicator - Signal ring position check	207	10.17.6	Generator mount - Measuring height of rubber element	268
10.12	Lube Oil System, Lube Oil Circuit	208	10.18	Engine Governor	269
10.12.1	Engine oil - Change	208	10.18.1	Engine Control Unit ECU 9 - Removal and installation	269
10.12.2	Engine oil - Level check	211	10.18.2	Engine governor plug connections - Check	270
10.12.3	Engine oil - Sample extraction and analysis	212			

10.19	Wiring (General) for Engine/Gearbox/Unit	271	11.2	Conversion tables	278
10.19.1	Engine cabling - Check	271	11.3	Contact person/Service partner	282
10.20	Accessories for (Electronic) Engine Governor / Control System	272	12	Appendix B	
10.20.1	Engine governor and connectors - Cleaning	272	12.1	Standard Tools and Special Tools	283
10.20.2	Parameters for drift correction (CDC) - Resetting with DiaSys®	273	12.2	Index	292
11	Appendix A				
11.1	Abbreviations	274			

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer Rolls-Royce Solutions.

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at: <http://www.mtu-solutions.com>

2.2 Important requirements for Power Generation application products

Project-specific operational environment

During integration and use of the diesel engine, all currently valid and relevant standards and guidelines on safety and specified operation must be implemented and observed. This applies to persons responsible for:

- The installation of the engine
- The design of the engine-generator set
- The installation of the engine-generator set

The relevant standards are, in particular:

- DIN EN 1679-1
- EN ISO 8528-13

Residual hazards

In the event of a defect, the diesel engine can unexpectedly have insufficient or no drive power at all. We therefore recommend a redundant design of the engine-generator set system in safety-critical applications.

Protection against hot surfaces

Combustion engines and their auxiliary components have hot surfaces (e.g. exhaust system, exhaust turbochargers, exhaust aftertreatment system, engine oil system, cooling system), which can cause injury to persons who approach or touch them (danger of burns).

- In operation
- During the cooling-down phase after operation

The plant integrator and operator must assess, based on spatial or other plant conditions, whether the danger potential usually associated with the state of technology is exceeded, e.g.:

- Particularly narrow maintenance spaces
- Particularly exposed position of hot surfaces

In such cases, the plant integrator or operator must equip the plant with the necessary and suitable safety devices to reliably exclude the possibility of personal injury, e.g.:

- Heat shields
- Insulation

The operator must ensure that the plant is not operated without these protective devices. Operating and maintenance personnel must be informed about the danger of hot surfaces and the prohibition of operation without the protective devices.

Noise

Noise protection measures that comply with statutory requirements must be implemented by the plant integrator and operator.

Chemical resistance

Only use hoses, pipes, fittings, etc. that can tolerate the fluids and lubricants in accordance with the Fluids and Lubricants Specifications. Only use options that are resistant to the fluids and lubricants in accordance with the Fluids and Lubricants Specifications.

Electrical devices

The IP protection class of the electrical devices required by the manufacturer must be observed.

Hoses

For vibration decoupling, where possible only use hoses or rubber sleeves. Install devices in low-vibration areas and not on the engine. Hoses must be installed such that they do not chafe and are not under tension.