



Operating Instructions

Diesel engine
12V4000Rx4
16V4000Rx4

MS15072/06E

Engine model	kW/cyl.	Application group
12V4000R64	125 kW/cyl.	2A, Continuous operation, unrestricted
12V4000R84	150 kW/cyl.	2A, Continuous operation, unrestricted
16V4000R64	125 kW/cyl.	2A, Continuous operation, unrestricted
16V4000R74	137,5 kW/cyl.	2A, Continuous operation, unrestricted
16V4000R84	150 kW/cyl.	2A, Continuous operation, unrestricted

Table 1: Applicability

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

Table of Contents

1 Preface			
1.1 Preface	5	6.7 Plant – Check	53
		6.8 Plant – Cleaning	54
2 Safety		7 Maintenance	
2.1 Important provisions for all products	6	7.1 Maintenance task reference table [QL1]	55
2.2 Intended use of all products	7	8 Troubleshooting	
2.3 Functional safety, special information for rolling stock	8	8.1 Troubleshooting	57
2.4 Personnel and organizational requirements	9	8.2 Fault messages on PAU display	60
2.5 Safety regulations for commissioning and operation	10	8.3 Fault messages	61
2.6 Safety regulations for assembly, maintenance, and repair work	12	9 Task Description	
2.7 Fire and environmental protection, indirect materials	16	9.1 Engine	127
2.8 Standards for warning messages in the text and highlighted information	19	9.1.1 Engine – Test run	127
		9.1.2 Cranking engine manually	128
		9.1.3 Engine – Cranking on starting system	129
3 Transport		9.2 Cylinder Liner	130
3.1 Transport	20	9.2.1 Cylinder liner – Endoscopic inspection	130
3.2 Lifting specifications	21	9.2.2 Cylinder liner – Instructions and comments on endoscopic and visual examination	132
3.3 Transport locking device for crankshaft	24	9.3 Crankcase Breather	134
		9.3.1 Crankcase breather – Oil mist separator replacement	134
4 General Information		9.4 Valve Drive	135
4.1 Engine side and cylinder designations	27	9.4.1 Valve protrusion – Measurement	135
4.2 Data acquisition and data transmission	28	9.4.2 Valve gear – Lubrication	139
4.3 Engine – Overview	29	9.4.3 Valve clearance – Check and adjustment	140
4.4 Sensors, actuators, and injectors – Overview	33	9.4.4 Cylinder head cover – Removal and installation	143
5 Technical Data		9.5 Fuel System (High Pressure)	144
5.1 Product data 12/16V4000Rx4	39	9.5.1 HP pump – Filling with engine oil	144
5.2 Firing order	44	9.6 Injector	147
5.3 Engine – Main dimensions	45	9.6.1 Injector – Replacement	147
		9.6.2 Injector – Removal and installation	148
6 Operation		9.7 Fuel System	153
6.1 Preparations for putting into operation after extended out-of-service periods (>3 months)	47	9.7.1 Fuel system – Venting	153
6.2 Putting the engine into operation after scheduled out-of-service period	48	9.8 Fuel Filter	155
6.3 Starting the engine in manual mode	49	9.8.1 Fuel filter – Replacement	155
6.4 Re-starting the engine following an automatic safety shutdown	50	9.8.2 Additional fuel filter – Replacement	157
6.5 Stopping the engine in manual mode	51	9.8.3 Fuel prefilter with internal electrical priming pump (optional) – Draining	158
6.6 Preparations for extended out-of-service period	52	9.8.4 Fuel prefilter with internal electrical priming pump (optional) – Filter element replacement	159
		9.9 Exhaust Turbocharger	161
		9.9.1 Exhaust turbocharger – Turbine housing check	161

9.9.2 Exhaust turbocharger (LP) – Turbine housing check	162	9.17.5 Charge-air coolant pump – Relief bore check	240
9.9.3 Exhaust turbocharger (HP) – Turbine housing check	168	9.18 Battery-Charging Generator (Optional)	241
9.10 Air Filter (Optional)	173	9.18.1 Battery-charging generator drive – Coupling condition check	241
9.10.1 Air filter element and dust bowl (option) – Cleaning	173	9.19 Storage	242
9.10.2 Air filter – Replacement	174	9.19.1 Resilient mounts – Condition check	242
9.10.3 Air filter element – Removal and installation (optional)	175	9.19.2 Resilient mounts – Checking securing screws for firm seating	243
9.11 Air Intake (Optional)	176	9.19.3 Generator mounting – Checking firm seating of securing screws	244
9.11.1 Contamination indicator – Signal ring position check	176	9.19.4 Resilient mounts – Measuring and adjusting buffer clearance	245
9.12 Exhaust Gas Recirculation	177	9.19.5 Resilient mounts – Measuring height of rubber element	247
9.12.1 Exhaust flaps – Overview	177	9.20 Coupling	248
9.12.2 Exhaust flaps – Function test	179	9.20.1 Steel-spring coupling – Check	248
9.12.3 Exhaust flaps – Axial clearance check	183	9.20.2 Torsionally rigid diaphragm coupling – Condition check	249
9.12.4 Exhaust flaps – Checking articulated rod for wear	186	9.21 Wiring (General) for Engine/Gearbox/Unit	250
9.12.5 Exhaust flaps – Coupling rod replacement	187	9.21.1 Engine cabling – Check	250
9.13 Exhaust Gas Aftertreatment	191	9.22 Accessories for (Electronic) Engine Governor / Control System	251
9.13.1 DPF system – Removal	191	9.22.1 Resetting CDC parameter and entering IIG with DiaSys®	251
9.13.2 DPF element – Cleaning / replacement	196	9.22.2 Actuators – Visual inspection and test	252
9.13.3 DPF system – Installation	206	9.22.3 Diesel particulate filter – Reset with DiaSys®	254
9.14 Engine Oil System	211	9.22.4 Engine governor and connectors – Cleaning	255
9.14.1 Engine oil – Level check with oil dipstick	211	9.22.5 Engine governor plug connections – Check	256
9.14.2 Engine oil – Change	212	9.22.6 NOx sensor – Replacement	257
9.14.3 Engine oil – Sample extraction and analysis	214	9.22.7 Lambda sensor – Replacement	259
9.15 Oil Filtration / Cooling	216	9.23 Regeneration of Exhaust Gas Aftertreatment System	261
9.15.1 Engine oil filter – Replacement	216	9.23.1 Information on exhaust aftertreatment system	261
9.15.2 Centrifugal oil filter – Cleaning and filter sleeve replacement	217	9.23.2 Automatic regeneration	262
9.16 Coolant Circuit, General, High-Temperature Circuit	221	9.23.3 Stationary regeneration	263
9.16.1 Engine coolant level – Check	221	9.23.4 Preventive regeneration	264
9.16.2 Engine coolant – Change	222	10 Appendix A	
9.16.3 Engine coolant – Draining	223	10.1 Tightening specifications for screws, nuts and bolts	265
9.16.4 Engine coolant – Filling	226	10.2 List of abbreviations	279
9.16.5 Engine coolant – Sample extraction and analysis	228	10.3 Contact person/Service partner	282
9.16.6 Engine coolant pump – Relief bore check	230	11 Appendix B	
9.16.7 Coolant expansion tank – Valve cover (optional) replacement	231	11.1 Standard Tools and Special Tools	283
9.17 Low-Temperature Circuit	233	11.2 Index	296
9.17.1 Charge-air coolant level – Check	233		
9.17.2 Charge-air coolant – Change	234		
9.17.3 Charge-air coolant – Draining	235		
9.17.4 Charge-air coolant – Filling	238		

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer Rolls-Royce Solutions.

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at: <http://www.mtu-solutions.com>

2.2 Intended use of all products

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/Rolls-Royce Solutions contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all safety and warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

2.3 Functional safety, special information for rolling stock

Consider those functions which are relevant to safety when planning and engineering the project

The user of the vehicle and its systems is responsible for assessing the risks involved in their usage. The vehicle manufacturer is responsible for defining safety objectives for the vehicle when planning to produce rolling stock.

Rolls-Royce Solutions has conducted a hazard & risk analysis for the diesel engine system in accordance with SIRF (Safety Directive for Rolling Stock, SIRF 400 provisions).

This hazard & risk analysis was based neither on a specific vehicle, nor any particular vehicle manufacturer.

The results are based on estimated parameters and are influenced by these to a large extent. These factors depend on the operating environment and the specific architecture of the vehicle concerned.

The following aspects having special relevance to matters of safety have been identified:

- The output signals from the Engine Control Unit (ECU) shall not be used for safety-relevant functions in the plant.
- The retarder function or dynamic brake on diesel-electric and hybrid vehicle systems shall not be used for safety-relevant braking operations due to the increased coolant flow rate this involves.
The vehicle manufacturer must draw up a suitable concept in cases where allowances are to be made for the dynamic brake or retarder.
- These diesel engines release very high levels of kinetic energy. The risk of flying parts cannot be fully avoided in accordance with a corresponding safety integrity level (SIL) by means of diesel engine design alone.

Note: Overspeed monitoring is implemented with Safety Integrity Level 1 (SIL 1) when a SafeMon is used by preventing flying parts.

- It may prove necessary to realize the “Safe Engine Stop” (emergency shutdown) functionality based on a safety integrity level (SIL). Select a control device (e.g. emergency stop button) with a suitably low probability of failure.

The emergency shutdown function for the diesel engine is integrated in the Engine Control Unit (ECU). The vehicle manufacturer must therefore ensure that the emergency stop signal is applied throughout the system until the engine has reached a standstill.

An uninterruptible power supply may serve as an alternative. This requires prior consultation with the Rolls-Royce Solutions Application Engineering department responsible for the project.

- Any workplace (e.g. driver's cab) must be equipped with a control which allows some, or all functions of the traction system to be stopped safely in a hazardous situation.
- The emergency stop control must feature a clearly recognizable, easily visible and rapidly accessible actuator. The control unit shall stop the process as quickly as possible without incurring any additional risk.

Project-specific operational environment

The user, vehicle manufacturer or integrator is responsible for verifying these safety-relevant aspects when the diesel engine system is used in a project-specific operational environment and in a particular vehicle.

2.4 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.

2.5 Safety regulations for commissioning and operation

Safety regulations for commissioning

Install the product correctly and carry out acceptance in accordance with the manufacturer's specifications before commissioning the product. All necessary approvals must be granted by the relevant authorities and all requirements for commissioning must be fulfilled.

Whenever the product is subsequently put into operation ensure that:

- All personnel is clear of the danger zone surrounding moving parts of the machine.
Electrically-actuated linkages may be set in motion when the Engine Control Unit (governor) is switched on.
- All maintenance and repair work has been completed.
- All loose parts have been removed from rotating machine components.
- All protective devices are in place.
- All lines bearing media are ready for operation.
- The walkways in the operating room are unobstructed and safe.
- No persons wearing pacemakers or any other technical body aids are present.
- Adequate ventilation of the operating room is ensured for any operating status.
- In the first few hours of operation, the product emits gases as a result of smoldering e.g. lacquers or oil. These gases may be hazardous to health. Always wear respiratory protection in the operating room during this period.
- The exhaust system is leak-tight and the gases are vented to atmosphere.
- The product is free of any damage, this applies in particular to lines and cabling.
- All components are properly grounded. Ground separately by means of a grounding stake as necessary.
- The power supply (mains plug) is always freely accessible to facilitate disconnecting the device or system from the power supply at any time.
- Battery terminals, generator terminals or cables are protected against accidental contact.
- All connections have been correctly allocated e.g. +/- polarity, fuel line/reducing agent line, supply/return.

Immediately after putting the product into operation, make sure that all control and display instruments as well as the monitoring, signaling and alarm systems work properly.

Smoking is prohibited in the area of the product.

Safety regulations during operation

The operator must be familiar with the control and display elements.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be observed with regard to present operating status, violation of limit values and warning or alarm messages.

Malfunctions and emergency stop

Practice emergency procedures, especially emergency stopping, at regular intervals.

Take the following steps if any system malfunctions are detected or signaled by the system:

- Inform supervisor(s) in charge.
- Analyze the message.
- Respond by taking any necessary emergency action, e.g. emergency stop.

After a safety shutdown, the engine may only be started after the cause of the shutdown has been eliminated.

Contact Service if the root cause of the malfunction cannot be clearly identified.

Operation

Do not remain in the operating room when the product is running unless absolutely necessary. Keep your stay as short as possible.