

Operating Instructions

Diesel engine

12V/16V/20V4000E83

**Only for emergency engine-generator sets in nuclear power stations
as per IEEE 387 and KTA 3702**

Application group 3C - NPP Standby Power

MS15073/00E



Power. Passion. Partnership.

Engine model	kW/cyl.	Application group
12V4000E83	140 kW/cyl.	3C, NPP standby power, time-limited operation, ICXN
Load factor:	≤ 100%	
Operating hours:	500 h per year or for the duration of an emergency	
Note: Non-scheduled revision must be carried out in the event of:	- Malfunction - Safety shutdown earthquake - Operation beyond the admissible operating limits (operation beyond design base)	
Load profile:	Continuous power as per IEEE 387 and ISO 8528-1	
Time between major overhauls:	9,000 h or 18 years (whatever applies first)	

Table 1: Applicability

Table of Contents

1 Safety		6 Maintenance	
1.1 Important provisions for all products	5	6.1 Maintenance task reference table [QL1]	51
1.2 Correct use of all products	7	7 Troubleshooting	
1.3 Personnel and organizational requirements	8	7.1 Troubleshooting	52
1.4 Safety regulations for initial start-up and operation	9	8 Task Description	
1.5 Safety regulations for assembly, maintenance, and repair work	11	8.1 Engine	55
1.6 Fire and environmental protection, fluids and lubricants	15	8.1.1 Engine - Barrage manually	55
1.7 Standards for warning notices in the text and highlighted information	18	8.1.2 Engine - Turning on starting system	57
2 Transport		8.1.3 Engine - Test run	58
2.1 Transport	19	8.2 Cylinder Liner	59
2.2 Lifting instructions	20	8.2.1 Cylinder liner - Endoscopic inspection	59
2.3 Crankshaft transport locking device	24	8.2.2 Cylinder liner - Instructions and comments on endoscopic and visual examination	61
3 General Information		8.3 Crankcase Breather	63
3.1 Engine side and cylinder designations	27	8.3.1 Crankcase breather - Oil separator element replacement	63
3.2 Engine - Overview	28	8.4 Valve Drive	65
3.3 Sensors and actuators - Overview	30	8.4.1 Valve protrusion - Measurement	65
3.4 Engine governor	34	8.4.2 Valve gear - Lubrication	69
4 Technical Data		8.4.3 Valve clearance - Check and adjustment	70
4.1 Product data 12V4000E83	35	8.4.4 Cylinder head cover - Removal and installation	74
4.2 Firing order	38	8.5 Injection Pump / HP Pump	75
4.3 Engine - Main dimensions	39	8.5.1 HP fuel pump - Filling with engine oil	75
5 Operation		8.6 Injector	78
5.1 Putting the engine into operation after extended out-of-service periods (>3 months)	40	8.6.1 Injector - Replacement	78
5.2 Putting the engine into operation after scheduled out-of-service-period	41	8.6.2 Injector - Removal and installation (jacketed fuel system)	79
5.3 Starting the engine in manual mode (test run)	42	8.7 Fuel System	86
5.4 Re-starting the engine following an automatic safety shutdown	43	8.7.1 Fuel system - Venting	86
5.5 Emergency engine start (Override mode)	44	8.8 Fuel Filter	88
5.6 Operational monitoring	45	8.8.1 Fuel filter - Replacement	88
5.7 Engine - Stopping in Manual mode (test run)	46	8.9 Exhaust Turbocharger	90
5.8 Emergency engine stop	48	8.9.1 Exhaust turbocharger - Turbine housing check	90
5.9 After stopping the engine - Putting the engine out of operation	49	8.10 Charge-Air Cooling	95
5.10 Plant - Cleaning	50	8.10.1 Intercooler - Checking condensate drain for coolant leakage and obstruction	95
		8.11 Air Filter	96
		8.11.1 Air filter - Replacement	96
		8.11.2 Air filter - Removal and installation	97
		8.12 Air Intake	98

8.12.1 Contamination indicator - Signal ring position check	98	8.17.3 Charge-air coolant - Draining	121
		8.17.4 Charge-air coolant - Filling	123
8.13 Starting Equipment	99	8.17.5 Charge-air coolant pump - Relief bore check	126
8.13.1 Air starter - Manual operation	99	8.18 Engine Mounting / Support	127
8.14 Lube Oil System, Lube Oil Circuit	100	8.18.1 Engine mounting - Checking resilient element	127
8.14.1 Engine oil level - Check	100	8.18.2 Engine mounting - Checking securing screws for firm seating	128
8.14.2 Engine oil - Change	101	8.19 Wiring (General) for Engine/Gearbox/Unit	129
8.14.3 Engine oil - Sampling and analysis	103	8.19.1 Engine cabling - Check	129
8.15 Oil Filtration / Cooling	104	8.20 Accessories for (Electronic) Engine Governor / Control System	130
8.15.1 Oil indicator filter - Cleaning and check	104	8.20.1 Engine governor plug connections - Check	130
8.15.2 Centrifugal oil filter - Cleaning and filter sleeve replacement	106	8.20.2 Engine governor and connector - Cleaning	131
8.16 Coolant Circuit, General, High-Temperature Circuit	109	9 Appendix A	
8.16.1 Engine coolant - Level check	109	9.1 Abbreviations	132
8.16.2 Engine coolant - Change	111	9.2 MTU Contact/Service Partners	135
8.16.3 Draining engine coolant	112	10 Appendix B	
8.16.4 Engine coolant - Filling	114	10.1 Special Tools	136
8.16.5 Engine coolant pump - Relief bore check	117	10.2 Index	145
8.17 Low-Temperature Circuit	118		
8.17.1 Charge-air coolant level - Check	118		
8.17.2 Charge-air coolant - Change	120		

1 Safety

1.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by MTU come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emission specifications and emission label

Responsibility for compliance with emission regulations

Modification or removal of any mechanical/electronic components or the installation of additional components including the execution of calibration processes that might affect the emission characteristics of the product are prohibited by emission regulations. Emission-related components must only be serviced, exchanged or repaired if the components used for this purpose are approved by the manufacturer.

Noncompliance with these specifications will invalidate the design type approval or certification issued by the emissions regulation authorities. The manufacturer does not accept any liability for violations of the emission regulations.

The product must be operated over its entire life cycle according to the conditions defined as "Intended use" (→ Page 7).

Emission certification applicable to engines with EPA Nonroad Tier 4 emission certification in accordance with 40 CFR 1039 and with EPA Locomotive emission certification in accordance with 40 CFR 1033

Extract from the standard:

Failing to follow these instructions when installing a certified engine in a piece of nonroad equipment violates federal law (40 CFR 1068.105(b)), subject to fines or other penalties as described in the Clean Air Act.

Extract from the standard:

If you install the engine in a way that makes the engine's emission control information label hard to read during normal engine maintenance, you must place a duplicate label on the equipment, as described in 40 CFR 1068.105.

When fitting the second label, the requirements of 40 CFR 1068.105(c) must be followed and observed. This paragraph describes the process for requesting and fitting the label, the documentation obligations and storage obligations for the required documents.

Replacing components with emission labels

On all MTU engines fitted with emission labels, these labels must remain on the engine throughout its operational life.

Exception: Engines used exclusively in land-based, military applications other than by US government agencies.

Please note the following when replacing components with emission labels:

- The relevant emission labels must be affixed to the spare part.
- Emission labels shall not be transferred from the replaced part to the spare part.
- The emission labels must be removed from the replaced part and destroyed.

1.2 Correct use of all products

Correct use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/MTU contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found on the websites:

- For drive systems: <http://www.mtu-online.com>
- For power generation: <http://www.mtuonsiteenergy.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

1.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.

1.4 Safety regulations for initial start-up and operation

Safety regulations for initial start-up

Install the product correctly and carry out acceptance in accordance with the manufacturer's specifications before putting the product into service. All necessary approvals must be granted by the relevant authorities and all requirements for initial startup must be fulfilled.

Whenever the product is subsequently taken into operation ensure that:

- All personnel is clear of the danger zone surrounding moving parts of the machine.
Electrically-actuated linkages may be set in motion when the Engine Control Unit (governor) is switched on.
- All maintenance and repair work has been completed.
- All loose parts have been removed from rotating machine components.
- All safeguards are in place.
- All components must be properly grounded. Ground separately by means of a grounding stake as necessary.
- No persons wearing pacemakers or any other technical body aids are present.
- Adequate ventilation of the operating room must be ensured for any operating status.
- In the first few hours of operation, the product emits gases as a result of smoldering e.g. lacquers or oil. These gases may be hazardous to health. Always wear respiratory protection in the operating room during this period.
- The exhaust system is leak-tight and that the gases are vented to atmosphere.
- The product must be free of any damage, this applies in particular to lines and cabling.
- Protect battery terminals, generator terminals or cables against accidental contact.
- Check that all connections have been correctly allocated e.g. +/- polarity, fuel line/reduction agent line, supply/return.

Immediately after putting the product into operation, make sure that all control and display instruments as well as the monitoring, signaling and alarm systems work properly.

Smoking is prohibited in the area of the product.

Safety regulations during operation

The operator must be familiar with the control and display elements.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be permanently observed with regard to present operating status, violation of limit values and warning or alarm messages.

Malfunctions and emergency stop

Practice emergency procedures, especially emergency stopping, at regular intervals.

Take the following steps if any system malfunctions are detected or signaled by the system:

- Inform supervisor(s) in charge.
- Analyze the message.
- Respond by taking any necessary emergency action, e.g. emergency stop.

After a safety shutdown, the engine must only be started after the cause of the shutdown has been eliminated.

Contact Service if the root cause of the malfunction cannot be clearly identified.

Operation

Do not remain in the operating room when the product is running unless absolutely necessary. Keep your stay as short as possible.

Keep a safe distance away from the product if possible. Do not touch the product unless expressly instructed to do so following a written procedure.

Do not inhale the exhaust gases of the product.

The following requirements must be fulfilled before the product is started:

- Wear ear protectors.
- Mop up any leaked or spilled fluids and lubricants immediately or soak up with a suitable binding agent.

Operation of electrical equipment

When electrical equipment is in operation, certain components of these appliances are electrically live.

Follow the applicable operating and safety instructions when operating the devices and heed warnings at all times.