

Operation and Maintenance Manual

Electric Drilling Package 60 Hz with
MTU Series 4000 12V4000G73
PEDPG12V4000-2A0
Oil & Gas

SS180000/03E



Power. Passion. Partnership.

System designation	Engine model	Hz	Application group
PEDPG 12V4000-2A0	12V4000G73	60	3B Continuous Operation – Variable load

Table 1: Applicability

Preface

This Operation & Maintenance Manual provides general instructions for operating your MTU engine-generator set properly. It is essential that every person who works on or with the engine-generator set be completely familiar with the contents of this manual and that he/she carefully follows the instructions contained herein.

Each operation and maintenance may require some modification of the suggested guidelines in this manual. They must be consistent with locally applicable standards and take into consideration safety guidelines and measures.

Following this guide will result in an efficient and reliable installation.

Carefully follow all procedures and safety precautions to ensure proper equipment operation and to avoid bodily injury. Read and follow the Safety Precautions section at the beginning of this manual.

All instructions and diagrams have been checked for accuracy and simplicity of application, however, the skills of the operator are most important. MTU does not guarantee the result of any operation contained in this manual nor can MTU assume responsibility for any injury or damage to property. Persons engaging in operating do so entirely at their own risk.

Table of Contents

1	Safety		2.8.8	Interface J1939	83
1.1	General Service Safety	7	2.9	Electrical System	98
1.2	Use of MTU Technical Documentation	9	2.9.1	Starter batteries	98
1.3	MTU Engine Safety Section	10	2.10	Base and Mounting System	100
1.4	MTU General Shop Safety Section	12	2.10.1	Base and mounting system	100
1.5	MTU System Safety Section	16			
1.6	Engine-Generator Set - Lockout/Tagout and Unlocking Procedures	18	3	Operating Instructions	
1.6.1	Lockout/tagout procedure	18	3.1	Basic Operations	101
1.6.2	Unlocking procedure	20	3.1.1	Putting the engine-generator set into operation after extended out-of-service-periods (>3 months)	101
2	Overview		3.1.2	Putting the engine-generator set into operation after scheduled out-of-service-period	102
2.1	Engine-Generator Set	22	3.1.3	Start engine-generator set locally	103
2.1.1	Electrical drilling package with MTU 12 V 4000 G73 engine	22	3.1.4	Operational checks	104
2.1.2	Electrical drilling package with MTU 12 V 4000 G73 engine - Overall Dimensions	26	3.1.5	Stop engine-generator set locally	105
2.1.3	Remote package	27	3.1.6	Emergency stop	106
2.1.4	Remote package - Overall Dimensions	31	3.1.7	After stopping the engine - engine remains ready for operation	107
2.2	Engine	32	3.1.8	After stopping the engine - Putting the engine out of operation	108
2.2.1	Series 4000 G73 engine	32	3.2	Troubleshooting	109
2.2.2	Sensors, actuators, and injectors - Overview	34	3.2.1	Troubleshooting	109
2.3	Generator	38	3.2.2	Fault indication	112
2.3.1	Generator - General information	38	3.2.3	Fault message - Service and Automation Module (SAM)	144
2.4	Air System	43	3.3	Engine	149
2.4.1	Air system	43	3.3.1	Engine - Barring manually	149
2.4.2	Heavy-duty air filter	45	3.3.2	Engine - Turning on starting system	151
2.5	Cooling System	48	3.3.3	Cylinder liner - Endoscopic examination	152
2.5.1	Cooling system for engine-generator set with 12 V 4000 G73 engine	48	3.3.4	Cylinder liner - Instructions and comments on endoscopic and visual examination	153
2.5.2	Engine driven radiator	51	3.3.5	Crankcase breather - Oil separator replacement, diaphragm check and replacement	155
2.5.3	Remote radiator	53	3.3.6	Valve gear - Lubrication	157
2.5.4	Jacket water heater	55	3.3.7	Valve clearance - Check and adjustment	158
2.6	Exhaust System	57	3.3.8	Cylinder head cover - Removal and installation	160
2.6.1	Exhaust system	57	3.3.9	HP fuel pump - Filling with engine oil	161
2.6.2	Industrial Grade Exhaust Silencer (standard)	59	3.3.10	Injector - Replacement	163
2.6.3	Critical Slim Line Exhaust Silencer (optional)	60	3.3.11	Injector - Removal and installation (jacketed fuel system)	164
2.7	Fuel System	61	3.3.12	Fuel system - Venting	170
2.7.1	Fuel system with common-rail injection	61	3.3.13	Fuel filter - Replacement	171
2.7.2	Dual fuel/water separator	64	3.3.14	Charge-air cooler - Check water drain for coolant leakage and obstruction	172
2.8	Engine Control System	66	3.3.15	Heavy duty air filter - Replacement	173
2.8.1	Engine Control Unit ECU 7 (ADEC)	66	3.3.16	Heavy-duty air filter - Removal and installation	174
2.8.2	Engine Monitoring Unit EMU 7	67	3.3.17	Vacuator valve - Check and clean	175
2.8.3	Service and Automation Module SAM	68			
2.8.4	Engine governor	70			
2.8.5	ADEC - Description	72			
2.8.6	EMU 7 - Technical data	79			
2.8.7	SAM - Technical data	80			

3.3.18	Contamination indicator - Signal ring position check	176	3.6	Jacket Water Heater	231
3.3.19	Rubber sleeves between air intake elbow and turbocharger - Replacement	177	3.6.1	Jacket water heater control box - Wiring check	231
3.3.20	Emergency air-shutoff flaps - Electric control check	178	3.6.2	Jacket water heating element - Wiring check	232
3.3.21	Emergency air shut-off flaps - Lubrication	179	3.6.3	Jacket water heating element and tank - Check	233
3.3.22	Rubber sleeves in air pipework before intercooler - Replacement	180	3.7	Exhaust System	235
3.3.23	Air starter - Manual operation	181	3.7.1	Rain cap - Visually check	235
3.3.24	Engine oil level - Check	182	3.8	Fuel Filter	236
3.3.25	Engine oil - Change	183	3.8.1	Dual or triple fuel/water separator - Differential pressure check	236
3.3.26	Engine oil - Sample extraction and analysis	185	3.8.2	Dual or triple fuel/water separator - Draining	237
3.3.27	Engine oil filter - Replacement	187	3.8.3	Dual or triple fuel/water separator - Filter element replacement	238
3.3.28	Centrifugal oil filter - Cleaning and filter sleeve replacement	188	3.9	Engine Control System	239
3.3.29	Engine coolant - Level check	191	3.9.1	LOP Dampers - visual inspection	239
3.3.30	Engine coolant - Change	193	3.9.2	Engine Control Unit - Self-test	240
3.3.31	Engine coolant - Draining	194	3.9.3	Parametrization with dialog unit	241
3.3.32	Engine coolant - Filling	196	3.9.4	SAM minidialog	243
3.3.33	Engine coolant pump - Relief bore check	199	3.9.5	SAM parameters - Overview	247
3.3.34	Engine coolant - Sample extraction and analysis	200	3.9.6	Engine control unit - Web feature	259
3.3.35	Engine coolant filter - Replacement	202	3.9.7	SAM - Replacement	261
3.3.36	Charge-air coolant - Level check	203	3.9.8	SAM fuse - Replacement	262
3.3.37	Charge-air coolant - Change	204	3.9.9	CF-card - Replacement	263
3.3.38	Charge-air coolant - Draining	205	3.10	Electrical System	264
3.3.39	Charge-air coolant - Filling	207	3.10.1	Battery Charge State, Electrolyte Specific Gravity and Level Checks	264
3.3.40	Charge-air coolant pump - Relief bore check	210	3.11	Coupling	265
3.3.41	Drive belt - Condition check	211	3.11.1	Coupling condition check	265
3.3.42	Battery-charging generator - Check	212	4	Maintenance	
3.3.43	Battery-charging generator - Drive belt tension adjustment	213	4.1	Preface	266
3.3.44	Battery-charging generator - Drive belt and belt tensioner replacement	214	4.2	Maintenance schedule matrix	268
3.3.45	Engine cabling - Check	215	4.3	Maintenance tasks	274
3.3.46	Engine governor and connector - Cleaning	216	5	Manufacturer's Documentation	
3.3.47	EMU and connectors - Cleaning	217	5.1	MURPHY - Display Operation Manual	279
3.3.48	Engine governor plug connections - Check	218	5.2	Isolated Current Converter	317
3.3.49	EMU - Checking plug-in connections	219	6	Appendix A	
3.3.50	Engine governor ECU 7 - Removal and installation	220	6.1	List of abbreviations	319
3.4	Generator	221	6.2	Conversion tables	322
3.4.1	Generator - Check	221	7	Appendix B	
3.4.2	Generator - Cleaning electric components	222	7.1	Special Tools	326
3.4.3	Generator - Cleaning inside outlet box	223			
3.5	Radiator	224			
3.5.1	Electric fan drive motor bearings - Regrease	224			
3.5.2	Fan belt - Temperature check	225			
3.5.3	Pillow block bearings - Regrease	226			
3.5.4	Fan guard - Check	227			
3.5.5	Drive belt - Condition check	228			
3.5.6	Fan drive - Drive belt tension check / adjustment	229			

1 Safety

1.1 General Service Safety

Contact Authorized Service for Additional Help

If you have any questions about a procedure or safety message related to servicing this engine, contact an authorized service outlet for assistance. Repair or engine overhaul must be carried out in an MTU authorized workshop.

Trained and Authorized Personnel Only

Maintenance and repair work is to be carried out by trained and authorized personnel only. Do not allow unauthorized personnel on or near the engine when the engine is serviced. Work on or around this engine must be performed by people who have the necessary training, skills, and tools to do the work. Improper maintenance or repair work can cause severe injury or death for yourself or bystanders.

Using this Manual

Read and understand this safety section before working on this product. This section contains general safety messages. Additional safety messages are included in the specific task procedures.

Signal Words Used in this Manual

Failure to follow the signal words and safety alert symbols contained in this manual can result in serious injury or death. Important safety information is distinguished in this manual by the following notations:

DANGER 	In the event of immediate danger. Consequences: Death or serious injury • Remedial action
WARNING 	In the event of potentially dangerous situations. Consequences: Death or serious injury • Remedial action
CAUTION 	In the event of hazardous situations. Consequences: Minor or moderate injuries • Remedial action
NOTICE 	In the event of a situation involving potentially adverse effects on the product. Consequences: Material damage! • Remedial action. • Additional product information.

Consider the Safety of Procedures You Choose

The manufacturer cannot anticipate every possible circumstance that might involve a potential hazard. If a tool, procedure, work method, or operating technique that is not specifically recommended by the manufacturer is used, you must consider possible hazards and take responsibility to ensure that it is safe for you and for others. Ensure the product will not be damaged or made unsafe by the transport, installation, commissioning, operation, lubrication, maintenance, repair, or storage procedures that you choose.

Hazardous Environment Operation

MTU equipment is not approved for hazardous environment operation. It is the responsibility of the operator to ensure the engine-system is not operated in a hazardous environment. A hazardous environment is defined as a mixture of volatile substances with air, in the form of gases, vapors, mist, or dust in which, ignition can occur.

ATEX in the EU and OSHA in the U.S., define and classifies hazardous environments.

Use Genuine Parts and Do Not Make Unauthorized Modifications

Unauthorized modifications, third-party add-on devices, and replacement parts may compromise the integrity of the equipment, and may present a safety risk. Only genuine MTU parts are allowed to be used to replace components or assemblies. Failure to heed this warning can lead to product damage, serious injury, or death and may cause non-compliance with environmental regulations.

Follow Applicable Standards and Regulations

MTU recommends owners, operators, and certified technicians become familiar with applicable national safety standards. To reduce the risk of severe injury or death, follow all codes, standards, regulations, and laws pertaining to the products installation and application.

Maintain Product Labels

Safety labels should be legible and not covered. If any safety labels are damaged, missing, or illegible, contact an MTU-authorized distributor or dealer to obtain replacement labels.

1.2 Use of MTU Technical Documentation

Access to MTU technical documentation is restricted, due to the highly technical nature of the information. Maintenance and workshop documentation is structured based on Qualification Levels (QLs). Personnel are to be qualified at the appropriate level to carry out specific tasks. The QLs are matched to MTU training courses and a demonstrated proficiency related to various tool kits.

QL1 - Operational monitoring and maintenance tasks that can be done during breaks in operation, and do not require disassembly of the system, engine or any components.

QL2 - Maintenance procedures requiring the exchange of assemblies.

QL3 - Maintenance procedures requiring overhaul of assemblies.

Do not use MTU Technical Documentation or attempt to perform the activities described in this manual if you have not been properly qualified by an MTU-authorized distributor for this QL level.

The information, specifications and illustrations in this manual are based upon information available at the time it was written. The information, specifications and illustrations can change at any time. These changes can affect the service given to the product. Obtain the complete and most current information before you start any work on the system, engine or any components.

If you did not receive this manual through MTU, stop all work and contact MTU to make sure you have the appropriate training and qualifications to follow the procedures within.

Keep this Manual near Engine for Personnel [QL1]

This publication must be provided to all MTU-certified personnel involved in any work being done on the engine and a copy must be located in the vicinity of the engine, accessible at all times.

General Responsibilities of Owners and Operators and MTU Technicians [QL1]

Owner and operator responsibilities

In preparation for service of an engine, owners and operators must:

- Keep unauthorized personnel clear of engine service areas.
- Provide a clear path for transport of the engine.
- Provide a service area for the engine.
- Provide proper equipment to transport the engine.
- Provide that lifting and handling of heavy objects are performed or supervised by personnel knowledgeable with lifting procedures.
- Provide certified forklift and crane operators.
- Provide proper tools for working on an engine that are properly maintained and calibrated.
- Provide necessary add-on heat generating devices, such as a fuel heater.
- Make sure that servicing of batteries is performed or supervised by personnel knowledgeable with batteries and required battery service procedures.

1.3 MTU Engine Safety Section

Preparing to Service Engine

Shut off equipment

You could be seriously injured or killed when working on running equipment. A release or spill of coolant, oil, fuel or hydraulic fluid while the engine is running can cause a fire or explosion. Do not fill coolant or fuel tanks while the engine is running. To reduce the risk of exposure to compressed air, fluids or moving parts, never carry out maintenance and repair work with the engine running and:

- Make sure that nobody is standing in the path of moving parts before barring over or starting the engine.
- Use care when working around moving belts and rotating parts.
- Remove safety guards only to complete service procedures that can only be completed with the guard removed and replace safety guards as soon as possible once the service is completed. Do not crank or start the engine with the safety guards removed unless specifically required in the procedure.

The engine may need to be running for some types of diagnostic activities.

Let engine and exhaust cool down

All exhaust components are hot when the engine is running and remain hot for an extended period after the engine is shut off. Other components and fluids are hot when the engine is running and remain hot for an extended period after the engine is shut off. Allow all components and fluids to cool before working on or near the unit, or use proper precautions to reduce the risk of being burned.

Engine placement [QL3]

When placing an engine in an area to be serviced, remember the following to reduce your risk of injury or death:

- Place the engine on a firm, flat and stable surface capable of supporting the units weight. Unless authorized by an MTU dealer or distributor, never set an engine down on the oil pan.
- Before servicing anything raised by hydraulics, make sure that it is mechanically supported by stands, blocks or a mechanical lock. Never rely on a hydraulic circuit alone when working underneath raised equipment.

Safe Engine Servicing

Following safe work practices can help reduce the risk of serious injury or death to yourself or bystanders when servicing an engine.

Use proper emergency shutdown procedures

If you have an emergency shutdown situation, use the hot shutdown procedure. You may damage the engine. Each emergency situation is unique. Follow the restart procedures in the manual.

Use lockout and tagout procedures

To reduce the risk of severe injury or death from electric shock or unintentional startup, disconnect all electrical power sources and batteries. Additionally, lockout and tagout the equipment before removing protective shields for service or maintenance. Do not remove a lockout tag unless proper authorization is obtained.

Provide proper ventilation

Do not operate this engine in an area where combustible chemicals or vapors may be present. Combustible vapors near the air intake system could be ingested into the engine, causing the engine to suddenly accelerate and overspeed or explode. This condition could cause an unexpected increase in engine rpm or fire. When changing the engine oil or working on the fuel system, make sure that the service area is properly ventilated.

Avoid carbon monoxide poisoning

All engine exhaust contains carbon monoxide, a deadly gas. Breathing carbon monoxide can cause headaches, dizziness, nausea, confusion and eventually death.