

# SPARE PART CATALOG



*Power. Passion. Partnership.*



Printed in Germany

© 2013 Copyright MTU Friedrichshafen GmbH

This Publication is protected by copyright and may not be used in any way whether in whole or in part without the prior written permission of MTU Friedrichshafen GmbH. This restriction also applies to copyright, distribution, translation, microfilming and storage or processing on electronic systems including data bases and online services.

This handbook is provided for use by maintenance and operating personnel in order to avoid malfunctions or damage during operation.

Subject to alterations and amendments **Business Portal Online Print 21-09-2017**

## Preface

This catalog is the basic reference document for ordering spare parts. Illustrations are provided for extensive assembly operations to assist trained personal in conducting such operations but do not claim to be complete. For better overview, even product components that are not available as spare parts are shown.

The individual components were taken from the assembly list.

## Catalog structure

The catalog is divided into Function Groups (FG) and Function Group Segments (FGS) in ascending order.

The side contain the following information:

- **MODEL:** (Product Type)
- **SERIAL NO.:**
- **FG/FGS DESIGNATION**
- **FG/FGS NO.:**
- **BOM No.:**

## Explanation of columns

- **ITEM:** Provides a cross-reference between illustration and text section.
- **PART NO.:** This is the valid number for ordering the part in question.
- **DESIGNATION:** The precise part name.
- **MODEL/TYPE** is an additional specification.
- **QTY.: (Quantity in Unit):** Indicates the quantity of this part required for the case in question. Quantities not stated are available on request.
- **UNIT:** The 3-character codes indicate: PC = Piece, KG= Kilogram, M= Meter, ROL= Roll, PAC= Pack
- **WEIGHT**
- **FN.:** (Footnote) Provides additional parts information. For clarification of footnote symbols, see Page 2.
- **DIMENSIONS:** This column contains standard-part dimensions or manufacturer designations for purchased parts.
- **STANDARD**

## Amendments service

Part No. changes and amendments which occur after publication of the catalog are not published. We therefore recommend that users make a record of amendments in their catalogs. This information is provided, for instance, in order confirmations and/or on spare parts labels.

**Footnotes: Key**

|            |                                                                                                                                                                                                                                                                                                                |
|------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>AB</b>  | Only available complete. Repair by manufacturer only.                                                                                                                                                                                                                                                          |
| <b>AC</b>  | Not scheduled as a spare part. Availability must be checked.                                                                                                                                                                                                                                                   |
| <b>ACN</b> | Not scheduled as a spare part. Availability must be checked. Component only available complete.                                                                                                                                                                                                                |
| <b>EM</b>  | Emission-relevant part. In the case of all marine engines with IMO certification it should be noted that the identification numbers of the emission-relevant parts on the engine must match the details given in the technical file.<br><br>When ordering, quote EM code with order no. E.g: 535 030 04 17 EM. |
| <b>EMN</b> | Emission-relevant parts. Component only available complete.                                                                                                                                                                                                                                                    |
| <b>KD</b>  | Group balancing required                                                                                                                                                                                                                                                                                       |
| <b>KE</b>  | Individual part; not scheduled as a spare part.                                                                                                                                                                                                                                                                |
| <b>KF</b>  | Adjusted spare part.                                                                                                                                                                                                                                                                                           |
| <b>KFN</b> | Adjusted spare part. Component only available complete.                                                                                                                                                                                                                                                        |
| <b>M</b>   | Spares-related components or parts with different repair sizes.<br>Dimensions are listed in the Tolerances and Wear Limits List.                                                                                                                                                                               |
| <b>MN</b>  | Spares-related components or parts with different repair sizes. Components only available complete.                                                                                                                                                                                                            |
| <b>MUB</b> | Spares-related components or Parts with different repair sizes. Available only as complete set.                                                                                                                                                                                                                |
| <b>NN</b>  | Component is not broken down into further sub-components.                                                                                                                                                                                                                                                      |
| <b>P</b>   | List of bought-in components                                                                                                                                                                                                                                                                                   |
| <b>SB</b>  | Group of parts which are welded or brazed together                                                                                                                                                                                                                                                             |
| <b>UA</b>  | Indicate dimensions when ordering                                                                                                                                                                                                                                                                              |
| <b>UB</b>  | Only supplied complete or as a complete set.                                                                                                                                                                                                                                                                   |

## Ordering Procedure

The following information is essential for spare-part order processing:

- Engine Model
- Serial number (see engine name plate)
- FG/FGS
- Item
- Part No.
- Designation
- Model/Type
- Quantity
- Page

When ordering replacement parts for ancillary equipment such as injection pumps, fuel pumps, etc., give both model and part number of the part.

**When ordering a calibrated part** (marked by "KF", "KFN" in the "FN" column), type the following additional information in the **Comments** field:

If the calibration No. is known (see part's nameplate):

Add the calibration No., preceded by an oblique stroke, as an extension to the part number ("/xxxxx")

e.g.: 0025362810/E1234 Here, the extension "E1234" would be the part's calibration number on the nameplate.

If the calibration No. is not known:

Give a detailed description of the required part's installation location by quoting the complete Device Description code (e.g. "= 37.1.1 + A022 - F003") plus the part number extension "/77" (e.g. 5005362810/77).

In this case, the calibrated spare part will be supplied under a new part number.

The Device Description is found on the nameplate at the part's installation location, or in the corresponding Wiring Diagram.

When ordering a non-calibrated adjustable part (marked by "KF", "KFN" in the "FN" column) which should not be calibrated by the factory: Add extension "/76" to the part number (e.g. 0025362810/76).

Phone orders should be confirmed in writing to prevent errors.

## Ordering Example:

| Engine model | Serial number   | FG/FGS | ITEM | Part No.   | Designation       | Quantity | Page |
|--------------|-----------------|--------|------|------------|-------------------|----------|------|
| 16V4000R41   | 527101836       | 031 88 | 5    | 5270300701 | Crankshaft        | 1        | 33   |
|              |                 | 083 05 | 10   | 0020922801 | Easy-Cange Filter | 2        | 92   |
| Blue Line    | V4000M Waterjet | 517 00 | 75   | 5185301593 | Control Console   | 1        | 53   |

## Factory repairs

Parts shipped to MTU for repair must be marked with the relevant engine serial number (tag or label, for example).

### **Exchange components (Reman)**

Exchange components are parts overhauled by the manufacturer. They have the same service life and quality characteristics as new parts.

Components which are included in the Reman exchange program are marked by the following letters in front of the item number:

For instance:       **E 524 010 3520 = New component in exchange program**


**R 524 010 3520 = Reman component in exchange program**

### **Exchange procedure**

With the introduction of exchange components, the so-called core deposit will also be charged for new parts. The core deposit will be indicated separately on the invoice and the respective value will be credited upon return of reusable components.

Further information upon request.

## Engine side and cylinder designations



Engine sides / banks are always designated as viewed from the driving end (KS).

The left bank of cylinders is designated "A" and the right bank "B" (according to DIN ISO 1204).

The cylinders of each bank are numbered consecutively from the driving end, starting with No. 1.

Other engine components are also numbered consecutively from the driving end, starting with No. 1.

### Designations and abbreviations

Driving end = KS

Free end = KGS

Left-hand side

Right-hand side

Top

Bottom

Turbocharger = ATL





FG FG DESIGNATION  
004 LABELS AND AUXILIARY MATERIALS  
011 CRANKCASE  
014 OIL PAN  
015 ENGINE MOUNTING  
016 END HOUSING, DRIVING END AND FREE END  
018 CRANKCASE BREATHER  
024 GEARCASE, AUX PTO END  
031 CRANKSHAFT WITH BEARINGS  
032 CRANKSHAFT, PTO ON DRIVING END  
035 CRANKSHAFT, PTO ON AUX PTO END  
036 TRANSPORT LOCK/LOCK FOR CRANKSHAFT  
037 PISTON  
038 CONNECTING ROD  
041 CYLINDER HEAD  
051 CAMSHAFT  
052 CAMSHAFT DRIVE  
054 ROLLER TAPPETS, PUSH RODS  
055 VALVE DRIVE  
073 INJECTION PUMP / HP PUMP  
075 FUEL INJECTOR  
077 INJECTION LINE / HP FUEL LINE  
081 FUEL PIPEWORK BEFORE DELIVERY PUMP  
082 FUEL PIPEWORK FROM DELIVERY PUMP TO FILTER  
083 FUEL FILTER  
101 EXHAUST TURBOCHARGER, GENERAL OR H.P. TURBOCHARGER  
114 CHARGE AIR COOLING, CENTRAL  
124 AIR SUPPLY TO CYLINDERS  
125 AIR ROUTING BETWEEN TURBOCHARGER AND CHARGE-AIR COOLER  
142 CONSTANT-PRESSURE EXHAUST MANIFOLD  
172 ELECTRIC STARTING  
181 LUBE OIL PUMP AND DRIVE  
183 OIL FILTRATION/COOLING  
185 TURBOCHARGER OIL SUPPLY  
202 COOLANT CIRCUIT, GENERAL, HT CIRCUIT  
203 LOW-TEMPERATURE CIRCUIT  
206 COOLANT PIPEWORK WITH THERMOSTAT  
213 GENERATOR  
221 MECHANICAL FAN DRIVE  
227 FAN  
231 ENGINE MOUNTING  
259 AUXILIARY PTO, SIDE-MOUNTED  
300 ACCESSORIES  
507 WIRING, GENERAL, FOR ENGINE/GEARBOX/PLANT  
810 PAINTING OF COMPLETE ENGINE  
XX XX