

# Technical Documentation

Diesel Engine  
**16 V 595 TE 70L**

Operating Instructions  
**MS150024/01E**



Printed in Germany

© 2007 Copyright MTU Friedrichshafen GmbH

This Publication is protected by copyright and may not be used in any way whether in whole or in part without the prior written permission of MTU Friedrichshafen GmbH. This restriction also applies to copyright, distribution, translation, microfilming and storage or processing on electronic systems including data bases and online services. This handbook is provided for use by maintenance and operating personnel in order to avoid malfunctions or damage during operation.

Subject to alterations and amendments.

# Wichtig – Important – Importante

---

**Bitte die Karte „Inbetriebnahmemeldung“ abtrennen und ausgefüllt an MTU Friedrichshafen GmbH zurücksenden.**

Die Informationen der Inbetriebnahmemeldung sind Grundlage für den vertraglich vereinbarten Logistik-Support (Gewährleistung, Ersatzteile etc.).

**Please complete and return the “Commissioning Note” card below to MTU Friedrichshafen GmbH.**

The Commissioning Note information serves as a basis for the contractually agreed logistic support (warranty, spare parts, etc.).

**Veillez séparer la carte “Signalisation de mise en service” et la renvoyer à la MTU Friedrichshafen GmbH.**

Les informations contenues dans la signalisation de mise en service constituent la base pour l'assistance en exploitation contractuelle (garantie, rechanges, etc.).

**Rogamos separar la tarjeta “Aviso de puesta en servicio” y la devuelvan rellena a MTU Friedrichshafen GmbH.**

Las informaciones respecto al aviso de puesta en servicio constituyen la base para el soporte logístico contractual (garantía, piezas de repuesto, etc.).

**Ritagliare “Avviso di messa in servizio” e rispedirlo debitamente compilato alla MTU Friedrichshafen GmbH.**

Le informazioni ivi registrate sono la base per il supporto logistico contrattuale (garanzia, ricambi, ecc.).

**É gentileza cortar o cartão “Participação da colocação em serviço”, preenché-lo e devolvê-lo a MTU Friedrichshafen.**

Os dados referentes à colocação em serviço representam a base para o suporte logístico (garantia, peças sobressalentes, etc.) estabelecido contratualmente.



Postcard

MTU Friedrichshafen GmbH  
Department MST  
88040 Friedrichshafen  
GERMANY

*Bitte in Blockschrift ausfüllen!*  
*Please use block capitals!*  
*Prière de remplir en lettres capitales!*  
*¡A rellenar en letras de imprenta!*  
*Scrivere in stampatello!*  
*Favor preencher com letras de forma!*



|                                                                                         |
|-----------------------------------------------------------------------------------------|
| Motomr.:<br>Engine No.:<br>N° du moteur:<br>N° de motor:<br>Motore N.:<br>No. do motor: |
|-----------------------------------------------------------------------------------------|

|                                                                                                            |
|------------------------------------------------------------------------------------------------------------|
| Auftragsnr.:<br>MTU works order No.:<br>N° de commande:<br>N° de pedido:<br>N. commessa:<br>No. do pedido: |
|------------------------------------------------------------------------------------------------------------|

**Inbetriebnahme-  
meldung**

**Commissioning  
Note**

**Notice de mise  
en service**

**Aviso de puesta  
en servicio**

**Avviso di messa  
in servizio**

**Participação da  
colocação em  
serviço**

|                                                                                                   |
|---------------------------------------------------------------------------------------------------|
| Motortyp:<br>Engine model:<br>Type du moteur:<br>Tipo de motor:<br>Motore tipo:<br>Tipo do motor: |
|---------------------------------------------------------------------------------------------------|

|                                                                                                                                                                   |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Inbetriebnahmedatum:<br>Date put into operation:<br>Mise en service le:<br>Fecha de puesta en servicio:<br>Messa in servizio il:<br>Data da colocação em serviço: |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|

|                                                                                                                |
|----------------------------------------------------------------------------------------------------------------|
| Eingebaut in:<br>Installation site:<br>Lieu de montage:<br>Lugar de montaje:<br>Installato:<br>Incorporado em: |
|----------------------------------------------------------------------------------------------------------------|

|                                                                                                                                                                                                          |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Schiffstyp / Schiffshersteller:<br>Vessel/type/class / Shipyard:<br>Type du bateau / Constructeur:<br>Tipo de buque / Constructor:<br>Tipo di barca / Costruttore<br>Tipo de embarcação/estaleiro naval: |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

|                                                                                                                                                                       |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Endabnehmer/Anschrift:<br>End user's address:<br>Adresse du client final:<br>Dirección del cliente final:<br>Indirizzo del cliente finale:<br>Usuário final/endereço: |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|

|                                                                                     |
|-------------------------------------------------------------------------------------|
| Bemerkung:<br>Remarks:<br>Remarques:<br>Observaciones:<br>Commento:<br>Observações: |
|-------------------------------------------------------------------------------------|

---

|          |                                                                                     |           |
|----------|-------------------------------------------------------------------------------------|-----------|
| <b>1</b> | <b>Safety</b>                                                                       | <b>05</b> |
| 1.1      | General conditions                                                                  | 05        |
| 1.2      | Personnel and organizational requirements                                           | 06        |
| 1.3      | Transport                                                                           | 07        |
| 1.4      | Safety requirements when working on the engine                                      | 08        |
| 1.5      | Auxiliary materials, fire prevention and environmental protection                   | 11        |
| 1.6      | Standards for warning notices in the publication                                    | 13        |
| <b>2</b> | <b>Product Summary</b>                                                              | <b>15</b> |
| 2.1      | Engine Overview                                                                     | 15        |
| 2.1.1    | Engine layout                                                                       | 15        |
| 2.2      | Engine Side and Cylinder Designations                                               | 17        |
| 2.2.1    | Engine side and cylinder designations                                               | 17        |
| 2.3      | Main Engine Dimensions                                                              | 18        |
| 2.3.1    | Main engine dimensions                                                              | 18        |
| 2.4      | Firing Order                                                                        | 19        |
| 2.4.1    | Firing order                                                                        | 19        |
| 2.5      | Technical Data                                                                      | 20        |
| 2.5.1    | 16V 595 TE70L engine data                                                           | 20        |
| <b>3</b> | <b>Operation</b>                                                                    | <b>23</b> |
| 3.1      | LOP – Overview                                                                      | 23        |
| 3.2      | Pump control – Control and display elements                                         | 30        |
| 3.3      | Putting the engine into operation after extended out-of-service periods (>3 months) | 31        |
| 3.4      | Putting the engine into operation after scheduled out-of-service periods            | 33        |
| 3.5      | Starting the engine from LOP                                                        | 34        |
| 3.6      | Operational checks                                                                  | 36        |
| 3.7      | Stopping the engine from LOP                                                        | 37        |
| 3.8      | Emergency stop                                                                      | 38        |
| 3.9      | After stopping the engine                                                           | 40        |
| 3.10     | PPC, LPU – Functional check                                                         | 41        |
| 3.11     | Plant – Cleaning                                                                    | 42        |
| <b>4</b> | <b>Engine Control System ECS-5</b>                                                  | <b>43</b> |
| 4.1      | Normal Operation: LOS or LOP with Display                                           | 43        |
| 4.1.1    | Local control mode – Engaging/disengaging the gearbox                               | 43        |
| 4.1.2    | Local control mode – Changing engine speed                                          | 44        |
| <b>5</b> | <b>Maintenance</b>                                                                  | <b>45</b> |
| 5.1      | Preface                                                                             | 45        |

---

|       |                                                                                          |     |
|-------|------------------------------------------------------------------------------------------|-----|
| 5.2   | 50-hours service .....                                                                   | 47  |
| 5.3   | Maintenance schedule matrix, V 595 TE70L .....                                           | 48  |
| 5.4   | Maintenance tasks .....                                                                  | 53  |
| 6     | Troubleshooting .....                                                                    | 57  |
| 6.1   | Troubleshooting .....                                                                    | 57  |
| 6.2   | Fault indication and fault messages .....                                                | 66  |
| 6.3   | Oil priming pump, oil refill pump – Troubleshooting .....                                | 94  |
| 7     | Task Description .....                                                                   | 97  |
| 7.1   | Engine .....                                                                             | 97  |
| 7.1.1 | Engine – Barring manually .....                                                          | 97  |
| 7.1.2 | Engine – Barring with starting system .....                                              | 99  |
| 7.2   | Cylinder Liner .....                                                                     | 100 |
| 7.2.1 | Combustion chambers – Draining condensate .....                                          | 100 |
| 7.3   | Valve Drive .....                                                                        | 101 |
| 7.3.1 | Valve clearance – Check and adjustment .....                                             | 101 |
| 7.3.2 | Cylinder-head cover – Removal and installation .....                                     | 103 |
| 7.4   | Injector .....                                                                           | 104 |
| 7.4.1 | Injector – Cleaning .....                                                                | 104 |
| 7.4.2 | Injector – Check .....                                                                   | 105 |
| 7.4.3 | Injector – Disassembly .....                                                             | 107 |
| 7.4.4 | Injector – Replacement .....                                                             | 109 |
| 7.4.5 | Injector – Nozzle replacement .....                                                      | 110 |
| 7.4.6 | Injector – Removal and installation .....                                                | 111 |
| 7.5   | Fuel System .....                                                                        | 117 |
| 7.5.1 | Leak-fuel tank – Draining .....                                                          | 117 |
| 7.5.2 | Fuel system – Venting .....                                                              | 118 |
| 7.6   | Fuel Filter .....                                                                        | 119 |
| 7.6.1 | Fuel filter – Replacement .....                                                          | 119 |
| 7.6.2 | Fuel prefilter – Differential pressure check and adjustment of gauge .....               | 121 |
| 7.6.3 | Fuel prefilter – draining .....                                                          | 122 |
| 7.6.4 | Fuel prefilter – flushing .....                                                          | 124 |
| 7.6.5 | Fuel prefilter – Filter element replacement .....                                        | 126 |
| 7.7   | Charge-air Cooling, General, Left-hand Side .....                                        | 129 |
| 7.7.1 | Intercooler – Checking condensate drain line for coolant discharge and obstruction ..... | 129 |
| 7.8   | Air Filter .....                                                                         | 130 |
| 7.8.1 | Air filter element – Cleaning .....                                                      | 130 |
| 7.8.2 | Air filter replacement .....                                                             | 131 |
| 7.8.3 | Air filter removal and installation .....                                                | 132 |
| 7.9   | Air Intake .....                                                                         | 133 |
| 7.9.1 | Air intake flap – Lubrication .....                                                      | 133 |
| 7.9.2 | Service indicator – Signal ring position check .....                                     | 134 |
| 7.9.3 | Charge-air manifold – Checking for coolant leakage .....                                 | 135 |

|             |                                                                      |            |
|-------------|----------------------------------------------------------------------|------------|
| 7.9.4       | Emergency air shut-off flap – Lubrication                            | 136        |
| 7.9.5       | Emergency air shut-off flaps – Electric control check                | 137        |
| 7.9.6       | Emergency air shut-off flaps – Opening/closing manually              | 138        |
| <b>7.10</b> | <b>Exhaust Flap with Actuation</b>                                   | <b>139</b> |
| 7.10.1      | Flap control – Functional test                                       | 139        |
| <b>7.11</b> | <b>Starting Equipment</b>                                            | <b>140</b> |
| 7.11.1      | Pressure reducing station – Putting into operation                   | 140        |
| 7.11.2      | Pressure reducing station – Venting and putting out of operation     | 142        |
| 7.11.3      | Pressure reducing station – Filter cleaning                          | 143        |
| 7.11.4      | Starter – Condition check                                            | 144        |
| <b>7.12</b> | <b>Lube-oil System, Lube-oil Circuit</b>                             | <b>145</b> |
| 7.12.1      | Engine oil – Level check                                             | 145        |
| 7.12.2      | Engine oil – Change                                                  | 147        |
| 7.12.3      | Engine oil – Sample extraction and analysis                          | 149        |
| 7.12.4      | Oil sludge inspection for metallic residues                          | 150        |
| 7.12.5      | Lube oil priming pump – Checking direction of rotation               | 151        |
| <b>7.13</b> | <b>Oil Filtration/Cooling</b>                                        | <b>152</b> |
| 7.13.1      | Disk-pack filter – Cleaning                                          | 152        |
| 7.13.2      | Disk-pack filter – Filter pack replacement                           | 153        |
| 7.13.3      | Engine oil filter – Draining oil sludge                              | 154        |
| 7.13.4      | Engine oil filter – Cleaning filter element                          | 155        |
| 7.13.5      | Engine oil filter – Replacement                                      | 156        |
| 7.13.6      | Centrifugal oil filter – Cleaning and filter-sleeve replacement      | 157        |
| <b>7.14</b> | <b>Coolant Circuit, General, HT Circuit</b>                          | <b>160</b> |
| 7.14.1      | Drain, venting and measuring points                                  | 160        |
| 7.14.2      | Vent line – Checking for obstructions                                | 165        |
| 7.14.3      | Engine coolant – Level check                                         | 166        |
| 7.14.4      | Engine coolant – Change                                              | 167        |
| 7.14.5      | Engine coolant – Draining                                            | 168        |
| 7.14.6      | Engine coolant system – Filling                                      | 169        |
| 7.14.7      | Engine coolant pump – Relief bore check                              | 170        |
| 7.14.8      | Engine coolant – Sample extraction and analysis                      | 171        |
| 7.14.9      | HT circuit coolant thermostat – Emergency adjustment                 | 172        |
| 7.14.10     | HT coolant circuit – Strainer removal                                | 173        |
| <b>7.15</b> | <b>LT Circuit</b>                                                    | <b>174</b> |
| 7.15.1      | LT circuit coolant thermostat – Emergency adjustment                 | 174        |
| <b>7.16</b> | <b>Raw Water Pump with Connections</b>                               | <b>175</b> |
| 7.16.1      | Raw water pump – Relief bore check                                   | 175        |
| <b>7.17</b> | <b>Engine Mounting</b>                                               | <b>176</b> |
| 7.17.1      | Engine mounts – securing screws check                                | 176        |
| <b>7.18</b> | <b>Cabling, General, for Engine / Gearbox / Genset</b>               | <b>177</b> |
| 7.18.1      | Engine wiring – Check                                                | 177        |
| 7.18.2      | Sensors and actuators                                                | 178        |
| <b>7.19</b> | <b>Accessories for Engine Governor (Electronic) / Control System</b> | <b>184</b> |
| 7.19.1      | ECS – Connectors and housing cleaning                                | 184        |

---

|             |            |                                                        |            |
|-------------|------------|--------------------------------------------------------|------------|
|             | 7.19.2     | Plug-in connections – Check .....                      | 185        |
|             | 7.19.3     | ECS – Removal and installation .....                   | 186        |
| <b>7.20</b> |            | <b>Displays and Controls, General .....</b>            | <b>187</b> |
|             | 7.20.1     | Limit switch – Check .....                             | 187        |
|             | 7.20.2     | Indicator lamp - LED replacement .....                 | 188        |
|             | 7.20.3     | Fluid level monitor – Check .....                      | 190        |
| <b>7.21</b> |            | <b>Emergency Instrumentation (Control Panel) .....</b> | <b>191</b> |
|             | 7.21.1     | Engine control system – Operational tests .....        | 191        |
| <b>8</b>    |            | <b>Special Tools .....</b>                             | <b>195</b> |
|             | <b>8.1</b> | <b>Special tools .....</b>                             | <b>195</b> |
|             | <b>8.2</b> | <b>Standard tools – Overview .....</b>                 | <b>204</b> |
| <b>9</b>    |            | <b>Annex .....</b>                                     | <b>205</b> |
|             | <b>9.1</b> | <b>Manufacturer's documentation .....</b>              | <b>205</b> |
|             | <b>9.2</b> | <b>MTU contact person/service partner .....</b>        | <b>206</b> |
|             | <b>9.3</b> | <b>Index .....</b>                                     | <b>207</b> |



# 1 Safety

## 1.1 General conditions

### General

In addition to the instructions in this publication, the applicable country-specific legislation and other compulsory regulations regarding accident prevention must be observed. This engine is a state-of-the art product and conforms with all applicable specifications and regulations. Nevertheless, persons and property may be at risk in the event of:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Modifications or conversions
- Non-compliance with the Safety Instructions

### Correct use

The engine is intended exclusively for the application specified in the contract or defined at the time of delivery. Any other use is considered improper use. The manufacturer will accept no liability for any resultant damage. The responsibility is borne by the user alone.

Correct use also includes observation of and compliance with the maintenance specifications.

### Modifications or Conversions

Modifications made by the customer to the engine may affect safety.

MTU will accept no liability or warranty claims for any damage caused by unauthorized modifications or conversions.

### Spare parts

Only genuine MTU spare parts must be used to replace components or assemblies. In the event of any damage caused by the use of other spare parts, no liability nor warranty claims vis-à-vis the engine manufacturer will be accepted.

## 1.2 Personnel and organizational requirements

### **Personnel**

Work on the engine must only be carried out by properly qualified and instructed personnel.

The specified legal minimum age must be observed.

Responsibilities of the operating, maintenance and repair personnel must be specified.

### **Organization**

This publication must be issued to all personnel involved in operation, maintenance, repair or transportation.

It must be kept at hand near the engine and accessible at any time to all personnel involved in operation, maintenance, repair or transportation.

The personnel must be instructed on engine operation and repair by means of this publication, and in particular the safety instructions must be explained.

This is especially important for personnel who work on the engine only on an occasional basis. Such personnel must be given instructions repeatedly.

### **Working clothes and protective equipment**

Wear proper work clothing for all work.

Depending on the kind of work, use additional protective equipment, e.g. protective goggles, gloves, helmet, apron.

Work clothing must be tight fitting so that it does not catch on rotating or projecting components.

Do not wear jewelry (e.g. rings, chains etc.).