



Operating Instructions

Diesel engine
20V956TB34

MS150131/03E

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

Table of Contents

1	Preface		5.9	Starting and Shutdown Equipment	52
1.1	Preface	6	5.9.1	Starting equipment	52
2	Revision Overview		5.9.2	Shutdown equipment	54
2.1	Revision overview	7	5.10	Lube Oil System	55
3	Safety		5.10.1	Oil pumps	55
3.1	Important provisions for all products	8	5.10.2	Oil pump - Engine (for c.c.w. rotation engine)	56
3.2	Intended use of all products	9	5.10.3	Oil pump - Valve-seat lubrication	57
3.3	Personnel and organizational requirements	10	5.10.4	Oil priming pump	58
3.4	Safety regulations for commissioning and operation	11	5.10.5	Engine oil system	59
3.5	Safety regulations for assembly, maintenance, and repair work	13	5.10.6	Oil conditioning system	60
3.6	Fire and environmental protection, indirect materials	17	5.10.7	Running-gear oil system	61
3.7	Standards for warning messages in the text and highlighted information	20	5.10.8	Piston cooling-oil circuit	63
4	Transport		5.10.9	Valve-gear oil system	64
4.1	Crankcase - Transport locking device	21	5.10.10	Priming-oil system	65
4.2	Engine mounting - Transport locking devices	24	5.10.11	Valve-seat lubrication system	67
5	Functional Description		5.10.12	Engine oil filter	68
5.1	Engine layout	26	5.11	Coolant System	70
5.2	Crankcase	27	5.11.1	Coolant pumps (counterclockwise-running engine)	70
5.3	Gear train	29	5.11.2	Coolant circuit	71
5.4	Crank drive	31	5.11.3	Engine coolant circuit	72
5.5	Cylinder head	32	5.11.4	Engine coolant circulating pump	74
5.6	Engine control	33	5.11.5	Coolant preheater	75
5.7	Fuel System	34	5.11.6	Engine coolant thermostat	76
5.7.1	Fuel system	34	5.11.7	Charge-air coolant circuit	77
5.7.2	Fuel injection equipment	36	5.11.8	Fuel heat exchanger	78
5.7.3	Fuel injector	37	5.12	Mounting / Support	79
5.7.4	Fuel delivery pump	39	5.12.1	Mounting	79
5.7.5	Fuel filter	41	5.12.2	Resilient engine mounts	80
5.8	Charge-Air System and Exhaust System	42	5.13	Drive Systems, Driving End and Free End (Coupling)	81
5.8.1	Turbocharging	42	5.13.1	Coupling	81
5.8.2	Intake air system and exhaust system	43	5.13.2	Steel-spring coupling	82
5.8.3	Air supply pipework	44	5.14	Control and Regulation Equipment	83
5.8.4	Emergency-air shutoff flap	46	5.14.1	Engine governor	83
5.8.5	Exhaust system	47	5.14.2	Governor actuator (electrohydraulic)	84
5.8.6	Turbocharger sequencing system	48	5.14.3	Governor linkage	85
5.8.7	Exhaust turbocharger control	50	6	Technical Data	
5.8.8	Charge-air preheating control	51	6.1	Engine side and cylinder designations	86
			6.2	Engine data 20V956TB34	87
			6.3	Engine - Main dimensions	91
			6.4	Firing order	92
			7	Operation	
			7.1	Preparations before putting the engine into operation	93
			7.2	One-time work after putting into operation	95

7.3 Putting the engine into operation after extended out-of-service periods (>3 months)	96	10.5.5 Fuel prefilter – Draining	144
7.4 Putting the engine into operation after scheduled out-of-service period	97	10.5.6 Fuel prefilter – Venting	145
7.5 Starting the engine	98	10.5.7 Fuel prefilter – Cleaning	146
7.6 Operational monitoring	99	10.5.8 Fuel filter – Replacement	148
7.7 Engine – Shutdown	100	10.6 Charge-Air Cooling	151
7.8 Engine emergency shutdown	101	10.6.1 Intercooler – Drain-line check	151
7.9 After stopping the engine – Engine remains ready for operation	102	10.6.2 Charge-air cooler – Drain valve check	152
7.10 After shutdown – Putting the engine out of operation	103	10.6.3 Intake housing – Replacement of air flap stop	153
8 Troubleshooting		10.7 Air Filter	154
8.1 Troubleshooting	104	10.7.1 Air filter – Cleaning	154
9 Maintenance		10.7.2 Air filter – Check	155
9.1 Maintenance Schedule Task Reference Table [QL1]	110	10.7.3 Air filter – Replacement	156
10 Task Description		10.7.4 Air filter – Removal and installation	157
10.1 Engine	112	10.7.5 Contamination indicator – Signal ring position check	158
10.1.1 Engine – Manual barring	112	10.8 Air Intake	159
10.1.2 Engine – Barring with starting system	114	10.8.1 Air supply pipework – Cover plates installation and removal	159
10.1.3 Engine – Test run	115	10.8.2 Pressure limiting valve – Replacement	160
10.1.4 Engine – Test run during commissioning	116	10.8.3 Valve block – Replacement	161
10.1.5 Flexible pipe connections – Hoseline visual check	117	10.8.4 Emergency air shut-off flap – Lubrication	162
10.1.6 Flexible pipe connections – Hose line replacement	118	10.8.5 Emergency-air shut-off flap – Check operation with electric actuation	163
10.2 Cylinder Liner	119	10.8.6 Emergency-air shutoff flap – Manual closing/opening	164
10.2.1 Cylinder liner – Endoscopic examination	119	10.9 Exhaust Pipework	165
10.2.2 Cylinder liner – Instructions and comments on endoscopic and visual examination	121	10.9.1 Exhaust pipework – Cover plates installation and removal	165
10.2.3 Combustion chambers – Draining condensate	123	10.9.2 Exhaust turbocharger control linkage – Lubrication	166
10.3 Valve Drive	124	10.9.3 Air and exhaust flaps – Functional check	167
10.3.1 Valve clearance – Check and adjustment	124	10.9.4 Exhaust pipework – Leak check of exhaust pipe bellows after cylinder head	168
10.3.2 Cylinder head cover – Removal and installation	126	10.9.5 Exhaust control line – Obstruction check	169
10.4 Injection Valve / Injector	127	10.9.6 Exhaust control line – Fluid discharge check	170
10.4.1 Injector – Replacement	127	10.10 Starting and Shutdown Equipment	171
10.4.2 Injector – Removal and installation	128	10.10.1 Starting valve – Ease of movement check	171
10.4.3 Injector – Disassembly	132	10.10.2 Starting-air distributor – Overview	172
10.4.4 Injector – Cleaning	133	10.10.3 Starting-air distributor – Removal and installation	175
10.4.5 Injector – Check	135	10.10.4 Starting-air distributor – Check	177
10.4.6 Injector – Assembly	137	10.10.5 Starting-air distributor – Checking basic setting of the distributor disc	183
10.5 Fuel System	139	10.10.6 Starting-air distributor – Adjustment	186
10.5.1 Fuel prefilter – Differential pressure check	139	10.10.7 Starting-air distributor – Reassembly with new stop screw	189
10.5.2 Leak fuel tank – Draining	140	10.10.8 Starting-air distributor – Lubricating of tongue-and-groove connection	191
10.5.3 Fuel system – Venting	141	10.10.9 3-way solenoid valve – Leak check	193
10.5.4 Fuel prefilter – Cut-in / cut-out	143	10.10.10 Automatic restrictor – Ease of movement check	194
		10.10.11 Shutdown equipment – Emergency stop function check	195
		10.11 Lube Oil System	196

10.11.1	Check valve - Operating position check	196	10.13.3	Charge-air coolant - Change	228
10.11.2	Engine oil - Level check	197	10.13.4	Charge-air coolant - Draining	229
10.11.3	Engine oil - Change	198	10.13.5	Charge-air coolant - Filling	230
10.11.4	Engine oil - Sample extraction and analysis	199	10.13.6	Charge-air coolant pump - Relief bore check	232
10.11.5	Engine oil filter - Draining oil sludge	200	10.13.7	Charge-air coolant - Sample extraction and analysis	233
10.11.6	Oil sludge - Check for metallic residues	201			
10.11.7	Oil priming pump - Checking direction of rotation	202	10.14	Engine Mounting / Support	234
10.11.8	Disk-pack filter - Cleaning	203	10.14.1	Engine mounting - Check and adjustment	234
10.11.9	Disk-pack filter - Filter pack replacement	205	10.14.2	Engine mounting - Securing screws check for firm seating	236
10.11.10	Engine oil filter - Edge-type filter element cleaning	206	10.15	Drive Systems, Driving End and Free End (Coupling)	237
10.11.11	Engine oil filter - Replacement	207	10.15.1	Steel-spring coupling - Leak check	237
10.11.12	Piston cooling-oil filter - Replacement	208	10.16	Control and Regulation Equipment	238
10.12	Coolant Circuit, General, High-Temperature Circuit	210	10.16.1	Engine governor - Operation check	238
10.12.1	Coolant pumps - Relief bore check	210	10.17	Cabling	239
10.12.2	Coolant level - Check	211	10.17.1	Engine cabling - Check	239
10.12.3	Drain, vent and sample extraction points	212	10.18	Accessories for (Electronic) Engine Governor / Control System	240
10.12.4	Vent line - Obstruction check	213	10.18.1	ECS - Connectors and housing cleaning	240
10.12.5	Coolant expansion tank - Valve cover replacement	214	10.18.2	Plug connections - Check	241
10.12.6	Engine coolant - Level check	216			
10.12.7	Engine coolant - Change	217	11	Appendix A	
10.12.8	Engine coolant - Draining	218	11.1	Abbreviations	242
10.12.9	Engine coolant - Filling	219	11.2	Conversion tables	246
10.12.10	Engine coolant pump - Relief bore check	221	11.3	Tightening specifications for screws, nuts and bolts	250
10.12.11	Engine coolant - Sample extraction and analysis	222	11.4	Contact person/Service partner	263
10.12.12	Engine coolant circuit - Cleaning strainer	223			
10.12.13	Engine coolant thermostat - Emergency adjustment	224	12	Appendix B	
10.13	Low-Temperature Circuit	225	12.1	Standard Tools and Special Tools	264
10.13.1	Coolant expansion tank - Valve cover replacement	225	12.2	Index	273
10.13.2	Charge-air coolant - Level check	227			

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer Rolls-Royce Solutions.

2 Revision Overview

2.1 Revision overview

Revision overview– General

Chapter	Edition MS150131/01	Edition MS150131/02
–	Warning notices in general.	Warning notices were updated.
–	Graphics in general.	Graphics were updated.
–	Special tools, consumables, spare parts in general.	Special tools, consumables, spare parts were updated.
–	Safety chapter.	Chapter was updated.

Revision overview – Maintenance schedule

Task No.	Edition MS50158/02	Edition MS50158/03
W1814	–	Task deleted.
W1815	–	Task deleted.
W4257	–	Task "Check starting-air distributor, replace components if necessary." added.
W4258	–	Task "Replace thrust screw with shim rings." added.
W4259	–	Task "Check basic setting, replace distribution disc and shaft if necessary." added.

Revision overview – Task description

Chapter	Edition MS150131/01	Edition MS150131/02
10.10.2	–	Chapter "Starting-air distributor - Overview" added.
10.10.3	Chapter "Starting-air distributor – Removal and installation"	Chapter updated.
10.10.4	Chapter "Starting-air distributor – Check"	Chapter updated.
10.10.5	Chapter "Starting-air distributor – Checking basic setting of the distributor disc"	Chapter updated.
10.10.6	Chapter "Starting-air distributor – Adjustment"	Chapter updated.
10.10.7	Chapter "Starting-air distributor – Reassembly of new stop screw"	Chapter updated.
10.10.8	Chapter "Starting-air distributor – Lubricating of tongue-and-groove connection"	Chapter updated.
–	–	Chapters updated to their latest status.

3 Safety

3.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at:<http://www.mtu-solutions.com>

3.2 Intended use of all products

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/Rolls-Royce Solutions contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all safety and warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

3.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.