

Functional Description

Electronics

Electronic Engine Control Unit

ECU 8

Application: Genset

Functional description

E532409/03E



Power. Passion. Partnership.

© 2017 Copyright MTU Friedrichshafen GmbH

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of MTU Friedrichshafen GmbH. This particularly applies to its reproduction, distribution, editing, translation, micro-filming and storage or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. MTU Friedrichshafen GmbH reserves the right to change, delete or supplement the information provided as and when required.

Table of Contents

1 Safety		5.1.1 ECU 8 plant interface function	39
1.1 Important provisions for all products	4	5.1.2 Channel assignment	49
1.2 Correct use of all products	5	5.1.3 Power supply	51
1.3 Personnel and organizational requirements	6	5.2 Engine	55
1.4 Safety regulations for initial start-up and operation	7	5.2.1 Sensors	55
1.5 Safety regulations for assembly, maintenance, and repair work	9	5.2.2 Sensors used	67
1.6 Fire prevention and environmental protection, fluids and lubricants, indirect materials	13	6 Devices	
1.7 Standards for warning notices in the text and highlighted information	15	6.1 Engine Identification Label EIL - Design and function	75
2 General Information		6.2 Smart Connect	76
2.1 ECU 8 - Overview	16	6.3 Diagnostics and tools	83
2.2 Scope of delivery	18	6.4 Maintenance and Servicing	86
2.3 Installation on the engine	19	6.4.1 USB maintenance concept - Use	86
2.4 ECU8 technical data	20	6.4.2 USB maintenance concept function	88
3 Connections, Cabling		6.4.3 Smart Connect USB Tool	89
3.1 ECU8 - Cable connectors	22	7 Appendix A	
3.2 Wiring harnesses	28	7.1 Smart Connect status displays	92
3.3 Customer interface	34	7.2 Smart Connect fault messages	94
4 Function		7.3 ECU 8 fault messages	99
4.1 General information about the function of the ECU8 Engine Control Unit	37	7.4 MTU Contact/Service Partners	114
5 Interfaces		8 Appendix B	
5.1 Electrical System	39	8.1 List of Figures	115
		8.2 Index	116

1 Safety

1.1 Important provisions for all products

General information

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number and must match with the information on the title page of this manual.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by MTU come with a second nameplate. When operating the machine in the EU: The second nameplate must be affixed in a prominent position as described in the accompanying specifications.

Emission regulations and emission labels

Responsibility for compliance with emission regulations

Modification or removal of any mechanical/electronic components or the installation of additional components including the execution of calibration processes that might affect the emission characteristics of the product are prohibited by emission regulations. Emission control units/systems may only be maintained, exchanged or repaired if the components used for this purpose are approved by the manufacturer.

Noncompliance with these regulations will invalidate the design type approval issued by the emissions regulation authorities. The manufacturer does not accept any liability for violations of the emission regulations.

The product must be operated over its entire life cycle according to the conditions defined as "Intended use" (→ Page 5).

Replacing components with emission labels

On all MTU engines fitted with emission labels, these labels must remain on the engine throughout its operational life.

Exception: Engines used exclusively in land-based, military applications other than by US government agencies.

Please note the following when replacing components with emission labels:

- The relevant emission labels must be affixed to the spare part.
- Emission labels shall not be transferred from the replaced part to the spare part.
- The emission labels must be removed from the replaced part and destroyed.

1.2 Correct use of all products

Correct use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/MTU contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found on the websites:

- For drive systems: <http://www.mtu-online.com>
- For power generation: <http://www.mtuonsiteenergy.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

1.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the descriptions of the individual activities.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorisation and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.

1.4 Safety regulations for initial start-up and operation

Safety regulations for initial start-up

Install the product correctly and carry out acceptance in accordance with the manufacturer's specifications before putting the product into service. All necessary approvals must be granted by the relevant authorities and all requirements for initial startup must be fulfilled.

Whenever the product is subsequently taken into operation ensure that:

- All personnel is clear of the danger zone surrounding moving parts of the machine.
Electrically-actuated linkages may be set in motion when the Engine Control Unit (governor) is switched on.
- All maintenance and repair work has been completed.
- All loose parts have been removed from rotating machine components.
- All safety equipment is in place.
- All components must be properly grounded. Ground separately by means of a grounding stake as necessary.
- No persons wearing pacemakers or any other technical body aids are present.
- The service room is adequately ventilated.
- In the first few hours of operation, the product emits gases as a result of smoldering e.g. lacquers or oil. These gases may be hazardous to health. Always wear respiratory protection in the operating room during this period.
- The exhaust system is leak-tight and that the gases are vented to atmosphere.
- The product must be free of any damage, this applies in particular to lines and cabling.
- Protect battery terminals, generator terminals or cables against accidental contact.
- Check that all connections have been correctly allocated e.g. +/- polarity, fuel line/urea solution line, supply/return.

Immediately after putting the product into operation, make sure that all control and display instruments as well as the monitoring, signaling and alarm systems work properly.

Smoking is prohibited in the area of the product.

Safety regulations during operation

The operator must be familiar with the control and display elements.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be permanently observed with regard to present operating status, violation of limit values and warning or alarm messages.

Malfunctions and emergency stop

Practice emergency procedures, especially emergency stopping, at regular intervals.

Take the following steps if any system malfunctions are detected or signaled by the system:

- inform supervisor(s) in charge,
- analyze the message,
- respond by taking any necessary emergency action, e.g. emergency stop.

Contact Service if the root cause of the malfunction cannot be clearly identified.

Operation

Do not remain in the operating room when the product is running unless absolutely necessary. Keep your stay as short as possible.

Keep a safe distance away from the product if possible. Do not touch the product unless expressly instructed to do so following a written procedure.

Do not inhale the exhaust gases of the product.

The following requirements must be fulfilled before the product is started:

- Wear ear protectors.
- Mop up any leaked or spilled fluids and lubricants immediately or soak up with a suitable binding agent.

Operation of electrical equipment

When electrical equipment is in operation, certain components of these appliances are electrically live.

Follow the applicable operating and safety instructions when operating the devices and heed warnings at all times.

1.5 Safety regulations for assembly, maintenance, and repair work

Safety regulations for work prior to assembly, maintenance, and repair

Have assembly, maintenance, or repair work carried out by qualified and authorized personnel only.

Allow the product to cool down to less than 50 °C (risk of explosion for oil vapors, fluids and lubricants, risk of burning).

Relieve pressure in fluid and lubricant systems and compressed-air lines which are to be opened. Use suitable containers of adequate capacity to catch fluids and lubricants.

Release residual pressure before removing or replacing a component in the supply line. To depressurize pressurized lines, shut off the lines first, then release the residual pressure.

When changing the oil or working on the fuel system, ensure that the service room is adequately ventilated.

Never carry out assembly, maintenance, or repair work with the product in operation, unless:

- It is expressly permitted to do so following a written procedure.

Lock-out the product to preclude undesired starting, e.g.

- Start interlock
- Key switch
- Close supply line for hydraulic starting.

Attach “Do not operate” sign in the operating area or to control equipment.

Disconnect the battery cables or actuate the battery isolating switch, if fitted. Lock circuit breakers.

Before starting work on CaPoS, if used:

- Switch of the charging system (DC/DC converter).
- Discharge the UltraCap modules using the appropriate discharger.
- Short-circuit the UltraCap modules with a suitable wire jumper.

Close the main valve on the compressed-air system and vent the compressed-air line when pneumatic starters are fitted.

Before working on the exhaust gas treatment system close the shut-off valve on the urea solution tank. Take into consideration that the urea solution pumps continue to run for a certain period when the engine was stopped.

Disconnect the control equipment from the product.

Use the recommended special tools or suitable equivalents when instructed to do so.

Safety regulations when performing assembly, maintenance, and repair work

Special tools and lifting equipment

Use only proper and calibrated tools. Observe the specified tightening torques during assembly or disassembly.

Setting down, lifting and climbing

Carry out work only on assemblies or plants which are properly secured.

Use appropriate lifting equipment for all components. Use all specified attachment points and observe the center of gravity.

Never work on engines or components when they are held in place by lifting equipment.

Make sure components or assemblies are placed on stable surfaces. Adopt suitable measures to avoid that components/tools fall down.

Ensure safe stand when performing assembly work.

Never use the product as a climbing aid.

When working high on the equipment, always use suitable ladders and work platforms. Special instructions for outdoor areas: There must be no risk of slipping e.g. due to icing.

Removing, installing and cleanliness

Pay particular attention to cleanliness at all times.

Take special care when removing ventilation or plug screws from the product.

Ensure that O-rings are not installed in a slanted/twisted condition.

Carry out appropriate cleaning procedures to clean and inspect components requiring special cleanliness (e.g. components carrying oil, fuel, or air).

Note cooling time for components which are heated for installation or removal (risk of burning).

Ensure that all retainers and dampers are installed correctly.

Remove any accumulation of condensate after assembling chilled components. Coat the components with a suitable corrosion inhibitor as necessary.

Lines

Keep gaseous/liquid fuel injection lines, lines for urea solution and connections clean.

Always seal connections with caps or covers if a line is removed or opened.

Fit new seals when re-installing lines.

Never bend lines and avoid damaging lines, particularly the fuel lines.

Ensure that all fuel injection and pressurized oil lines are installed with enough clearance to prevent contact with other components. Do not place fuel or oil lines near hot components.

Miscellaneous

Wear a breathing mask offering protection against soot, dust, and mineral fibers (filter class P2) when working on exhaust components. Wear protective gloves and goggles for protection against acidic condensate.

Do not touch elastomeric seals (e.g. Viton sealing rings) with your bare hands if they have a carbonized or resinous appearance.

Elastomer components (e.g. engine mounts, damping elements, couplings and V-belts) must not be painted. Only install them after painting the engine or mask them prior to painting.

The following applies to starters with copper-beryllium alloy pinions:

- Wear a respirator mask (filter class P3). Do not blow out the interior of the flywheel housing or the starter with compressed air. Clean the flywheel housing inside with a class H dust extraction device.
- Observe the safety data sheet.

Safety regulations after performing assembly, maintenance, and repair work

Before starting the engine, make sure that nobody is standing in the danger zone of the product.

Check that all access ports/apertures which have been opened to facilitate working are closed again.

Check that all safety equipment has been installed and that all tools and loose parts have been removed (especially the barring tool).

Ensure that no unattached parts have been left in/on the product (e.g. including rags and cable straps).

Ensure that the grounding system is properly connected.

Welding work

Welding operations on the product or mounted units are not permitted. Cover the product when welding in its vicinity.