



System Documentation

Electronics

Engine Control System ECS

- Engine Control Unit ECU 9
- Engine Monitoring Unit EMU 9
- Engine Interface Module EIM 10

Application: Marine

- 16V2000M87, M97, M97L

E532906/00E



A Rolls-Royce
solution

Engine model	kW/cyl.	Application group
16V2000M87	102 kW/cyl.	1D, continuous operation, variable, medium load
16V2000M97	112 kW/cyl.	1DS, continuous operation, variable, low load
16V2000M97L	121 kW/cyl.	1DS, continuous operation, variable, low load

Table 1: Applicability

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to §15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

Table of Contents

1 Safety		2.3.6.2 Wiring harness 16V2000Mx7	80
1.1 Important provisions for electronic products	8	2.3.7 Exhaust Gas Aftertreatment System	94
1.2 Intended use of electronic products	9	2.3.7.1 Exhaust gas aftertreatment system FlexBox – Wiring diagram	94
1.3 Personnel and organizational requirements	10	2.3.7.2 Exhaust gas aftertreatment (FlexBox) wiring harnesses – Overview	95
1.4 Safety regulations for commissioning and operation of electronic products	11	2.4 System Functions	101
1.5 Safety regulations for assembly, maintenance, and repair work on electronic products	12	2.4.1 General	101
1.6 Fire and environmental protection, consumables and auxiliary materials for electronic products	14	2.4.1.1 Process variables and parameters	101
1.7 Standards for warning messages in the text and highlighted information	15	2.4.1.2 Alarm generation	104
2 System Description		2.4.2 Starting Sequence and Stopping Sequence	107
2.1 System Layout	16	2.4.2.1 Engine start – Functional description	107
2.1.1 System design of an Engine Control System ECS featuring Engine Control Unit ECU 9	16	2.4.2.2 Signal sequence on engine starting	110
2.1.2 Engine management and monitoring	19	2.4.2.3 Engine stop – Normal	111
2.1.3 Component roles and configurations in the Engine Control System ECS	25	2.4.2.4 Safety stop	112
2.1.4 Bus topology	26	2.4.2.5 Emergency stop	113
2.1.5 Device installation locations – Engine Control System ECS	27	2.4.2.6 Emergency engine start (Override mode)	116
2.1.6 Scope of supply – Engine-related electronics	28	2.4.2.7 Engine start and engine stop – Parameters and process variables	117
2.1.7 Exhaust Gas Aftertreatment	29	2.4.3 DBR/MCR power limitation – Functional description	120
2.1.7.1 Exhaust gas aftertreatment – Overview	29	2.4.4 Torque limitation – Functional description	123
2.1.7.2 Exhaust pipework – SCR system	33	2.4.5 Load reserve – Functional description	126
2.1.7.3 RA dosing system – Overview	34	2.4.6 Manual turning – Functional description	127
2.1.7.4 Reducing agent dosing cabinet (FlexBox) – Internal design	38	2.4.7 Overspeed test – Functional description	128
2.1.7.5 SCR system (FlexBox) – Design data	42	2.4.8 Setpoint speed generation – Functional description	130
2.1.7.6 Electronic components – SCR system	43	2.4.9 Cylinder cutout – Functional description	142
2.2 Sensor and Actuator installation Locations	47	2.4.10 Level sensor test – Functional description	144
2.2.1 Engine-mounted sensors and actuators – Overview	47	2.4.11 Blankshot – Functional description	145
2.2.2 Sensors and actuators for exhaust gas aftertreatment – Overview	52	2.4.12 Pressure regulating valve Y45 / K45 – Functional description	146
2.3 Cabling	56	2.4.13 Charge-Air System and Exhaust System	147
2.3.1 Engine wiring diagrams – Overview	56	2.4.13.1 Turbocharger sequencing – Functional description	147
2.3.2 Engine wiring harness – Overview	57	2.4.13.2 Turbocharging system	149
2.3.3 Wiring harness overview	58	2.4.14 Exhaust Gas Aftertreatment	155
2.3.4 Engine device wiring harness	60	2.4.14.1 SCR – Operating principle	155
2.3.5 Battery-charging generator wiring harness	66	2.4.14.2 NO _x reduction in exhaust flow	157
2.3.6 Sensors, Actuators and Injectors on Engine Wiring Harness	67	2.4.14.3 Exhaust gas aftertreatment system FlexBox – Relevant parameters and process variables	158
2.3.6.1 Wiring harness 12V2000Mx7	67	3 Components	
		3.1 Engine Interface Module EIM	161
		3.1.1 Engine Interface Module EIM – Structure and function	161
		3.1.2 Power supply concept	163
		3.1.3 Connection variants	166

3.1.4	Signal – Overview	170	3.7.1.4.1	Crankshaft speed sensor 80 to 2800 rpm	270
3.1.5	External starting air pressure sensor	176	3.7.1.4.2	Camshaft speed sensor 80 to 2800 rpm	273
3.1.6	EIM status words	177	3.7.1.4.3	Exhaust turbocharger speed sensor 50 to 100000 rpm	276
3.1.7	EIM 10 – Technical data	183	3.7.1.5	Level Sensors	279
3.2	Engine Control Unit ECU 9	185	3.7.1.5.1	Level sensor	279
3.2.1	Engine Control Unit ECU 9 – Function	185	3.7.1.5.2	Level sensor	283
3.2.2	Engine Control Unit ECU 9 – Mechanical design	187	3.7.2	Actuators	287
3.2.3	Plant and engine inputs and outputs ECU 9 – Circuit design	189	3.7.2.1	Injectors	287
3.2.4	ECU 9 inputs and outputs – Engine	201	3.7.2.2	HP pump	289
3.2.5	ECU 9 inputs and outputs – Plant	205	3.8	Exhaust Gas Aftertreatment System	290
3.2.6	ECU 9 – Connector X1	211	3.8.1	Sensors	290
3.2.7	ECU 9 – Connector X2	213	3.8.1.1	Sensors – Overview	290
3.2.8	ECU 9 – Connector X3	216	3.8.2	Actuators	293
3.2.9	ECU 9 – Technical data	219	3.8.2.1	SCR elements	293
3.2.10	ECU 9 – Operating voltage	221	3.8.2.2	Pre-feed module	294
3.3	Engine Governor Extension Unit EXU	224	3.8.2.3	Supply unit	295
3.3.1	Engine Controller Extension Unit EXU – Function	224	3.8.2.4	Dosing unit	296
3.3.2	EXU – Mechanical design	225	4	Repair	
3.3.3	EXU – Technical data	227	4.1	Standard Tools and Special Tools	297
3.3.4	Technical data EXU – Additional I/O specifications	230	4.1.1	Universal test adapter – Overview	297
3.4	Engine Monitoring Unit EMU	233	4.1.2	Sensor/actuator assignment – Adapter cables	300
3.4.1	Engine Monitoring Unit EMU 9 – Design and functions	233	4.1.3	Measuring adapter for control unit – Overview	301
3.4.2	Engine Monitoring Unit (EMU) – Technical data	234	4.1.4	Special test leads for connectors X2 and X3 of Engine Control Unit ECU	304
3.5	Distributed Control Module DCM	235	4.1.5	Diagnostic tools	305
3.5.1	Control unit DCM – Overview	235	4.1.6	Diagnostic System DiaSys®	306
3.5.2	Pin assignment of connectors on control unit DCM	237	4.1.6.1	The DiaSys® program	306
3.6	Electronic Engine Identification Label EIL	241	4.1.6.2	Parameters	310
3.6.1	Electronic Engine Identification Label EIL	241	4.1.6.2.1	EIM – Parameter setting	310
3.7	Sensors, Actuators and Injectors on the Engine	244	4.1.6.2.2	Battery-charging generator monitoring – Parameters	311
3.7.1	Sensors	244	4.1.6.2.3	Starter control – Parameters	313
3.7.1.1	Measuring ranges and application scopes	244	4.2	Troubleshooting	316
3.7.1.2	Pressure Sensors	245	4.2.1	Sensors, Actuators and Injectors on the Engine	316
3.7.1.2.1	Pressure sensor	245	4.2.1.1	Pressure Sensors	316
3.7.1.2.2	Pressure sensor 0 to 6 bar(g)	248	4.2.1.1.1	Connectors of pressure sensor – Visual inspection	316
3.7.1.2.3	Pressure sensor 0.5 to 6 bar(a)	251	4.2.1.2	Temperature Sensors	317
3.7.1.2.4	Pressure sensor -70 to 70 mbar(g)	254	4.2.1.2.1	Connectors of temperature sensor (PT100) – Visual inspection	317
3.7.1.2.5	High-pressure sensor 1800/2400/2700 bar(g)	257	4.2.1.2.2	Connectors of temperature sensor (PT1000) – Visual inspection	318
3.7.1.3	Temperature Sensors	261	4.2.1.3	Level Sensors	319
3.7.1.3.1	Temperature sensor -40 to 150 °C	261	4.2.1.3.1	Connectors of level sensor – Visual inspection	319
3.7.1.3.2	Temperature sensor -40 to 150 °C	264	4.2.1.4	Actuators	320
3.7.1.3.3	Temperature sensor -40 to 900 °C	266	4.2.1.4.1	Socket contacts in connector X3 – Jumpering	320
3.7.1.4	Speed Sensors	270			

4.2.1.4.2	Injector – Check	322	4.3	Fault Messages	367
4.2.1.4.3	Test: Connectors on wiring harness and at valve end (Y45)	323	4.3.1	Fault messages – Key	367
4.2.1.4.4	Test: Connector on wiring harness and at valve (Y27.1, Y27.2, Y35, Y56)	324	4.3.2	Fault messages	368
4.2.1.4.5	Test: Connectors on wiring harness and valve ends (M52)	325	4.3.3	Engine Identification label EIL – Fault messages	417
4.2.1.4.6	Test: Connectors on wiring harness and control block ends (M8)	326	4.3.4	Engine restart following automatic safety shutdown	418
4.2.2	Cabling	327	4.4	Diagnosis and Programming	419
4.2.2.1	Wiring harness – Troubleshooting	327	4.4.1	Engine Interface Module EIM	419
4.2.2.2	Connector – Troubleshooting	328	4.4.1.1	Engine Interface Module EIM – Diagnostic features	419
4.2.2.3	Visual inspection: Check connector sockets and connectors for mechanical and corrosive damage	330	4.4.2	Engine Control Unit ECU	421
4.2.2.4	Engine cabling – Check	334	4.4.2.1	ECU-ITS off-line function	421
4.2.2.5	Visual inspection: Check injector wiring for external damage	335	4.4.2.2	Engine Control Unit ECU 9 – Test functions	423
4.2.2.6	Test: Continuity of injector wiring	338	4.4.3	Engine Governor Extension Unit EXU	425
4.2.2.7	Test: Electrical short circuit in injector wiring	340	4.4.3.1	Test: Engine Controller Extension Unit EXU self-test	425
4.2.2.8	Test: Short circuit to ground in injector wiring	341	4.4.4	Distributed Control Module DCM	427
4.2.2.9	Test: Electrical short circuit in wiring on injector	342	4.4.4.1	Control unit DCM – Diagnostic options	427
4.2.3	Exhaust Gas Aftertreatment System	343	4.4.4.2	Sockets and connectors – Visual inspection for mechanical and corrosive damage	429
4.2.3.1	Cabling	343	4.5	Measuring and Simulation Procedure	432
4.2.3.1.1	Wiring harnesses of SCR system – Overview for visual inspections	343	4.5.1	Wiring (General) for Engine/Gearbox/Unit	432
4.2.3.1.2	Wiring harness of SCR system – Visual inspection	344	4.5.1.1	Test: Short circuit to ground – Sensor-side / actuator-side	432
4.2.3.1.3	Wiring harnesses of RA dosing cabinets – Visual inspection	347	4.5.1.2	Measurement: Supply voltage at connector on wiring harness-side - without sensor	433
4.2.3.1.4	Wiring harness -X41/-W041 – Visual inspection	349	4.5.1.3	Test: Electrical short circuit	434
4.2.3.1.5	Power supply adapter cable -WDS6 – Visual Inspection	351	4.5.1.4	Test: Short circuit to ground – Wiring harness-side	435
4.2.3.1.6	Adapter cable W_XWA13 for SCR system – Visual inspection	353	4.5.1.5	Test: Continuity	436
4.2.3.1.7	Connector and socket XWA1/2 – Visual inspection for damage and corrosion	355	4.5.2	Pressure Sensors	438
4.2.3.1.8	Connector M81.1, M81.2 – Visual inspection	359	4.5.2.1	Test: Plausibility of measured value – Pressure sensor (relative pressure sensor 6 bar)	438
4.2.3.1.9	Connector M80.nX1, M80.nX2 – Visual inspection	360	4.5.2.2	Test: Plausibility of measured value – Pressure sensor (relative pressure sensor 10 bar)	440
4.2.3.1.10	Connector M81.n – Visual inspection	362	4.5.2.3	Test: Plausibility of measured value – Pressure sensor (relative pressure sensor 2500 bar)	442
4.2.3.2	Temperature Sensors	364	4.5.2.4	Test: Plausibility of measured value of pressure sensor (relative pressure sensor 15 bar)	444
4.2.3.2.1	Connectors of temperature sensor (PT200) – Visual inspection	364	4.5.2.5	Test: Plausibility of measured value of pressure sensor (pressure sensor 70 mbar relative)	446
4.2.3.3	Pressure Sensors	365	4.5.2.6	Test: Plausibility of measured value of pressure sensor (absolute pressure sensor 6 bar)	448
4.2.3.3.1	Connector B91.7, B91.8 – Visual inspection	365	4.5.3	Temperature Sensors	450
4.2.3.4	Special Sensors	366			
4.2.3.4.1	NOx sensor B88 – Troubleshooting	366			

4.5.3.1 Measurement: Voltage at connected temperature sensor	450	4.6.1.4.7 Injector replacement – With IIG	520
4.5.3.2 Measurement: Resistance at temperature sensor	452	4.6.1.4.8 Resetting CDC parameter and entering IIG with DiaSys®	524
4.5.4 Engine alarms – Simulation	454	4.6.1.4.9 Pressure regulating valve Y45 – Replacement	525
4.5.5 Sensor simulation	457	4.6.1.4.10 Solenoid valve to relieve charge-air pressure Y56 – Replacement	527
4.5.6 Simulator – Overview	458	4.6.2 Engine Interface Module EIM	530
4.5.7 Simulation of pressures and temperatures	464	4.6.2.1 Removal and installation Engine Interface Module (EIM)	530
4.5.8 Simulation of speeds	466	4.6.3 Engine Control Unit ECU	531
4.5.9 Simulation of level signals with a sensor	467	4.6.3.1 Engine Control Unit ECU 9 – Removal and installation	531
4.6 Repair Work	468	4.6.3.2 Engine Control Unit ECU 9 with Engine Controller Extension Unit EXU – Removal and installation	532
4.6.1 Sensors, Actuators and Injectors on the Engine	468	4.6.4 Engine Monitoring Unit EMU	533
4.6.1.1 Pressure Sensors	468	4.6.4.1 Extension unit EXU-EMU 9 – Removal and installation	533
4.6.1.1.1 Pressure sensors B5.1 and B5.3 – Replacement	468	4.6.5 Electronic Engine Identification Label EIL	534
4.6.1.1.2 Pressure sensors B5.2* (*optional) and B5.8 – Replacement	470	4.6.5.1 EIL configuration in case of replacement	534
4.6.1.1.3 Pressure sensor B10 – Replacement	472	4.6.5.2 EIL – Configuration	535
4.6.1.1.4 Pressure sensor B16 – Replacement	474	4.6.6 Distributed Control Module DCM	536
4.6.1.1.5 Pressure sensors B21 and B54 – Replacement	476	4.6.6.1 Distributed Control Unit DCM – Checking plug connections	536
4.6.1.1.6 Pressure sensor B34 – Replacement	478	4.6.6.2 Distributed Control Module (DCM) – Replacement	537
4.6.1.1.7 Pressure sensor B48 – Replacement	480	4.6.6.3 Distributed Control Module (DCM) – Electrical connection	540
4.6.1.1.8 Pressure sensor B50 – Replacement	482	4.6.7 Exhaust Gas Aftertreatment System	541
4.6.1.2 Temperature Sensors	484	4.6.7.1 Cabling	541
4.6.1.2.1 Temperature sensor B3 – Replacement	484	4.6.7.1.1 Wiring harnesses of SCR system – Removal	541
4.6.1.2.2 Temperature sensors B4.21 and B4.22 – Replacement	486	4.6.7.1.2 Wiring harnesses of SCR system – Installation	542
4.6.1.2.3 Temperature sensors B6.1 and B6.2* (*optional) – Replacement	488	4.6.7.1.3 Wiring harnesses of RA dosing cabinets – Removal	543
4.6.1.2.4 Temperature sensor B7 – Replacement	490	4.6.7.1.4 Wiring harnesses of RA dosing cabinets – Installation	545
4.6.1.2.5 Temperature sensor B9 – Replacement	492	4.6.7.2 Pressure Sensors	547
4.6.1.2.6 Temperature sensor B33 – Replacement	494	4.6.7.2.1 Exhaust gas pressure sensors – Checking and cleaning measuring lines	547
4.6.1.3 Level Sensors	496	4.6.7.2.2 Pressure sensor B91.7 – Replacement	549
4.6.1.3.1 Level sensors – Removal and installation	496	4.6.7.2.3 Pressure sensor B91.8 – Replacement	551
4.6.1.3.2 Level sensor F33 / B533 – Replacement	497	4.6.7.3 Temperature Sensors	553
4.6.1.3.3 Level sensor F46 / B546 – Replacement	499	4.6.7.3.1 Temperature sensor B85.5 – Replacement	553
4.6.1.3.4 Connecting cable to level sensor – Removal	501	4.6.7.3.2 Temperature sensor B85.6 – Replacement	555
4.6.1.3.5 Connecting cable to level sensor – Installation	502	4.6.7.4 Special Sensors	557
4.6.1.4 Actuators	503	4.6.7.4.1 NOx sensor – Replacement	557
4.6.1.4.1 Pressure regulating valve for wastegate control M52 – Replacement	503	4.6.7.4.2 Ammonia (NH3) sensor B100.2 – Replacement	560
4.6.1.4.2 HP pump – Control block replacement	506		
4.6.1.4.3 Solenoid valve Y35 to admit raw water to the second charge-air cooling stage (TB) – Replacement	510		
4.6.1.4.4 Cylinder head cover – Removal and installation	513		
4.6.1.4.5 Air filter – Removal and installation	514		
4.6.1.4.6 Injector – Removal and installation	515		

5 Appendix A		7.2 Index	653
5.1 Contact person / Service partner	562	8 Drawings	
5.2 Abbreviations	563	8.1 Wiring diagramm 12V2000Mx7 Maximum scope	659
6 Appendix B		8.2 Wiring diagramm 16V2000Mx7 Maximum scope	671
6.1 Assembly instructions SCR-system insulation mats	571	8.3 Wiring diagramm V2000Mx7 AGN WDS6	685
6.2 Assembly sequence for SCR-system insulation mats	575	8.4 Wiring diagramm V2000Mx7 AGN W_XWA13	689
7 Appendix C		8.5 Wiring diagramm V2000Mx7 AGN SCR-System	695
7.1 Standard Tools and Special Tools	643	8.6 Wiring diagramm V2000Mx7 AGN X41_W041	701

1 Safety

1.1 Important provisions for electronic products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Assembly, maintenance, and repair without ESD („Electro Static Discharge“) equipment and ESD work station
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

1.2 Intended use of electronic products

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/Rolls-Royce Solutions contact/Service partner)
- In the original configuration of the delivery or in a configuration approved in writing by the manufacturer
- In compliance with all safety regulations and in adherence with all safety and warning notices in this manual
- Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

1.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.