

System Documentation

Electronic Equipment

Engine Control System ECS

- Engine Control Unit ECU 9
- Power Output Module POM

Application: Rail

- 12V1600R50

E532465/00E



Power. Passion. Partnership.

Preliminary Edition !

Engine model	kW/cyl.	Application group
12V1600R50	58 kW/cyl.	2A, continuous operation, unrestricted

Table 1: Applicability

© 2018 Copyright MTU Friedrichshafen GmbH

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of MTU Friedrichshafen GmbH. This particularly applies to its reproduction, distribution, editing, translation, micro-filming and storage or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. MTU Friedrichshafen GmbH reserves the right to change, delete or supplement the information provided as and when required.

Preliminary Edition!

Table of Contents

1	Safety		2.6.1	Installation Positions of Sensors	84
1.1	Important provisions for all products	5	2.6.1.1	Sensors and actuators - Installation locations	84
1.2	Correct use of all products	7	2.6.2	Sensors	90
1.3	Personnel and organizational requirements	8	2.6.2.1	Pressure Sensors	90
1.4	Initial start-up and operation - Safety regulations	9	2.6.2.1.1	Pressure sensor 0.5 to 1.5 bar(a)	90
1.5	Safety regulations for assembly, maintenance, and repair work	11	2.6.2.1.2	Pressure sensor 0.5 to 6 bar(a)	94
1.6	Fire and environmental protection, fluids and lubricants	15	2.6.2.1.3	Pressure sensor 0 to 10 bar(g)	98
1.7	Standards for warning notices in the text and highlighted information	17	2.6.2.1.4	Pressure sensor 0 to 15 bar(g)	102
2	Design and Function		2.6.2.1.5	Rail pressure high-pressure sensor	106
2.1	System Layout	18	2.6.2.1.6	Pressure sensor -70 to 70 mbar(g)	110
2.1.1	Engine management system ECS with Engine Control Unit ECU 9 - System design	18	2.6.2.2	Temperature Sensors	114
2.1.2	Device installation locations - Engine Control System ECS	22	2.6.2.2.1	Temperature sensor -40 to 150 °C	114
2.1.3	Scope of supply - MTU	23	2.6.2.2.2	Temperature sensor -40 to 900 °C	117
2.2	Devices and Functions	24	2.6.2.3	Speed Sensors	121
2.2.1	Engine Control Unit ECU 9 - Function	24	2.6.2.3.1	Speed sensor	121
2.2.2	Power Output Module - Design and functionPower Output Modul POM	26	2.6.2.3.2	Speed sensor	124
2.2.3	Engine Identification Label EIL - Design and function	27	2.6.2.4	Level Sensors	127
2.3	Design and Technical Data of Devices	28	2.6.2.4.1	Level sensor	127
2.3.1	ECU 9 - Technical data	28	2.6.2.5	Special Sensors	131
2.3.2	ECU 9 - Mechanical design	30	2.6.2.5.1	Lambda sensor	131
2.3.3	Technical data ECU 9 - Additional I/O specifications	32	2.6.2.5.2	TriCAN sensor	134
2.3.4	Technical data - Additional operating voltage specifications	37	2.6.2.5.3	NOx sensor	139
2.3.5	ECU 9 - Operating voltage	38	2.6.3	Actuators	141
2.3.6	POM - Technical data	41	2.6.3.1	Injectors	141
2.4	Interfaces	43	2.6.3.2	Turbine bypass flap	144
2.4.1	Plant and engine inputs and outputs ECU 9 - Circuit design	43	2.6.3.3	Donor cylinder flap	147
2.4.2	Engine inputs and outputs - ECU 9	51	2.6.3.4	Shutoff cylinder flap	149
2.4.3	Plant inputs and outputs - ECU 9	55	2.7	Software	152
2.4.4	POM wiring harness	62	2.7.1	Software of the Engine Control Unit	152
2.4.5	Connector of Power Output Module POM	64	2.8	Functions	154
2.4.6	SAE J1939 - Introduction	66	2.8.1	Wheel spin	154
2.5	Cabling	68	2.8.2	Emergency speed demand voltage	156
2.5.1	Engine wiring harness Series 1600	68	2.8.3	Engine speed	157
2.5.2	Injector wiring harness Series 1600	78	2.8.4	Engine load signal	158
2.5.3	Plant cable W001 - ECU 9 at connector X1	81	2.8.5	Engine stop	159
2.6	Sensors, Actuators and Injectors on the Engine	84	2.8.6	Cylinder cutout off	160
			2.8.7	Forced idle	161
			2.8.8	Setpoint speed increase (braking)	162
			2.8.9	Engine start	163
			2.8.10	Safety system override	164
			2.8.11	Stop pushbutton	165
			2.8.12	Engine speed demand frequency	166
			2.8.13	Contactor negative On	167
			2.8.14	Emergency stop	168
			2.8.15	Combined red alarm	169
			2.8.16	Combined yellow alarm	170
			2.8.17	Starter On	171
			2.8.18	Cooling time	172
			2.8.19	Start interlock	174
			2.8.20	Speed limitation depending on coolant temperature	175
			2.8.21	Engine Cold Operation	177

Preliminary Edition !

2.8.22	Speed demand setting via J1939	178	4.2.4.9	Injector exchange - With IIG	211
2.8.23	Speed demand setting in "Emergency mode"	180	4.2.4.10	Reset DOC and/or DPF	215
3 Operation			4.2.5	Fault Code List	217
3.1	Starting the engine in manual mode	186	4.2.5.1	General information about fault codes	217
3.2	Emergency stop	187	4.2.5.2	Fault messages - ECS V4000Rx4	218
4 Repair			4.3	Measuring and Simulation Procedure	256
4.1	Diagnostic tools	188	4.3.1	Engine alarms - Simulation	256
4.2	Diagnosis and Programming	189	4.3.2	Simulation of pressures and temperatures	263
4.2.1	Engine Control Unit ECU 9 - Self-testing	189	4.3.3	Simulation of speeds	265
4.2.2	Engine Control Unit ECU 9 - Test functions	190	4.3.4	Simulation of level signals with a sensor	266
4.2.3	Power Output Module (POM), Integrated Test System (ITS)	192	4.4	Repair Work	267
4.2.4	Diagnostic System DiaSys®	193	4.4.1	Engine Control Unit ECU 9 - Removal and installation	267
4.2.4.1	The DiaSys® program	193	4.4.2	Engine wiring - Check	268
4.2.4.2	Engine governor - Loading	197	4.4.3	Power Output Module (POM) - Replacement	269
4.2.4.3	Servomotor - Calibration learning run	200	5 Appendix A		
4.2.4.4	Lambda sensor - Measured value range	202	5.1	MTU Contact/Service Partners	271
4.2.4.5	Lambda sensor - Resetting	203	5.2	Abbreviations	272
4.2.4.6	Lambda sensor - Manual calibration	205	6 Appendix B		
4.2.4.7	General information on injector functions	207	6.1	Index	277
4.2.4.8	Injector test	208			

1 Safety

1.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by MTU come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emission specifications and emission label

Responsibility for compliance with emission regulations

Modification or removal of any mechanical/electronic components or the installation of additional components including the execution of calibration processes that might affect the emission characteristics of the product are prohibited by emission regulations. Emission-related components must only be serviced, exchanged or repaired if the components used for this purpose are approved by the manufacturer.

Noncompliance with these specifications will invalidate the design type approval or certification issued by the emissions regulation authorities. The manufacturer does not accept any liability for violations of the emission regulations.

The product must be operated over its entire life cycle according to the conditions defined as "Intended use" (→ Page 7).

Emission certification applicable to engines with EPA Nonroad Tier 4 emission certification in accordance with 40 CFR 1039

Extract from the standard:

Failing to follow these instructions when installing a certified engine in a piece of nonroad equipment violates federal law (40 CFR 1068.105(b)), subject to fines or other penalties as described in the Clean Air Act.

Extract from the standard:

If you install the engine in a way that makes the engine's emission control information label hard to read during normal engine maintenance, you must place a duplicate label on the equipment, as described in 40 CFR 1068.105.

When fitting the second label, the requirements of 40 CFR 1068.105(c) must be followed and observed. This paragraph describes the process for requesting and fitting the label, the documentation obligations and storage obligations for the required documents.

Preliminary Edition !

Replacing components with emission labels

On all MTU engines fitted with emission labels, these labels must remain on the engine throughout its operational life.

Exception: Engines used exclusively in land-based, military applications other than by US government agencies.

Please note the following when replacing components with emission labels:

- The relevant emission labels must be affixed to the spare part.
- Emission labels shall not be transferred from the replaced part to the spare part.
- The emission labels must be removed from the replaced part and destroyed.

1.2 Correct use of all products

Correct use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/MTU contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found on the websites:

- For drive systems: <http://www.mtu-online.com>
- For power generation: <http://www.mtuonsiteenergy.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

1.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the descriptions of the individual activities.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of Chemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.

1.4 Initial start-up and operation – Safety regulations

Safety regulations for initial start-up

Install the product correctly and carry out acceptance in accordance with the manufacturer's specifications before putting the product into service. All necessary approvals must be granted by the relevant authorities and all requirements for initial startup must be fulfilled.

Whenever the product is subsequently taken into operation ensure that:

- All personnel is clear of the danger zone surrounding moving parts of the machine.
Electrically-actuated linkages may be set in motion when the Engine Control Unit (governor) is switched on.
- All maintenance and repair work has been completed.
- All loose parts have been removed from rotating machine components.
- All safeguards are in place.
- All components must be properly grounded. Ground separately by means of a grounding stake as necessary.
- No persons wearing pacemakers or any other technical body aids are present.
- The service room is adequately ventilated.
- In the first few hours of operation, the product emits gases as a result of smoldering e.g. lacquers or oil. These gases may be hazardous to health. Always wear respiratory protection in the operating room during this period.
- The exhaust system is leak-tight and that the gases are vented to atmosphere.
- The product must be free of any damage, this applies in particular to lines and cabling.
- Protect battery terminals, generator terminals or cables against accidental contact.
- Check that all connections have been correctly allocated e.g. +/- polarity, fuel line/reduction agent line, supply/return.

Immediately after putting the product into operation, make sure that all control and display instruments as well as the monitoring, signaling and alarm systems work properly.

Smoking is prohibited in the area of the product.

Safety regulations during operation

The operator must be familiar with the control and display elements.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be permanently observed with regard to present operating status, violation of limit values and warning or alarm messages.

Malfunctions and emergency stop

Practice emergency procedures, especially emergency stopping, at regular intervals.

Take the following steps if any system malfunctions are detected or signaled by the system:

- Inform supervisor(s) in charge.
- Analyze the message.
- Respond by taking any necessary emergency action, e.g. emergency stop.

After a safety shutdown, the engine must only be started after the cause of the shutdown has been eliminated.

Contact Service if the root cause of the malfunction cannot be clearly identified.

Operation

Do not remain in the operating room when the product is running unless absolutely necessary. Keep your stay as short as possible.

Keep a safe distance away from the product if possible. Do not touch the product unless expressly instructed to do so following a written procedure.

Preliminary Edition !

Do not inhale the exhaust gases of the product.

The following requirements must be fulfilled before the product is started:

- Wear ear protectors.
- Mop up any leaked or spilled fluids and lubricants immediately or soak up with a suitable binding agent.

Operation of electrical equipment

When electrical equipment is in operation, certain components of these appliances are electrically live.

Follow the applicable operating and safety instructions when operating the devices and heed warnings at all times.