

MTU_ValueService **Technical Documentation**

BlueLine
for Series 2000

ECS-5, MCS-5, RCS-5
Application Marine

Functional Description
Operating Instructions
Workshop Manual
Installation and Commissioning
Instructions

System documentation
E532226/01E



Printed in Germany

© 2010 Copyright MTU Friedrichshafen GmbH

This Publication is protected by copyright and may not be used in any way whether in whole or in part without the prior written permission of MTU Friedrichshafen GmbH. This restriction also applies to copyright, distribution, translation, microfilming and storage or processing on electronic systems including data bases and online services.

This handbook is provided for use by maintenance and operating personnel in order to avoid malfunctions or damage during operation.

Subject to alterations and amendments.

Commissioning Note

Important

Please complete and return the “Commissioning Note” card below to MTU Friedrichshafen GmbH.

The Commissioning Note information serves as a basis for the contractually agreed logistic support (warranty, spare parts, etc.).



Postcard
MTU Friedrichshafen GmbH
Technical Information Management
Dept. AST
88040 Friedrichshafen
GERMANY

Commissioning Note

Please use block capitals!



Engine No.:	MTU works order No.:
Engine model:	Date put into operation:
Installation site:	Vessel/type/class / Shipyard:
End user`s address:	
Remarks:	

**Commission-
ing Note**

1	General Provisions	11
1.1	Safety	11
1.1.1	General conditions	11
1.1.2	Personnel and organizational requirements	12
1.1.3	Safety requirements when working on the engine	13
1.1.4	Auxiliary materials, fire prevention and environmental protection	16
1.1.5	Conventions for safety instructions in the text	18
2	Functional Description	19
2.1	Product Summary	19
2.1.1	BlueLine system – Overview	19
2.1.2	BlueLine subsystems – Use	21
2.2	Subsystems	22
2.2.1	Remote Control System RCS-5	22
2.2.1.1	RCS-5 BlueLine – Overview	22
2.2.1.2	RCS-5 BlueLine – Use of devices	24
2.2.1.3	RCS-5 BlueLine – Main control stand 1	28
2.2.1.4	RCS-5 BlueLine – Main control stand 2	31
2.2.1.5	RCS-5 BlueLine – Slave control stand	32
2.2.2	Monitoring and Control System MCS-5	34
2.2.2.1	MCS-5 BlueLine – Overview	34
2.2.2.2	MCS-5 BlueLine – Use of the devices	36
2.2.2.3	MCS-5 BlueLine – Main control stand	39
2.2.2.4	MCS-5 BlueLine – Slave control stand	42
2.2.3	Engine Control System ECS-5	43
2.2.3.1	ECS-5 BlueLine – Overview	43
2.2.3.2	ECS-5 BlueLine – Use of devices	47
3	Operating Instructions	51
3.1	Monitoring and Control System MCS-5	51
3.1.1	Controls and Displays	51
3.1.1.1	MCS-5 – Controls and displays	51
3.1.1.2	LOP display – Overview of screen pages	55
3.1.2	Operation	65
3.1.2.1	Overall BlueLine system – Switching on	65
3.1.2.2	Brightness of indicators/instruments – Adjustment	66
3.1.2.3	Engine start	67
3.1.2.4	Override function – Activation	68
3.1.2.5	Override function – Deactivation	69
3.1.2.6	Engine shutdown	70
3.1.2.7	Emergency engine shutdown	71
3.1.2.8	Overall system – Switching off	72
3.2	Remote Control System RCS-5	73
3.2.1	Controls and Displays (Standard Version)	73
3.2.1.1	Command unit for one shaft	73
3.2.1.2	Command unit for two shafts	75
3.2.1.3	Command unit for three shafts	77
3.2.1.4	Command unit for four shafts	79

3.2.2	Controls and Displays (Special Version).....	81
3.2.2.1	Operating station and rotary encoder modules	81
3.2.3	Operation.....	83
3.2.3.1	Initial command – Allocation.....	83
3.2.3.2	Command transfer.....	84
3.2.3.3	Operation.....	85
3.2.3.4	Engine speed – Change without engagement.....	86
3.2.3.5	Single Control Lever mode (SCL) – Activation.....	87
3.2.3.6	Single Control Lever mode (SCL) – Deactivation.....	88
3.2.3.7	Trolling mode – Activation.....	91
3.2.3.8	Trolling mode – Deactivation.....	92
3.3	Engine Control System ECS-5.....	93
3.3.1	Controls and Displays.....	93
3.3.1.1	Local Operating Panel LOP.....	93
3.3.1.2	Local Operating Station LOS and Local Operating Panel LOP – Controls and displays.....	94
3.3.2	Normal Operation: LOS or LOP with Display.....	96
3.3.2.1	Engine – Switching ready for operation.....	96
3.3.2.2	Local mode – Activation.....	97
3.3.2.3	Engine – Start	98
3.3.2.4	Local mode – Gearbox engagement/disengagement.....	99
3.3.2.5	Local mode – Engine speed adjustment.....	100
3.3.2.6	Engine – Shutdown	101
3.3.2.7	Local mode – Deactivation	102
3.3.2.8	Engine start – Interlock	103
3.3.2.9	Engine – Emergency shutdown.....	104
3.3.3	Operation during Servicing: LOP without Display	105
3.3.3.1	Engine – Start	105
3.3.3.2	Engine – Shutdown	106
3.3.3.3	Engine start – Interlock	107
3.3.3.4	Engine – Emergency shutdown.....	108
3.4	Troubleshooting.....	109
3.4.1	Faults in BlueLine system.....	109
3.4.2	Troubleshooting.....	110
3.4.3	Alarms – General information.....	114
3.4.4	Single-point alarms – Acknowledgment.....	115
3.4.5	Fault messages on display of LOP or LOS.....	116
3.4.6	Fault indication on printed circuit board MPU 29.....	121
3.4.7	Fault messages of Engine Control Unit ECU 4 for Series 2000 PLD (unit-pump system).....	126
3.5	Task Description.....	135
3.5.1	Wiring (General) for Engine/Gearbox/Unit.....	135
3.5.1.1	Engine wiring – Check	135
4	Workshop Manual.....	137
4.1	Task Description.....	137
4.1.1	Operating Tests.....	137
4.1.1.1	Test mode, BlueLine – Execution	137
4.1.1.2	Overspeed test	140

4.1.1.3	Emergency stop test	141
4.1.1.4	Cranking	142
4.1.2	Checks and Settings	143
4.1.2.1	LOP display DIS settings – Check	143
4.1.2.2	LOP display DIS – Setting	144
4.1.2.3	PIM 4 node number – Check	145
4.1.2.4	PIM 4 node number – Setting	146
4.1.2.5	Serial interface terminator plugs – Check	147
4.1.2.6	Jumper configuration of MCS-5 control unit – Check	149
4.1.2.7	CAN bus line resistance – Check	150
4.1.2.8	MPU 29 node address in LOP – Check	152
4.1.2.9	Control stand configuration in Local Operating Panel LOP – Check	153
4.1.2.10	Shaft number setting – Check	155
4.1.2.11	LOP power supply – Check	156
4.1.2.12	Jumper configuration of LOP – Check	158
4.1.2.13	GCU 2 jumper configuration – Check	160
4.1.2.14	GCU 3 jumper configuration – Check	161
4.1.2.15	GCU node number – Check	162
4.1.2.16	MPU 29 node address – Setting	163
4.1.2.17	CAN node configuration BlueLine	164
4.1.2.18	MPU 29 node address in LOP – Setting	165
4.1.3	Repair Work	166
4.1.3.1	PIM 4 cover – Removal	166
4.1.3.2	PIM 4 cover – Installation	167
4.1.3.3	Command unit – Replacement	168
4.1.3.4	Rotary encoder module – Replacement	169
4.1.3.5	Operating station – Replacement	170
4.1.3.6	Analog display instrument VDO OceanLine – Replacement	171
4.1.3.7	Lamp in analog display instrument VDO OceanLine – Replacement	172
4.1.3.8	Indicator lamp – Replacement	173
4.1.3.9	Indicator lamp – Removal	174
4.1.3.10	Indicator lamp – Installation	175
4.1.3.11	Contacting – Replacement	176
4.1.3.12	LED in pushbutton/switch – Replacement	177
4.1.3.13	LOP display DIS – Replacement	179
4.1.3.14	PIM 4 parameters – Reset	181
4.1.3.15	Fuse in control unit PIM 4 – Replacement	182
4.1.3.16	Control unit PIM 4 – Replacement	183
4.1.3.17	Printed circuit board in PIM cassette – Replacement	185
4.1.3.18	Fuse on printed circuit board in PIM cassette – Replacement	187
4.1.3.19	Printed circuit board MPU 29 – Removal	190
4.1.3.20	Printed circuit board MPU 29 – Installation	191
4.1.3.21	Printed circuit board MPU 29 – Replacement	192
4.1.3.22	Data module MEM on MPU 29 – Replacement	193
4.1.3.23	Data module MEM on MPU 29 – Transfer	194
4.1.3.24	LOP fuse – Replacement	195
4.1.3.25	LOP with display front flap – Replacement	197
4.1.3.26	LOP – Replacement	199
4.1.3.27	Local Operating Station LOS – Replacement	200
4.1.3.28	Gear Control Unit GCU – Replacement	201
4.1.4	Supplementary Technical Information	203

4.1.4.1	PIM 4 RCS – Internal design.....	203
4.1.4.2	Control unit PIM 4 MCS – Internal design.....	208
4.1.4.3	Local Operating Panel LOP – Design.....	214
4.1.4.4	Gear Control Unit GCU – Design.....	223
5	Installation and Commissioning Instructions.....	229
5.1	Installation.....	229
5.1.1	Preparation.....	229
5.1.1.1	Cable routes and openings between all installation locations – Check ..	229
5.1.1.2	Cables – Routing between installation locations.....	230
5.1.2	Mechanical Installation.....	232
5.1.2.1	PIM 4 module housing – Installation.....	232
5.1.2.2	OceanLine analog display instruments – Installation.....	233
5.1.2.3	Horn VDO – Installation.....	235
5.1.2.4	Indicator lamp – Installation.....	236
5.1.2.5	Illuminated pushbuttons/key switches – Installation.....	237
5.1.2.6	GCU – Installation.....	239
5.1.2.7	Terminal box X010 – Installation.....	241
5.1.2.8	LOP display DIS – Installation.....	242
5.1.2.9	LOP – Installation	244
5.1.2.10	LOS – Installation	246
5.1.2.11	Command unit ROS 11 – Installation	248
5.1.2.12	Command unit ROS 7 / ROS 9 – Installation.....	249
5.1.2.13	Rotary encoder modules ROS 10/P and ROS 10/S – Installation.....	251
5.1.2.14	Remote Operating Station ROS 10/T – Installation	252
5.1.3	Electrical Installation	254
5.1.3.1	HSK cable gland – Preparation.....	254
5.1.3.2	Terminal block – Preparation.....	255
5.1.3.3	PIM 4 cover – Removal.....	256
5.1.3.4	GCU 2 – Connection	257
5.1.3.5	GCU 3 – Connection	258
5.1.3.6	GCU – Pin assignment for non-MTU gearbox.....	260
5.1.3.7	Engine Control Unit ECU – Connection	262
5.1.3.8	Display instruments on main control stand – Connection.....	263
5.1.3.9	Controls and status indicator lamps on main control stands – Connection	264
5.1.3.10	Indicator lamps for single-point alarms – Connection.....	265
5.1.3.11	Devices on a slave control stand – Connection.....	266
5.1.3.12	PIM 4 MCS control unit – Connection	267
5.1.3.13	Terminal box X010 – Connection.....	270
5.1.3.14	Starter and battery-charging generator – Connection.....	273
5.1.3.15	Barring gear limit switch – Connection	276
5.1.3.16	LOP display (option), main control stand – Connection.....	277
5.1.3.17	LOP – Connection	278
5.1.3.18	Additional Yard signals (optional) – Connection.....	281
5.1.3.19	LOS – Connection	283
5.1.3.20	Command units on triple-shaft propulsion systems – Connection.....	284
5.1.3.21	Command units on propulsion systems with four shafts – Connection...	286
5.1.3.22	Command unit ROS 7 / ROS 9 – Connection.....	287
5.1.3.23	Rotary encoder module and remote operating station – Connection.....	288
5.1.3.24	PIM 4 RCS control unit – Connection.....	289

	5.1.3.25 RCS extension module – Installation in PIM 4 RCS	291
5.2	Initial Operation.....	292
	5.2.1 Preparation.....	292
	5.2.1.1 Checks prior to startup.....	292
	5.2.1.2 Operating voltage – Initial connection	293
	5.2.1.3 Supply voltage distribution – Check.....	295
	5.2.2 Settings.....	298
	5.2.2.1 CAN node configuration BlueLine.....	298
	5.2.2.2 Minidialog – Settings	299
	5.2.3 Tests.....	311
	5.2.3.1 Initial engine start-up at the service interface of the LOP.....	311
	5.2.3.2 Initial engine start-up at the display on a Local Operating Panel LOP or a Local Operating station LOS	313
	5.2.3.3 Initial engine start at MCS.....	315
	5.2.3.4 Speed control and clutch setting – Check.....	317
	5.2.3.5 Command transfer – Check (only when several control stands are instal- led)	318
	5.2.3.6 System reset.....	319
6	Appendix A.....	321
	6.1 Conversion tables.....	321
	6.2 Abbreviations.....	325
	6.3 MTU Contact/Service partners.....	328
7	Appendix B.....	329
	7.1 Special Tools	329
	7.2 Spare Parts	330
	7.3 Index.....	332

