

MTU_ValueService **Technical Documentation**

BlueLine
Series 2000 M92, M93

ECS-5, MCS-5, RCS-5
Application Marine

Functional Description
Operating Instructions
Workshop Manual
Installation and Commissioning
Instructions

System documentation
E532227/01E



Printed in Germany

© 2010 Copyright MTU Friedrichshafen GmbH

This Publication is protected by copyright and may not be used in any way whether in whole or in part without the prior written permission of MTU Friedrichshafen GmbH. This restriction also applies to copyright, distribution, translation, microfilming and storage or processing on electronic systems including data bases and online services.

This handbook is provided for use by maintenance and operating personnel in order to avoid malfunctions or damage during operation.

Subject to alterations and amendments.

Commissioning Note

Important

Please complete and return the “Commissioning Note” card below to MTU Friedrichshafen GmbH.

The Commissioning Note information serves as a basis for the contractually agreed logistic support (warranty, spare parts, etc.).



Postcard
MTU Friedrichshafen GmbH
Technical Information Management
Dept. AST
88040 Friedrichshafen
GERMANY

Commissioning Note

Please use block capitals!



Engine No.:	MTU works order No.:
Engine model:	Date put into operation:
Installation site:	Vessel/type/class / Shipyard:
End user`s address:	
Remarks:	

**Commission-
ing Note**

1	General Provisions	11
1.1	Safety	11
1.1.1	General conditions	11
1.1.2	Personnel and organizational requirements	12
1.1.3	Safety requirements when working on the engine	13
1.1.4	Auxiliary materials, fire prevention and environmental protection	16
1.1.5	Conventions for safety instructions in the text	18
2	Functional Description	19
2.1	Product Summary	19
2.1.1	BlueLine system – Overview	19
2.1.2	BlueLine subsystems – Use	21
2.2	Subsystems	22
2.2.1	Remote Control System RCS-5	22
2.2.1.1	RCS-5 BlueLine – Overview	22
2.2.1.2	RCS-5 BlueLine – Use of devices	24
2.2.1.3	RCS-5 BlueLine – Main control stand 1	28
2.2.1.4	RCS-5 BlueLine – Main control stand 2	31
2.2.1.5	RCS-5 BlueLine – Slave control stand	32
2.2.2	Monitoring and Control System MCS-5	34
2.2.2.1	MCS-5 BlueLine – Overview	34
2.2.2.2	MCS-5 BlueLine – Use of devices	36
2.2.2.3	MCS-5 BlueLine – Main control stand	39
2.2.2.4	MCS-5 BlueLine – Slave control stand	42
2.2.3	Engine Control System ECS-5	43
2.2.3.1	ECS-5 BlueLine – Overview	43
2.2.3.2	ECS-5 BlueLine – Use of devices	47
3	Operating Instructions	51
3.1	Monitoring and Control System MCS-5	51
3.1.1	Controls and Displays	51
3.1.1.1	MCS-5 – Controls and displays	51
3.1.1.2	LOP display – Overview of the screen pages	55
3.1.2	Operation	65
3.1.2.1	Overall BlueLine system – Switching on	65
3.1.2.2	Brightness of indicators/instruments – Adjustment	66
3.1.2.3	Engine start	67
3.1.2.4	Override function – Activation	68
3.1.2.5	Override function – Deactivation	69
3.1.2.6	Engine shutdown	70
3.1.2.7	Emergency engine shutdown	71
3.1.2.8	Overall system – Switching off	72
3.2	Remote Control System RCS-5	73
3.2.1	Controls and Displays (Standard Version)	73
3.2.1.1	Command unit for one shaft	73
3.2.1.2	Command unit for two shafts	75
3.2.1.3	Command unit for three shafts	77
3.2.1.4	Command unit for four shafts	79

3.2.2	Controls and Displays (Special Version).....	81
3.2.2.1	Operating station and rotary encoder modules	81
3.2.3	Operation.....	83
3.2.3.1	Initial command – Allocation.....	83
3.2.3.2	Command transfer.....	84
3.2.3.3	Operation.....	85
3.2.3.4	Engine speed – Change without engagement.....	86
3.2.3.5	Single Control Lever mode (SCL) – Activation.....	87
3.2.3.6	Single Control Lever mode (SCL) – Deactivation.....	88
3.2.3.7	Trolling mode – Activation.....	91
3.2.3.8	Trolling mode – Deactivation.....	92
3.3	Engine Control System ECS-5.....	93
3.3.1	Controls and Displays.....	93
3.3.1.1	Local Operating Panel LOP.....	93
3.3.1.2	Local Operating Station LOS and Local Operating Panel LOP – Controls and displays.....	94
3.3.2	Normal Operation: LOS or LOP with Display.....	96
3.3.2.1	Engine – Switching ready for operation.....	96
3.3.2.2	Local mode – Activation.....	97
3.3.2.3	Engine – Start	98
3.3.2.4	Local mode – Gearbox engagement/disengagement.....	99
3.3.2.5	Local mode – Engine speed adjustment.....	100
3.3.2.6	Engine – Shutdown	101
3.3.2.7	Local mode – Deactivation	102
3.3.2.8	Engine start – Interlock	103
3.3.2.9	Emergency engine shutdown.....	104
3.3.3	Operation during Servicing: LOP without Display	105
3.3.3.1	Engine – Start	105
3.3.3.2	Engine – Shutdown	106
3.3.3.3	Engine start – Interlock	107
3.3.3.4	Engine – Emergency shutdown.....	108
3.4	Troubleshooting.....	109
3.4.1	Faults in BlueLine system.....	109
3.4.2	Troubleshooting.....	110
3.4.3	Alarms – General information.....	114
3.4.4	Single-point alarms – Acknowledgment.....	115
3.4.5	Fault messages on the display of LOP or LOS	116
3.4.6	Fault indication on printed circuit board MPU 29.....	121
3.4.7	Fault messages of Engine Control Unit ECU 7 for Series 2000 CR.....	125
4	Workshop Manual.....	133
4.1	Task Description.....	133
4.1.1	Operating Tests.....	133
4.1.1.1	Test mode, BlueLine – Execution	133
4.1.1.2	Overspeed test	136
4.1.1.3	Emergency stop test	137
4.1.1.4	Cranking	138
4.1.2	Checks and Settings	139
4.1.2.1	LOP-DIS settings – Check.....	139
4.1.2.2	LOP display DIS – Setting	140

4.1.2.3	PIM 4 node number – Check.....	141
4.1.2.4	PIM 4 node number – Setting.....	142
4.1.2.5	Serial interface terminator plugs – Check.....	143
4.1.2.6	Jumper configuration of MCS-5 control unit – Check.....	145
4.1.2.7	CAN bus connections PIM 4 – Check.....	146
4.1.2.8	CAN bus line resistance – Check.....	148
4.1.2.9	MPU 29 node address – Check.....	150
4.1.2.10	Control stand configuration in Local Operating Panel LOP – Check.....	151
4.1.2.11	Shaft number setting – Check.....	153
4.1.2.12	LOP power supply – Check.....	154
4.1.2.13	Jumper configuration of LOP – Check.....	156
4.1.2.14	GCU 2 jumper configuration – Check.....	158
4.1.2.15	GCU 3 jumper configuration – Check.....	159
4.1.2.16	GCU node number – Check.....	160
4.1.2.17	MPU 29 node address – Setting.....	161
4.1.2.18	Configuration.....	162
4.1.2.19	MPU 29 node address in LOP – Setting.....	164
4.1.2.20	MPU 29 node address in LOP – Check.....	165
4.1.3	Repair Work.....	166
4.1.3.1	PIM 4 cover – Removal.....	166
4.1.3.2	PIM 4 cover – Installation.....	167
4.1.3.3	Command unit – Replacement.....	168
4.1.3.4	Rotary encoder module – Replacement.....	169
4.1.3.5	Operating station – Replacement.....	170
4.1.3.6	Analog display instrument VDO OceanLine – Replacement.....	171
4.1.3.7	Lamp in analog display instrument VDO OceanLine – Replacement.....	172
4.1.3.8	Indicator lamp – Replacement.....	173
4.1.3.9	Indicator lamp – Removal.....	174
4.1.3.10	Indicator lamp – Installation.....	175
4.1.3.11	Indicator lamp – LED replacement.....	176
4.1.3.12	Contactorm – Replacement.....	178
4.1.3.13	LED in pushbutton/switch – Replacement.....	179
4.1.3.14	LOP display DIS – Replacement.....	181
4.1.3.15	PIM 4 parameters – Reset.....	183
4.1.3.16	Fuse in control unit PIM 4 – Replacement.....	184
4.1.3.17	Control unit PIM 4 – Replacement.....	185
4.1.3.18	Printed circuit board in PIM cassette – Replacement.....	187
4.1.3.19	Fuse on printed circuit board in PIM cassette – Replacement.....	189
4.1.3.20	Printed circuit board MPU 29 – Removal.....	192
4.1.3.21	Printed circuit board MPU 29 – Installation.....	193
4.1.3.22	Printed circuit board MPU 29 – Replacement.....	194
4.1.3.23	Data module MEM on MPU 29 – Replacement.....	195
4.1.3.24	Data module MEM on MPU 29 – Transfer.....	196
4.1.3.25	LOP fuse – Replacement.....	197
4.1.3.26	LOP with display front flap – Replacement.....	199
4.1.3.27	LOP – Replacement.....	201
4.1.3.28	Local Operating Station LOS – Replacement.....	202
4.1.3.29	Gear Control Unit GCU – Replacement.....	203
4.1.4	Supplementary Technical Information.....	205
4.1.4.1	PIM 4 RCS – Internal design.....	205
4.1.4.2	Control unit PIM 4 MCS – Internal design.....	210

4.1.4.3	Local Operating Panel LOP – Design.....	216
4.1.4.4	Gear Control Unit GCU – Design.....	225
5	Installation and Commissioning Instructions.....	231
5.1	Installation.....	231
5.1.1	Preparation.....	231
5.1.1.1	Cable routes and openings between all installation locations – Check ..	231
5.1.1.2	Cables – Routing between installation locations.....	232
5.1.2	Mechanical Installation.....	234
5.1.2.1	PIM 4 module housing – Installation.....	234
5.1.2.2	OceanLine analog display instruments – Installation.....	235
5.1.2.3	Horn VDO – Installation.....	237
5.1.2.4	Indicator lamp – Installation.....	238
5.1.2.5	Illuminated pushbuttons/key switches – Installation.....	239
5.1.2.6	GCU – Installation.....	241
5.1.2.7	Terminal box X010 – Installation.....	243
5.1.2.8	LOP display DIS – Installation.....	244
5.1.2.9	LOP – Installation.....	246
5.1.2.10	LOS – Installation.....	248
5.1.2.11	Command unit ROS 11 – Installation.....	250
5.1.2.12	Command unit ROS 7 / ROS 9 – Installation.....	251
5.1.2.13	Rotary encoder modules ROS 10/P and ROS 10/S – Installation.....	253
5.1.2.14	Remote Operating Station ROS 10/T – Installation.....	254
5.1.3	Electrical Installation.....	256
5.1.3.1	HSK cable gland – Preparation.....	256
5.1.3.2	Terminal block – Preparation.....	257
5.1.3.3	PIM 4 cover – Removal.....	258
5.1.3.4	GCU 2 – Connection.....	259
5.1.3.5	GCU 3 – Connection.....	260
5.1.3.6	GCU – Pin assignment for non-MTU gearbox.....	262
5.1.3.7	Engine Control Unit ECU 7 – Connection.....	264
5.1.3.8	Display instruments on main control stand – Connection.....	265
5.1.3.9	Controls and status indicator lamps on main control stands – Connection.....	266
5.1.3.10	Indicator lamps for single-point alarms – Connection.....	267
5.1.3.11	Devices on a slave control stand – Connection.....	268
5.1.3.12	PIM 4 MCS control unit – Connection.....	269
5.1.3.13	Terminal box X010 – Connection.....	272
5.1.3.14	Starter and battery-charging generator – Connection.....	275
5.1.3.15	LOP display (option), main control stand – Connection.....	279
5.1.3.16	LOP – Connection.....	280
5.1.3.17	Additional Yard signals (optional) – Connection.....	283
5.1.3.18	LOS – Connection.....	285
5.1.3.19	Command units on triple-shaft propulsion systems – Connection.....	286
5.1.3.20	Command units on propulsion systems with four shafts – Connection...	288
5.1.3.21	Command unit ROS 7 / ROS 9 – Connection.....	289
5.1.3.22	Rotary encoder module and remote operating station – Connection.....	290
5.1.3.23	PIM 4 RCS control unit – Connection.....	291
5.1.3.24	RCS extension module – Installation in PIM 4 RCS.....	293
5.2	Initial Operation.....	294

5.2.1	Preparation.....	294
5.2.1.1	Checks prior to startup.....	294
5.2.1.2	Operating voltage – Initial connection	295
5.2.1.3	Supply voltage distribution – Check.....	297
5.2.2	Settings.....	300
5.2.2.1	CAN node configuration – BlueLine.....	300
5.2.2.2	Minidialog – Settings	301
5.2.3	Tests.....	313
5.2.3.1	Initial engine start-up at the service interface of the LOP.....	313
5.2.3.2	Initial engine start-up at the display on a Local Operating Panel LOP or a Local Operating station LOS	315
5.2.3.3	Initial engine start at MCS.....	317
5.2.3.4	Speed control and clutch setting – Check.....	319
5.2.3.5	Command transfer – Check (only when several control stands are instal- led)	320
5.2.3.6	System reset.....	321
6	Appendix A.....	323
6.1	Abbreviations.....	323
6.2	Conversion tables.....	326
6.3	MTU Contact/Service partners.....	330
7	Appendix B.....	331
7.1	Special Tools	331
7.2	Spare Parts	332
7.3	Index.....	334

