

System Documentation

Electronics

BlueLine

with Multifunction Display MFD

Series 2000 (unit-pump system) FPP

MDEC

Application: Marine

Functional Description

Operating Instructions

Workshop Manual

Installation and

Commissioning Instructions

E532775/03E



Power. Passion. Partnership.

© 2014 Copyright MTU Friedrichshafen GmbH

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of MTU Friedrichshafen GmbH. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. MTU Friedrichshafen GmbH reserves the right to change, delete or supplement the information provided as and when required.

Table of Contents

1	Safety	
1.1	Important requirements for all products	6
1.2	Personnel and organizational requirements	7
1.3	Safety requirements for startup and operation	8
1.4	Safety requirements for maintenance and repair work	9
1.5	Fire prevention and environmental protection, fluids and lubricants, auxiliary materials	12
1.6	Standards for safety notices in the text	14
2	General Information	
2.1	Engine side and cylinder designations	15
3	General Provisions	
4	Functional Description	
4.1	Product Summary	17
4.1.1	BlueLine system - Overview	17
4.1.2	BlueLine subsystems - Use	20
4.2	Subsystems	21
4.2.1	Remote Control System RCS-5	21
4.2.1.1	RCS-5 BlueLine - Overview	21
4.2.1.2	RCS-5 BlueLine - Use of devices	23
4.2.1.3	RCS-5 BlueLine - Main control stand 1	27
4.2.1.4	RCS-5 BlueLine - Main control stand 2	30
4.2.1.5	RCS-5 BlueLine - Slave control stand	31
4.2.2	Monitoring and Control System MCS-5	32
4.2.2.1	MCS-5 BlueLine - Overview	32
4.2.2.2	MCS-5 BlueLine - Use of the devices	35
4.2.2.3	RS422 PIM 4 serial interface as per MTU specifications	38
4.2.2.4	MCS-5 BlueLine - Main control stand	43
4.2.2.5	MCS-5 BlueLine - Slave control stand	46
4.2.3	Engine Control System ECS-5	47
4.2.3.1	ECS-5 BlueLine - Overview	47
4.2.3.2	ECS-5 BlueLine - Use of devices	51
5	Operating Instructions	
5.1	Monitoring and Control System MCS-5	55
5.1.1	Controls and Displays	55
5.1.1.1	MCS-5 - Controls and displays	55
5.1.1.2	LOP display - Overview of screen pages	59
5.1.1.3	Display MFD - Overview of screen pages	69
5.1.2	Operation	80
5.1.2.1	Overall BlueLine system - Switching on	80
5.1.2.2	Brightness of indicators/instruments - Adjustment	81
5.1.2.3	Engine - Start	82
5.1.2.4	Override function - Activation	83
5.1.2.5	Override function - Deactivation	84
5.1.2.6	Stopping the engine	85
5.1.2.7	Emergency engine shutdown	86
5.1.2.8	Overall system - Switching off	87
5.2	Remote Control System RCS-5	88
5.2.1	Controls and Displays (Standard Version)	88
5.2.1.1	Command unit for one shaft	88
5.2.1.2	Command unit for two shafts	90
5.2.1.3	Command unit for three shafts	92
5.2.1.4	Command unit for four shafts	94
5.2.2	Controls and Displays (Special Version)	96
5.2.2.1	Operating station and rotary encoder modules	96
5.2.3	Operation	98
5.2.3.1	Initial command - Allocation	98
5.2.3.2	Command transfer	99
5.2.3.3	Operation	100
5.2.3.4	Engine speed - Change without engagement	101
5.2.3.5	Single Control Lever mode (SCL) - Activation	102
5.2.3.6	Single Control Lever mode (SCL) - Deactivation	103
5.2.3.7	Trolling mode - Activation	105
5.2.3.8	Trolling mode - Deactivation	106
5.3	Engine Control System ECS-5	107
5.3.1	Controls and Displays	107
5.3.1.1	Local Operating Panel LOP	107
5.3.1.2	Local Operating Station LOS and Local Operating Panel LOP - Controls and displays	108
5.3.2	Normal Operation: LOS or LOP with Display	110
5.3.2.1	Engine - Switching ready for operation	110
5.3.2.2	Local mode - Activation	111
5.3.2.3	Engine - Start	112
5.3.2.4	Local mode - Gearbox engagement/disengagement	113
5.3.2.5	Local mode - Engine speed adjustment	114
5.3.2.6	Engine - Shutdown	115
5.3.2.7	Local mode - Deactivation	116
5.3.2.8	Engine start - Interlock	117
5.3.2.9	Engine - Emergency shutdown	118
5.3.3	Operation during Servicing: LOP without Display	119
5.3.3.1	Engine - Starting	119
5.3.3.2	Stopping the engine	120
5.3.3.3	Engine start - Interlock	121
5.3.3.4	Engine - Emergency shutdown	122
5.4	Troubleshooting	123
5.4.1	Faults in the BlueLine system	123
5.4.2	Troubleshooting	125

5.4.3	Alarms - General information	129	6.1.3.8	Indicator lamp - Replacement	243
5.4.4	Single-point alarms - Acknowledgment	130	6.1.3.9	Indicator lamp - Removal	244
5.4.5	Fault messages on the LOP display	131	6.1.3.10	Indicator lamp - Installation	245
5.4.6	Fault indication on MFD display of main control stand	138	6.1.3.11	Indicator lamp - LED replacement	246
5.4.7	Fault indication on printed circuit board MPU 29	146	6.1.3.12	Contactor - Replacement	248
5.4.8	Fault messages - Engine Control Unit	151	6.1.3.13	LED in pushbutton/switch - Replacement	249
5.5	Task Description	198	6.1.3.14	Display MFD - Replacement	251
5.5.1	Wiring (General) for Engine/Gearbox/Unit	198	6.1.3.15	Battery on MFD display - Replacement	252
5.5.1.1	Engine wiring - Check	198	6.1.3.16	SD card on MFD display - Replacement	254
5.5.2	Control and Display Elements, General	199	6.1.3.17	PIM 4 parameters - Reset	255
5.5.2.1	Indicator lamp - LED replacement	199	6.1.3.18	Fuse in control unit PIM 4 - Replacement	256
			6.1.3.19	Control unit PIM 4 - Replacement	257
			6.1.3.20	Printed circuit board in module cassette - Replacement	259
			6.1.3.21	Fuse on printed circuit board in PIM cassette - Replacement	261
			6.1.3.22	Printed circuit board MPU 29 - Removal	263
			6.1.3.23	Printed circuit board MPU 29 - Installation	264
			6.1.3.24	Printed circuit board MPU 29 - Replacement	265
			6.1.3.25	Data module MEM on MPU 29 - Replacement	266
			6.1.3.26	Data module MEM on MPU 29 - Transfer	267
			6.1.3.27	LOP fuse - Replacement	268
			6.1.3.28	LOP with display front flap - Replacement	269
			6.1.3.29	LOP - Replacement	271
			6.1.3.30	Local Operating Station LOS - Replacement	272
			6.1.3.31	Gear Control Unit GCU - Replacement	273
			6.1.4	Supplementary Technical Information	275
			6.1.4.1	PIM 4 RCS - Internal design	275
			6.1.4.2	Control unit PIM 4 MCS - Internal design	280
			6.1.4.3	Local Operating Panel LOP - Design	286
			6.1.4.4	Gear Control Unit GCU - Design	294
6	Workshop Manual		7	Installation and Commissioning Instructions	
6.1	Task Description	201	7.1	Installation	299
6.1.1	Operating Tests	201	7.1.1	Preparation	299
6.1.1.1	Test mode, BlueLine - Execution	201	7.1.1.1	Cable routes and openings between all installation locations - Check	299
6.1.1.2	Overspeed test	204	7.1.1.2	Cables - Routing between installation locations	300
6.1.1.3	Emergency stop test	205	7.1.2	Mechanical Installation	302
6.1.1.4	Cranking	206	7.1.2.1	PIM 4 module housing - Installation	302
6.1.2	Checks and Settings	207	7.1.2.2	OceanLine analog display instruments - Installation	303
6.1.2.1	LOP-DIS settings - Check	207	7.1.2.3	Horn VDO - Installation	305
6.1.2.2	LOP display DIS - Setting	208	7.1.2.4	Indicator lamp - Installation	306
6.1.2.3	Display MFD settings - Check	209	7.1.2.5	Illuminated pushbuttons/key switches - Installation	307
6.1.2.4	Display MFD - Setting	210	7.1.2.6	GCU - Installation	309
6.1.2.5	PIM 4 node number - Check	212	7.1.2.7	Display MFD - Installation	310
6.1.2.6	PIM 4 node number - Setting	213	7.1.2.8	LOP - Installation	311
6.1.2.7	Serial interface terminator plugs - Check	214	7.1.2.9	LOS - Installation	313
6.1.2.8	Emergency stop shorting plug X18 - Check	215	7.1.2.10	Command unit ROS 11 - Installation	315
6.1.2.9	Jumper configuration of MCS-5 control unit - Check	217	7.1.2.11	Command unit ROS 7 / ROS 9 - Installation	317
6.1.2.10	CAN bus connections PIM 4 - Check	218	7.1.2.12	Rotary encoder modules ROS 10/P and ROS 10/S - Installation	319
6.1.2.11	CAN bus line resistance - Check	220			
6.1.2.12	MPU 29 node address in LOP - Check	222			
6.1.2.13	MPU 29 node address in LOP - Setting	223			
6.1.2.14	Control stand configuration in Local Operating Panel LOP - Check	224			
6.1.2.15	Shaft number setting - Check	226			
6.1.2.16	LOP power supply - Check	227			
6.1.2.17	Jumper configuration of LOP - Check	230			
6.1.2.18	GCU 6 jumper configuration - Check	231			
6.1.2.19	GCU 3 jumper configuration - Check	232			
6.1.2.20	GCU node number - Check	233			
6.1.2.21	Configuration	234			
6.1.3	Repair Work	236			
6.1.3.1	PIM 4 cover - Removal	236			
6.1.3.2	PIM 4 cover - Installation	237			
6.1.3.3	Command unit - Replacement	238			
6.1.3.4	Rotary encoder module - Replacement	239			
6.1.3.5	Operating station - Replacement	240			
6.1.3.6	Analog display instrument VDO OceanLine - Replacement	241			
6.1.3.7	Lamp in analog display instrument VDO OceanLine - Replacement	242			

7.1.2.13	Remote Operating Station ROS 10/T - Installation	320	7.1.5.1	Technical data - LOP	369
7.1.2.14	Terminal box X010 - Installation	322	7.1.5.2	Display MFD - Technical data	370
7.1.3	Electrical Installation	323	7.1.5.3	ECU 4 - Technical data	372
7.1.3.1	HSK cable gland - Preparation	323	7.1.5.4	GCU 3 - Technical data	373
7.1.3.2	Terminal block - Preparation	324	7.1.5.5	GCU 6 - Technical data	374
7.1.3.3	PIM 4 cover - Removal	325	7.1.5.6	Technical data X010	375
7.1.3.4	GCU 3 - Connection	326	7.1.5.7	PIM 4 control unit - Technical data	376
7.1.3.5	GCU - Pin assignment for non-MTU gearbox	328	7.2	Initial Operation	377
7.1.3.6	Display instruments on main control stand - Connection	331	7.2.1	Preparation	377
7.1.3.7	Controls and status indicator lamps on main control stands - Connection	332	7.2.1.1	Checks prior to startup	377
7.1.3.8	Indicator lamps for single-point alarms - Connection	333	7.2.1.2	Operating voltage - First power-up	379
7.1.3.9	Devices on a slave control stand - Connection	334	7.2.1.3	Supply voltage distribution - Check	381
7.1.3.10	PIM 4 MCS control unit - Connection	335	7.2.1.4	Data module MEM on MPU 29 - Installation	384
7.1.3.11	Starter and battery-charging generator - Connection	338	7.2.1.5	SD memory card in display MFD - Installation	385
7.1.3.12	Engine Control Unit ECU - Connection	342	7.2.2	Settings	386
7.1.3.13	Barring gear limit switch - Connection	343	7.2.2.1	Configuration	386
7.1.3.14	Display MFD - Connection	344	7.2.2.2	Minidialog - Settings	388
7.1.3.15	LOP - Connection	346	7.2.3	Tests	401
7.1.3.16	Additional Yard signals (optional) - Connection	349	7.2.3.1	Initial engine startup at service interface of LOP	401
7.1.3.17	LOS - Connection	351	7.2.3.2	Initial engine startup at the display of Local Operating Panel LOP	403
7.1.3.18	Command units on triple-shaft propulsion systems - Connection	352	7.2.3.3	Initial engine start at MCS	405
7.1.3.19	Command units on propulsion systems with four shafts - Connection	355	7.2.3.4	Speed control and clutch setting - Check	407
7.1.3.20	Command unit ROS 7 / ROS 9 - Connection	358	7.2.3.5	Command transfer - Check (only when several control stands are installed)	408
7.1.3.21	Rotary encoder module and remote operating station - Connection	359	7.2.3.6	System reset	409
7.1.3.22	PIM 4 RCS control unit - Connection	361	8	Appendix A	
7.1.3.23	RCS extension module - Installation in PIM 4 RCS	364	8.1	Abbreviations	410
7.1.3.24	Terminal box X010 - Connection	365	8.2	Conversion tables	415
7.1.4	Data Transmission	368	8.3	MTU contact persons/service partners	419
7.1.4.1	RS422 - Transmission values	368	9	Appendix B	
7.1.5	Technical Data	369	9.1	Special Tools	420
			9.2	Index	421

1 Safety

1.1 Important requirements for all products

Nameplate

The product is identified by a nameplate, model designation or serial number which must match the information on the title page of this manual.

Nameplate, model designation or serial number can be found on the product.

General information

This product may pose a risk of injury or damage in the following cases:

- Improper use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications
- Noncompliance with the safety instructions and warning notices

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/MTU contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (including engine management/parameters)
- In compliance with all safety regulations and in accordance with all warning notices in this manual
- With maintenance work performed in accordance with the (→ Maintenance Schedule) throughout the useful life of the product
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair
- By contracting only workshops authorized by the manufacturer to carry out repair and overhaul

Any other use shall be considered non-intended. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

Changes or modifications

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

1.2 Personnel and organizational requirements

Organizational measures of the operator

This manual must be issued to all personnel involved in operation, maintenance, repair or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair and transport personnel at all times.

Use this manual as a basis for instructing personnel on product operation and repair, whereby the safety-relevant instructions, in particular, must be read and understood.

This is particularly important in the case of personnel who only occasionally perform work on or around the product. This personnel must be instructed repeatedly.

Personnel requirements

All work on the product shall be carried out by trained and qualified personnel only.

- Training at the Training Center of the manufacturer
- Qualified personnel specialized in mechanical and plant engineering

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair and transport.

Working clothes and personal protective equipment

Wear proper protective clothing for all work.

When working, always wear the necessary personal protective equipment (e.g. ear protectors, protective gloves, goggles, breathing protection). Observe the information on personal protective equipment in the respective activity description.

1.3 Safety requirements for startup and operation

Safety requirements for startup

The product must be installed and accepted in accordance with manufacturers' specifications prior to initial startup.

All the requisite regulatory approvals must have been granted and all startup requirements fulfilled prior to initial startup.

Whenever the product is started, always ensure that:

- All maintenance and repair work has been completed.
- All loose parts have been removed from rotating machine components.
- Wearers of cardiac pacemakers or other active medical implants are well clear.
- The operating room is adequately ventilated.
- Exhaust pipework is leak-tight and routed to atmosphere.
- Battery terminals, generator terminals and cables are guarded to preclude accidental contact.
- All personnel is clear of the danger zone represented by moving parts.

Immediately after putting the product into operation, make sure that all control and display instruments as well as the monitoring, signaling and alarm systems are working properly.

Safety requirements for operation

The operator must be familiar with the controls and displays.

The operator must be aware of the consequences of any operations he/she performs.

During operation, the display instruments and monitoring units must be constantly observed in regard of present operating status, limit value violation and warning or alarm messages.

Malfunctions and emergency stop

Emergency procedures, in particular emergency stop, must be practiced on a regular basis.

Take the following steps if a system malfunction is detected or signaled by the system:

- Inform the duty supervisor(s).
- Evaluate the message.
- Respond to the emergency appropriately, e.g. execute an emergency stop.

Operation

Do not stay in the operating room when the product is running unless absolutely necessary and then as briefly as possible.

Keep a safe distance away from the product whenever possible. Do not touch the product unless expressly instructed to do so.

Do not inhale exhaust gases emitted by the product.

Ensure that the following requirements have been fulfilled before starting the product:

- Ear protectors are worn.
- Mop up any leaked or spilled fluids and lubricants immediately or soak up with a suitable binding agent.

Operation of electrical equipment

Some components are live (high voltage) when electrical equipment is in operation.

Observe the safety instructions for these appliances.

1.4 Safety requirements for maintenance and repair work

Safety requirements before commencing maintenance and repair work

Have maintenance or repair work carried out by qualified and authorized personnel only.

Allow the product to cool down to less than 50°C (risk of explosion for oil vapors, fluids and lubricants, risk of burning).

Relieve pressure in fluid and lubricant systems and compressed-air lines which are to be opened. Use suitable collection vessels with a sufficient filling volume.

Ensure that the operating room is adequately ventilated when changing the oil or working on the fuel system.

Do not perform maintenance or repair work when the product is running unless:

- expressly instructed to do so.
- the product is running in the low load range and only for as long as necessary to complete the task.

Lock-out the product to preclude undesired starting, e.g. start interlock.

Tag-out the product with a “Do Not Start” sign in the operation room or on the control facility.

Disconnect the battery. Lock the contactor.

Close the main valve on the compressed-air system and vent the compressed-air line when pneumatic starters are fitted.

Disconnect the control facility from the product.

For starters with pinions made of copper-beryllium alloy:

- Wear a respirator mask (filter class P3). Do not blow out the interior of the flywheel housing or the starter with compressed air. Clean the interior of the flywheel housing with a class H dust extractor.
- Observe the safety data sheet.

Safety requirements during maintenance and repair work

Take special care when removing vent plugs or plug screws from the product. Hold a cloth over the screw or plug to prevent discharge of highly pressurized liquids.

Take care when draining hot fluids and lubricants (risk of burning).

Use suitable and calibrated tools only. Observe the specified tightening torques during assembly or disassembly.

Carry out work only on assemblies and/or installations which are properly secured.

Never climb up on the lines.

Keep fuel injection lines and connections clean.

Always seal connections with caps or covers if a line is removed or opened.

Fit new seals when re-installing lines.

Avoid damaging lines, particularly the fuel lines.

Ensure that all retainers and dampers are installed correctly.

Ensure that all fuel injection and pressurized oil lines are installed with enough clearance to prevent contact with other components. Never route fuel or oil lines in the vicinity of hot components.

Do not touch elastomeric seals (e.g. Viton sealing rings) with your bare hands if they have a carbonized or resinous appearance.

Observe the cooling time for components which have been heated for installation or removal (risk of burning!).

Always use suitable ladders and work platforms when working above head-height. Ensure that components or assemblies are placed on stable surfaces.

Pay particular attention to cleanliness at all times.

Safety requirements after completing maintenance and repair work

Ensure that all personnel is clear of danger zones before cranking.

Check that all access ports/apertures which have been opened to facilitate working are closed again.

Check that all safety equipment has been installed and that all tools and loose parts have been removed (especially the barring gear).

Ensure that no unattached parts have been left in/on the product (e.g. including rags and cable straps).

Welding work

Do not perform welding on the product or its attachments. Cover the product when performing welding work in the vicinity.

Before commencing welding work:

- Switch off the master power supply switch.
- Disconnect the battery.
- Disconnect electronic and genset grounds.

Do not perform maintenance or repair work on the product when welding is in progress in its vicinity. Risk of explosion or fire due to oil vapors and highly flammable process materials.

Do not use the product as a grounding terminal.

Do not route the welding cable over or near the wiring harnesses of the product. The welding current may otherwise induce an interference voltage in the wiring harnesses which could conceivably damage the electrical system.

Remove components (e.g. exhaust pipe) from the product before performing necessary welding work .

Hydraulic installation and removal

Check function and satisfactory condition of the jigs and fixtures to be used. Use only the specified jigs and fixtures for hydraulic removal/installation.

Observe the max. permissible force-on pressure specified for the installation/removal jig.

Do not attempt to bend or exert force on HP lines.

Before starting work, pay attention to the following:

- Vent the installation/removal jig, the pumps and the pipework at the relevant designated points.
- For hydraulic installation, screw on the jig with the piston retracted.
- For hydraulic removal, screw on the jig with the piston extended.

For hydraulic installation/removal jigs with central expansion pressure supply, screw the spindle into the shaft end until correct sealing has been established.

During hydraulic installation and removal, ensure that nobody is standing in the immediate vicinity of the component to be installed/removed.

Working with batteries

Observe the safety requirements of the battery manufacturer when working with batteries.

Gases released from the battery are explosive. Avoid sparks and naked flames.

Do not allow electrolyte (battery acid) to come into contact with skin or clothing.

Wear goggles and protective gloves.

Do not place tools on the battery.

Check polarity before connecting the cable to the battery. Battery polarity reversal may lead to injury by the sudden discharge of acid or bursting of the battery unit.