

System Documentation

Electronic Equipment

BlueLine

with Multifunction Display

Series 2000 (unit-pump system) Waterjet

MDEC

Application: Marine

Functional Description

Operating Instructions

Workshop Manual

Installation and

Commissioning Instructions

E532778/03E



Power. Passion. Partnership.

© 2014 Copyright MTU Friedrichshafen GmbH

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of MTU Friedrichshafen GmbH. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. MTU Friedrichshafen GmbH reserves the right to change, delete or supplement the information provided as and when required.

Table of Contents

1	Safety		4.1.2.8	Switching off the overall BlueLine system	75
1.1	Important requirements for all products	6	4.2	Engine Control System ECS-5	76
1.2	Personnel and organizational requirements	7	4.2.1	Controls and Displays	76
1.3	Safety requirements for startup and operation	8	4.2.1.1	Local Operating Panel LOP	76
1.4	Safety requirements for maintenance and repair work	9	4.2.1.2	Local Operating Panel LOP with display	77
1.5	Fire prevention and environmental protection, fluids and lubricants, auxiliary materials	12	4.2.2	Normal Operation: LOP with Display	79
1.6	Standards for safety notices in the text	14	4.2.2.1	Engine - Switching ready for operation	79
2	General Information		4.2.2.2	Activating Local mode	80
2.1	Engine side and cylinder designations	15	4.2.2.3	Engine start	81
3	Functional Description		4.2.2.4	Local mode - Gearbox engagement/disengagement	82
3.1	Product Summary	16	4.2.2.5	Local mode - Engine speed adjustment	83
3.1.1	BlueLine system - Overview	16	4.2.2.6	Stopping the engine	84
3.1.2	BlueLine subsystems - Use	19	4.2.2.7	Deactivating Local mode	85
3.2	Subsystems	20	4.2.2.8	Engine start - Interlock	86
3.2.1	Monitoring and Control System MCS-5	20	4.2.2.9	Engine - Emergency shutdown	87
3.2.1.1	MCS-5 BlueLine - Overview	20	4.2.3	Operation during Servicing: LOP without Display	88
3.2.1.2	MCS-5 BlueLine - Use of the devices	22	4.2.3.1	Engine start	88
3.2.1.3	RS422 PIM 4 serial interface as per MTU specifications	25	4.2.3.2	Stopping the engine	89
3.2.1.4	MCS-5 BlueLine - Main control stand	30	4.2.3.3	Interlocking engine start	90
3.2.1.5	MCS-5 BlueLine - Slave control stand	33	4.2.3.4	Engine - Emergency shutdown	91
3.2.2	Engine Control System ECS-5	34	4.3	Troubleshooting	92
3.2.2.1	ECS-5 BlueLine - Overview	34	4.3.1	Faults in the BlueLine system	92
3.2.2.2	ECS-5 BlueLine - Use of the devices	37	4.3.2	Troubleshooting	94
3.2.3	Remote Control System	40	4.3.3	Alarms - General information	97
3.2.3.1	Interface to remote control system	40	4.3.4	Single-point alarms - Acknowledgment	98
3.2.3.2	Remote control interface - Use of devices	42	4.3.5	Fault messages on the LOP display	99
4	Operating Instructions		4.3.6	Fault indications on the MFD display of the main control stand	103
4.1	Monitoring and Control System MCS-5	43	4.3.7	Fault indication on printed circuit board MPU 29	109
4.1.1	Controls and Displays	43	4.3.8	Fault messages - Engine Control Unit	113
4.1.1.1	MCS-5 - Controls and displays	43	4.4	Task Description	160
4.1.1.2	LOP display - Overview of screen pages	47	4.4.1	Cabling	160
4.1.1.3	Display MFD - Overview of screen pages	57	4.4.1.1	Engine wiring - Check	160
4.1.2	Operation	68	4.4.2	Control and Display Elements, General	161
4.1.2.1	Switching on the overall BlueLine system	68	4.4.2.1	Indicator lamp - LED replacement	161
4.1.2.2	Brightness of indicators/instruments - Adjustment	69	5	Workshop Manual	
4.1.2.3	Engine start	70	5.1	Task Description	163
4.1.2.4	Override function - Activation	71	5.1.1	Operating Tests	163
4.1.2.5	Override function - Deactivation	72	5.1.1.1	BlueLine test mode - Execution	163
4.1.2.6	Stopping the engine	73	5.1.1.2	Overspeed test	165
4.1.2.7	Emergency engine shutdown	74	5.1.1.3	Emergency stop test	166
			5.1.1.4	Cranking	167
			5.1.2	Checks and Settings	168
			5.1.2.1	LOP display DIS settings - Check	168
			5.1.2.2	LOP display DIS - Setting	169
			5.1.2.3	MFD settings - Check	170
			5.1.2.4	MFD display - Set	171

5.1.2.5	PIM 4 node number - Check	173
5.1.2.6	PIM 4 node number - Setting	174
5.1.2.7	Serial interface terminator plugs - Check	175
5.1.2.8	Emergency stop shorting plug X18 - Check	176
5.1.2.9	Jumper configuration of MCS-5 control unit - Check	178
5.1.2.10	CAN bus connections PIM 4 - Check	179
5.1.2.11	CAN bus line resistance - Check	180
5.1.2.12	MPU 29 node address in LOP - Check	182
5.1.2.13	MPU 29 node address in LOP - Setting	183
5.1.2.14	Control stand configuration in Local Operating Panel LOP - Check	184
5.1.2.15	Shaft number setting - Check	186
5.1.2.16	LOP power supply - Check	187
5.1.2.17	Jumper configuration of LOP - Check	190
5.1.2.18	GCU 6 jumper configuration - Check	191
5.1.2.19	GCU node number - Check	192
5.1.2.20	CAN node configuration - BlueLine	193
5.1.3	Repair Work	195
5.1.3.1	PIM 4 cover - Removal	195
5.1.3.2	PIM 4 cover - Installation	196
5.1.3.3	Analog display instrument VDO OceanLine - Replacement	197
5.1.3.4	Lamp in analog display instrument VDO OceanLine - Replacement	198
5.1.3.5	Indicator lamp - Replacement	199
5.1.3.6	Indicator lamp - Removal	200
5.1.3.7	Indicator lamp - Installation	201
5.1.3.8	Indicator lamp - LED replacement	202
5.1.3.9	Contact or - Replacement	204
5.1.3.10	LED in pushbutton/switch - Replacement	205
5.1.3.11	MFD display - Replacement	207
5.1.3.12	Battery on MFD display - Replacement	209
5.1.3.13	SD card on MFD display - Replacement	211
5.1.3.14	PIM 4 parameters - Reset	212
5.1.3.15	Fuse in control unit PIM 4 - Replacement	213
5.1.3.16	Control unit PIM 4 - Replacement	214
5.1.3.17	Printed circuit board in module cassette - Replacement	216
5.1.3.18	Fuse on printed circuit board in PIM cassette - Replacement	218
5.1.3.19	Printed circuit board MPU 29 - Removal	220
5.1.3.20	Printed circuit board MPU 29 - Installation	221
5.1.3.21	Printed circuit board MPU 29 - Replacement	222
5.1.3.22	Data module MEM on MPU 29 - Replacement	223
5.1.3.23	Data module MEM on MPU 29 - Transfer	224
5.1.3.24	LOP fuse - Replacement	225
5.1.3.25	LOP with display front flap - Replacement	226
5.1.3.26	LOP - Replacement	228
5.1.3.27	Gear Control Unit GCU - Replacement	229
5.1.4	Supplementary Technical Information	231
5.1.4.1	Control unit PIM 4 MCS - Internal design	231
5.1.4.2	Local Operating Panel LOP - Design	237
5.1.4.3	Gear Control Unit GCU 6 - Design	245

6 Installation and Commissioning Instructions

6.1	Installation	250
6.1.1	Preparation	250
6.1.1.1	Cable routes and openings between all installation locations - Check	250
6.1.1.2	Cables between installation locations - Routing	251
6.1.2	Mechanical Installation	253
6.1.2.1	PIM 4 module housing - Installation	253
6.1.2.2	OceanLine analog display instruments - Installation	254
6.1.2.3	Horn VDO - Installation	256
6.1.2.4	Indicator lamp - Installation	257
6.1.2.5	Illuminated pushbuttons/key switches - Installation	258
6.1.2.6	GCU - Installation	260
6.1.2.7	Display MFD - Installation	261
6.1.2.8	LOP - Installation	262
6.1.2.9	LOP with display - Conversion to application with remote control system (shipyard)	264
6.1.2.10	Terminal box X010 - Installation	266
6.1.3	Electrical Installation	267
6.1.3.1	HSK cable gland - Preparation	267
6.1.3.2	Terminal block - Preparation	268
6.1.3.3	PIM 4 cover - Removal	269
6.1.3.4	GCU 6 - Connection	270
6.1.3.5	Waterjet remote control system (shipyard) - Connection	272
6.1.3.6	Non-MTU gearbox - Connection	276
6.1.3.7	Display instruments on main control stand - Connection	279
6.1.3.8	Controls and status indicator lamps on main control stands - Connection	280
6.1.3.9	Indicator lamps for single-point alarms - Connection	281
6.1.3.10	Devices on a slave control stand - Connection	282
6.1.3.11	PIM 4 MCS control unit - Connection	283
6.1.3.12	Starter and battery-charging generator - Connection	286
6.1.3.13	Engine Control Unit ECU 4 - Connection	290
6.1.3.14	Barring gear limit switch - Connection	291
6.1.3.15	Display MFD - Connection	292
6.1.3.16	LOP - Connection	294
6.1.3.17	Additional Yard signals (optional) - Connection	297
6.1.3.18	Terminal box X010 - Connection	299
6.1.4	Data Transmission	302
6.1.4.1	RS422 - Transmission values	302
6.1.5	Technical Data	303
6.1.5.1	Technical data - LOP	303
6.1.5.2	Display MFD - Technical data	304
6.1.5.3	ECU 4 - Technical data	306
6.1.5.4	GCU 6 - Technical data	307
6.1.5.5	Technical data X010	308

6.1.5.6	PIM 4 control unit – Technical data	309	6.2.3.2	Initial engine startup at the display of Local Operating Panel LOP	334
6.2	Initial Operation	310	6.2.3.3	Initial engine start at MCS	336
6.2.1	Preparation	310			
6.2.1.1	Checks prior to startup	310	7	Appendix A	
6.2.1.2	Operating voltage – Initial application	311	7.1	Conversion tables	338
6.2.1.3	Supply voltage distribution – Check	313	7.2	Abbreviations	343
6.2.1.4	Data module MEM on MPU 29 – Installation	315	7.3	MTU contact persons/service partners	348
6.2.1.5	SD memory card in display MFD – Installation	316			
6.2.2	Settings	317	8	Appendix B	
6.2.2.1	CAN node configuration – BlueLine	317	8.1	Special Tools	349
6.2.2.2	ECU configuration	319	8.2	Index	350
6.2.2.3	Minidialog – Settings	320			
6.2.3	Tests	333			
6.2.3.1	Initial engine start-up at the service interface of the LOP	333			

1 Safety

1.1 Important requirements for all products

Nameplate

The product is identified by a nameplate, model designation or serial number which must match the information on the title page of this manual.

Nameplate, model designation or serial number can be found on the product.

General information

This product may pose a risk of injury or damage in the following cases:

- Improper use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications
- Noncompliance with the safety instructions and warning notices

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/MTU contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (including engine management/parameters)
- In compliance with all safety regulations and in accordance with all warning notices in this manual
- With maintenance work performed in accordance with the (→ Maintenance Schedule) throughout the useful life of the product
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair
- By contracting only workshops authorized by the manufacturer to carry out repair and overhaul

Any other use shall be considered non-intended. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

Changes or modifications

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

1.2 Personnel and organizational requirements

Organizational measures of the operator

This manual must be issued to all personnel involved in operation, maintenance, repair or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair and transport personnel at all times.

Use this manual as a basis for instructing personnel on product operation and repair, whereby the safety-relevant instructions, in particular, must be read and understood.

This is particularly important in the case of personnel who only occasionally perform work on or around the product. This personnel must be instructed repeatedly.

Personnel requirements

All work on the product shall be carried out by trained and qualified personnel only.

- Training at the Training Center of the manufacturer
- Qualified personnel specialized in mechanical and plant engineering

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair and transport.

Working clothes and personal protective equipment

Wear proper protective clothing for all work.

When working, always wear the necessary personal protective equipment (e.g. ear protectors, protective gloves, goggles, breathing protection). Observe the information on personal protective equipment in the respective activity description.

1.3 Safety requirements for startup and operation

Safety requirements for startup

The product must be installed and accepted in accordance with manufacturers' specifications prior to initial startup.

All the requisite regulatory approvals must have been granted and all startup requirements fulfilled prior to initial startup.

Whenever the product is started, always ensure that:

- All maintenance and repair work has been completed.
- All loose parts have been removed from rotating machine components.
- Wearers of cardiac pacemakers or other active medical implants are well clear.
- The operating room is adequately ventilated.
- Exhaust pipework is leak-tight and routed to atmosphere.
- Battery terminals, generator terminals and cables are guarded to preclude accidental contact.
- All personnel is clear of the danger zone represented by moving parts.

Immediately after putting the product into operation, make sure that all control and display instruments as well as the monitoring, signaling and alarm systems are working properly.

Safety requirements for operation

The operator must be familiar with the controls and displays.

The operator must be aware of the consequences of any operations he/she performs.

During operation, the display instruments and monitoring units must be constantly observed in regard of present operating status, limit value violation and warning or alarm messages.

Malfunctions and emergency stop

Emergency procedures, in particular emergency stop, must be practiced on a regular basis.

Take the following steps if a system malfunction is detected or signaled by the system:

- Inform the duty supervisor(s).
- Evaluate the message.
- Respond to the emergency appropriately, e.g. execute an emergency stop.

Operation

Do not stay in the operating room when the product is running unless absolutely necessary and then as briefly as possible.

Keep a safe distance away from the product whenever possible. Do not touch the product unless expressly instructed to do so.

Do not inhale exhaust gases emitted by the product.

Ensure that the following requirements have been fulfilled before starting the product:

- Ear protectors are worn.
- Mop up any leaked or spilled fluids and lubricants immediately or soak up with a suitable binding agent.

Operation of electrical equipment

Some components are live (high voltage) when electrical equipment is in operation.

Observe the safety instructions for these appliances.

1.4 Safety requirements for maintenance and repair work

Safety requirements before commencing maintenance and repair work

Have maintenance or repair work carried out by qualified and authorized personnel only.

Allow the product to cool down to less than 50°C (risk of explosion for oil vapors, fluids and lubricants, risk of burning).

Relieve pressure in fluid and lubricant systems and compressed-air lines which are to be opened. Use suitable collection vessels with a sufficient filling volume.

Ensure that the operating room is adequately ventilated when changing the oil or working on the fuel system.

Do not perform maintenance or repair work when the product is running unless:

- expressly instructed to do so.
- the product is running in the low load range and only for as long as necessary to complete the task.

Lock-out the product to preclude undesired starting, e.g. start interlock.

Tag-out the product with a “Do Not Start” sign in the operation room or on the control facility.

Disconnect the battery. Lock the contactor.

Close the main valve on the compressed-air system and vent the compressed-air line when pneumatic starters are fitted.

Disconnect the control facility from the product.

For starters with pinions made of copper-beryllium alloy:

- Wear a respirator mask (filter class P3). Do not blow out the interior of the flywheel housing or the starter with compressed air. Clean the interior of the flywheel housing with a class H dust extractor.
- Observe the safety data sheet.

Safety requirements during maintenance and repair work

Take special care when removing vent plugs or plug screws from the product. Hold a cloth over the screw or plug to prevent discharge of highly pressurized liquids.

Take care when draining hot fluids and lubricants (risk of burning).

Use suitable and calibrated tools only. Observe the specified tightening torques during assembly or disassembly.

Carry out work only on assemblies and/or installations which are properly secured.

Never climb up on the lines.

Keep fuel injection lines and connections clean.

Always seal connections with caps or covers if a line is removed or opened.

Fit new seals when re-installing lines.

Avoid damaging lines, particularly the fuel lines.

Ensure that all retainers and dampers are installed correctly.

Ensure that all fuel injection and pressurized oil lines are installed with enough clearance to prevent contact with other components. Never route fuel or oil lines in the vicinity of hot components.

Do not touch elastomeric seals (e.g. Viton sealing rings) with your bare hands if they have a carbonized or resinous appearance.

Observe the cooling time for components which have been heated for installation or removal (risk of burning!).

Always use suitable ladders and work platforms when working above head-height. Ensure that components or assemblies are placed on stable surfaces.

Pay particular attention to cleanliness at all times.

Safety requirements after completing maintenance and repair work

Ensure that all personnel is clear of danger zones before cranking.

Check that all access ports/apertures which have been opened to facilitate working are closed again.

Check that all safety equipment has been installed and that all tools and loose parts have been removed (especially the barring gear).

Ensure that no unattached parts have been left in/on the product (e.g. including rags and cable straps).

Welding work

Do not perform welding on the product or its attachments. Cover the product when performing welding work in the vicinity.

Before commencing welding work:

- Switch off the master power supply switch.
- Disconnect the battery.
- Disconnect electronic and genset grounds.

Do not perform maintenance or repair work on the product when welding is in progress in its vicinity. Risk of explosion or fire due to oil vapors and highly flammable process materials.

Do not use the product as a grounding terminal.

Do not route the welding cable over or near the wiring harnesses of the product. The welding current may otherwise induce an interference voltage in the wiring harnesses which could conceivably damage the electrical system.

Remove components (e.g. exhaust pipe) from the product before performing necessary welding work .

Hydraulic installation and removal

Check function and satisfactory condition of the jigs and fixtures to be used. Use only the specified jigs and fixtures for hydraulic removal/installation.

Observe the max. permissible force-on pressure specified for the installation/removal jig.

Do not attempt to bend or exert force on HP lines.

Before starting work, pay attention to the following:

- Vent the installation/removal jig, the pumps and the pipework at the relevant designated points.
- For hydraulic installation, screw on the jig with the piston retracted.
- For hydraulic removal, screw on the jig with the piston extended.

For hydraulic installation/removal jigs with central expansion pressure supply, screw the spindle into the shaft end until correct sealing has been established.

During hydraulic installation and removal, ensure that nobody is standing in the immediate vicinity of the component to be installed/removed.

Working with batteries

Observe the safety requirements of the battery manufacturer when working with batteries.

Gases released from the battery are explosive. Avoid sparks and naked flames.

Do not allow electrolyte (battery acid) to come into contact with skin or clothing.

Wear goggles and protective gloves.

Do not place tools on the battery.

Check polarity before connecting the cable to the battery. Battery polarity reversal may lead to injury by the sudden discharge of acid or bursting of the battery unit.