

Technical Documentation

BlueLine Waterjet for series 4000

ECS-5, MCS-5
Application Marine

Functional Description
Operating Instructions
Workshop Manual
Installation and Commissioning
Instructions

E532231/00E



Printed in Germany

© 2006 Copyright MTU Friedrichshafen GmbH

Diese Veröffentlichung einschließlich aller ihrer Teile ist urheberrechtlich geschützt. Jede Verwertung oder Nutzung bedarf der vorherigen schriftlichen Zustimmung der MTU Friedrichshafen GmbH. Das gilt insbesondere für Vervielfältigung, Verbreitung, Bearbeitung, Übersetzung, Mikroverfilmungen und die Einspeicherung und / oder Verarbeitung in elektronischen Systemen, einschließlich Datenbanken und Online-Diensten. Das Handbuch ist zur Vermeidung von Störungen oder Schäden beim Betrieb zu beachten und daher vom Betreiber dem jeweiligen Wartungs- und Bedienungspersonal zur Verfügung zu stellen. Änderungen bleiben vorbehalten.

Printed in Germany

© 2006 Copyright MTU Friedrichshafen GmbH

This Publication is protected by copyright and may not be used in any way whether in whole or in part without the prior written permission of MTU Friedrichshafen GmbH. This restriction also applies to copyright, distribution, translation, microfilming and storage or processing on electronic systems including data bases and online services.

This handbook is provided for use by maintenance and operating personnel in order to avoid malfunctions or damage during operation.

Subject to alterations and amendments.

Imprimé en Allemagne

© 2006 Copyright MTU Friedrichshafen GmbH

Tout droit réservé pour cet ouvrage dans son intégralité. Toute utilisation ou exploitation requiert au préalable l'accord écrit de MTU Friedrichshafen GmbH. Ceci s'applique notamment à la reproduction, la diffusion, la modification, la traduction, l'archivage sur microfiches, la mémorisation et / ou le traitement sur des systèmes électroniques, y compris les bases de données et les services en ligne.

Le manuel devra être observé en vue d'éviter des incidents ou des endommagements pendant le service. Aussi recommandons-nous à l'exploitant de le mettre à la disposition du personnel chargé de l'entretien et de la conduite.

Modifications réservées.

Impreso en Alemania

© 2006 Copyright MTU Friedrichshafen GmbH

Esta publicación se encuentra protegida, en toda su extensión, por los derechos de autor. Cualquier utilización de la misma, así como su reproducción, difusión, transformación, traducción, microfilmación, grabación y/o procesamiento en sistemas electrónicos, entre los que se incluyen bancos de datos y servicios en línea, precisa de la autorización previa de MTU Friedrichshafen GmbH.

El manual debe tenerse presente para evitar fallos o daños durante el servicio, y, por dicho motivo, el usuario debe ponerlo a disposición del personal de mantenimiento y de servicio.

Nos reservamos el derecho de introducir modificaciones.

Stampato in Germania

© 2006 Copyright MTU Friedrichshafen GmbH

Questa pubblicazione è protetta dal diritto d'autore in tutte le sue parti. Ciascun impiego o utilizzo, con particolare riguardo alla riproduzione, alla diffusione, alla modifica, alla traduzione, all'archiviazione in microfilm e alla memorizzazione o all'elaborazione in sistemi elettronici, comprese banche dati e servizi on line, deve essere espressamente autorizzato per iscritto dalla MTU Friedrichshafen GmbH.

Il manuale va consultato per evitare anomalie o guasti durante il servizio, per cui va messo a disposizione dall'utente al personale addetto alla manutenzione e alla condotta.

Con riserva di modifiche.

Impresso na Alemanha

© 2006 Copyright MTU Friedrichshafen GmbH

A presente publicação, inclusive todas as suas partes, está protegida pelo direito autoral. Qualquer aproveitamento ou uso exige a autorização prévia e por escrito da MTU Friedrichshafen GmbH. Isto diz respeito em particular à reprodução, divulgação, tratamento, tradução, microfilmagem, e a memorização e/ou processamento em sistemas eletrônicos, inclusive bancos de dados e serviços on-line.

Para evitar falhas ou danos durante a operação, os dizeres do manual devem ser respeitados. Quem explora o equipamento economicamente consequentemente deve colocá-lo à disposição do respectivo pessoal da conservação, e à disposição dos operadores.

Salvo alterações.

Wichtig – Important – Importante

Bitte die Karte „Inbetriebnahmemeldung“ abtrennen und ausgefüllt an MTU Friedrichshafen GmbH zurücksenden.

Die Informationen der Inbetriebnahmemeldung sind Grundlage für den vertraglich vereinbarten Logistik-Support (Gewährleistung, Ersatzteile etc.).

Please complete and return the “Commissioning Note” card below to MTU Friedrichshafen GmbH.

The Commissioning Note information serves as a basis for the contractually agreed logistic support (warranty, spare parts, etc.).

Veillez séparer la carte “Signalisation de mise en service” et la renvoyer à la MTU Friedrichshafen GmbH.

Les informations contenues dans la signalisation de mise en service constituent la base pour l'assistance en exploitation contractuelle (garantie, rechanges, etc.).

Rogamos separen la tarjeta “Aviso de puesta en servicio” y la devuelvan rellena a MTU Friedrichshafen GmbH.


Las informaciones respecto al aviso de puesta en servicio constituyen la base para el soporte logístico contractual (garantía, piezas de repuesto, etc.).

Ritagliare “Avviso di messa in servizio” e rispedirlo debitamente compilato alla MTU Friedrichshafen GmbH.

Le informazioni ivi registrate sono la base per il supporto logistico contrattuale (garanzia, ricambi, ecc.).

É gentileza cortar o cartão “Participação da colocação em serviço”, preenchê-lo e devolvê-lo a MTU Friedrichshafen.

Os dados referentes à colocação em serviço representam a base para o suporte logístico (garantia, peças sobressalentes, etc.) estabelecido contratualmente.

	
	Postcard MTU Friedrichshafen GmbH Department SCSD 88040 Friedrichshafen GERMANY

Bitte in Blockschrift ausfüllen!
Please use block capitals!
Prière de remplir en lettres capitales!
¡A rellenar en letras de imprenta!
Scrivere in stampatello!
Favor preencher com letras de forma!



Motornr.: Engine No.: N° du moteur: N° de motor: Motore N.: No. do motor:	Auftragsnr.: MTU works order No.: N° de commande: N° de pedido: N. commessa: No. do pedido:	Inbetriebnahme- meldung Commissioning Note
Motortyp: Engine model: Type du moteur: Tipo de motor: Motore tipo: Tipo do motor:	Inbetriebnahmedatum: Date put into operation: Mise en service le: Fecha de puesta en servicio: Messa in servizio il: Data da colocação em serviço:	Notice de mise en service Aviso de puesta en servicio
Eingebaut in: Installation site: Lieu de montage: Lugar de montaje: Installato: Incorporado em:	Schiffstyp / Schiffshersteller: Vessel/type/class / Shipyard: Type du bateau / Constructeur: Tipo de buque / Constructor: Tipo di barca / Costruttore Tipo de embarcação/estaleiro naval:	Avviso di messa in servizio Participação da colocação em serviço
Endabnehmer/Anschrift: End user's address: Adresse du client final: Dirección del cliente final: Indirizzo del cliente finale: Usuário final/endereço:		
Bemerkung: Remarks: Remarques: Observaciones: Commento: Observações:		

General Conditions	07
1 Safety	09
1.1 General conditions	09
1.2 Personnel and organizational requirements	10
1.3 Safety precautions when working on the engine	11
1.4 Auxiliary materials, fire prevention and environmental protection	14
1.5 Standards for warning notices in the publication	16
Functional Description	17
2 Product Summary	19
2.1 BlueLine system – Overview	19
2.2 BlueLine subsystems – Use	21
3 Devices and Functions	23
3.1 Monitoring and Control System MCS-5	23
3.1.1 MCS-5 BlueLine – Overview	23
3.1.2 MCS-5 BlueLine – Use of the devices	25
3.1.3 MCS-5 BlueLine – Main control stand	28
3.1.4 MCS-5 BlueLine – Slave control stand	30
3.2 Engine Control System ECS-5	31
3.2.1 ECS-5 BlueLine – Overview	31
3.2.2 ECS-5 BlueLine – Use of the devices	38
3.3 Remote Control System	42
3.3.1 Interface to remote control system	42
3.3.2 Remote control interface – Use of devices	44
Operating Instructions	45
4 Monitoring and Control System MCS-5	47
4.1 Controls and Displays	47
4.1.1 MCS-5 – Controls and displays	47
4.1.2 Display – Overview of the screen pages	50
4.2 Operation	60
4.2.1 Switching on the overall BlueLine system	60
4.2.2 Adjusting brightness of indicators / instruments	61
4.2.3 Starting the engine	62
4.2.4 Override function – Activation	63
4.2.5 Override function – Deactivation	64
4.2.6 Stopping the engine	65
4.2.7 Emergency engine stop	66
4.2.8 Switching off the overall BlueLine system	67
5 Operation	69
5.1 Priming Pump Controller PPC — Controls and displays	69

5.2	Priming Pump Controller PPC – Function check	70
6	Engine Control System ECS-5	71
6.1	Controls and Displays	71
6.1.1	LOP	71
6.1.2	LOP with display	72
6.2	Normal Operation: LOS or LOP with Display	74
6.2.1	Switching the engine ready for operation	74
6.2.2	Activating Local mode	75
6.2.3	Starting the engine	76
6.2.4	Local mode – Gearbox engagement/disengagement	77
6.2.5	Local mode – Changing engine speed	78
6.2.6	Stopping the engine	79
6.2.7	Deactivating Local mode	80
6.2.8	Interlocking engine start	81
6.2.9	Emergency engine stop	82
6.3	Operation during Servicing: LOP without Display	83
6.3.1	Starting the engine	83
6.3.2	Stopping the engine	84
6.3.3	Interlocking engine start	85
6.3.4	Emergency engine stop	86
7	Troubleshooting	87
7.1	Faults in the BlueLine system	87
7.2	Troubleshooting	88
7.3	Fault indication on the display of LOP with display DIS	91
7.4	Fault indication on printed circuit board MPU 29	96
7.5	Fault messages of Engine Control Unit ECU 4 for Series 4000	100
7.6	Oil priming pump PPC – Troubleshooting	109
8	Alarm Messages	111
8.1	Alarms – General information	111
8.2	Alarm – Acknowledging at the control stand	112
9	Task Descriptions	113
9.1	Wiring, General for Engine / Gearbox / Plant	113
9.1.1	Engine wiring check	113
9.2	General Display and Control Elements	114
9.2.1	Indicator lamp - LED replacement	114
	Workshop Manual	117
10	Task Descriptions	119
10.1	Operating Tests	119
10.1.1	BlueLine test mode – Execution	119
10.1.2	Overspeed test	121
10.1.3	Emergency stop test	122

10.1.4	Barring the engine	123
10.2	Checks and Settings	124
10.2.1	DIS settings – Check	124
10.2.2	Display DIS – Setting	125
10.2.3	PIM 4 node number – Check	126
10.2.4	PIM 4 node number – Setting	127
10.2.5	Serial interface terminator plugs – Check	128
10.2.6	Jumper configuration of MCS-5 control unit – Check	129
10.2.7	CAN bus connections PIM 4 – Check	130
10.2.8	CAN bus line resistance – Check	131
10.2.9	LOP power supply – Check	133
10.2.10	Jumper configuration of LOP – Check	136
10.2.11	MPU 29 node address in LOP – Setting	137
10.2.12	Control stand configuration in Local Operating Panel LOP – Check	138
10.2.13	Shaft number setting – Check	139
10.2.14	GCU 6 jumper configuration – Check	140
10.2.15	GCU node number – Check	141
10.2.16	CAN nodes BlueLine – Configuration	142
10.3	Repair Work	143
10.3.1	Analog display instrument VDO OceanLine – Replacement	143
10.3.2	Lamp in analog display instrument VDO OceanLine – Replacement	144
10.3.3	Indicator lamp – Removal	145
10.3.4	Indicator lamp – Installation	146
10.3.5	LED in indicator lamp – Replacement	147
10.3.6	Contactors – Replacement	149
10.3.7	LED in pushbutton/switch – Replacement	150
10.3.8	Display DIS – Replacement	152
10.3.9	Control unit PIM 4 – Replacement	154
10.3.10	PIM 4 cover – Removal	156
10.3.11	PIM 4 cover – Installation	157
10.3.12	PIM 4 parameters – Reset	158
10.3.13	Fuse in control unit PIM 4 – Replacement	159
10.3.14	Printed circuit board in a PIM cassette – Replacement	160
10.3.15	Fuse on printed circuit board in a PIM cassette – Replacement	161
10.3.16	Printed circuit board MPU 29 – Removal	163
10.3.17	Printed circuit board MPU 29 – Installation	164
10.3.18	Printed circuit board MPU 29 – Replacement	165
10.3.19	Data module on MPU 29 – Replacement	167
10.3.20	Data module on MPU 29 – Transfer	168
10.3.21	LOP fuse – Replacement	169
10.3.22	LOP with display front flap – Replacement	171
10.3.23	Local Operating Panel LOP – Replacement	173
10.3.24	Gear Control Unit GCU – Replacement	174
10.3.25	Priming Pump Controller PPC – Repair	176
10.3.26	Priming Pump Controller PPC – Replacement	178
10.4	Supplementary Technical Information	179
10.4.1	Control unit PIM 4 MCS – Internal design	179
10.4.2	Local Operating Panel LOP – Design	184

10.4.3	Gear Control Unit GCU 6 – Design	194
10.4.4	Priming Pump Controller PPC – Design	199
Installation and Commissioning Instructions		201
11	Installation	203
11.1	Preparation	203
11.1.1	Cable routes and openings between all installation locations – Check	203
11.1.2	Cables between installation locations – Routing	205
11.2	Mechanical Installation	207
11.2.1	PIM 4 module housing – Installation	207
11.2.2	OceanLine analog display instruments – Installation	208
11.2.3	VDO horn – Installation	210
11.2.4	Indicator lamp – Installation	211
11.2.5	Illuminated pushbutton / key switch – Installation	212
11.2.6	GCU – Installation	214
11.2.7	Priming Pump Controller PPC – Installation	215
11.2.8	DIS – Installation	216
11.2.9	LOP – Installation	217
11.2.10	LOP with display – Adaptation for Waterjet applications	219
11.2.11	Terminal box X010 – Installation	221
11.3	Electric Installation	222
11.3.1	HSK cable bushing – Preparation	222
11.3.2	Terminal strip – Preparation	223
11.3.3	PIM 4 cover – Removal	224
11.3.4	Connecting GCU 6	225
11.3.5	Waterjet remote control system (shipyard) – Connection	227
11.3.6	Third-party gearbox – Connection	232
11.3.7	Connecting engine governor ECU	235
11.3.8	Connecting display instruments on the main control stand	236
11.3.9	Main control stands – Connecting controls and status indicator lamps	237
11.3.10	Connecting devices on a slave control stand	238
11.3.11	Control unit PIM 4 MCS – Connection	239
11.3.12	Priming Pump Controller PPC (3-phase) – Connection	243
11.3.13	Starter and battery-charging generator – Connection	245
11.3.14	Display (option) main control stand – Connection	251
11.3.15	LOP – Connection	252
11.3.16	Connecting additional Yard signals (optional)	255
11.3.17	Priming Pump Controller PPC (single-phase) – Connection	257
11.3.18	Terminal box X010 – Connection (battery-charging generator charges starter battery)	259
12	Initial Operation	263
12.1	Preparation	263
12.1.1	Checks prior to startup	263
12.1.2	Operating voltage – Initial connection	264
12.1.3	Supply voltage distribution – Check	266
12.2	Settings	269
12.2.1	CAN nodes BlueLine – Configuration	269

12.2.2	ECU configuration	270
12.2.3	Making settings via Mini Dialog	271
12.3	Tests	279
12.3.1	Initial engine start-up at the service interface of the LOP	279
12.3.2	Initial engine startup at the display of Local Operating Panel LOP	280
12.3.3	Initial engine start at MCS	281
Annex		283
13	Annex	285
13.1	Conversion tables	285
13.2	Abbreviations	291
13.3	Index	297

