



Installation and Commissioning Instructions

Electronic control system
BlueVision | NewGeneration
Series 2000 / 4000
FPP / ADEC
Application: Marine

E532792/08E



A Rolls-Royce
solution

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to §15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

Table of Contents

1 Safety			
1.1 Important provisions for electronic products	5	2.3.14 Command unit ROS 17 (Palm Beach) – Installation	41
1.2 Intended use of electronic products	6	2.3.15 Command unit ROS 18 (Pininfarina Premium Yacht Design) – Installation	43
1.3 Personnel and organizational requirements	7	2.3.16 Control panel PAN 9 – Installation	44
1.4 Safety regulations for commissioning and operation of electronic products	8	2.3.17 Control panel PAN 10 – Installation	45
1.5 Safety regulations for assembly, maintenance, and repair work on electronic products	9	2.3.18 Emergency panel – Installation	46
1.6 Fire and environmental protection, consumables and auxiliary materials for electronic products	11	2.3.19 Ethernet dialog interface – Installation	47
1.7 Standards for warning messages in the text and highlighted information	12	2.3.20 Systembus Coupling Unit SCU – Installation (Advanced scope)	48
2 Installation		2.3.21 Ethernet switch SMCS 8GT – Installation (Advanced scope)	49
2.1 Preparation	13	2.3.22 Local Operating Panel LOP – Installation	50
2.1.1 Cables for Local Operating Panel LOP and control stands – Routing	13	2.3.23 MEM in front panel of LOS 4 of LOP 14 – Installation	52
2.1.2 Cable routes and openings between all installation locations – Check	16	2.3.24 Labeling kit for Local Operating Panel LOP – Replacement	53
2.1.3 Cables – Routing between installation locations (Basic scope)	17	2.4 Mechanical Installation – Optional Portable Control Unit	54
2.1.4 Cables – Routing between installation locations (Advanced scope)	19	2.4.1 Remote Interface Module RIM 2 – Installation	54
2.1.5 Emergency panel option – Cable routes	21	2.4.2 Portable control unit connection socket – Installation	56
2.2 Preparation – Optional Portable Control Unit	22	2.5 Electrical Installation	57
2.2.1 Portable control unit system cable routes and openings	22	2.5.1 Numbering convention for multiple-engine plants	57
2.2.2 Portable control unit system – Cable routing	23	2.5.2 Power supply for mtu components with separate earth/ground	59
2.3 Mechanical Installation	24	2.5.3 Local Operating Panel LOP – Connection	60
2.3.1 Analog display instruments – Installation (Basic scope)	24	2.5.4 Connecting cables on Local Operating Panel LOP (Basic scope) – Connection	70
2.3.2 Analog display instruments – Installation (Advanced scope)	26	2.5.5 Connecting cables on Local Operating Panel LOP (Advanced scope) – Connection	71
2.3.3 Buzzer – Installation (exposed control stand)	27	2.5.6 Signal connection in LOP yard interface	72
2.3.4 Key switch – Installation	28	2.5.7 Engine Interface Module EIM – Connection	79
2.3.5 Display Basic DIS – Installation	29	2.5.8 Gearbox interface – Connection	80
2.3.6 SD card in display Basic DIS – Installation	30	2.5.9 Priming Pump Controller PPC (single phase) – Connection	81
2.3.7 Display MFD – Installation	31	2.5.10 Priming Pump Controller PPC (three phases) – Connection	82
2.3.8 SD card in display MFD – Installation	32	2.5.11 Systembus Coupling Unit SCU (Advanced scope) – Connection	83
2.3.9 Display MTD – Installation	33	2.5.12 Connecting cables at SCU (Advanced scope) – Connection	86
2.3.10 Display MTD2/MTD3 – Removal	35	2.5.13 Ethernet switch SMCS 8GT (Advanced scope) – Connection	88
2.3.11 Display MTD2/MTD3 – Installation	36	2.5.14 Key switch (optional) – Connection	90
2.3.12 Display MTD2/MTD3 – SD card installation and battery connection	38	2.5.15 Controls and display instruments (Basic scope) – Connection	91
2.3.13 Command unit – Installation	40	2.5.16 Controls and display instruments (Advanced scope) – Connection	95

2.5.17	Control panel PAN – Connection	98	4.2.10	Front panel with labels – Replacement	143
2.5.18	Command units – Connection (all variants)	99	4.2.11	Systembus Coupling Unit SCU – Setting	145
2.5.19	Lever with bow thruster pushbutton – Connection to shipyard interface (option)	102	4.2.12	Display Basic DIS – Settings	146
2.5.20	Emergency panel – Connection	103	4.2.13	MFD display – Settings	148
2.6	Electrical Installation – Optional Portable Control Unit	105	4.2.14	Display MTD1 – Setting	151
2.6.1	RIM 2 – Opening	105	4.2.15	Display MTD2/MTD3 – SD card installation for software installation	153
2.6.2	Terminal strips or terminal blocks (spring terminals) – Preparation	106	4.2.16	Display MTD2/MTD3 – Software installation	154
2.6.3	RIM 2 connection – Remote control	108	4.2.17	Display MTD2/MTD3 – Setting node number later	156
2.6.4	RIM 2 connection – Yard interface	110	4.2.18	Display MTD2/MTD3 – Setting	158
2.6.5	RIM 2 – Closing	112	4.2.19	Emergency panel – Setting	162
3	Data Transmission		4.2.20	Settings via the Service interface	163
3.1	NMEA0183 (VDR) – Applications	113	4.3	Tests	165
3.2	RS-422 for NMEA0183 (VDR) – Description	114	4.3.1	Oil priming pump control unit PPC – Check and adjustment	165
3.3	VDR connector on LOP – Pin assignment	116	4.3.2	Lamp test	166
3.4	Transmission values as per NMEA0183	117	4.3.3	Assuming initial command – Check	167
3.5	Proprietary parameter set table – mtu - NMEA0183	118	4.3.4	Command transfer – Check (Basic scope)	168
3.6	RS422 – Transmission values	120	4.3.5	Command transfer – Check (Advanced scope)	169
4	Initial Operation		4.3.6	Engine – Cranking	171
4.1	Preparation	121	4.3.7	Initial engine start-up	172
4.1.1	Checks before startup	121	4.3.8	Emergency stop test	174
4.1.2	Operating voltage – Initial connection	122	4.3.9	Overspeed test	175
4.1.3	RIM 2 – Status displays	123	4.3.10	Clutch settings – Check	176
4.2	Settings	125	4.3.11	Portable control unit speed control and clutch setting – Check	177
4.2.1	Configuration of CAN nodes BlueVision_Basic NewGeneration	125	4.3.12	Emergency panel speed control and clutch setting – Check	178
4.2.2	CAN node BlueVision_Advanced NewGeneration – Configuration	127	4.3.13	Crash stop function – Setting	179
4.2.3	Portable controller CAN node number – Setting	129	4.3.14	Operation of ZF Autotroll Type Inside – Setting	180
4.2.4	Local Operating Panel LOP – Settings	130	4.4	Data retrieval	181
4.2.5	LOP display DIS – Setting	135	5	Appendix A	
4.2.6	Control panel PAN 9 – Settings	137	5.1	Abbreviations	182
4.2.7	Control panel PAN 10 – Settings	139	5.2	Conversion tables	186
4.2.8	Control panel locking device – Replacement	140	5.3	Contact person / Service partner	190
4.2.9	Control panel cover cap – Replacement	142	6	Appendix B	
			6.1	Standard Tools and Special Tools	191
			6.2	Index	192

1 Safety

1.1 Important provisions for electronic products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Assembly, maintenance, and repair without ESD („Electro Static Discharge“) equipment and ESD work station
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

1.2 Intended use of electronic products

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/Rolls-Royce Solutions contact/Service partner)
- In the original configuration of the delivery or in a configuration approved in writing by the manufacturer
- In compliance with all safety regulations and in adherence with all safety and warning notices in this manual
- Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

1.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.

1.4 Safety regulations for commissioning and operation of electronic products

Safety regulations for commissioning

Install the product correctly and carry out acceptance in accordance with the manufacturer's specifications before putting the product into service. All necessary approvals must be granted by the relevant authorities and all requirements for initial startup must be fulfilled.

Whenever the product is subsequently taken into operation ensure that:

- All maintenance and repair work has been completed.
- All protective devices are in place.
- The power supply (power plug) must always be accessible to allow isolation of the equipment from supply voltage at any time.
- All components are properly grounded. Ground separately by means of a grounding stake as necessary.
- No persons wearing pacemakers or any other technical body aids are present.
- Adequate ventilation of the operating room must be ensured for any operating status.
- The product must be free of any damage, this applies in particular to lines and cabling.
- Protect battery terminals, generator terminals or cables against accidental contact.
- All connections are correctly arranged/assigned, e.g. polarization.

Immediately after putting the product into operation, make sure that all control and display instruments as well as the monitoring, signaling and alarm systems work properly.

Safety regulations during operation

The operator must be familiar with the control and display elements.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be observed with regard to present operating status, violation of limit values and warning or alarm messages.

Malfunctions and emergency stop

Practice emergency procedures, especially emergency stopping, at regular intervals.

The emergency stop safety function must be triggered at least once a year and checked for function in accordance with the emergency stop test specifications (see (→ workshop manual) or (→ operating instructions)). Furthermore, the class requirements apply and must be observed additionally if necessary.

Take the following steps if any system malfunctions are detected or signaled by the system:

- Inform supervisor(s) in charge.
- Analyze the message.
- If required, carry out emergency operations e.g. isolate the equipment from the power supply.

Contact Service if the root cause of the malfunction cannot be clearly identified.

Operation of electrical equipment

When electrical equipment is in operation, certain components of these appliances are electrically live.

Follow the applicable operating and safety instructions when operating the devices and heed warnings at all times.

1.5 Safety regulations for assembly, maintenance, and repair work on electronic products

Safety regulations for work prior to assembly, maintenance, and repair

Have assembly, maintenance, or repair work carried out by qualified and authorized personnel only.

Never carry out assembly, maintenance, or repair work with the product in operation, unless:

- It is expressly permitted to do so following a written procedure.

Attach "Do not operate" sign in the operating area or to control equipment.

Use the recommended special tools or suitable equivalents when instructed to do so.

Safety regulations when performing assembly, maintenance, and repair work

Special tools and lifting equipment

Use only proper and calibrated tools.

Removing, installing and cleanliness

Pay particular attention to cleanliness at all times.

Working on electrical and electronic assemblies

Always obtain the permission of the person in charge before commencing assembly, maintenance, or repair work and before switching off any part of the electronic system required to do so.

De-energize the relevant areas prior to working on assemblies.

Follow the safety rules:

- Disconnect the electric system from live parts.
- Reliably prevent inadvertent power-on.
- Verify absence of voltage using suitable measuring/test equipment e.g. voltage indicator.
- Connect conductors and grounding with a short-circuiting device, e.g. grounding bar.
- Cover adjacent live parts. Prevent access by unauthorized persons.

ESD (Electrostatic Discharge): Work on components which could be damaged by electrostatic discharge must always be carried out with appropriate equipment. Appropriate equipment are e.g. electrically conductive work surfaces or antistatic wristbands.

Do not damage cabling during removal work. When reconnecting, ensure that cabling cannot be damaged during operation by:

- Contact with sharp edges
- Chafing on components
- Contact with hot surfaces.

Do not secure cables on lines carrying fluids.

Do not use cable ties to secure lines.

Always use connector pliers to tighten union nuts on connectors.

Never use the product as a climbing aid.

Subject the device as well as the product to functional testing on completion of all repair work. The emergency stop function must be tested in particular. The emergency stop function test involves the deactivation of the engine controller power supply. This test may only be performed when the product is cold.

Store spare parts properly prior to replacement, i.e. protect them against moisture in particular. Package faulty electronic components or assemblies properly before dispatching for repair:

- Moisture-proof
- Shock-proof
- Wrapped in antistatic foil (as necessary)

Safety regulations after performing assembly, maintenance, and repair work

Re-install all protective devices and remove all tools and loose parts.

Ensure that no unattached parts have been left in/on the product (e.g. including rags and cable straps).

Ensure that the grounding system is properly connected.