

System documentation

Electronics

BlueVision

Engine Control System ECS-5

Application: Marine

Functional Description

Operating Instructions

E532175/02E



Power. Passion. Partnership.

Printed in Germany

© 2013 Copyright MTU Friedrichshafen GmbH

This Publication is protected by copyright and may not be used in any way whether in whole or in part without the prior written permission of MTU Friedrichshafen GmbH. This restriction also applies to copyright, distribution, translation, microfilming and storage or processing on electronic systems including data bases and online services.

This handbook is provided for use by maintenance and operating personnel in order to avoid malfunctions or damage during operation.

Subject to alterations and amendments.

Table of Contents

1 General Provisions			
1.1 Safety	4		
1.1.1 Important provisions for all products	4		
1.1.2 Personnel and organizational requirements	5		
1.1.3 Safety regulations for startup and operation	6		
1.1.4 Safety regulations for maintenance and repair work	7		
1.1.5 Standards for safety notices in the text	10		
2 Functional Description			
2.1 Design and Function	11		
2.1.1 BlueVision system – Complete overview	11		
2.1.2 ECS-5 BlueVision – Overview	13		
2.1.3 ECS-5 BlueVision – Use of devices	18		
2.1.4 ECS-5 BlueVision – Interaction of devices and signal paths	25		
2.1.5 Exhaust Flap Control	28		
2.1.5.1 Function	28		
3 Operating Instructions			
3.1 Controls and Displays	30		
3.1.1 All Engine Series, All Propulsion Systems	30		
3.1.1.1 Local Operating Panel LOP 8 – Displays and controls	30		
3.1.1.2 Display on LOP 8 – Screen pages, navigation and function keys	33		
3.1.1.3 Fault message displays	45		
3.1.2 Engine Series 4000 only, Option	48		
3.1.2.1 Controls and indicators	48		
3.2 Operation	49		
3.2.1 All Engine Series	49		
3.2.1.1 Power train – Ready for operation switching	49		
3.2.1.2 Local mode – Activation	50		
3.2.1.3 Engine – Start (without oil priming pump option)	51		
3.2.1.4 Engine – Start (with oil priming pump option)	52		
3.2.1.5 Local mode – Gearbox engagement/disengagement	53		
3.2.1.6 Local mode – Engine speed adjustment	54		
3.2.1.7 Engine shutdown	55		
3.2.1.8 Local mode – Deactivation	56		
3.2.1.9 Engine start – Interlock	57		
3.2.1.10 Engine – Emergency shutdown	58		
3.2.2 All Engine Series, Waterjet Propulsion only	59		
3.2.2.1 Backflush for Waterjet featuring backflush	59		
3.2.3 Engine Series 4000 only, Option	60		
3.2.3.1 Priming Pump Controller PPC – Function check	60		
3.3 Troubleshooting	61		
3.3.1 All Engine Series	61		
3.3.1.1 Fault and alarm handling on BlueVision ECS-5	61		
3.3.1.2 Horn and alarm acknowledgment at the LOP	62		
3.3.1.3 Troubleshooting	63		
3.3.1.4 Fault displays on the screen	65		
3.3.1.5 Fault displays on printed circuit board MPU 29	75		
3.3.1.6 Fault displays on SAM	79		
3.3.2 Engine Series 2000 M60, M70, M90, M91	80		
3.3.2.1 Fault messages of Engine Control Unit ECU 4 for Series 2000 PLD (unit-pump system)	80		
3.3.3 Engine Series 2000 M72, M73, M92, M93	89		
3.3.3.1 Fault messages of Engine Control Unit ECU 7 for Series 2000 CR	89		
3.3.4 Engine Series 4000 M60, M61, M70, M71, M90	97		
3.3.4.1 Fault messages of Engine Control Unit ECU 4 for Series 4000	97		
3.3.4.2 Oil priming pump, oil refill pump – Troubleshooting	106		
3.4 Task Description	109		
3.4.1 Wiring (General) for Engine/Gearbox/Unit	109		
3.4.1.1 Engine wiring – Check	109		
3.4.1.2 Wiring – Check	110		
3.4.2 Operating Tests	111		
3.4.2.1 Overspeed test	111		
3.4.2.2 Cranking	112		
3.4.3 Control and Display Elements, General	113		
3.4.3.1 Indicator lamp – LED replacement	113		
4 Appendix A			
4.1 Abbreviations	115		
4.2 Conversion tables	119		
4.3 MTU contact persons/service partners	123		
5 Appendix B			
5.1 Special Tools	124		
5.2 Index	125		

1 General Provisions

1.1 Safety

1.1.1 Important provisions for all products

Nameplate

The product is identified by nameplate, model designation or serial number and must match with the information on the title page of this manual.

Nameplate, model designation or serial number can be found on the product.

General information

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Modifications or conversions
- Noncompliance with the safety instructions and warning notices

Correct use

The product is intended exclusively for the application specified in the contract or defined at the time of delivery.

This means that the equipment must be operated:

- Within the permissible operating parameters in accordance with the (→ product data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ applicable Spare Parts Catalog)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (including engine control/parameters)
- In compliance with all safety instructions and in adherence to all warning notices in this manual
- In accordance with the maintenance requirements over the entire service life of the product (→ Maintenance Schedule)
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair
- By contracting only workshops authorized by the manufacturer to carry out repair and overhaul

Any other use is considered improper use and increases the risk of personnel injury or material damage in product operation. The manufacturer will accept no liability for such damage.

Modifications or conversions

Unauthorized modifications to the product compromise safety.

The manufacturer will accept no liability or warranty claims for any damage caused by unauthorized modifications or conversions.

Spare parts

Only genuine spare parts must be used to replace components or assemblies.

The manufacturer will accept no liability or warranty claims for any damage caused by the use of other spare parts.

1.1.2 Personnel and organizational requirements

Organizational measures of the operator

This manual must be issued to all personnel involved in operation, maintenance, repair or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair and transport personnel at all times.

Use this manual as a basis for instructing personnel on product operation and repair, whereby the safety-relevant instructions, in particular, must be read and understood.

This is particularly important in the case of personnel who only occasionally perform work on or around the product. This personnel must be instructed repeatedly.

Personnel requirements

All work on the product shall be carried out by trained and qualified personnel only.

- Training at the Training Center of the manufacturer
- Qualified personnel specialized in mechanical and plant engineering

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair and transport.

Working clothes and personal protective equipment

Wear proper protective clothing for all work.

When working, always wear the necessary personal protective equipment (e.g. ear protectors, protective gloves, goggles, breathing protection). Observe the information on personal protective equipment in the respective activity description.

1.1.3 Safety regulations for startup and operation

Safety regulations for startup

Install the product correctly and carry out acceptance in accordance the manufacturer's specifications before putting the product into service.

Before the product is put into operation for the first time, all official authorizations must be available and commissioning preconditions met.

When putting the product into operation, always ensure

- that all maintenance and repair work has been completed;
- that all loose parts have been removed from rotating machine components;
- that no-one is present in the danger zone of rotating machine components.

Immediately after putting the product into operation, make sure that all control and display instruments as well as the signaling and alarm systems work properly.

Safety regulations for equipment operation

The operator must be familiar with the control and display elements.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be permanently observed with regard to present operating status, violation of limit values and warning or alarm messages.

Malfunctions and emergency stop

The procedures for cases of emergency, in particular, emergency stop, must be practiced regularly.

The following steps must be taken if a malfunction of the system is recognized or reported by the system:

- Inform supervisor(s) in charge,
- Analyze the message,
- If required, carry out emergency operations e.g. emergency stop.

Operation

The following conditions must be fulfilled before starting the product:

- Wear ear protection.
- Ensure that the engine room is well ventilated.
- Do not inhale the exhaust gases of the product.
- Ensure that the exhaust system is free of leaks and that the gases are discharged to atmosphere.
- Mop up any leaked or spilt fluids and lubricants immediately or soak up with a suitable binding agent.
- Protect battery terminals, generator terminals or cables against accidental contact.

Operation of electrical equipment

When electrical equipment is in operation, certain components of these appliances are electrically live.

Observe the safety instructions for these devices.

1.1.4 Safety regulations for maintenance and repair work

Safety regulations prior to maintenance and repair work

Have maintenance or repair work carried out by qualified and authorized personnel only.

Allow the product to cool down to less than 50°C before starting maintenance work (risk of explosion of oil vapors, fluids and lubricants, risk of burning).

Before starting work, relieve pressure in systems and compressed-air lines which are to be opened. Use suitable containers of adequate capacity to catch fluids and lubricants.

When changing the oil or working on the fuel system, ensure that the engine room is adequately ventilated.

Never carry out maintenance and repair work with the product in operation.

Carry out function checks on a product in operation only if expressly permitted to do so.

Secure the product against unintentional starting, e.g. with start interlock.

Attach "Do not operate" sign in the operating area or to control equipment.

Disconnect the battery. Lock circuit breakers.

Close the main valve on the compressed-air system and vent the compressed-air line when pneumatic starters are fitted.

Disconnect the control equipment from the product.

The following additional instructions apply to starters with beryllium copper pinion:

- Breathing protection of filter class P2 must be applied during maintenance work to avoid health hazards caused by the beryllium-containing pinion. Do not blow out the interior of the flywheel housing or the starter with compressed air. Clean the flywheel housing inside with a class H dust extraction device as an additional measure.

Safety regulations during maintenance and repair work

Take special care when removing ventilation or plug screws from the product. Cover the screw or plug with a rag to prevent fluids escaping under pressure.

Take care when draining hot fluids and lubricants (risk of burning).

Use only proper and calibrated tools. Observe the specified tightening torques during assembly or disassembly.

Carry out work only on assemblies or plants which are properly secured.

Never use lines for climbing.

Keep fuel injection lines and connections clean.

Always seal connections with caps or covers if a line is removed or opened.

Take care not to damage lines, in particular fuel lines, during maintenance and repair work.

Ensure that all retainers and dampers are installed correctly.

Ensure that all fuel injection and pressurized oil lines are installed with enough clearance to prevent contact with other components. Do not place fuel or oil lines near hot components.

Do not touch elastomeric seals if they have carbonized or resinous appearance unless hands are properly protected.

Note cooling time for components which are heated for installation or removal (risk of burning).

When working high on the equipment, always use suitable ladders and work platforms. Make sure components or assemblies are placed on stable surfaces.

Ensure particular cleanness during maintenance and repair work on the product. After completion of maintenance and repair work, make sure that no loose objects are in/on the product (e.g. cloths and cable ties)

Safety regulations after completion of maintenance and repair work

Before barring, make sure that nobody is standing in the danger zone of the product.

Check that all guards have been reinstalled and that all tools and loose parts have been removed after working on the product (in particular, the barring tool).

Welding work

Welding operations on the product or mounted units are not permitted. Cover the product when welding in its vicinity.

Before starting welding work:

- Switch off the power supply master switch.
- Disconnect the battery.
- Separate the electrical ground of electronic equipment from the ground of the unit.

No other maintenance or repair work must be carried out in the vicinity of the product while welding is going on. Risk of explosion or fire due to oil vapors and highly flammable fluids and lubricants.

Do not use product as ground terminal.

Never position the welding power supply cable adjacent to, or crossing wiring harnesses of the product. The welding current may otherwise induce an interference voltage in the wiring harnesses which could conceivably damage the electrical system.

Remove parts (e.g. exhaust pipes) which are to be welded from the product beforehand.

Hydraulic installation and removal

Check the function and safe operating condition of tools and fixtures to be used. Use only the specified devices for hydraulic removal/installation procedures.

Observe the max. permissible push-on pressure specified for the equipment.

Do not attempt to bend or apply force to lines.

Before starting work, pay attention to the following:

- Vent the hydraulic installation/removal tool, the pumps and the lines at the relevant points for the equipment to be used (e.g. open vent plugs, pump until bubble-free air emerges, close vent plugs).
- For hydraulic installation, screw on the tool with the piston retracted.
- For hydraulic removal, screw on the tool with the piston extended.

For a hydraulic installation/removal tool with central expansion pressure supply, screw spindle into shaft end until correct sealing is established.

During hydraulic installation and removal, ensure that nobody is standing in the immediate vicinity of the component to be installed/removed.

Working with batteries

Observe the safety instructions of the battery manufacturer when working with batteries.

Gases emanating from the battery are explosive. Avoid sparks and naked flames.

Do not allow electrolyte to come in contact with skin or clothing.

Wear protective clothing and protective gloves.

Never place tools on the battery.

Before connecting the cable to the battery, check the battery polarity. Battery pole reversal may lead to injury through the sudden discharge of acid or bursting of the battery body.

Working on electrical and electronic assemblies

Always obtain the permission of the person in charge before commencing maintenance and repair work or switching off any part of the electronic system required to do so.

De-energize the appropriate areas prior to working on assemblies.

Do not damage cabling during removal work. When reinstalling ensure that wiring is not damaged during operation by contact with sharp objects, by rubbing against other components or by a hot surface.

Do not secure cables on lines carrying fluids.

Do not use cable binders to secure cables.

Always use connector pliers to tighten union nuts on connectors.

Subject the device as well as the product to a function check on completion of all repair work. In particular, check the function of the engine emergency stop feature.

Store spare parts properly prior to replacement, i.e. protect them against moisture in particular. Pack defective electronic components and assemblies in a suitable manner when dispatched for repair, i.e. protected, in particular, against moisture and impact and wrapped in antistatic foil if necessary.

Working with laser equipment

When working with laser equipment, always wear special laser-protection goggles (hazard due to heavily focused radiation).

Laser equipment must be fitted with the protective devices necessary for safe operation according to type and application.

For conducting light-beam procedures and measurement work, only the following laser devices must be used:

- Laser devices of classes 1, 2 or 3A.
- Laser devices of class 3B, which have maximum output in the visible wavelength range (400 to 700 nm), a maximum output of 5 mW, and in which the beam axis and surface are designed to prevent any risk to the eyes.

1.1.5 Standards for safety notices in the text

DANGER 	In the event of immediate danger. Consequences: Death, serious or permanent injury! • Remedial action.
WARNING 	In the event of a situation involving potential danger. Consequences: Death, serious or permanent injury! • Remedial action.
CAUTION 	In the event of a situation involving potential danger. Consequences: Minor or moderate injuries! • Remedial action.
NOTICE 	In the event of a situation involving potentially adverse effects on the product. Consequences: Material damage. • Remedial action • Additional product information

Safety notices

- This manual with all safety instructions and safety notices must be issued to all personnel involved in operation, maintenance, repair or transportation.