

MTU_ValueService **Technical Documentation**

Electronic Equipment
BlueVision
Remote Control System RCS-5 WJ

Application: Marine

Installation and Commissioning Instructions
E532345/00E



Printed in Germany

© 2011 Copyright MTU Friedrichshafen GmbH

This Publication is protected by copyright and may not be used in any way whether in whole or in part without the prior written permission of MTU Friedrichshafen GmbH. This restriction also applies to copyright, distribution, translation, microfilming and storage or processing on electronic systems including data bases and online services.

This handbook is provided for use by maintenance and operating personnel in order to avoid malfunctions or damage during operation.

Subject to alterations and amendments.

1	Safety	5
1.1	General conditions	5
1.2	Personnel and organizational requirements	6
1.3	Safety regulations for startup and operation	7
1.4	Safety regulations for maintenance and repair work	8
1.5	Conventions for safety instructions in the text	10
2	Installation	11
2.1	Preparation	11
2.1.1	Numbering standard for multi-shaft systems	11
2.1.2	Cable routes and openings between installation locations	13
2.1.3	Cables – Routing between installation locations	14
2.1.4	Control Panel PAN	22
2.1.4.1	Installation planning	22
2.2	Mechanical Installation	23
2.2.1	Control lever panel ROS – Overview for installation	23
2.2.2	Control lever panel ROS – Preparation for installation	24
2.2.3	Control lever housing ROS – Installation	25
2.2.4	Control lever panel ROS – Connection of control lever housing to connection housing	27
2.2.5	Control panel – Installation	28
2.2.6	Steering wheel – Installation	30
2.2.7	Joystick – Installation	31
2.2.8	Analog (square type) display instruments – Installation	32
2.2.9	PCMU – Installation	33
2.3	Electrical Installation	34
2.3.1	Control lever panel ROS – Connection housing connection	34
2.3.2	CCP connection plates – Connection for RCS-5	38
2.3.3	PCMU – Connection	41
3	Initial Operation	43
3.1	Preparation	43
3.1.1	Pre-startup checks	43
3.1.2	Operating voltage – Initial application	44
3.1.3	CAN node number and transmission rate – Setting	45
3.1.4	Node address at control panel – Setting	46
3.1.5	Node address, PCMU – Setting	47
3.1.6	PCMU – Putting into operation	48
3.1.7	Software download	49
3.2	Control Lever Panel Checks	50
3.2.1	Speed control and clutch setting – Check	50
3.2.2	Command transfer – Check (only when several control stands are installed)	51
4	Appendix A	55
4.1	Abbreviations	55

	4.2	Conversion tables.....	58
	4.3	MTU contacts/service partners	62
5		Appendix B.....	63
	5.1	Special Tools	63
	5.2	Consumables.....	64
	5.3	Index.....	65

1 Safety

1.1 General conditions

General

In addition to the instructions in this publication, the applicable country-specific legislation and other compulsory regulations regarding accident prevention and environmental protection must be observed. This state-of-the-art engine has been designed to meet all applicable laws and regulations. The engine may nevertheless present a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Modifications or conversions
- Noncompliance with the Safety Instructions

Correct use

The engine is intended solely for use in accordance with contractual agreements and the purpose envisaged for it on delivery. Any other use is considered improper use. The engine manufacturer accepts no liability whatsoever for resultant damage or injury in such case. The responsibility is borne by the user alone.

Correct use also includes observation of and compliance with the operating instructions and maintenance and repair specifications.

Modifications or conversions

Unauthorized modifications to the engine represent a safety risk.

MTU will accept no liability or warranty claims for any damage caused by unauthorized modifications or conversions.

Spare parts

Only genuine MTU spare parts must be used to replace components or assemblies. MTU accepts no liability whatsoever for damage or injury resulting from the use of other spare parts and the warranty shall be voided in such case.

Reworking components

Repair or engine overhaul must be carried out in workshops authorized by MTU.

1.2 Personnel and organizational requirements

Personnel requirements

Work on the engine must only be carried out by appropriately qualified and instructed personnel.

Observe the minimum legal age.

Responsibilities of the operating, maintenance and repair personnel must be specified by the operating company.

Organizational measures

This publication must be issued to all personnel involved in operation, maintenance, repair or transportation.

Keep it handy in the vicinity of the engine such that it is accessible to operating, maintenance, repair and transport personnel at all times.

Use the manual as a basis for instructing personnel on engine operation and repair. In particular, personnel must have read and understood the safety-relevant instructions.

This is especially important for personnel who work on the engine only on an occasional basis. These persons shall receive repeated instruction.

Use the Spare Parts Catalog to identify spare parts during maintenance and repair work.

Working clothes and protective equipment

Wear proper protective clothing for all work.

Depending on the kind of work, use the necessary personal protective equipment.

1.3 Safety regulations for startup and operation

Safety requirements for initial operation

Prior to initial operation of the unit, install the assembly or unit according to the specifications and check the installation according to the MTU specifications.

Before putting the device or plant into operation, always ensure:

- that all maintenance and repair work is completed,
- that all loose parts have been removed from rotating machine components,
- that nobody is in the danger area of moving machine parts.

Immediately after putting the device or plant into operation, make sure that all control and display instruments as well as the signaling and alarm systems work properly.

Safety requirements for operators

The procedures for cases of emergency must be practiced regularly.

The operator must be familiar with the control and display elements.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be permanently observed with regard to present operating status, violation of limit values and warning or alarm messages.

The following steps must be taken if a malfunction of the system is recognized or reported by the system:

- inform supervisor(s) in charge,
- analyze the message,
- if required, carry out emergency operations e.g. emergency engine stop.

Engine operation

The following conditions must be fulfilled before starting the engine:

- Wear ear protection.
- Ensure that the engine room is well ventilated.
- Do not inhale engine exhaust gases.
- Ensure that the exhaust system is free of leaks and that the gases are discharged to atmosphere.
- Mop up any leaked or spilt fluids and lubricants immediately or soak up with a suitable binding agent.
- Protect battery terminals, battery-charger terminals and cables against accidental contact.
- When the engine is running, never release coolant, oil, fuel, compressed-air or hydraulic lines.

Operation of electrical equipment

When electrical equipment is in operation, certain components of these appliances are electrically live.

Observe the safety instructions for these devices.

1.4 Safety regulations for maintenance and repair work

Safety regulations for maintenance and repair work

Have maintenance and repair work carried out by qualified and authorized personnel only.

Allow the engine to cool down before starting maintenance work (risk of explosion of oil vapors).

Before starting work, relieve pressure in systems and compressed-air lines which are to be opened.

Take special care when removing ventilation or plug screws from the engine. Cover the screw or plug with a rag to prevent fluids escaping under pressure.

Take special care when draining hot fluids ⇒ Risk of injury.

When changing the engine oil or working on the fuel system, ensure that the engine room is adequately ventilated.

Allow the engine / system to cool down before starting to work.

Observe the maintenance and repair instructions.

Never carry out maintenance and repair work with the engine running unless expressly instructed to do so.

Secure the engine against accidental starting.

Disconnect the battery when electrical starters are fitted.

Close the main valve on the compressed-air system and vent the compressed-air line when pneumatic starters are fitted.

Disconnect the control equipment from the assembly or system.

Use only proper, calibrated tools. Observe the specified tightening torques during assembly/disassembly.

Carry out work only on assemblies and/or units which are properly secured.

Never use lines for climbing.

Keep fuel injection lines and connections clean.

Always seal connections with caps or covers if a line is removed or opened.

Take care not to damage lines, in particular fuel lines, during maintenance and repair work.

Ensure that all retainers and dampers are installed correctly.

Ensure that all fuel injection and pressurized oil lines are installed with enough clearance to prevent contact with other components. Do not place fuel or oil lines near hot components.

Do not touch elastomeric seals if they have carbonized or resinous appearance unless hands are properly protected.

Note cooling time for components which are heated for installation or removal ⇒ Risk of burning.

When working high on the engine, always use suitable ladders and work platforms. Make sure components are placed on stable surfaces.

Observe special cleanness when conducting maintenance and repair work on the assembly or system. After completion of maintenance and repair work, make sure that no loose objects are in/on the assembly or system.

Before barring the engine, make sure that nobody is standing in the danger zone. Check that all guards have been reinstalled and that all tools and loose parts have been removed after working on the engine.

The following additional instructions apply to starters with beryllium copper pinion:

- Breathing protection of filter class P2 must be applied during maintenance work to avoid health hazards caused by the beryllium-containing pinion. Do not blow out the interior of the flywheel housing or the starter with compressed air. Clean the flywheel housing inside with a class H dust extraction device as an additional measure.

Welding work

Never carry out welding work on the assembly, system, or engine-mounted units. Cover the engine when welding in its vicinity.

Do not use the assembly or system as ground terminal.

Do not route the welding lead over or near the wiring harnesses of MTU systems. The welding current may otherwise induce an interference voltage in the wiring harnesses which could conceivably damage the electrical system.

Remove parts (e.g. exhaust pipes) which are to be welded from the engine beforehand.

Hydraulic installation and removal

Check the function and safe operating condition of tools and fixtures to be used. Use only the specified devices for hydraulic removal/installation procedures.

Observe the max. permissible push-on pressure specified for the equipment.

Do not attempt to bend or apply force to lines.

Before starting work, pay attention to the following:

- Vent the hydraulic installation/removal tool, the pumps and the lines at the relevant points for the equipment to be used (e.g. open vent plugs, pump until bubble-free air emerges, close vent plugs).
- For hydraulic installation, screw on the tool with the piston retracted.
- For hydraulic removal, screw on the tool with the piston extended.

For a hydraulic installation/removal tool with central expansion pressure supply, screw spindle into shaft end until correct sealing is established.

During hydraulic installation and removal, ensure that nobody is standing in the immediate vicinity of the component to be installed/removed.

Working on electrical/electronic assemblies

Always obtain the permission of the person in charge before commencing maintenance and repair work or switching off any part of the electronic system required to do so.

De-energize the appropriate areas prior to working on assemblies.

Do not damage cabling during removal work. When reinstalling ensure that wiring is not damaged during operation by contact with sharp objects, by rubbing against other components or by a hot surface.

Do not secure cables on lines carrying fluids.

Do not use cable binders to secure cables.

Always use connector pliers to tighten connectors.

Subject the device or system to a function check on completion of all repair work.

Store spare parts properly prior to replacement, i.e. protect them against moisture in particular. Pack defective electronic components and assemblies in a suitable manner when dispatched for repair, i.e. particularly protected against moisture and impact and wrapped in antistatic foil if necessary.

Working with laser equipment

When working with laser equipment, always wear special laser-protection goggles ⇒ Heavily focused radiation.

Laser equipment must be fitted with the protective devices necessary for safe operation according to type and application.

For conducting light-beam procedures and measurement work, only the following laser devices must be used:

- Laser devices of classes 1, 2 or 3A.
- Laser devices of class 3B, which have maximum output in the visible wavelength range (400 to 700 nm), a maximum output of 5 mW, and in which the beam axis and surface are designed to prevent any risk to the eyes.

1.5 Conventions for safety instructions in the text

Cautions

 DANGER	In the event of immediate danger. Consequences: Death or serious injury • Remedial action
 WARNING	In the event of potentially dangerous situations. Consequences: Death or serious injury • Remedial action
 CAUTION	In the event of dangerous situations. Consequences: Minor injury or material damage • Remedial action

Note:

This manual contains highlighted safety warnings in accordance with the US ANSI Z535 standard which begin with one of the signal words listed above depending on the severity of the hazard.

Safety instructions

1. Read and familiarize yourself with all safety notices before starting up or repairing the product.
2. Pass on all safety instructions to your operating, maintenance, repair and transport personnel.