

Installation and Commissioning Instructions

Electronics

Engine Control System ECS-5

BR4000C22

ECU-4, EMU-1, FCB or SAM (optional)

Application: C&I

E532319/03E



Power. Passion. Partnership.

Printed in Germany

© 2013 Copyright MTU Friedrichshafen GmbH

This Publication is protected by copyright and may not be used in any way whether in whole or in part without the prior written permission of MTU Friedrichshafen GmbH. This restriction also applies to copyright, distribution, translation, microfilming and storage or processing on electronic systems including data bases and online services.

This handbook is provided for use by maintenance and operating personnel in order to avoid malfunctions or damage during operation.

Subject to alterations and amendments.

General information about documentation

Documentation structure

Documentation Part	Title/contents	Target group(s)
1	Structure and function	Operating personnel etc.
2	Operation	Operating personnel
3	Maintenance and repair	Plant personnel
4	Service manual	Electronic service personnel
5	Illustrated parts catalog	Plant personnel, electronic service personnel, logistics personnel
6	Plant-specific configuration	Electronic service personnel, installation personnel, start-up personnel
7	Mechanical and electrical installation	Installation personnel (electromechanical/mechatronic engineer)
8	Initial start-up	Start-up personnel

Note: Not all parts of the documentation are written for every product.

Required knowledge

To understand each part of the documentation, we recommend reading the preceding parts, if applicable.

(This page intentionally blank)

Part 1

Structure and function

(This page intentionally blank)

Table of contents

1	Use	2
1.1	Introduction	2
1.2	Application	2
2	Features	3
3	Structure	4
3.1	System structure	4
3.1.1	Scope with FCB 2 (Version 1)	4
3.1.2	Scope with SAM (Version 2)	5
3.2	Display DIS 10	6
3.2.1	Display DIS 10 – Structure	6
3.2.1.1	Technical data	9
3.2.2	Configuration of display DIS10	10
3.3	Functional description of the devices	13
3.3.1	Engine Control Unit ECU 4	14
3.3.1.1	Structure	14
3.3.1.2	Function	14
3.3.1.3	Installation location	15
3.3.1.4	Connection technology	16
3.3.1.5	Technical data	17
3.3.2	Engine Monitoring Unit EMU 1	18
3.3.2.1	Structure	18
3.3.2.2	Function	18
3.3.2.3	Installation location	20
3.3.2.4	Connection technology	20
3.3.2.5	Technical data	21
3.3.3	Fault code display FCB 2 (A531)	22
3.3.3.1	Structure	22
3.3.3.2	Rotary switches	23
3.3.3.3	Function	24
3.3.3.4	Installation location	27
3.3.3.5	Connection technology	27
3.3.3.6	Technical data	28
3.3.4	System Adaption Module SAM	29
3.3.4.1	Structure	29
3.3.4.2	Installation location	30
3.3.4.3	Connection technology	30
3.3.4.4	Technical data	31

Table of contents *(cont.)*

3.3.4.5	Activation CCB-Gateway	33
3.3.4.5.1	CanOpen: Cruise Control/Vehicle Speed	33
3.3.4.5.2	CanOpen: Electronic Transmission Controller 5	34
3.3.4.5.3	CanOpen: Proprietary Command Signals 1	34
3.3.4.5.4	CanOpen: Electronic Brake Controller 1	37
3.3.4.5.5	CanOpen: Off-Highway Engine Control Selection	37
3.3.4.5.6	CanOpen: Reset	38
3.3.4.5.7	CanOpen: Torque/Speed Control 1	38
3.3.4.5.8	Setting CCB gateway monitoring	39
3.3.4.6	MCS-5 Bus Monitoring	42
3.3.5	Interface module MAU	44
3.3.5.1	Installation location	44
3.3.5.2	Connection technology	44
3.3.6	Display instruments (optional)	45
3.3.6.1	SAM	45
3.3.6.2	ECU	47
3.3.6.3	Engine speed display instrument	48
3.3.6.3.1	Structure	48
3.3.6.3.2	Function	48
3.3.6.3.3	Installation location	48
3.3.6.3.4	Connection technology	48
3.3.6.3.5	Technical data	49
3.3.6.4	Coolant temperature display instrument	50
3.3.6.4.1	Structure	50
3.3.6.4.2	Function	50
3.3.6.4.3	Installation location	50
3.3.6.4.4	Connection technology	50
3.3.6.4.5	Technical data	51
3.3.6.5	Lube oil temperature display instrument (option)	51
3.3.6.5.1	Structure	51
3.3.6.5.2	Function	52
3.3.6.5.3	Installation location	52
3.3.6.5.4	Connection technology	52
3.3.6.5.5	Technical data	52
3.3.6.6	Lube oil pressure display instrument	53
3.3.6.6.1	Structure	53
3.3.6.6.2	Function	53
3.3.6.6.3	Installation location	53
3.3.6.6.4	Connection technology	53
3.3.6.6.5	Technical data	54

Table of contents *(cont.)*

3.4	Sensors and actuators	55
3.4.1	Engine Side Monted Sensors	55
3.4.2	ECU sensors	56
3.4.3	ECU actuators	57
3.5	Cables	58
3.5.1	MTU engine mounted harnesses	58
3.5.2	MTU system cables for the ECU 4	60
3.5.2.1	Technical data	60
3.5.3	MTU system cables for the EMU 1	61
3.5.3.1	Technical data	61
4	Functions	62
4.1	Control functions	62
4.1.1	Engine start	63
4.1.1.1	Normal engine start	63
4.1.1.2	Emergency engine start	64
4.1.1.3	Prelube procedure	64
4.1.2	Engine stop	65
4.1.3	Override	65
4.2	Monitoring functions	65
4.2.1	Engine safety system	65
4.2.1.1	General	65
4.2.1.2	Use	66
4.2.1.3	Safety shutdowns	67
4.2.1.4	Integral Test System (ITS)	67
4.2.1.5	Monitoring of the electronics in the Engine Control Unit ECU	68
4.2.1.6	Sensor/actuator monitoring	68
4.2.1.7	Bus communication monitoring	68
4.2.2	Combined alarm signalling	68
4.2.3	Lamp test (binary output test)	68
4.3	Regulating functions	71
4.3.1	Speed/injection regulation	71
4.3.2	Common Rail injection system	72
4.3.3	Angle measuring/determining engine timing	73
4.3.4	Adjustable speed droop	74
4.3.5	Power limitation (quantity limitation)	75
4.3.5.1	Dynamic quantity limitation	75
4.3.5.2	Fixed quantity limitation	75
4.3.5.3	Fuel quantity control during engine starting	75

Table of contents (cont.)

4.3.6	Cylinder cutout	75
4.3.7	Speed setting	76
4.3.7.1	Speed demand	76
4.3.7.2	Speed setting limit	76
4.3.7.3	Fixed speed	76
4.3.8	Engine mounted fan	77
4.3.9	Braking (increase idle speed)	78
4.3.10	Override (safety system override)	78
4.3.11	Engine speed (UA1)	78
4.3.12	Engine load signal (UA2 optional, default)	78
4.3.13	Lube oil temperature (UA2 optional)	79
4.3.14	Fan speed 0 – 100% (UA2 optional)	79
4.3.15	Set injection quantity (UA2 optional)	79
4.3.16	Lube oil pressure (UA3)	79
4.3.17	Coolant temperature (UA4)	79
4.3.18	Engine control	80
4.3.18.1	Software ECU 4	80
4.3.18.2	Software EMU 1	80
4.3.18.3	Software fault code module A531	81
4.3.18.4	Software SAM	81
4.4	Start and Stop Signals	82
4.4.1	Start	82
4.4.2	Stop	84
5	Interfaces	87
5.1	Serial interface/CAN bus	87
5.2	Binary inputs	87
5.2.1	MDEC (ECU 4)	87
5.2.1.1	BE1 engine stop	87
5.2.1.2	BE2 fan override	87
5.2.1.3	BE3 braking (increase idle speed)	87
5.2.1.4	BE4 speed setpoint switching	87
5.2.1.5	BE5 fixed speed 1	87
5.2.1.6	BE6 Test speed (/fixed speed 2)	88
5.2.1.7	BE7 alarm reset	88
5.2.1.8	BE8 override	88
5.2.1.9	BE9 engine start	88
5.2.2	SAM	88
5.2.2.1	B_IN3 – Request Test Overspeed	88
5.2.2.2	B_IN4 – Reset Trip Fuel Consumption	89
5.2.2.3	B_IN10 – Alarm Rest/Alarm Acknowledge	89