

MTU_ValueService **Technical Documentation**

Electronic equipment
Propulsion plant
remote control system
RCS-5 CPP
Application: Marine

System documentation
E532294/00E



Printed in Germany

© 2012 Copyright MTU Friedrichshafen GmbH

This Publication is protected by copyright and may not be used in any way whether in whole or in part without the prior written permission of MTU Friedrichshafen GmbH. This restriction also applies to copyright, distribution, translation, microfilming and storage or processing on electronic systems including data bases and online services.

This handbook is provided for use by maintenance and operating personnel in order to avoid malfunctions or damage during operation.

Subject to alterations and amendments.

Commissioning Note

Important

Please complete and return the “Commissioning Note” card below to MTU Friedrichshafen GmbH.

The Commissioning Note information serves as a basis for the contractually agreed logistic support (warranty, spare parts, etc.).



Postcard
MTU Friedrichshafen GmbH
Technical Information Management
Dept. VOT
88040 Friedrichshafen
GERMANY

Commissioning Note

Please use block capitals!



Engine No.:	MTU works order no.:
Engine model:	Date put into operation:
Application : * ☐ Marine ☐ Rail ☐ Genset ☐	Type : Manufacturer:
End user`s address:	
Remarks:	

**Commissioning
Note**

Tick appropriate box

1	Safety	7
1.1	General conditions	7
1.2	Personnel and organizational requirements	8
1.3	Safety regulations for startup and operation	9
1.4	Conventions for safety instructions in the text	10
2	Functional Description	11
2.1	Design and Function	11
2.1.1	RCS-5 – Purpose, overview and features of the system	11
2.1.2	RCS-5 CPP – Purpose and function of the units	14
2.1.3	RCS-5 CPP – Bus structure and system integration	16
2.1.4	Printed circuit board RCI 3	17
2.1.5	Single Control Lever mode (SCL)	19
2.1.6	RCS-5 CPP – Performance curves	20
2.1.7	PAN control panel – Design	23
2.2	Technical Data	24
2.2.1	ROS 14 – Technical data	24
2.2.2	PAN 5 – Technical data	26
2.2.3	PAN 6 – Technical data	27
2.2.4	PAN 7 – Technical data	28
2.2.5	PAN 8 – Technical data	29
3	Operating Instructions	31
3.1	Controls and Displays	31
3.1.1	Display and control unit – Control lever panel	31
3.1.2	Control lever panel – Illuminated pushbuttons	33
3.1.3	Control lever panel – Speed step scale	34
3.1.4	Control lever panel – Graphic display and function keys	36
3.1.5	Display and control device – PAN	43
3.2	Operation	45
3.2.1	Switching on remote control system	45
3.2.2	Command transfer – Priorities, conditions and variants	46
3.2.3	Assuming initial command	48
3.2.4	Transferring command	49
3.2.5	Engagement / disengagement	53
3.2.6	Maneuvering	55
3.2.7	Single Control Lever (SCL) mode – Selection	56
3.2.8	Single Control Lever (SCL) mode – Deselection	59
3.2.9	Optional operating modes – Selection and deselection	61
3.2.10	Changing from remote control in multi-lever mode to local control mode	62
3.2.11	Changing from remote control in SCL mode to local control mode	64
3.2.12	Remote to Local mode – Switching	66
3.2.13	Switching off remote control system	68
3.3	Troubleshooting	69
3.3.1	General information about RCS-5 faults	69
3.3.2	Acknowledging alarms at the control lever panel	70

	3.3.3	Fault indication in the graphic display of the control lever panel	71
	3.3.4	Fault symptoms	77
3.4	Repair Work		82
	3.4.1	Checking wiring	82
	3.4.2	LED and actuator in ROS 14 control lever panel – Replacement	83
	3.4.3	PAN 5 and PAN 7 LED – Replacement	85
	3.4.4	PAN 6 and PAN 8 LED – Replacement	87
	3.4.5	PAN 5 and PAN 7 actuator plunger – Replacement	90
	3.4.6	PAN 6 and PAN 8 actuator plunger – Replacement	92
4	Appendix A		95
	4.1	Abbreviations	95
	4.2	MTU contacts/service partners	97
5	Appendix B		99
	5.1	Index	99

1 Safety

1.1 General conditions

General

In addition to the instructions in this publication, the applicable country-specific legislation and other compulsory regulations regarding accident prevention and environmental protection must be observed. This state-of-the-art engine has been designed to meet all applicable laws and regulations. The engine may nevertheless present a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Modifications or conversions
- Noncompliance with the Safety Instructions

Correct use

The engine is intended solely for use in accordance with contractual agreements and the purpose envisaged for it on delivery. Any other use is considered improper use. The engine manufacturer accepts no liability whatsoever for resultant damage or injury in such case. The responsibility is borne by the user alone.

Correct use also includes observation of and compliance with the maintenance specifications.

Modifications or conversions

Unauthorized modifications to the engine represent a safety risk.

MTU will accept no liability or warranty claims for any damage caused by unauthorized modifications or conversions.

Spare parts

Only genuine MTU spare parts must be used to replace components or assemblies. MTU accepts no liability whatsoever for damage or injury resulting from the use of other spare parts and the warranty shall be voided in such case.

Reworking components

Repair or engine overhaul must be carried out in workshops authorized by MTU.

1.2 Personnel and organizational requirements

Personnel requirements

All work on the engine shall be carried out by trained and qualified personnel only.

The specified legal minimum age must be observed.

The operator must specify the responsibilities of the operating, maintenance and repair personnel.

Organizational measures

This publication must be issued to all personnel involved in operation, maintenance, repair or transportation.

Keep it at hand at the operating site of the engine so that it is available to operating, maintenance, repair and transport personnel at all times.

Use the manual as a basis for instructing personnel on engine operation and repair with an emphasis on explaining safety-relevant instructions.

This is particularly important in the case of personnel who only occasionally perform work on or around the engine.

This personnel must be instructed repeatedly.

For the identification and layout of the spare parts during maintenance or repair work, take photos or use the spare parts catalog.

Working clothes and protective equipment

Wear proper protective clothing for all work.

Use the necessary protective equipment for the given work to be done.

1.3 Safety regulations for startup and operation

Safety requirements for initial operation

Prior to initial operation of the unit, install the assembly or unit according to the specifications and check the installation according to the MTU specifications.

Before putting the device or plant into operation, always ensure:

- that all maintenance and repair work is completed,
- that all loose parts have been removed from rotating machine components,
- that nobody is in the danger area of moving machine parts.

Immediately after putting the device or plant into operation, make sure that all control and display instruments as well as the signaling and alarm systems work properly.

Safety requirements for operators

The procedures for cases of emergency must be practiced regularly.

The operator must be familiar with the control and display elements.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be permanently observed with regard to present operating status, violation of limit values and warning or alarm messages.

The following steps must be taken if a malfunction of the system is recognized or reported by the system:

- inform supervisor(s) in charge,
- analyze the message,
- if required, carry out emergency operations e.g. emergency engine stop.

Engine operation

The following conditions must be fulfilled before starting the engine:

- Wear ear protection.
- Ensure that the engine room is well ventilated.
- Do not inhale engine exhaust gases.
- Ensure that the exhaust system is free of leaks and that the gases are discharged to atmosphere.
- Mop up any leaked or spilt fluids and lubricants immediately or soak up with a suitable binding agent.
- Protect battery terminals, battery-charger terminals and cables against accidental contact.
- When the engine is running, never release coolant, oil, fuel, compressed-air or hydraulic lines.

Operation of electrical equipment

When electrical equipment is in operation, certain components of these appliances are electrically live.

Observe the safety instructions for these devices.

1.4 Conventions for safety instructions in the text

Cautions

 DANGER	In the event of immediate danger. Consequences: Death or serious injury • Remedial action
 WARNING	In the event of potentially dangerous situations. Consequences: Death or serious injury • Remedial action
 CAUTION	In the event of dangerous situations. Consequences: Minor injury or material damage • Remedial action
 NOTICE	In the event of a situation involving potentially adverse effects on the product. Consequences: Material damage. • Remedial action • Additional product information

Note:

This manual contains highlighted safety warnings in accordance with the US ANSI Z535 standard which begin with one of the signal words listed above depending on the severity of the hazard.

Safety instructions

1. Read and familiarize yourself with all safety notices before starting up or repairing the product.
2. Pass on all safety instructions to your operating, maintenance, repair and transport personnel.