

Installation and Commissioning Instructions

Electronics

**GenoLine System with LOP 10
and MDEC**

for Onboard Power Generators

Engine Series 2000 P

Application: Marine

E532428/00E



Power. Passion. Partnership.

Printed in Germany

© 2013 Copyright MTU Friedrichshafen GmbH

This Publication is protected by copyright and may not be used in any way whether in whole or in part without the prior written permission of MTU Friedrichshafen GmbH. This restriction also applies to copyright, distribution, translation, microfilming and storage or processing on electronic systems including data bases and online services.

This handbook is provided for use by maintenance and operating personnel in order to avoid malfunctions or damage during operation.

Subject to alterations and amendments.

Commissioning Note

Important

Please complete and return the “Commissioning Note” card below to MTU Friedrichshafen GmbH.

The Commissioning Note information serves as a basis for the contractually agreed logistic support (warranty, spare parts, etc.).



Postcard


MTU Friedrichshafen GmbH

Technical Information Management

Dept. VOT

88040 Friedrichshafen

GERMANY



Engine No.:	MTU works order no.:
Engine model:	Date put into operation:
Application: * ☐ Marine ☐ Rail ☐ Genset ☐	Type: Manufacturer:
End user's address:	
Remarks:	

Table of Contents

1 Safety		3.4.9 Starter and battery-charging generator - Connection	51
1.1 Important provisions for all products	6		
1.2 Personnel and organizational requirements	7		
1.3 Safety regulations for maintenance and repair work	8	4 Initial Operation	
1.4 Fire prevention and environmental protection, fluids and lubricants, process materials	11	4.1 Preparation	54
1.5 Standards for safety notices in the text	14	4.1.1 Checks prior to startup	54
		4.1.2 SAM device settings	56
2 Mechanical Installation		4.2 Settings	57
2.1 LOP - Installation	15	4.2.1 CAN nodes - Configuration	57
2.2 Priming Pump Controller PPC - Installation	17	4.2.2 Setting SAM node address	58
		4.2.3 Minidialog - Settings	59
3 Electrical Installation		5 Supplementary Technical Information	
3.1 Processing Specifications	18	5.1 Internal design of Local Operating Panel LOP 10	67
3.1.1 Cable gland ICOTEK - Assembly	18	5.2 Supply voltages in LOP 10 - Distribution and fuse protection	73
3.1.2 Cables in HSK cable glands - Assembly	20		
3.1.3 Terminal strips or terminal blocks (spring terminals) - Preparation	22	6 Technical Data of the Devices	
3.2 Cables between devices and assemblies - Routing	24	6.1 LOP 10 - Technical data	75
3.3 General Information	26	6.2 ECU 4 - Technical data	76
3.3.1 Cabling, MTU scope of delivery; preparing Yard cables	26	6.3 EMU 1 - Technical data	77
3.3.2 Cable connector pin numbers	29	6.4 PPC - Technical data	78
3.4 Connection	31	7 Appendix A	
3.4.1 Local Operating Panel LOP 10 - Connection	31	7.1 RS 422 serial interface	79
3.4.2 LOP 10 - Cabling of individual signals	33	7.2 Abbreviations	95
3.4.3 Engine Control Unit ECU 4 - Connection	43	7.3 Conversion tables	99
3.4.4 Engine Monitoring Unit EMU 1 - Connection	44	7.4 MTU contact persons/service partners	103
3.4.5 PPC - Connection (single phase)	45		
3.4.6 PPC - Connection (three phases)	47	8 Appendix B	
3.4.7 Fuel prefilter level sensors - Connection	49	8.1 Index	104
3.4.8 Barring gear limit switch - Connection	50		

1 Safety

1.1 Important provisions for all products

Nameplate

The product is identified by nameplate, model designation or serial number and must match with the information on the title page of this manual.

Nameplate, model designation or serial number can be found on the product.

General information

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Modifications or conversions
- Noncompliance with the safety instructions and warning notices

Intended use

The product is intended exclusively for the application specified in the contract or defined at the time of delivery.

This means that the equipment must be operated:

- Within the admissible operating parameters as specified in the (→ Product Data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With manufacturer-approved spare parts in accordance with the (→ relevant Spare Parts Catalog)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (including engine management/parameters)
- In compliance with all safety regulations and in adherence with all warning notices in this manual
- In accordance with the maintenance requirements over the entire service life of the product (→ Maintenance Schedule)
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair
- By contracting only workshops authorized by the manufacturer to carry out repair and overhaul

Any other use is considered improper use and increases the risk of personnel injury or material damage in product operation. The manufacturer will accept no liability for such damage.

Modifications or conversions

Unauthorized modifications to the product compromise safety.

The manufacturer will accept no liability or warranty claims for any damage caused by unauthorized modifications or conversions.

Spare parts

Only genuine spare parts must be used to replace components or assemblies.

The manufacturer will accept no liability or warranty claims for any damage caused by the use of other spare parts.

1.2 Personnel and organizational requirements

Organizational measures of the operator

This manual must be issued to all personnel involved in operation, maintenance, repair or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair and transport personnel at all times.

Use this manual as a basis for instructing personnel on product operation and repair, whereby the safety-relevant instructions, in particular, must be read and understood.

This is particularly important in the case of personnel who only occasionally perform work on or around the product.

- This personnel must be instructed repeatedly.

Personnel requirements

All work on the product shall be carried out by trained and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel specialized in mechanical and plant engineering

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair and transport.

Working clothes and personal protective equipment

- Wear proper protective clothing for all work.
- Always wear appropriate personal protection when working. For example:
 - Ear protectors
 - Protective gloves
 - Industrial goggles
 - Breathing protection
 - Safety mask
- Observe the information on personal protective equipment in the respective activity description.

1.3 Safety regulations for maintenance and repair work

Safety regulations prior to maintenance and repair work

Have maintenance or repair work carried out by qualified and authorized personnel only.

Allow the product to cool down to less than 50°C before starting maintenance work (risk of explosion of oil vapors, fluids and lubricants, risk of burning).

Before starting work, relieve pressure in systems and compressed-air lines which are to be opened. Use suitable containers of adequate capacity to catch fluids and lubricants.

When changing the oil or working on the fuel system, ensure that the service room is adequately ventilated.

Never carry out maintenance and repair work with the product in operation, unless:

- Expressly permitted to do so following a written procedure.
- The product is running in the low load range and only for as long as absolutely necessary.

Secure the product against unintentional starting, e.g. with start interlock.

Attach "Do not operate" sign in the operating area or to control equipment.

Disconnect the battery. Lock contactors.

Close the main valve on the compressed-air system and vent the compressed-air line when pneumatic starters are fitted.

Disconnect the control equipment from the product.

The following applies to starters with copper-beryllium alloy pinions:

- Wear breathing protection of filter class P3 during maintenance work. Do not blow out the interior of the flywheel housing or the starter with compressed air. Clean the flywheel housing inside with a class H dust extraction device.
- Observe the safety data sheet.

Safety regulations during maintenance and repair work

Take special care when removing ventilation or plug screws from the product. Cover the screw or plug with a rag to prevent fluids escaping under pressure.

Take care when draining hot fluids and lubricants (risk of burning).

Use only proper and calibrated tools. Observe the specified tightening torques during assembly or disassembly.

Carry out work only on assemblies or plants which are properly secured.

Never use lines for climbing.

Keep fuel injection lines and connections clean.

Always seal connections with caps or covers if a line is removed or opened.

Take care not to damage lines, in particular fuel lines, during maintenance and repair work.

Ensure that all retainers and dampers are installed correctly.

Ensure that all fuel injection and pressurized oil lines are installed with enough clearance to prevent contact with other components. Do not place fuel or oil lines near hot components.

Do not touch elastomeric seals if they have carbonized or resinous appearance unless hands are properly protected.

Note cooling time for components which are heated for installation or removal (risk of burning).

When working high on the equipment, always use suitable ladders and work platforms. Make sure components or assemblies are placed on stable surfaces.

Ensure particular cleanness during maintenance and repair work on the product. After completion of maintenance and repair work, make sure that no unattached parts are in/on the product (e.g. cloths and cable ties).

Safety regulations after completion of maintenance and repair work

Before barring, make sure that nobody is standing in the danger zone of the product.

Check that all guards have been reinstalled and that all tools and loose parts have been removed after working on the product (in particular, the barring tool).

Welding work

Welding operations on the product or mounted units are not permitted. Cover the product when welding in its vicinity.

Before starting welding work:

- Switch off the power supply master switch.
- Disconnect the battery.
- Separate the electrical ground of electronic equipment from the ground of the unit.

No other maintenance or repair work must be carried out in the vicinity of the product while welding is going on. Risk of explosion or fire due to oil vapors and highly flammable fluids and lubricants.

Do not use product as ground terminal.

Never position the welding power supply cable adjacent to, or crossing wiring harnesses of the product. The welding current may otherwise induce an interference voltage in the wiring harnesses which could conceivably damage the electrical system.

Remove parts (e.g. exhaust pipes) which are to be welded from the product beforehand.

Hydraulic installation and removal

Check satisfactory function and safe operating condition of tools, jigs and fixtures to be used. Use only the specified jigs and fixtures for hydraulic removal/installation procedures.

Observe the max. permissible force-on pressure specified for the jig/fixture.

Do not attempt to bend or apply force to lines.

Before starting work, pay attention to the following:

- Vent the hydraulic installation/removal jig, the pumps and the lines at the relevant points for the equipment to be used (e.g. open vent plugs, pump until bubble-free air emerges, close vent plugs).
- For hydraulic installation, screw on the jig with the piston retracted.
- For hydraulic removal, screw on the jig with the piston extended.

For a hydraulic installation/removal jig with central expansion pressure supply, screw spindle into shaft end until correct sealing is established.

During hydraulic installation and removal, ensure that nobody is standing in the immediate vicinity of the component to be installed/removed.

Working with batteries

Observe the safety instructions of the battery manufacturer when working with batteries.

Gases emanating from the battery are explosive. Avoid sparks and naked flames.

Do not allow electrolyte to come in contact with skin or clothing.

Wear goggles and protective gloves.

Never place tools on the battery.

Before connecting the cable to the battery, check the battery polarity. Battery pole reversal may lead to injury through the sudden discharge of acid or bursting of the battery body.

Working on electrical and electronic assemblies

Always obtain the permission of the person in charge before commencing maintenance and repair work or switching off any part of the electronic system required to do so.

De-energize the appropriate areas prior to working on assemblies.

Do not damage cabling during removal work. When reinstalling ensure that wiring is not damaged during operation by contact with sharp objects, by rubbing against other components or by a hot surface.

Do not secure cables on lines carrying fluids.

Do not use cable straps to secure cables.

Always use connector pliers to tighten union nuts on connectors.

Subject the device as well as the product to a function check on completion of all repair work. In particular, check the function of the engine emergency stop feature.

Store spare parts properly prior to replacement, i.e. protect them against moisture in particular. Pack defective electronic components and assemblies in a suitable manner when dispatched for repair, i.e. protected, in particular, against moisture and impact and wrapped in antistatic foil if necessary.

Working with laser equipment

When working with laser equipment, always wear special laser-protection goggles (hazard due to heavily focused radiation).

Laser equipment must be equipped with the protective devices necessary for safe operation according to type and application.

For conducting light-beam procedures and measurement work, only the following laser devices must be used:

- Laser devices of classes 1, 2 or 3A.
- Laser devices of class 3B, which have maximum output in the visible wavelength range (400 to 700 nm), a maximum output of 5 mW, and in which the beam axis and surface are designed to prevent any risk to the eyes.