

Device Description

Electronic Equipment
Network Switch NSW 4

E532851/00E



Power. Passion. Partnership.

© 2016 Copyright MTU Friedrichshafen GmbH

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of MTU Friedrichshafen GmbH. This particularly applies to its reproduction, distribution, editing, translation, micro-filming and storage or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. MTU Friedrichshafen GmbH reserves the right to change, delete or supplement the information provided as and when required.

Table of Contents

1 Safety		4.2 Design	21
1.1 Important provisions for all products	4	4.3 Status and diagnostic indicators	22
1.2 Correct use for all products	5	4.4 Technical data	25
1.3 Personnel and organizational requirements	6	5 Troubleshooting	
1.4 Safety regulations for startup and operation	7	5.1 Fault indication by status LEDs	27
1.5 Safety regulations for maintenance and repair work	9	6 Instructions for Exchange of Sub-assemblies	
1.6 Fire prevention and environmental protection, fluids and lubricants, auxiliary materials	12	6.1 Device - Replacement	28
1.7 Standards for safety notices in the text	14	7 Appendix A	
1.8 Electrostatic discharge (ESD)	15	7.1 MTU Contact/Service Partners	30
2 General Provisions		8 Appendix B	
2.1 Structure of this documentation	16	8.1 Index	31
3 Functional Description			
3.1 Purpose	18		
3.2 MEM-Plug (optional)	19		
4 Technical Description			
4.1 General information	20		

1 Safety

1.1 Important provisions for all products

Nameplate

The product is identified by nameplate, model designation or serial number and must match with the information on the title page of this manual.

Nameplate, model designation or serial number can be found on the product.

All EU-certified engines delivered by MTU come with a second nameplate. When operating the machine in the EU: The second nameplate must be affixed in a prominent position as described in the accompanying specifications.

General information

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Modifications or conversions
- Noncompliance with the safety instructions and warning notices

Emission regulations and emission labels

Responsibility for compliance with emission regulations

Modification or removal of any mechanical/electronic components or the installation of additional components including the execution of calibration processes that might affect the emission characteristics of the product are prohibited by emission regulations. Emission control units/systems may only be maintained, exchanged or repaired if the components used for this purpose are approved by the manufacturer.

Noncompliance with these regulations will invalidate the design type approval issued by the emissions regulation authorities. The manufacturer does not accept any liability for violations of the emission regulations. The maintenance schedules of the manufacturer must be observed over the entire life cycle of the product.

Replacing components with emission labels

On all MTU engines fitted with emission labels, these labels must remain on the engine throughout its operational life.

Engines used exclusively in land-based, military applications other than by US government agencies are excepted from this proviso.

Please note the following when replacing components with emission labels:

- The relevant emission labels must be affixed to the spare part.
- Do not transfer the emission labels from the replaced part to the spare part.
- Remove the emission labels from the replaced part and destroy them.

1.2 Correct use for all products

Correct use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/MTU contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (including engine control/parameters)
- In compliance with all safety regulations and in adherence with all warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair
- By contracting only workshops authorized by the manufacturer to carry out repair and overhaul

The product shall not be operated in explosive atmospheres unless the necessary approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found on the websites:

- For drive systems: <http://www.mtu-online.com>
- For power generation: <http://www.mtuonsiteenergy.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

1.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and maintenance based on this manual with a special emphasis on safety requirements and warnings.

This is important in the case of personnel who only occasionally perform work on or around the product. These personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the descriptions of the individual activities.

1.4 Safety regulations for startup and operation

Safety regulations for startup

Install the product correctly and carry out acceptance in accordance with the manufacturer's specifications before putting the product into service. All necessary approvals must be granted by the relevant authorities and all requirements for initial startup must be fulfilled.

Whenever the product is subsequently taken into operation ensure that:

- All personnel is clear of the danger zone surrounding moving parts of the machine.
Electrically-actuated linkages may be set in motion when the Engine Control Unit (governor) is switched on.
- All maintenance and repair work has been completed.
- All loose parts have been removed from rotating machine components.
- All safety equipment is in place.
- No persons wearing pacemakers or any other technical body aids are present.
- The service room is adequately ventilated.
- In the first few hours of operation, the product emits gases as a result of smoldering e.g. lacquers or oil. These gases may be hazardous to health. Always wear respiratory protection in the operating room during this period.
- The exhaust system is leak-tight and that the gases are vented to atmosphere.
- Protect battery terminals, generator terminals or cables against accidental contact.
- Check that all connections have been correctly allocated (e.g. +/- polarity, direction).

Immediately after putting the product into operation, make sure that all control and display instruments as well as the signaling and alarm systems work properly.

Smoking is prohibited in the area of the product.

Safety regulations during operation

The operator must be familiar with the control and display elements.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be permanently observed with regard to present operating status, violation of limit values and warning or alarm messages.

Malfunctions and emergency stop

Practice emergency procedures, especially emergency stopping, at regular intervals.

The following steps must be taken if a malfunction of the system is detected or reported by the system:

- Inform supervisor(s) in charge.
- Analyze the message.
- Respond by taking any necessary emergency action, e.g. emergency stop.

Operation

Do not remain in the operating room when the product is running for any longer than absolutely necessary.

Keep a safe distance away from the product if possible. Do not touch the product unless expressly instructed to do so following a written procedure.

Do not inhale the exhaust gases of the product.

The following requirements must be fulfilled before the product is started:

- Wear ear protection.
- Mop up any leaked or spilled fluids and lubricants immediately or soak up with a suitable binder agent.

Operation of electrical equipment

Parts of the electrical equipment are live, i.e. under voltage/high tension, during operation.

Follow the applicable warning instructions pertaining to such devices.

1.5 Safety regulations for maintenance and repair work

Safety regulations prior to maintenance and repair work

Have maintenance or repair work carried out by qualified and authorized personnel only.

Allow the product to cool down to less than 50 °C (risk of explosion for oil vapors, fluids and lubricants, risk of burning).

Relieve pressure in fluid and lubricant systems and compressed-air lines which are to be opened. Use suitable collecting vessels of adequate capacity to catch fluids and lubricants.

When changing the oil or working on the fuel system, ensure that the service room is adequately ventilated.

Never carry out maintenance and repair work with the product in operation, unless:

- It is expressly permitted to do so following a written procedure.
- The product is running in the low load range and only for as long as absolutely necessary.

Lock-out the product to preclude undesired starting, e.g.

- Start interlock
- Key switch
- With hydraulic starting system: shut off supply line.

Attach "Do not operate" sign in the operating area or to control equipment.

Disconnect the battery cables or actuate the battery isolating switch, if fitted. Lock out circuit breakers.

Close the main valve on the compressed-air system and vent the compressed-air line when pneumatic starters are fitted.

Disconnect the control equipment from the product.

Use the recommended special tools or suitable equivalents when instructed to do so.

Elastomer components (e.g. engine mounts, damping elements, couplings and V-belts) must not be painted. They must only be installed after painting the engine or must be covered before painting work is carried out.

The following applies to starters with copper-beryllium alloy pinions:

- Wear a respirator mask (filter class P3). Do not blow out the interior of the flywheel housing or the starter with compressed air. Clean the flywheel housing inside with a class H dust extraction device.
- Observe the safety data sheet.

Safety regulations during maintenance and repair work

Take special care when removing ventilation or plug screws from the product.

Release residual pressure before removing or replacing a component in the supply line. To depressurize pressurized lines, shut off the lines first, then release the residual pressure.

Use only proper and calibrated tools. Observe the specified tightening torques during assembly or disassembly.

Carry out work only on assemblies or plants which are properly secured.

Make sure components or assemblies are placed on stable surfaces. Adopt suitable measures to avoid that components/tools fall down. Use the specified lifting equipment for all components.

Never use the product as a climbing aid.

When working high on the equipment, always use suitable ladders and work platforms. Never work on engines or components that are held in place by lifting equipment.

Keep fuel injection lines and connections clean.

Carry out appropriate cleaning procedures to clean and inspect components requiring special cleanliness (e.g. components carrying oil, fuel, or air).

Always seal connections with caps or covers if a line is removed or opened.

Fit new seals when re-installing lines.

Never bend lines and avoid damaging lines, particularly the fuel lines.

Ensure that all mounts and dampers are installed correctly.

Ensure that O-rings are not installed in a slanted/twisted condition.

Ensure that all fuel injection and pressurized oil lines are installed with enough clearance to prevent contact with other components. Do not place fuel or oil lines near hot components.

Do not touch elastomeric seals (e.g. Viton sealing rings) with your bare hands if they have a carbonized or resinous appearance.

Note cooling time for components which are heated for installation or removal (risk of burning).

Pay particular attention to cleanliness at all times.

Remove any condensate from components which were chilled before assembly. If necessary, coat the components with a suitable corrosion inhibitor.

Safety regulations following maintenance and repair work

Before barring the engine, make sure that nobody is standing in the danger zone of the product.

Check that all access ports/apertures which have been opened to facilitate working are closed again.

Check that all safety equipment has been installed and that all tools and loose parts have been removed (especially the barring device).

Ensure that no unattached parts have been left in/on the product (e.g. including rags and cable straps).

Ensure that the grounding system is properly connected.

Welding work

Welding operations on the product or mounted units are not permitted. Cover the product when welding in its vicinity.

Before starting welding work:

- Switch off the power supply master switch.
- Disconnect the battery cables or actuate the battery isolating switch.
- Separate the electrical ground of electronic equipment from the ground of the unit.

No other maintenance or repair work must be carried out in the vicinity of the product while welding is going on. Risk of explosion or fire due to oil vapors and highly flammable process materials.

Do not use product as ground terminal.

Never position the welding power supply cable adjacent to, or crossing cabling harnesses of the product. The welding current may otherwise induce an interference voltage in the cabling harnesses which could conceivably damage the electrical system.

Remove components (e.g. exhaust pipe) from the product before performing necessary welding work.

Hydraulic installation and removal

Check satisfactory function and safe operating condition of tools, devices and fixtures to be used. Use only the specified devices and fixtures for hydraulic removal/installation procedures.

Observe the max. permissible force-on pressure specified for the device/fixture.

Do not attempt to bend or exert force on HP lines.

Before starting work, pay attention to the following:

- Vent the installation/removal device, the pumps and the pipework at the relevant designated points.
- During the installation procedure, screw on device with pushed-in plunger.
- During the removal procedure, screw on device with retracted plunger.

For a hydraulic installation/removal device with central expansion pressure supply, screw spindle into shaft end until correct sealing is established.