

Functional Description

Electronic Equipment

Dialog System

DiaSys®

Version 2.72

E531920/06E



Power. Passion. Partnership.

© 2019 Copyright MTU Friedrichshafen GmbH

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of MTU Friedrichshafen GmbH. This particularly applies to its reproduction, distribution, editing, translation, micro-filming and storage or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. MTU Friedrichshafen GmbH reserves the right to change, delete or supplement the information provided as and when required.

Table of Contents

1 General Provisions		4.8 RailDiag	93
1.1 Safety	5	4.9 Programming mode	94
1.1.1 Important provisions for all products	5	5 Use	
1.1.2 Personnel and organizational requirements	7	5.1 Available Functions	99
1.1.3 Safety regulations for initial start-up and operation	8	5.1.1 Establish connection to control unit	99
1.1.4 Safety regulations for assembly, maintenance, and repair work	10	5.1.2 Recording measured data	100
1.1.5 Fire and environmental protection, fluids and lubricants	14	5.1.3 Analyze measured data	104
1.1.6 Standards for warning notices in the text and highlighted information	17	5.1.4 Exporting measured data	108
1.1.7 Correct use of all products	18	5.1.5 Special Parameter	109
2 Introduction		5.1.5.1 Edit input/output settings	109
2.1 General information on the DiaSys program	19	5.1.5.2 Edit alarm parameters	113
2.2 Preparation	23	5.1.5.3 Edit protection/monitoring parameters	114
3 Available Functions		5.1.6 Edit single parameters	117
3.1 Overview of "Available functions ECU"	26	5.1.7 Edit 2D parameters	121
3.2 Overview of "Available functions EXU, SXU, EIM"	33	5.1.8 Edit 3D parameters	124
3.3 Overview of "Available functions SafeDEC"	37	5.1.9 Send changed data to control unit	127
3.4 Overview of "Available functions ECS-UNI, ADEC-UNI"	39	5.1.10 Download edited parameters to control unit	129
3.5 Overview of "Available functions RCS/MCS/SAM"	43	5.1.11 Log Files	130
3.6 Overview of "Available functions CDS"	46	5.1.11.1 Error log file	130
3.7 Overview of "Available functions C1, ECU-2, LMB, ECU-183, R082"	51	5.1.11.2 Modification log file	132
4 Unit's Assembly Description		5.1.11.3 Parameter modified by	133
4.1 Create new device description	55	5.1.11.4 EOL parameter modified by	134
4.2 Edit device description ...	57	5.1.11.5 Show device information	135
4.3 Options	60	5.1.11.6 Device ID	136
4.3.1 Settings - General	60	5.1.11.7 Data record information	137
4.3.2 Settings - Standard hardware	64	5.1.11.8 Information on device description	138
4.4 BDM programming - Preparation	65	5.1.12 Extras	139
4.5 Show system faults	72	5.1.12.1 Export to Excel file	139
4.6 Open device description	73	5.1.12.2 Show xxx alive signal	140
4.7 Data Transfer to / from Central Database	74	5.1.12.3 Select language	142
4.7.1 Establish connection to central database	74	5.1.12.4 Show data record number	143
4.7.2 Connecting to the central database - CDS/C and CDS/CR-OX only	80	5.1.12.5 Show hardware CCS	144
4.7.3 Transfer data by file	82	5.1.12.6 Autolearn performance map ESD	145
4.7.4 Edit engine data in local database	90	5.1.12.7 Reset Functions	146
4.7.5 Retrieve xxxinfo.dat from central database	92	5.1.12.7.1 General information on reset functions	146
		5.1.12.7.2 P-Crankcase monitoring reset function	147
		5.1.12.7.3 SCR aging adaptation reset function	148
		5.1.12.7.4 Bag measurement reset function	149
		5.1.12.7.5 EGAT reset function (DOC and DPF)	150
		5.1.12.7.6 NOx monitoring reset function	152
		5.1.12.7.7 Oxygen sensor reset function	153
		5.1.12.7.8 Inducement reset function	154
		5.1.12.7.9 Dosing unit reset function	155
		5.1.12.7.10 CDS control unit reset function	156
		5.1.12.8 Crash Recorder	157
		5.1.12.8.1 Crash recorder functions	157
		5.1.12.9 Hardware key info	158
		5.1.12.10 Show trip data	159
		5.1.12.11 Retrieve all parameter settings	160
		5.1.12.12 Show header information	161
		5.1.12.13 Show CCS tree	162
		5.1.12.14 Read out leakage map	163

5.1.12.15	Injector Functions	164	5.2	Teaching valve limits	217
5.1.12.15.1	General information on injector functions	164	5.3	Maintenance Forecast	219
5.1.12.15.2	Injector shutoff	165	5.3.1	Load profile	219
5.1.12.15.3	Injector test	167	5.3.2	Save data for analysis	221
5.1.12.15.4	Show analysis	170	5.3.3	Save all (for restore)	222
5.1.12.15.5	Injector exchange - without IIG	171	5.3.4	Restore	223
5.1.12.15.6	Injector exchange - with IIG	174	5.3.5	Scheduled maintenance	224
5.1.12.16	Parameter comparison	178	5.3.6	Load-dependent maintenance	225
5.1.12.17	'Alive' signal info	179	5.3.7	TBO parameters	226
5.1.12.18	Show engine number	180	5.3.8	Service life matrix	228
5.1.12.19	Show CCS info	181	5.3.9	Modify K factor	229
5.1.12.20	Upload performance maps	182	5.3.10	New Ti matrix	230
5.1.12.21	Export 'MCR overshoots'	183	5.4	Update Controller	231
5.1.12.22	Settings	184	5.4.1	Update control unit (modernization)	231
5.1.12.23	Data record from local database...	185	5.4.2	Emergency mode	232
5.1.12.24	Actuator functions	186	5.5	Program Controller	233
5.1.12.25	Calibration functions	187	5.5.1	Download descriptors and parameters	233
5.1.12.26	Edit engine configuration	188	5.6	Program Controller / Program MEM	234
5.1.12.27	Data provision	189	5.6.1	Delete control unit and download new data (offline), Set to storage mode	234
5.1.12.28	Show load profile	190	5.6.2	Program LOP MEM	235
5.1.12.29	Transfer parameter settings to backup device	191	5.7	Additional Functions in 'Menus'	236
5.1.12.30	Reset oil priming pump	192	5.7.1	Parameters/Compare parameters	236
5.1.12.31	Export 'Initial <-> Original value'	193	5.7.2	Show/Online	237
5.1.12.32	XPC	194	5.7.3	File/Database utilities/Compress/Repair database	238
5.1.12.32.1	Read XCP status	194	5.7.4	Parameters/Modification log and Log file/ Delete log file	239
5.1.12.33	Hardware Replacement	195	5.7.5	Programs	240
5.1.12.33.1	Delete control unit and download new data	195	5.7.6	Templates	241
5.1.12.33.2	Delete control unit and download new data (CDS only)	201	5.8	Engine number must be available on control unit	245
5.1.12.33.3	Set to storage mode	202	6	Appendix A	
5.1.13	Engine History Data	203	6.1	Abbreviations	246
5.1.13.1	Load profile	203	6.2	Conversion tables	247
5.1.13.2	Load change counter	204	6.3	MTU Contact/Service Partners	251
5.1.13.3	Turbocharger switching counter	205	7	Appendix B	
5.1.13.4	Start counter	206	7.1	List of Figures	252
5.1.13.5	Rev counter	207	7.2	List of Tables	254
5.1.13.6	Show PV recorder	208	7.3	Index	255
5.1.13.7	Save data for analysis	209			
5.1.13.8	Save as	210			
5.1.14	To menus	211			
5.1.15	Read device description	212			
5.1.16	Establish connection to CAN bus	213			
5.1.17	Select device	214			
5.1.18	Injector code	215			
5.1.19	BDM log	216			

1 General Provisions

1.1 Safety

1.1.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by MTU come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emission specifications and emission label

Responsibility for compliance with emission regulations

Modification or removal of any mechanical/electronic components or the installation of additional components including the execution of calibration processes that might affect the emission characteristics of the product are prohibited by emission regulations. Emission-related components must only be serviced, exchanged or repaired if the components used for this purpose are approved by the manufacturer.

Noncompliance with these specifications will invalidate the design type approval or certification issued by the emissions regulation authorities. The manufacturer does not accept any liability for violations of the emission regulations.

The product must be operated over its entire life cycle according to the conditions defined as "Intended use" (→ Page 18).

Emission certification applicable to engines with EPA Nonroad Tier 4 emission certification in accordance with 40 CFR 1039 and with EPA Locomotive emission certification in accordance with 40 CFR 1033

Extract from the standard:

Failing to follow these instructions when installing a certified engine in a piece of nonroad equipment violates federal law (40 CFR 1068.105(b)), subject to fines or other penalties as described in the Clean Air Act.

Extract from the standard:

If you install the engine in a way that makes the engine's emission control information label hard to read during normal engine maintenance, you must place a duplicate label on the equipment, as described in 40 CFR 1068.105.

When fitting the second label, the requirements of 40 CFR 1068.105(c) must be followed and observed. This paragraph describes the process for requesting and fitting the label, the documentation obligations and storage obligations for the required documents.

Replacing components with emission labels

On all MTU engines fitted with emission labels, these labels must remain on the engine throughout its operational life.

Exception: Engines used exclusively in land-based, military applications other than by US government agencies.

Please note the following when replacing components with emission labels:

- The relevant emission labels must be affixed to the spare part.
- Emission labels shall not be transferred from the replaced part to the spare part.
- The emission labels must be removed from the replaced part and destroyed.

1.1.2 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.

1.1.3 Safety regulations for initial start-up and operation

Safety regulations for initial start-up

Install the product correctly and carry out acceptance in accordance with the manufacturer's specifications before putting the product into service. All necessary approvals must be granted by the relevant authorities and all requirements for initial startup must be fulfilled.

Whenever the product is subsequently taken into operation ensure that:

- All personnel is clear of the danger zone surrounding moving parts of the machine.
Electrically-actuated linkages may be set in motion when the Engine Control Unit (governor) is switched on.
- All maintenance and repair work has been completed.
- All loose parts have been removed from rotating machine components.
- All safeguards are in place.
- All components must be properly grounded. Ground separately by means of a grounding stake as necessary.
- No persons wearing pacemakers or any other technical body aids are present.
- Adequate ventilation of the operating room must be ensured for any operating status.
- In the first few hours of operation, the product emits gases as a result of smoldering e.g. lacquers or oil. These gases may be hazardous to health. Always wear respiratory protection in the operating room during this period.
- The exhaust system is leak-tight and that the gases are vented to atmosphere.
- The product must be free of any damage, this applies in particular to lines and cabling.
- Protect battery terminals, generator terminals or cables against accidental contact.
- Check that all connections have been correctly allocated e.g. +/- polarity, fuel line/reduction agent line, supply/return.

Immediately after putting the product into operation, make sure that all control and display instruments as well as the monitoring, signaling and alarm systems work properly.

Smoking is prohibited in the area of the product.

Safety regulations during operation

The operator must be familiar with the control and display elements.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be permanently observed with regard to present operating status, violation of limit values and warning or alarm messages.

Malfunctions and emergency stop

Practice emergency procedures, especially emergency stopping, at regular intervals.

Take the following steps if any system malfunctions are detected or signaled by the system:

- Inform supervisor(s) in charge.
- Analyze the message.
- Respond by taking any necessary emergency action, e.g. emergency stop.

After a safety shutdown, the engine must only be started after the cause of the shutdown has been eliminated.

Contact Service if the root cause of the malfunction cannot be clearly identified.

Operation

Do not remain in the operating room when the product is running unless absolutely necessary. Keep your stay as short as possible.

Keep a safe distance away from the product if possible. Do not touch the product unless expressly instructed to do so following a written procedure.

Do not inhale the exhaust gases of the product.

The following requirements must be fulfilled before the product is started:

- Wear ear protectors.
- Mop up any leaked or spilled fluids and lubricants immediately or soak up with a suitable binding agent.

Operation of electrical equipment

When electrical equipment is in operation, certain components of these appliances are electrically live.

Follow the applicable operating and safety instructions when operating the devices and heed warnings at all times.

1.1.4 Safety regulations for assembly, maintenance, and repair work

Safety regulations for work prior to assembly, maintenance, and repair

Have assembly, maintenance, or repair work carried out by qualified and authorized personnel only.

Allow the product to cool down to less than 50 °C (risk of explosion from oil vapors, fluids and lubricants, risk of burning).

Relieve pressure in fluid and lubricant systems and compressed-air lines which are to be opened. Use suitable containers of adequate capacity to catch fluids and lubricants.

Release residual pressure before removing or replacing a component in the supply line. To depressurize pressurized lines, shut off the lines first, then release the residual pressure.

Work must only be carried out on lines when they are free of fluids and lubricants.

Ensure adequate ventilation of the operating room when conducting an oil change, working on the gaseous/liquid fuel system or working with consumables (e.g. adhesive, cleaner).

Never carry out assembly, maintenance, or repair work with the product in operation, unless:

- It is expressly permitted to do so following a written procedure.

Lock-out the product to preclude undesired starting, e.g.

- Start interlock
- Key switch
- Close supply line for hydraulic starting.
- Close the main valve on the compressed-air system and vent the compressed-air line when air starters are fitted.

Attach “Do not operate” sign in the operating area or to control equipment.

Disconnect the battery cables or actuate the battery isolating switch, if fitted. Lock circuit breakers.

Before starting work on CaPoS, if used:

- Switch off the charging system (DC/DC converter).
- Discharge the UltraCap modules using the appropriate discharger.
- Short-circuit the UltraCap modules with a suitable wire jumper.

Before working on the exhaust gas aftertreatment system, close the shutoff valve on the reducing agent tank. Note that the reducing agent pumps continue to run for a certain period when the engine is stopped.

Disconnect the control equipment from the product.

Use the recommended special tools or suitable equivalents when instructed to do so.

Safety regulations when performing assembly, maintenance, and repair work

Special tools and lifting equipment

Use only proper and calibrated tools. Observe the specified tightening torques during assembly or disassembly.

Setting down, lifting and climbing

Carry out work only on assemblies or plants which are properly secured.

Use appropriate lifting equipment for all components. Use all specified attachment points and observe the center of gravity.

Never stand beneath a suspended load.

Never work on engines or components when they are held in place by lifting equipment.

Make sure components or assemblies are placed on stable surfaces and secured against tilting over or rolling away. Adopt suitable measures to prevent components/tools from falling down.

Assume a safe standing position when performing assembly work.