

AGC-4 Modbus descriptions

Software version

The information contained in these tables (Revision **G**) is applicable to software version **4.80.0** of the AGC-4.

Row Hyperlink index

13	Modbus function codes
24	Discrete output coil
32	Discrete input contact
41	Output holding register
50	Input register

[Back to index](#)

Modbus function codes	
Function code	Description
01	Read a single or multiple discrete output coils.
02	Read a single or multiple discrete input contacts.
03	Read a single or multiple output holding registers.
04	Read a single or multiple input registers.
05	Write a value to a single discrete output coil.
06	Write a value to a single output holding register.
15	Write a value to multiple consecutive discrete output coils.
16	Write a value to multiple consecutive output holding registers.

[Back to index](#)

Discrete output coil	
Function code	Effect
01	Read
05 or 15	Write
Function group	Description
	Activate a command in the controller.
Command flag	Read: The controller always returns 0 (false). Write: The controller executes the command if you write 1 (true).

[Back to index](#)

Discrete input contact	
Function code	Effect
02	Read
Function group	Description
Digital input	Read the state of a digital input on the controller. The controller returns 0 (false) when the digital input is inactive. The controller returns 1 (true) when the digital input is active.
Digital output	Read the state of a digital output on the controller. The controller returns 0 (false) when the digital output is inactive. The controller returns 1 (true) when the digital output is active.
Status flag	Read whether a status flag is activated. The controller returns 0 (false) when the status flag is not activated. The controller returns 1 (true) when the status flag is activated.

[Back to index](#)

Output holding register	
Function code	Effect
03	Read
06 or 16	Write
Function group	Description
	Activate a command in the controller.
Control command	Read: The controller always returns 0 (false) from the bits. Write: The controller executes the command if you write 1 (true) to the address bit.
	Read and write the time and date values of the controller.
Control time command	Read: The controller returns the value of the associated function. Write: The controller changes the value of the associated function if a valid value is entered.

Input register	
Function code	Effect
04	Read
Function group	Description
	Read one bit to see whether the AC alarm is activated.
AC alarm	The controller returns 0 (false) when the alarm is not activated. The controller returns 1 (true) when the alarm is activated.
AC measurement	Read the operating value of the associated AC measurement.

AGC-4 Modbus descriptions

[Back to index](#)

	Read one bit to see whether the alarm is activated.
Alarm	The controller returns 0 (false) when the alarm is not activated. The controller returns 1 (true) when the alarm is activated.
APPL version	Read the controller application version.
Control command state	Read the state of all the bits in the control command address.
Counter	Read the counter value.
	Read one bit to see whether the digital AVR alarm is activated.
DAVR alarm	The controller returns 0 (false) when the alarm is not activated. The controller returns 1 (true) when the alarm is activated.
DAVR measurement	Read the operating value of the associated measurement.
	Read one bit to see whether the digital AVR state is activated.
DAVR state	The controller returns 0 (false) when the state is not activated. The controller returns 1 (true) when the state is activated.
DC measurement	Read the operating value of the associated measurement.
	Read one bit to see whether the alarm from engine communication is activated.
EIC alarm	The controller returns 0 (false) when the alarm is not activated. The controller returns 1 (true) when the alarm is activated.
EIC measurement	Read the operating value of the associated engine communication measurement.
	Read one bit to see whether the engine communication state is activated.
EIC state	The controller returns 0 (false) when the state is not activated. The controller returns 1 (true) when the state is activated.
	Read one bit to see whether the M-Logic virtual event or flip-flop is activated.
M-Logic state	The controller returns 0 (false) when the state is not activated. The controller returns 1 (true) when the state is activated.
	Read one bit to see whether the mode is activated.
Modes	The controller returns 0 (false) when the mode is not activated. The controller returns 1 (true) when the mode is activated.
	Read the value of the function assigned to the address using the Modbus configurator.
Modbus configurable area	Additional information about the assigned address should be completed by the user. Modbus addresses 0 to 499 are available for configurable Modbus. For more information, see Option H2 and H9, Modbus communication .
	Read one bit to see whether the state is activated.
Plant logic state	The controller returns 0 (false) when the state is not activated. The controller returns 1 (true) when the state is activated.
PM AC measurement	Read the operating value of the associated Power Management measurements and settings.
	Read one bit to see whether the Power Management alarm is activated.
PM alarm	The controller returns 0 (false) when the alarm is not activated. The controller returns 1 (true) when the alarm is activated.
	Read one bit to see whether the Power Management state is activated.
PM Plant logic state	The controller returns 0 (false) when the state is not activated. The controller returns 1 (true) when the state is activated.
	Read the value of the function assigned to the address using the Modbus configurator.
Profibus configurable area	Additional information about the assigned address should be completed by the user. Modbus addresses 0 to 62 are available for configurable Profibus. For more information, see Option H2 and H9, Modbus communication .
	Read one bit to see whether the relay is activated.
Relay state	The controller returns 0 (false) when the relay is not activated. The controller returns 1 (true) when the relay is activated.

Discrete output coil (01;05;15)

Function group	Modbus address	PLC address	Modbus function code	Controller function name	BTB	MAINS	DG
Command flag	0	1	01; 05; 15	Remote start			X
Command flag	1	2	01; 05; 15	Remote GB ON			X
Command flag	1	2	01; 05; 15	Remote TB ON		X	
Command flag	2	3	01; 05; 15	Remote GB OFF			
Command flag	2	3	01; 05; 15	Remote TB OFF		X	
Command flag	2	3	01; 05; 15	Remote BTB OFF	X		
Command flag	3	4	01; 05; 15	Remote stop			
Command flag	4	5	01; 05; 15	Alarm inhibit 1	X	X	X
Command flag	5	6	01; 05; 15	Alarm inhibit 2	X	X	X
Command flag	6	7	01; 05; 15	Alarm inhibit 3	X	X	X
Command flag	7	8	01; 05; 15	Reset GOV/AVR regulation output to offset			X
Command flag	9	10	01; 05; 15	Alarm ack.	X	X	X
Command flag	10	11	01; 05; 15	Nominal setting 1	X	X	X
Command flag	11	12	01; 05; 15	Nominal setting 2			
Command flag	12	13	01; 05; 15	Nominal setting 3	X	X	X
Command flag	13	14	01; 05; 15	Nominal setting 4	X	X	X
Command flag	14	15	01; 05; 15	Start+sync. (semi)	X	X	X
Command flag	15	16	01; 05; 15	Deload/stop (semi)			
Command flag	16	17	01; 05; 15	Island		X	X
Command flag	17	18	01; 05; 15	Automatic mains failure (AMF)		X	X
Command flag	18	19	01; 05; 15	Peak shaving		X	X
Command flag	19	20	01; 05; 15	Fixed power		X	X
Command flag	20	21	01; 05; 15	Mains power export (MPE)		X	X
Command flag	21	22	01; 05; 15	Load takeover (LTO)		X	X
Command flag	24	25	01; 05; 15	MB ON (Single DG)		X	X
Command flag	24	25	01; 05; 15	MB ON			
Command flag	25	26	01; 05; 15	MB OFF (Single DG)			X
Command flag	25	26	01; 05; 15	MB OFF		X	
Command flag	26	27	01; 05; 15	Auto start/stop		X	X
Command flag	27	28	01; 05; 15	Manual mode		X	X
Command flag	28	29	01; 05; 15	Semi-auto mode	X	X	X
Command flag	29	30	01; 05; 15	Auto mode	X	X	X
Command flag	30	31	01; 05; 15	Test mode		X	X
Command flag	31	32	01; 05; 15	External frequency control			
Command flag	32	33	01; 05; 15	External voltage control			X
Command flag	33	34	01; 05; 15	External power control		X	X
Command flag	34	35	01; 05; 15	External reactive power control			X
Command flag	35	36	01; 05; 15	External power factor control			X
Command flag	36	37	01; 05; 15	Capacitive PF			X
Command flag	37	38	01; 05; 15	Base load			X
Command flag	38	39	01; 05; 15	1..priority			
Command flag	40	41	01; 05; 15	Application 1	X	X	X
Command flag	41	42	01; 05; 15	Application 2	X	X	X
Command flag	42	43	01; 05; 15	Application 3	X	X	X
Command flag	43	44	01; 05; 15	Application 4	X	X	X
Command flag	44	45	01; 05; 15	Battery test			X
Command flag	46	47	01; 05; 15	Synchronise dock to 4:00 a.m.	X	X	X
Command flag	48	49	01; 05; 15	Virtual event 1	X	X	X
Command flag	49	50	01; 05; 15	Virtual event 2	X	X	X
Command flag	50	51	01; 05; 15	Virtual event 3	X	X	X
Command flag	51	52	01; 05; 15	Virtual event 4	X	X	X
Command flag	52	53	01; 05; 15	Virtual event 5	X	X	X
Command flag	53	54	01; 05; 15	Virtual event 6	X	X	X

Discrete output coil (01;05;15)

Function group	Modbus address	PLC address	Modbus function code	Controller function name	BTB	MAINS	DG
Command flag	54	55	01; 05; 15	Virtual event 7	X	X	X
Command flag	55	56	01; 05; 15	Virtual event 8	X	X	X
Command flag	56	57	01; 05; 15	Virtual event 9	X	X	X
Command flag	57	58	01; 05; 15	Virtual event 10	X	X	X
Command flag	58	59	01; 05; 15	Virtual event 11	X	X	X
Command flag	59	60	01; 05; 15	Virtual event 12	X	X	X
Command flag	60	61	01; 05; 15	Virtual event 13	X	X	X
Command flag	61	62	01; 05; 15	Virtual event 14	X	X	X
Command flag	62	63	01; 05; 15	Virtual event 15	X	X	X
Command flag	63	64	01; 05; 15	Virtual event 16	X	X	X
Command flag	64	65	01; 05; 15	Virtual event 17	X	X	X
Command flag	65	66	01; 05; 15	Virtual event 18	X	X	X
Command flag	66	67	01; 05; 15	Virtual event 19	X	X	X
Command flag	67	68	01; 05; 15	Virtual event 20	X	X	X
Command flag	68	69	01; 05; 15	Virtual event 21	X	X	X
Command flag	69	70	01; 05; 15	Virtual event 22	X	X	X
Command flag	70	71	01; 05; 15	Virtual event 23	X	X	X
Command flag	71	72	01; 05; 15	Virtual event 24	X	X	X
Command flag	72	73	01; 05; 15	Virtual event 25	X	X	X
Command flag	73	74	01; 05; 15	Virtual event 26	X	X	X
Command flag	74	75	01; 05; 15	Virtual event 27	X	X	X
Command flag	75	76	01; 05; 15	Virtual event 28	X	X	X
Command flag	76	77	01; 05; 15	Virtual event 29	X	X	X
Command flag	77	78	01; 05; 15	Virtual event 30	X	X	X
Command flag	78	79	01; 05; 15	Virtual event 31	X	X	X
Command flag	79	80	01; 05; 15	Virtual event 32	X	X	X
Command flag	121	122	01; 05; 15	Clear log			
Command flag	122	123	01; 05; 15	Clear Parameter edits			
Command flag	123	124	01; 05; 15	Enable external frequency control			X
Command flag	124	125	01; 05; 15	Disable external frequency control			X
Command flag	125	126	01; 05; 15	Enable external voltage control			X
Command flag	126	127	01; 05; 15	Disable external voltage control			X
Command flag	127	128	01; 05; 15	Enable external power control		X	X
Command flag	128	129	01; 05; 15	Disable external power control		X	X
Command flag	129	130	01; 05; 15	Enable external VAR control			X
Command flag	130	131	01; 05; 15	Disable external VAR control			X
Command flag	131	132	01; 05; 15	Enable external CosPhi control			X
Command flag	132	133	01; 05; 15	Disable external CosPhi control			X
Command flag	133	134	01; 05; 15	Enable PM base load			X
Command flag	134	135	01; 05; 15	Disable PM base load			X
Command flag	135	136	01; 05; 15	Reset horn			
Command flag	136	137	01; 05; 15	Activate manual memory backup	X	X	X
Command flag	137	138	01; 05; 15	DVC 310/D510C: Reset Alarms	X	X	X
Command flag	142	143	01; 05; 15	Virtual event 33	X	X	X
Command flag	143	144	01; 05; 15	Virtual event 34	X	X	X
Command flag	144	145	01; 05; 15	Virtual event 35	X	X	X
Command flag	145	146	01; 05; 15	Virtual event 36	X	X	X
Command flag	146	147	01; 05; 15	Virtual event 37	X	X	X
Command flag	147	148	01; 05; 15	Virtual event 38	X	X	X
Command flag	148	149	01; 05; 15	Virtual event 39	X	X	X
Command flag	149	150	01; 05; 15	Virtual event 40	X	X	X
Command flag	150	151	01; 05; 15	Virtual event 41	X	X	X
Command flag	151	152	01; 05; 15	Virtual event 42	X	X	X
Command flag	152	153	01; 05; 15	Virtual event 43	X	X	X

Discrete output coil (01;05;15)

Function group	Modbus address	PLC address	Modbus function code	Modbus function name	BTB	MAINS	DG
Command flag	153	154	01; 05; 15	Virtual event 44	X	X	X
Command flag	154	155	01; 05; 15	Virtual event 45	X	X	X
Command flag	155	156	01; 05; 15	Virtual event 46	X	X	X
Command flag	156	157	01; 05; 15	Virtual event 47	X	X	X
Command flag	157	158	01; 05; 15	Virtual event 48	X	X	X
Command flag	158	159	01; 05; 15	Virtual event 49	X	X	X
Command flag	159	160	01; 05; 15	Virtual event 50	X	X	X
Command flag	160	161	01; 05; 15	Virtual event 51	X	X	X
Command flag	161	162	01; 05; 15	Virtual event 52	X	X	X
Command flag	162	163	01; 05; 15	Virtual event 53	X	X	X
Command flag	163	164	01; 05; 15	Virtual event 54	X	X	X
Command flag	164	165	01; 05; 15	Virtual event 55	X	X	X
Command flag	165	166	01; 05; 15	Virtual event 56	X	X	X
Command flag	166	167	01; 05; 15	Virtual event 57	X	X	X
Command flag	167	168	01; 05; 15	Virtual event 58	X	X	X
Command flag	168	169	01; 05; 15	Virtual event 59	X	X	X
Command flag	169	170	01; 05; 15	Virtual event 60	X	X	X
Command flag	170	171	01; 05; 15	Virtual event 61	X	X	X
Command flag	171	172	01; 05; 15	Virtual event 62	X	X	X
Command flag	172	173	01; 05; 15	Virtual event 63	X	X	X
Command flag	173	174	01; 05; 15	Virtual event 64	X	X	X
Command flag	174	175	01; 05; 15	Virtual event 65	X	X	X
Command flag	175	176	01; 05; 15	Virtual event 66	X	X	X
Command flag	176	177	01; 05; 15	Virtual event 67	X	X	X
Command flag	177	178	01; 05; 15	Virtual event 68	X	X	X
Command flag	178	179	01; 05; 15	Virtual event 69	X	X	X
Command flag	179	180	01; 05; 15	Virtual event 70	X	X	X
Command flag	180	181	01; 05; 15	Virtual event 71	X	X	X
Command flag	181	182	01; 05; 15	Virtual event 72	X	X	X
Command flag	182	183	01; 05; 15	Virtual event 73	X	X	X
Command flag	183	184	01; 05; 15	Virtual event 74	X	X	X
Command flag	184	185	01; 05; 15	Virtual event 75	X	X	X
Command flag	185	186	01; 05; 15	Virtual event 76	X	X	X
Command flag	186	187	01; 05; 15	Virtual event 77	X	X	X
Command flag	187	188	01; 05; 15	Virtual event 78	X	X	X
Command flag	188	189	01; 05; 15	Virtual event 79	X	X	X
Command flag	189	190	01; 05; 15	Virtual event 80	X	X	X
Command flag	190	191	01; 05; 15	Virtual event 81	X	X	X
Command flag	191	192	01; 05; 15	Virtual event 82	X	X	X
Command flag	192	193	01; 05; 15	Virtual event 83	X	X	X
Command flag	193	194	01; 05; 15	Virtual event 84	X	X	X
Command flag	194	195	01; 05; 15	Virtual event 85	X	X	X
Command flag	195	196	01; 05; 15	Virtual event 86	X	X	X
Command flag	196	197	01; 05; 15	Virtual event 87	X	X	X
Command flag	197	198	01; 05; 15	Virtual event 88	X	X	X
Command flag	198	199	01; 05; 15	Virtual event 89	X	X	X
Command flag	199	200	01; 05; 15	Virtual event 90	X	X	X
Command flag	200	201	01; 05; 15	Virtual event 91	X	X	X
Command flag	201	202	01; 05; 15	Virtual event 92	X	X	X
Command flag	202	203	01; 05; 15	Virtual event 93	X	X	X
Command flag	203	204	01; 05; 15	Virtual event 94	X	X	X
Command flag	204	205	01; 05; 15	Virtual event 95	X	X	X
Command flag	205	206	01; 05; 15	Virtual event 96	X	X	X
Command flag	206	207	01; 05; 15	Set flipflop 01	X	X	X

Discrete output coil (01;05;15)

Function group	Modbus address	PLC address	Modbus function code	Controller function name	BTB	MAINS	DG
Command flag	207	208	01;05;15	Set fliplop 02	X	X	X
Command flag	208	209	01;05;15	Set fliplop 03	X	X	X
Command flag	209	210	01;05;15	Set fliplop 04	X	X	X
Command flag	210	211	01;05;15	Set fliplop 05	X	X	X
Command flag	211	212	01;05;15	Set fliplop 06	X	X	X
Command flag	212	213	01;05;15	Set fliplop 07	X	X	X
Command flag	213	214	01;05;15	Set fliplop 08	X	X	X
Command flag	214	215	01;05;15	Set fliplop 09	X	X	X
Command flag	215	216	01;05;15	Set fliplop 10	X	X	X
Command flag	216	217	01;05;15	Set fliplop 11	X	X	X
Command flag	217	218	01;05;15	Set fliplop 12	X	X	X
Command flag	218	219	01;05;15	Set fliplop 13	X	X	X
Command flag	219	220	01;05;15	Set fliplop 14	X	X	X
Command flag	220	221	01;05;15	Set fliplop 15	X	X	X
Command flag	221	222	01;05;15	Set fliplop 16	X	X	X
Command flag	222	223	01;05;15	Reset fliplop 01	X	X	X
Command flag	223	224	01;05;15	Reset fliplop 02	X	X	X
Command flag	224	225	01;05;15	Reset fliplop 03	X	X	X
Command flag	225	226	01;05;15	Reset fliplop 04	X	X	X
Command flag	226	227	01;05;15	Reset fliplop 05	X	X	X
Command flag	227	228	01;05;15	Reset fliplop 06	X	X	X
Command flag	228	229	01;05;15	Reset fliplop 07	X	X	X
Command flag	229	230	01;05;15	Reset fliplop 08	X	X	X
Command flag	230	231	01;05;15	Reset fliplop 09	X	X	X
Command flag	231	232	01;05;15	Reset fliplop 10	X	X	X
Command flag	232	233	01;05;15	Reset fliplop 11	X	X	X
Command flag	233	234	01;05;15	Reset fliplop 12	X	X	X
Command flag	234	235	01;05;15	Reset fliplop 13	X	X	X
Command flag	235	236	01;05;15	Reset fliplop 14	X	X	X
Command flag	236	237	01;05;15	Reset fliplop 15	X	X	X
Command flag	237	238	01;05;15	Reset fliplop 16	X	X	X
Command flag	238	239	01;05;15	Toggle fliplop 01	X	X	X
Command flag	239	240	01;05;15	Toggle fliplop 02	X	X	X
Command flag	240	241	01;05;15	Toggle fliplop 03	X	X	X
Command flag	241	242	01;05;15	Toggle fliplop 04	X	X	X
Command flag	242	243	01;05;15	Toggle fliplop 05	X	X	X
Command flag	243	244	01;05;15	Toggle fliplop 06	X	X	X
Command flag	244	245	01;05;15	Toggle fliplop 07	X	X	X
Command flag	245	246	01;05;15	Toggle fliplop 08	X	X	X
Command flag	246	247	01;05;15	Toggle fliplop 09	X	X	X
Command flag	247	248	01;05;15	Toggle fliplop 10	X	X	X
Command flag	248	249	01;05;15	Toggle fliplop 11	X	X	X
Command flag	249	250	01;05;15	Toggle fliplop 12	X	X	X
Command flag	250	251	01;05;15	Toggle fliplop 13	X	X	X
Command flag	251	252	01;05;15	Toggle fliplop 14	X	X	X
Command flag	252	253	01;05;15	Toggle fliplop 15	X	X	X
Command flag	253	254	01;05;15	Toggle fliplop 16	X	X	X
Command flag	274	275	01;05;15	Easy connect add genset			X
Command flag	275	276	01;05;15	Easy connect remove genset			X
Command flag	276	277	01;05;15	Select yes on display for easy connect			X
Command flag	277	278	01;05;15	Select no on display for easy connect			X
Command flag	284	285	01;05;15	DVC 550/D550: Reset faults			X

Discrete input contact (02)

Function group	Modbus address	PLC address	Modbus function code	Controller function name	BTB	MAINS	DG
Digital input	22506	122507	02	Digital input 91	X	X	X
Digital input	22505	122506	02	Digital input 92	X	X	X
Digital input	22504	122505	02	Digital input 93	X	X	X
Digital input	22503	122504	02	Digital input 94	X	X	X
Digital input	22502	122503	02	Digital input 95	X	X	X
Digital input	22501	122502	02	Digital input 96	X	X	X
Digital input	22500	122501	02	Digital input 97	X	X	X
Digital input	22513	122514	02	Digital input 127	X	X	X
Digital input	22512	122513	02	Digital input 128	X	X	X
Digital input	22511	122512	02	Digital input 129	X	X	X
Digital input	22510	122511	02	Digital input 130	X	X	X
Digital input	22509	122510	02	Digital input 131	X	X	X
Digital input	22508	122509	02	Digital input 132	X	X	X
Digital input	22507	122508	02	Digital input 133	X	X	X
Digital input	22514	122515	02	Digital input 29	X	X	X
Digital input	22515	122516	02	Digital input 30	X	X	X
Digital input	22516	122517	02	Digital input 31	X	X	X
Digital input	22517	122518	02	Digital input 32	X	X	X
Digital input	22518	122519	02	Digital input 33	X	X	X
Digital input	22519	122520	02	Digital input 34	X	X	X
Digital input	22520	122521	02	Digital input 35	X	X	X
Digital input	22521	122522	02	Digital input 65	X	X	X
Digital input	22522	122523	02	Digital input 66	X	X	X
Digital input	22523	122524	02	Digital input 67	X	X	X
Digital input	22524	122525	02	Digital input 68	X	X	X
Digital input	22525	122526	02	Digital input 69	X	X	X
Digital input	22526	122527	02	Digital input 70	X	X	X
Digital input	22527	122528	02	Digital input 71	X	X	X
Digital input	22528	122529	02	Digital input 43	X	X	X
Digital input	22529	122530	02	Digital input 44	X	X	X
Digital input	22530	122531	02	Digital input 45	X	X	X
Digital input	22531	122532	02	Digital input 46	X	X	X
Digital input	22532	122533	02	Digital input 47	X	X	X
Digital input	22533	122534	02	Digital input 48	X	X	X
Digital input	22534	122535	02	Digital input 49	X	X	X
Digital input	22535	122536	02	Digital input 50	X	X	X
Digital input	22536	122537	02	Digital input 51	X	X	X
Digital input	22537	122538	02	Digital input 52	X	X	X
Digital input	22538	122539	02	Digital input 53	X	X	X
Digital input	22539	122540	02	Digital input 54	X	X	X
Digital input	22540	122541	02	Digital input 55	X	X	X
Digital input	22541	122542	02	Digital input 23	X	X	X
Digital input	22589	122590	02	Digital input 112	X	X	X
Digital input	22588	122589	02	Digital input 113	X	X	X
Digital input	22587	122588	02	Digital input 114	X	X	X
Digital input	22586	122587	02	Digital input 115	X	X	X
Digital input	22585	122586	02	Digital input 116	X	X	X
Digital input	22584	122585	02	Digital input 117	X	X	X
Digital input	22583	122584	02	Digital input 118 - Emergency stop	X	X	X
Digital input	22593	122594	02	Digital input 102	X	X	X
Digital input	22592	122593	02	Digital input 105	X	X	X
Digital input	22591	122592	02	Digital input 108	X	X	X
Digital input	22594	122595	02	External digital input/CIO 116 no. 1. Input 10	X	X	X
Digital input	22595	122596	02	External digital input/CIO 116 no. 1. Input 11	X	X	X
Digital input	22596	122597	02	External digital input/CIO 116 no. 1. Input 12	X	X	X

Discrete input contact (02)

Function group	Modbus address	PLC address	Modbus function code	Controller function name	BTB	MAINS	DG
Digital input	22597	122598	02	External digital input/CIO 116 no. 1. Input 13	X	X	X
Digital input	22598	122599	02	External digital input/CIO 116 no. 1. Input 14	X	X	X
Digital input	22599	122600	02	External digital input/CIO 116 no. 1. Input 15	X	X	X
Digital input	22600	122601	02	External digital input/CIO 116 no. 1. Input 16	X	X	X
Digital input	22601	122602	02	External digital input/CIO 116 no. 1. Input 17	X	X	X
Digital input	22602	122603	02	External digital input/CIO 116 no. 1. Input 19	X	X	X
Digital input	22603	122604	02	External digital input/CIO 116 no. 1. Input 20	X	X	X
Digital input	22604	122605	02	External digital input/CIO 116 no. 1. Input 21	X	X	X
Digital input	22605	122606	02	External digital input/CIO 116 no. 1. Input 22	X	X	X
Digital input	22606	122607	02	External digital input/CIO 116 no. 1. Input 23	X	X	X
Digital input	22607	122608	02	External digital input/CIO 116 no. 1. Input 24	X	X	X
Digital input	22608	122609	02	External digital input/CIO 116 no. 1. Input 25	X	X	X
Digital input	22609	122610	02	External digital input/CIO 116 no. 1. Input 26	X	X	X
Digital input	22610	122611	02	CIO 116 no. 2. Input 10	X	X	X
Digital input	22611	122612	02	CIO 116 no. 2. Input 11	X	X	X
Digital input	22612	122613	02	CIO 116 no. 2. Input 12	X	X	X
Digital input	22613	122614	02	CIO 116 no. 2. Input 13	X	X	X
Digital input	22614	122615	02	CIO 116 no. 2. Input 14	X	X	X
Digital input	22615	122616	02	CIO 116 no. 2. Input 15	X	X	X
Digital input	22616	122617	02	CIO 116 no. 2. Input 16	X	X	X
Digital input	22617	122618	02	CIO 116 no. 2. Input 17	X	X	X
Digital input	22618	122619	02	CIO 116 no. 2. Input 19	X	X	X
Digital input	22619	122620	02	CIO 116 no. 2. Input 20	X	X	X
Digital input	22620	122621	02	CIO 116 no. 2. Input 21	X	X	X
Digital input	22621	122622	02	CIO 116 no. 2. Input 22	X	X	X
Digital input	22622	122623	02	CIO 116 no. 2. Input 23	X	X	X
Digital input	22623	122624	02	CIO 116 no. 2. Input 24	X	X	X
Digital input	22624	122625	02	CIO 116 no. 2. Input 25	X	X	X
Digital input	22625	122626	02	CIO 116 no. 2. Input 26	X	X	X
Digital input	22626	122627	02	CIO 116 no. 3. Input 10	X	X	X
Digital input	22627	122628	02	CIO 116 no. 3. Input 11	X	X	X
Digital input	22628	122629	02	CIO 116 no. 3. Input 12	X	X	X
Digital input	22629	122630	02	CIO 116 no. 3. Input 13	X	X	X
Digital input	22630	122631	02	CIO 116 no. 3. Input 14	X	X	X
Digital input	22631	122632	02	CIO 116 no. 3. Input 15	X	X	X
Digital input	22632	122633	02	CIO 116 no. 3. Input 16	X	X	X
Digital input	22633	122634	02	CIO 116 no. 3. Input 17	X	X	X
Digital input	22634	122635	02	CIO 116 no. 3. Input 19	X	X	X
Digital input	22635	122636	02	CIO 116 no. 3. Input 20	X	X	X
Digital input	22636	122637	02	CIO 116 no. 3. Input 21	X	X	X
Digital input	22637	122638	02	CIO 116 no. 3. Input 22	X	X	X
Digital input	22638	122639	02	CIO 116 no. 3. Input 23	X	X	X
Digital input	22639	122640	02	CIO 116 no. 3. Input 24	X	X	X
Digital input	22640	122641	02	CIO 116 no. 3. Input 25	X	X	X
Digital input	22641	122642	02	CIO 116 no. 3. Input 26	X	X	X
Digital output	23000	123001	02	Relay 65 (M14.4)	X	X	X
Digital output	23001	123002	02	Relay 67 (M14.4)	X	X	X
Digital output	23002	123003	02	Relay 69 (M14.4)	X	X	X
Digital output	23003	123004	02	Relay 71 (M14.4)	X	X	X
Digital output	23007	123008	02	Relay 126 (M14.8)	X	X	X
Digital output	23006	123007	02	Relay 128 (M14.8)	X	X	X
Digital output	23005	123006	02	Relay 130 (M14.8)	X	X	X
Digital output	23004	123005	02	Relay 132 (M14.8)	X	X	X
Digital output	23011	123012	02	Relay 90 (M14.6)	X	X	X
Digital output	23010	123011	02	Relay 92 (M14.6)	X	X	X

Discrete input contact (02)

Function group	Modbus address	PLC address	Modbus function code	Controller function name	BTB	MAINS	DG
Digital output	23009	123010	02	Relay 94 (M14.6)	X	X	X
Digital output	23008	123009	02	Relay 96 (M14.6)	X	X	X
Digital output	23012	123013	02	Relay 29 (M14.2)	X	X	X
Digital output	23013	123014	02	Relay 31 (M14.2)	X	X	X
Digital output	23014	123015	02	Relay 33 (M14.2)	X	X	X
Digital output	23015	123016	02	Relay 35 (M14.2)	X	X	X
Digital output	23016	123017	02	Relay 57 (M12)	X	X	X
Digital output	23017	123018	02	Relay 59 (M12)	X	X	X
Digital output	23018	123019	02	Relay 61 (M12)	X	X	X
Digital output	23019	123020	02	Relay 63 (M12)	X	X	X
Digital output	23047	123048	02	Relay 69 (EF4)	X	X	X
Digital output	23048	123049	02	Relay 71 (EF4)	X	X	X
Digital output	23022	123023	02	Any inhibit active (LED, DU2)	X	X	X
Digital output	23025	123026	02	Relay 5	X	X	X
Digital output	23050	123051	02	Start prepare			X
Digital output	23052	123053	02	Stop coil			X
Digital output	23051	123052	02	Start relay(ckrank)			X
Digital output	23049	123050	02	Run coil			X
Digital output	23030	123031	02	Relay 20	X	X	X
Digital output	23031	123032	02	Relay 21	X	X	X
Digital output	23053	123054	02	LED CAN B	X	X	X
Digital output	23054	123055	02	LED CAN A	X	X	X
Digital output	23055	123056	02	LED USB	X	X	X
Digital output	23056	123057	02	External digital output/CIO 208 no. 1. Output 9	X	X	X
Digital output	23057	123058	02	External digital output/CIO 208 no. 1. Output 11	X	X	X
Digital output	23058	123059	02	External digital output/CIO 208 no. 1. Output 13	X	X	X
Digital output	23059	123060	02	External digital output/CIO 208 no. 1. Output 15	X	X	X
Digital output	23060	123061	02	External digital output/CIO 208 no. 1. Output 18	X	X	X
Digital output	23061	123062	02	External digital output/CIO 208 no. 1. Output 21	X	X	X
Digital output	23062	123063	02	External digital output/CIO 208 no. 1. Output 24	X	X	X
Digital output	23063	123064	02	External digital output/CIO 208 no. 1. Output 27	X	X	X
Digital output	23064	123065	02	External digital output/CIO 208 no. 2. Output 9	X	X	X
Digital output	23065	123066	02	External digital output/CIO 208 no. 2. Output 11	X	X	X
Digital output	23066	123067	02	External digital output/CIO 208 no. 2. Output 13	X	X	X
Digital output	23067	123068	02	External digital output/CIO 208 no. 2. Output 15	X	X	X
Digital output	23068	123069	02	External digital output/CIO 208 no. 2. Output 18	X	X	X
Digital output	23069	123070	02	External digital output/CIO 208 no. 2. Output 21	X	X	X
Digital output	23070	123071	02	External digital output/CIO 208 no. 2. Output 24	X	X	X
Digital output	23071	123072	02	External digital output/CIO 208 no. 2. Output 27	X	X	X
Digital output	23072	123073	02	CIO 208 no. 3. Output 9	X	X	X
Digital output	23073	123074	02	CIO 208 no. 3. Output 11	X	X	X
Digital output	23074	123075	02	CIO 208 no. 3. Output 13	X	X	X
Digital output	23075	123076	02	CIO 208 no. 3. Output 15	X	X	X
Digital output	23076	123077	02	CIO 208 no. 3. Output 18	X	X	X
Digital output	23077	123078	02	CIO 208 no. 3. Output 21	X	X	X
Digital output	23078	123079	02	CIO 208 no. 3. Output 24	X	X	X
Digital output	23079	123080	02	CIO 208 no. 3. Output 27	X	X	X
Digital output	23080	123081	02	CIO 116 no. 1 conf. status out	X	X	X
Digital output	23081	123082	02	CIO 116 no. 2 conf. status out	X	X	X
Digital output	23082	123083	02	CIO 116 no. 3 conf. status out	X	X	X
Digital output	23083	123084	02	CIO 208 no. 1 conf. status out	X	X	X
Digital output	23084	123085	02	CIO 208 no. 2 conf. status out	X	X	X
Digital output	23085	123086	02	CIO 208 no. 3 conf. status out	X	X	X
Digital output	23086	123087	02	CIO 308 no. 1 conf. status out	X	X	X
Digital output	23087	123088	02	CIO 308 no. 2 conf. status out	X	X	X

Discrete input contact (02)

Function group	Modbus address	PLC address	Modbus function code	Controller function name	BTB	MAINS	DG
Digital output	23088	123089	02	CIO 308 no. 3 conf. status out	X	X	X
Digital input	22506	122507	02	Digital input 91	X	X	X
Digital input	22505	122506	02	Digital input 92	X	X	X
Digital input	22504	122505	02	Digital input 93	X	X	X
Digital input	22503	122504	02	Digital input 94	X	X	X
Digital input	22502	122503	02	Digital input 95	X	X	X
Digital input	22501	122502	02	Digital input 96	X	X	X
Digital input	22500	122501	02	Digital input 97	X	X	X
Digital input	22513	122514	02	Digital input 127	X	X	X
Digital input	22512	122513	02	Digital input 128	X	X	X
Digital input	22511	122512	02	Digital input 129	X	X	X
Digital input	22510	122511	02	Digital input 130	X	X	X
Digital input	22509	122510	02	Digital input 131	X	X	X
Digital input	22508	122509	02	Digital input 132	X	X	X
Digital input	22507	122508	02	Digital input 133	X	X	X
Digital input	22514	122515	02	Digital input 29	X	X	X
Digital input	22515	122516	02	Digital input 30	X	X	X
Digital input	22516	122517	02	Digital input 31	X	X	X
Digital input	22517	122518	02	Digital input 32	X	X	X
Digital input	22518	122519	02	Digital input 33	X	X	X
Digital input	22519	122520	02	Digital input 34	X	X	X
Digital input	22520	122521	02	Digital input 35	X	X	X
Digital input	22521	122522	02	Digital input 65	X	X	X
Digital input	22522	122523	02	Digital input 66	X	X	X
Digital input	22523	122524	02	Digital input 67	X	X	X
Digital input	22524	122525	02	Digital input 68	X	X	X
Digital input	22525	122526	02	Digital input 69	X	X	X
Digital input	22526	122527	02	Digital input 70	X	X	X
Digital input	22527	122528	02	Digital input 71	X	X	X
Digital input	22528	122529	02	Digital input 43	X	X	X
Digital input	22529	122530	02	Digital input 44	X	X	X
Digital input	22530	122531	02	Digital input 45	X	X	X
Digital input	22531	122532	02	Digital input 46	X	X	X
Digital input	22532	122533	02	Digital input 47	X	X	X
Digital input	22533	122534	02	Digital input 48	X	X	X
Digital input	22534	122535	02	Digital input 49	X	X	X
Digital input	22535	122536	02	Digital input 50	X	X	X
Digital input	22536	122537	02	Digital input 51	X	X	X
Digital input	22537	122538	02	Digital input 52	X	X	X
Digital input	22538	122539	02	Digital input 53	X	X	X
Digital input	22539	122540	02	Digital input 54	X	X	X
Digital input	22540	122541	02	Digital input 55	X	X	X
Digital input	22541	122542	02	Digital input 23	X	X	X
Digital input	22589	122590	02	Digital input 112	X	X	X
Digital input	22588	122589	02	Digital input 113	X	X	X
Digital input	22587	122588	02	Digital input 114	X	X	X
Digital input	22586	122587	02	Digital input 115	X	X	X
Digital input	22585	122586	02	Digital input 116	X	X	X
Digital input	22584	122585	02	Digital input 117	X	X	X
Digital input	22583	122584	02	Digital input 118 - Emergency stop	X	X	X
Digital input	22593	122594	02	Digital input 102	X	X	X
Digital input	22592	122593	02	Digital input 105	X	X	X
Digital input	22591	122592	02	Digital input 108	X	X	X
Digital input	22594	122595	02	External digital input/CIO 116 no. 1. Input 10	X	X	X
Digital input	22595	122596	02	External digital input/CIO 116 no. 1. Input 11	X	X	X