



Assembly Instructions

Assembly Instructions for Catalytic Converters on Gas Gensets with Series 400 /
Series 4000 Engines

M060803/01E

© 2019 MTU Onsite Energy GmbH, Augsburg

The original document was created in the German language.

This publication including all of its parts is protected by copyright. Each instance of use requires the prior written consent of MTU Onsite Energy GmbH. This applies in particular to duplication, dissemination, editing, translation, microfilming, and storage and/or processing in electronic systems, including databases and online services.

All of the information presented in this publication was current and up-to-date at the time of publishing. MTU Onsite Energy GmbH reserves the right to make changes to, delete, or supplement the provided information and data as needed.

Preface

These Assembly Instructions are intended to assist project planners, system/component designers and assembly personnel in planning or carrying out the installation of MTU components.

The Assembly Instructions apply to all gas gensets with Series 400 and Series 4000 engines.

The objective of the Assembly Instructions is to facilitate the assembly of components.

The Assembly Instructions do not relieve those responsible for the system from independently ensuring that installation is carried out in an appropriate manner.

The following accompanying documents must be complied with, in addition to the Assembly Instructions:

- Planning drawing
- Schematic diagrams
- TEN data
- Arrangement drawings
- Operating Instructions (see Business Portal)
- Maintenance Schedule (see Business Portal)
- Fluids and Lubricants Specifications (see Business Portal)
- MTU standards

The relevant documents are defined in the specifications related to the order concerned.

Performing prescribed maintenance tasks properly and on schedule positively influences operational safety, reliability and service life. Ensure good accessibility for operation, maintenance and repair work when planning and installing the system.

Definition of Important field

Important

This text box is for information purposes only.
It does not contain any type of references to situations where damage to material or personal injury are possible!
It must only contain information and tips concerning the product.

Table of Contents

1	Safety		
1.1	MTU Onsite Energy GmbH gas systems - Intended use	6	
1.2	Important provisions for all products	8	
1.3	Personnel and organizational requirements	10	
1.4	Safety regulations for assembly, maintenance, and repair work	11	
1.5	Fire and environmental protection, fluids and lubricants	15	
1.6	Standards for warning notices in the text and highlighted information	18	
2	Functional Description		
2.1	Catalytic converters	19	
3	Installation		
3.1	Preparations for assembly	20	
3.2	Catalytic converter for 400 Series - Installation		21
3.3	Catalytic converter for 4000 Series - Installation		24
4	Appendix A		
4.1	Tightening torques for flanged connections		26
5	Appendix B		
5.1	Index		29

1 Safety

1.1 MTU Onsite Energy GmbH gas systems – Intended use

Intended use

The machine is intended to be used exclusively for electrical power generation and waste heat utilization in stationary operation, either in sufficiently ventilated rooms or in container solutions.

A gas/air mixture is fed to the internal combustion reciprocating piston engine. This is converted into mechanical work in the individual cylinders through combustion. The flywheel of the engine drives the synchronous generator connected via an elastic coupling, resulting in a conversion to electric energy. The engine and the generator are joined to the base frame with elastic, vibration-damped elements. For mains frequency 60 Hz, depending on the series either a gearbox is used between the engine and generator (Series 4000) or the engine speed is increased accordingly (Series 400). The waste heat generated during the combustion process is dissipated to the surroundings via coolers (power generator) and/or made available to the customer via heat exchangers (combined heat and power plant).

Area of application	Suitable	Comment
Industry	Yes	–
Business/Service	Yes	In some individual cases, however, such as with swimming pool facilities, schools, heating stations for apartment buildings and the like, there is no end user in the classical sense involved.
Household	No	Operation is excluded
Potentially explosive area	No	Operation is not permitted in potentially explosive areas
Underground	No	Operation is excluded
Mobile use	No	Operation is excluded

Table 1: Area of application of machine

There are 3 operating modes of the machine:

- Grid parallel operation
- Mains backup mode
- Isolated operation

Foreseeable misuse

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper use.

Operation

Operation is not permissible if the physical conditions specified on the technical data sheet or on/in other documents (concerning temperature, pressure, site altitude, etc.) are not complied with. Operation is not permissible without protective equipment, usage of approved spare parts, exclusion of conversions, warning of foreseeable misuse.

Operation is not permissible without the use of fluids and lubricants from MTU Onsite Energy (natural gas, biogas, quality-compliant gas, quality-compliant water, lubricants) in accordance with the (→ fluids and lubricants specifications).

Operation is not permissible without adopting the preservation measures approved by MTU Onsite Energy according to the (→ Preservation and Represervation Specifications).

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version of these are adopted. The latest version can be found at:

- <http://www.mtuonsiteenergy.com>

Surroundings, climate, temperature

The weather plays no role with regard to the intended use of the genset/module provided that the operation takes place inside an installation room. For container applications, however, the permissible outdoor temperatures at the installation site plays a decisive role. The product-specific ambient conditions such as climate and temperature are indicated in the technical description.

Prerequisite for proper use

Fulfillment of all the requirements set out in the “Installation conditions” document.

Any use that does not fall within the described limits for use is regarded as improper.

Modifications or conversions

Unauthorized changes to the product breach the conditions concerning its intended use and compromise safety.

Only modifications or conversions expressly authorized by the manufacturer are regarded as compliant in this sense. The manufacturer shall not be held liable for any damage resulting from unauthorized modifications or conversions.

1.2 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by MTU come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emission specifications and emission label

Responsibility for compliance with emission regulations

Modification or removal of any mechanical/electronic components or the installation of additional components including the execution of calibration processes that might affect the emission characteristics of the product are prohibited by emission regulations. Emission-related components must only be serviced, exchanged or repaired if the components used for this purpose are approved by the manufacturer.

Noncompliance with these specifications will invalidate the design type approval or certification issued by the emissions regulation authorities. The manufacturer does not accept any liability for violations of the emission regulations.

The product must be operated over its entire life cycle according to the conditions defined as "Intended use" (→ Page 6).

Emission certification applicable to engines with EPA Nonroad Tier 4 emission certification in accordance with 40 CFR 1039 and with EPA Locomotive emission certification in accordance with 40 CFR 1033

Extract from the standard:

Failing to follow these instructions when installing a certified engine in a piece of nonroad equipment violates federal law (40 CFR 1068.105(b)), subject to fines or other penalties as described in the Clean Air Act.

Extract from the standard:

If you install the engine in a way that makes the engine's emission control information label hard to read during normal engine maintenance, you must place a duplicate label on the equipment, as described in 40 CFR 1068.105.

When fitting the second label, the requirements of 40 CFR 1068.105(c) must be followed and observed. This paragraph describes the process for requesting and fitting the label, the documentation obligations and storage obligations for the required documents.

Replacing components with emission labels

On all MTU engines fitted with emission labels, these labels must remain on the engine throughout its operational life.

Exception: Engines used exclusively in land-based, military applications other than by US government agencies.

Please note the following when replacing components with emission labels:

- The relevant emission labels must be affixed to the spare part.
- Emission labels shall not be transferred from the replaced part to the spare part.
- The emission labels must be removed from the replaced part and destroyed.

1.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.