



Assembly Instructions

Gas engine-generator sets

**MTU 8V4000 GS – GG08V4000A1/A2 with engines 8V4000L32/
L32FB/L33 and 8V4000L64/L64FNER**

**MTU 12V4000 GS – GG12V4000A1/A2 with engines 12V4000L32/
L32FB/L33 and 12V4000L64/L64FNER**

**MTU 16V4000 GS – GG16V4000A1/A2 with engines 16V4000L32/
L32FB/L33 and 16V4000L64/L64FNER**

**MTU 20V4000 GS – GG20V4000A1/A2 with engines 20V4000L32/
L32FB/L33 and 20V4000L64/L64FNER**

M060808/05E



A Rolls-Royce
solution

Name	SLU name, model	Engine model	Application group
MTU 8V4000 GS	GG08V4000A1/A2	8V4000L32/L32FB/L33	3A, continuous operation, unrestricted
	GG08V4000D1/D1M/D2	8V4000L64/L64FNER	
MTU 12V4000 GS	GG12V4000A1/A2	12V4000L32/L32FB/L33	
	GG12V4000D1/D1M/D2	12V4000L64/L64FNER	
MTU 16V4000 GS	GG16V4000A1/A2	16V4000L32/L32FB/L33	
	GG16V4000D1/D1M/D2	16V4000L64/L64FNER	
MTU 20V4000 GS	GG20V4000A1/A2	20V4000L32/L32FB/L33	
	GG20V4000D1/D1M/D2	20V4000L64/L64FNER	

Table 1: Applicability

© Copyright MTU

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of MTU. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or its processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. MTU reserves the right to change, delete or supplement the information or data provided as and when required.

Table of Contents

1 Preface		4.2 Engine-generator set – Standard scope of supply	48
1.1 Preface	5	4.3 Engine-generator set – Optional scope of supply	58
2 Safety		5 Installation Conditions	
2.1 Important provisions for all products	6	5.1 Installation room – Requirements	59
2.2 Gas systems – Intended use	8	5.2 Assembly – Preparatory work	60
2.3 Personnel and organizational requirements	10	5.3 Engine-generator set – Lifting and installation	62
2.4 Safety regulations for commissioning and operation	11	5.4 Engine-generator set with split base frame – Lifting and installation	63
2.5 Safety regulations for commissioning and operation, specific information for gaseous fuel supply or and dual fuel applications	13	5.5 Optional Components	64
2.6 Safety regulations for assembly, maintenance, and repair work	15	5.5.1 Accessory pack components	64
2.7 Safety regulations for assembly, maintenance and servicing work, specific information for gaseous fuel and dual fuel supply or applications	19	5.5.2 Heat module – Lifting and installation	65
2.8 Fire and environmental protection, indirect materials	20	5.5.3 Cooler – Lifting and installation	66
2.9 Fire prevention and environmental protection, fluids and lubricants, auxiliary materials, specific information for gaseous fuel supply in gaseous-fuel or dual-fuel applications	23	5.5.4 Plate-core heat exchanger – Lifting and installation	67
2.10 Standards for warning notices in the text and highlighted information	24	5.5.5 Control cabinet – Installation	68
2.11 Conventions for warning notices on safety signs on the engine-generator set	25	6 Interface Description	
2.12 Safety signs on engine-generator set – Overview	27	6.1 Engine generator set – Interfaces	69
2.13 Overview of protective devices on the engine-generator set	29	6.2 Heat module – Interfaces	71
3 Transport		6.3 Controller	73
3.1 Transport	31	7 Depreservation	
3.2 Transport locking device for engine mounting	38	7.1 Depreservation	74
3.3 Transport locking device of generator mounting	39	8 Mechanical Installation	
3.4 Crankshaft transport locking device	41	8.1 Cooling System and Heating Water System	75
3.5 Tie-down instructions	43	8.1.1 Coolant hoses – Installation requirements	75
4 Engine-Generator Set		8.1.2 Engine coolant system – Connection	78
4.1 Engine-generator set – Nameplate and designation	45	8.1.3 Mixture cooling system – Connection	80
		8.1.4 Heat recovery module – Connection	83
		8.1.5 Heating water circuit – Connection	85
		8.1.6 Cooler – Connection	86
		8.1.7 Exhaust gas heat exchanger – Connection	88
		8.1.8 Emergency cooler – Connection	89
		8.1.9 Coolant-conveying lines – Check	90
		8.1.10 Insulation for cooling system – Installation	92
		8.2 Gas System	93
		8.2.1 Gas train – Installation requirements	93
		8.2.2 Gas train – Installation	95
		8.2.3 Gas train – Connection	98
		8.2.4 Gas-conveying lines – Check	99
		8.3 Lube Oil System	101
		8.3.1 Metal hoses for oil – Installation requirements	101

8.3.2	Lube oil system - Connection	102	9.5	MMC control cabinet - Connection	143
8.3.3	Oil-conveying lines - Check	104	9.6	Cable X2X - Connection	144
8.4	Exhaust System	106	9.7	Starter battery - Connection	146
8.4.1	Exhaust system - Installation requirements	106	9.8	Starter - Connection	156
8.4.2	Exhaust pipe bellows - Installation	107	9.9	Intrinsically safe circuits - Connection	158
8.4.3	Exhaust silencer - Connection	109	9.10	Protective equipotential bonding and protective conductor (grounding) - Connection	159
8.4.4	Catalytic converter for Series 4000 - Installation	112	9.11	Checking cabling	161
8.4.5	Exhaust gas heat exchanger - Installation	114	9.12	Cable list	162
8.4.6	Exhaust lines - Check	117	9.13	Correct cabling	166
8.4.7	Insulation for exhaust system - Installation	118	9.14	Electromagnetic compatibility (EMC)	167
8.5	Engine-Generator Set Room	120	10	Supplementary Technical Information	
8.5.1	Room temperature sensor - Connection	120	10.1	Lines - Flushing	169
8.5.2	Gas alarm system - Connection	121	10.2	Initial operation - Prerequisites	170
8.5.3	Fire detection system - Connection	123	11	Appendix A	
8.5.4	Flashing horn - Connection	125	11.1	Abbreviations	171
8.6	Switchgear Cabinet	126	11.2	Standards and directives to be complied with	172
8.6.1	MIP control cabinet - Installation	126	11.3	Contact person/Service partner	174
9	Electrical Installation		12	Appendix B	
9.1	Wiring - Requirements	130	12.1	Index	175
9.2	Power cable - Installation	132			
9.3	Power cables on generator - Connection	137			
9.4	Generator circuit breaker (control unit) - Connection	141			

1 Preface

1.1 Preface

These Assembly Instructions are intended to assist project planners, system/component designers and installation personnel in planning or carrying out the installation of MTU components.

These Assembly Instructions apply to gas engine-generator sets from MTU, see (→ Page 0).

The objective of these Assembly Instructions is to facilitate the assembly of components.

The Assembly Instructions do not relieve those responsible for the system from independently ensuring that installation is carried out in an appropriate manner.

In addition to the Assembly Instructions, the following documents included in the scope of supply must be observed:

- Planning drawing
- Schematic diagrams
- TEN data
- Arrangement drawings
- Operating instructions (see business portal)
- Maintenance schedule (see business portal)
- Fluids and lubricants specifications (see business portal)
- MTU standards

Each document is taken from the respective specifications document required for the order.

Adherence to the prescribed schedule for maintenance tasks will have a positive effect on operational safety, reliability and long service life. During the planning or installation of the plant system, ease of access for operation, maintenance and repair work is to be ensured.

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer MTU.

Definition of MTU

MTU refers to Rolls-Royce Power Systems AG and MTU Friedrichshafen GmbH or an affiliated company pursuant to Section § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture).

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by MTU come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations and emissions label

Responsibility for compliance with emissions regulations

Modification or removal of any mechanical/electronic components or the installation of additional components including the execution of calibration processes that might affect the emissions characteristics of the product are prohibited by emissions regulations. Emissions-related components must only be serviced, exchanged or repaired if the components used for this purpose are approved by the manufacturer.

Noncompliance with these specifications will invalidate the design type approval or certification issued by the emissions regulation authorities. The manufacturer does not accept any liability for violations of the emissions regulations.

The product must be operated over its entire life cycle according to the conditions defined as "Intended use" (→ Page 8).

Emissions certification applicable to engines with EPA Nonroad Tier 4 emissions certification in accordance with 40 CFR 1039 and with EPA Locomotive emissions certification in accordance with 40 CFR 1033

Extract from the standard:

Failing to follow these instructions when installing a certified engine in a piece of nonroad equipment violates federal law (40 CFR 1068.105(b)), subject to fines or other penalties as described in the Clean Air Act.

Extract from the standard:

If you install the engine in a way that makes the engine's emission control information label hard to read during normal engine maintenance, you must place a duplicate label on the equipment, as described in 40 CFR 1068.105.

When fitting the second label, the requirements of 40 CFR 1068.105(c) must be followed and observed. This paragraph describes the process for requesting and fitting the label, the documentation obligations and storage obligations for the required documents.

Replacing components with emissions labels

On all engines from MTU fitted with emissions labels, these labels must remain on the engine throughout its operational life.

Exception: Engines used exclusively in land-based, military applications other than by US government agencies.

Please note the following when replacing components with emissions labels:

- The relevant emissions labels must be affixed to the spare part.
- Emissions labels shall not be transferred from the replaced part to the spare part.
- The emissions labels must be removed from the replaced part and destroyed.

2.2 Gas systems – Intended use

Intended use

The machine is intended to be used exclusively for electrical power generation and waste heat utilization in stationary operation, either in sufficiently ventilated rooms or in container solutions.

A gas/air mixture is fed to the internal combustion reciprocating piston engine. This is converted into mechanical work in the individual cylinders through combustion. The flywheel of the engine drives the synchronous generator connected via an elastic coupling, resulting in a conversion to electric energy. The engine and the generator are joined to the base frame with resilient, vibration-damped elements. For mains frequency 60 Hz, depending on the series either a gearbox is used between the engine and generator (Series 4000) or the engine speed is increased accordingly (Series 400). The waste heat generated during the combustion process is dissipated to the surroundings via coolers (power generator) and/or made available to the customer via heat exchangers (combined heat and power plant).

Area of application	Applicable	Comment
Industry	Yes	–
Business/Service	Yes	In some individual cases, however, such as with swimming pool facilities, schools, heating stations for apartment buildings and the like, no end user in the classic sense is involved
Household	No	Operation is excluded
Potentially explosive area	No	Operation is not permitted in potentially explosive areas
Underground	No	Operation is excluded
Mobile use	No	Operation is excluded

Table 2: Area of application of machine

There are 3 operating modes of the machine:

- Mains parallel operation
- Mains failure operation
- Isolated operation

Foreseeable misuse

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper use.

Operation

Operation is not permissible if the physical conditions specified on the technical data sheet or on/in other documents (concerning temperature, pressure, site altitude, etc.) are not complied with. Operation is not permissible without protective equipment, usage of approved spare parts, exclusion of conversions, warning of foreseeable misuse.

Operation is only permissible with the use of fluids and lubricants (natural gas, biogas, quality-compliant gas, quality-compliant water, lubricants) in accordance with the (→ Fluids and Lubricants Specifications).

Operation is only permissible with preservation agents approved by MTU in accordance with the (→ Preservation and Represervation Specifications).

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version of these are adopted. The latest version can be found at:

- <http://www.mtu-solutions.com>

Surroundings, climate, temperature

The weather plays no role with regard to the intended use of the engine-generator set/module provided that operation takes place inside an installation room. For container applications, however, the permissible outdoor temperatures at the installation site play a decisive role. The product-specific ambient conditions such as climate and temperature are indicated in the technical description.

Prerequisite for proper use

Fulfillment of all the requirements set out in the "Installation conditions" document.

Any use that does not fall within the described limits for use is regarded as improper.

Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.

Modifications or conversions

Unauthorized changes to the product breach the conditions concerning its intended use and compromise safety.

Only modifications or conversions expressly authorized by the manufacturer are regarded as compliant in this sense. The manufacturer shall not be held liable for any damage resulting from unauthorized modifications or conversions.

2.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.