



Assembly Instructions

Assembly Instructions for NOx sensor on Series 400/4000

M060815/04E

Name	Model number	Engine model	Application group
mtu 8V4000 GS	GG08V4000A1	8V4000L32 / L32FB 8V4000L33 8V4000L64 / L64FNER 8V4000L62 / L62FB 8V4000L63	3A, continuous operation, unrestricted
	GG08V4000A2	8V4000L32 / L32FB 8V4000L33 8V4000L64 / L64FNER	3A, continuous operation, unrestricted
mtu 12V4000 GS	GG12V4000A1	12V4000L32 / L32FB 12V4000L33 12V4000L64 / L64FNER 12V4000L62 / L62FB 12V4000L63	3A, continuous operation, unrestricted
	GG12V4000A2	12V4000L32 / L32FB 12V4000L33 12V4000L64 / L64FNER	3A, continuous operation, unrestricted
mtu 16V4000 GS	GG16V4000A1	16V4000L32 / L32FB 16V4000L33 16V4000L64 / L64FNER 16V4000L62 / L62FB 16V4000L63	3A, continuous operation, unrestricted
	GG16V4000A2	16V4000L32 / L32FB 16V4000L33 16V4000L64 / L64FNER	3A, continuous operation, unrestricted
mtu 20V4000 GS	GG20V4000A1	20V4000L32 / L32FB 20V4000L33 20V4000L64 / L64FNER 20V4000L62 / L62FB 20V4000L63	3A, continuous operation, unrestricted
	GG20V4000A2	20V4000L32 / L32FB 20V4000L33 20V4000L64 / L64FNER	3A, continuous operation, unrestricted
mtu 6R400 GS	GG06R0400A1	B3066Z8	3A, continuous operation, unrestricted
mtu 6R400 GS	GG06R0400A1	E3066Z5	3A, continuous operation, unrestricted
mtu 6R400 GS	GG06R0400A1	B3066L8	3A, continuous operation, unrestricted
mtu 6R400 GS	GG06R0400A1	E3066L9	3A, continuous operation, unrestricted
mtu 6R400 GS	GG06R0400A1	E3066LH9	3A, continuous operation, unrestricted
mtu 6R400 GS	GG06R0400A1	B3066L9	3A, continuous operation, unrestricted
mtu 6R400 GS	GG06R0400B1	E3066D4	3A, continuous operation, unrestricted
mtu 12V400 GS	GG12V0400A1	E3042Z6	3A, continuous operation, unrestricted
mtu 12V400 GS	GG12V0400A1	B3042Z7	3A, continuous operation, unrestricted
mtu 12V400 GS	GG12V0400A1	E3042L5	3A, continuous operation, unrestricted
mtu 12V400 GS	GG12V0400A1	B3042L5	3A, continuous operation, unrestricted
mtu 12V400 GS	GG12V0400A1	E3042D3	3A, continuous operation, unrestricted
mtu 12V400 GS	GG12V0400A1	E3042D4	3A, continuous operation, unrestricted
mtu 12V400 GS	GG12V0400A1	E3042DH4	3A, continuous operation, unrestricted

Table 1: Applicability

Table of Contents

1	Safety		3.1.1	Installation instructions and responsibilities for Series 400	31
1.1	Important provisions for all products	4	3.1.2	NOx sensor installation Series 400	33
1.2	Intended use of gas systems	5	3.1.3	Required material Series 400	39
1.3	Personnel and organizational requirements	7	3.2	Series 4000 L62/L62FB/L63 Gas Engine-Generator Sets	40
1.4	Safety regulations for commissioning and operation	8	3.2.1	Installation instructions and responsibilities for 8/12/16/20V engines	40
1.5	Safety regulations for commissioning and operation, specific information for gaseous fuel supply or and dual fuel applications	10	3.2.2	NOx sensor 8/12/16/20V – Installation	42
1.6	Safety regulations for assembly, maintenance, and repair work	12	3.2.3	Required material 8/12/16/20V	48
1.7	Safety regulations for assembly, maintenance and servicing work, specific information for gaseous fuel and dual fuel supply or applications	16	3.3	Series 4000 L32/L33/L33FBL64 Gas Engine-Generator Sets	50
1.8	Fire and environmental protection, indirect materials	17	3.3.1	Installation instructions and responsibilities 8/12/16V	50
1.9	Fire prevention and environmental protection, fluids and lubricants, auxiliary materials, specific information for gaseous fuel supply in gaseous-fuel or dual-fuel applications	20	3.3.2	NOx sensor installation on 8/12/16V engines	52
1.10	Standards for warning messages in the text and highlighted information	21	3.3.3	Required material 8/12/16V	55
1.11	Conventions for warning notices on safety signs on the engine-generator set	22	3.3.4	Installation instructions and special features 20V	56
1.12	Safety signs on engine-generator set - Overview	24	3.3.5	NOx sensor installation on 20V engines	58
1.13	Overview of protective devices on the engine-generator set	26	3.3.6	Required material 20V	61
2	General		4	Monitoring and Control	
2.1	General	28	4.1	Monitoring and Control Series 400/4000	62
2.2	Further requirements from the 44th edition of the German Federal Immission Control Ordinance (BlmSchV)	30	4.2	Checklist for commissioning Series 400/4000	70
3	Installation		5	Supplementary Technical Information	
3.1	Series 400 Gas Engine-Generator Sets	31	5.1	Operation log / Service Report	71
			6	Appendix A	
			6.1	Standards and directives to be complied with	72
			6.2	Contact person/Service partner	74
			7	Appendix B	
			7.1	Index	75

1 Safety

1.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at: <http://www.mtu-solutions.com>

1.2 Intended use of gas systems

Intended use

The machine is intended to be used exclusively for electrical power generation and waste heat utilization in stationary operation, either in sufficiently ventilated rooms or in container solutions.

A gas/air mixture is fed to the internal combustion reciprocating piston engine. This is converted into mechanical work in the individual cylinders through combustion. The flywheel of the engine drives the synchronous generator connected via an elastic coupling, resulting in a conversion to electric energy. The engine and the generator are joined to the base frame with resilient, vibration-damped elements.

For mains frequency 60 Hz, depending on the series either a gearbox is used between the engine and generator or the engine speed is increased accordingly. The waste heat generated during the combustion process is dissipated to the surroundings via coolers (power generator) and/or made available to the customer via heat exchangers (combined heat and power plant).

Area of application	Applicable	Comment
Industry	Yes	–
Business/Service	Yes	In some individual cases, however, such as with swimming pool facilities, schools, heating stations for apartment buildings and the like, no end user in the classic sense is involved
Household	No	Operation is excluded
Potentially explosive area	No	Operation is not permitted in potentially explosive areas
Underground	No	Operation is excluded
Mobile use	No	Operation is excluded

Table 2: Area of application of machine

There are 3 operating modes of the machine:

- Mains parallel operation
- Mains failure operation
- Isolated operation

Foreseeable misuse

Any other use, particularly misuse or wrong parametrization, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

Operation

Operation is not permissible if the physical conditions specified on the technical data sheet or on/in other documents (concerning temperature, pressure, site altitude, etc.) are not complied with. Operation is not permissible without protective equipment, usage of approved spare parts, supplied accessory parts, exclusion of conversions, warning of foreseeable misuse.

Operation is only permissible with the use of fluids and lubricants (natural gas, biogas, quality-compliant gas, quality-compliant water, lubricants) in accordance with the (→ Fluids and Lubricants Specifications).

Operation is only permissible with preservation agents approved by Rolls-Royce Solutions in accordance with the (→ Preservation and Represervation Specifications).

Operation is only permissible after proper integration/installation.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Surroundings, climate, temperature

The weather plays no role with regard to the intended use of the engine-generator set/module provided that operation takes place inside an installation room. For container applications, however, the permissible outdoor temperatures at the installation site play a decisive role. The product-specific ambient conditions such as climate and temperature are indicated in the technical description.

Prerequisite for proper use

Fulfillment of all the requirements set out in the “Installation conditions” document.

Any use that does not fall within the described limits for use is regarded as improper.

Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

1.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.

1.4 Safety regulations for commissioning and operation

Safety regulations for commissioning

Install the product correctly and carry out acceptance in accordance with the manufacturer's specifications before commissioning the product. All necessary approvals must be granted by the relevant authorities and all requirements for commissioning must be fulfilled.

Whenever the product is subsequently put into operation ensure that:

- All personnel is clear of the danger zone surrounding moving parts of the machine.
Electrically-actuated linkages may be set in motion when the Engine Control Unit (governor) is switched on.
- All maintenance and repair work has been completed.
- All loose parts have been removed from rotating machine components.
- All protective devices are in place.
- All lines bearing media are ready for operation.
- The walkways in the operating room are unobstructed and safe.
- No persons wearing pacemakers or any other technical body aids are present.
- Adequate ventilation of the operating room is ensured for any operating status.
- In the first few hours of operation, the product emits gases as a result of smoldering e.g. lacquers or oil. These gases may be hazardous to health. Always wear respiratory protection in the operating room during this period.
- The exhaust system is leak-tight and the gases are vented to atmosphere.
- The product is free of any damage, this applies in particular to lines and cabling.
- All components are properly grounded. Ground separately by means of a grounding stake as necessary.
- The power supply (mains plug) is always freely accessible to facilitate disconnecting the device or system from the power supply at any time.
- Battery terminals, generator terminals or cables are protected against accidental contact.
- All connections have been correctly allocated e.g. +/- polarity, fuel line/reducing agent line, supply/return.

Immediately after putting the product into operation, make sure that all control and display instruments as well as the monitoring, signaling and alarm systems work properly.

Smoking is prohibited in the area of the product.

Safety regulations during operation

The operator must be familiar with the control and display elements.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be observed with regard to present operating status, violation of limit values and warning or alarm messages.

Malfunctions and emergency stop

Practice emergency procedures, especially emergency stopping, at regular intervals.

Take the following steps if any system malfunctions are detected or signaled by the system:

- Inform supervisor(s) in charge.
- Analyze the message.
- Respond by taking any necessary emergency action, e.g. emergency stop.

After a safety shutdown, the engine may only be started after the cause of the shutdown has been eliminated.

Contact Service if the root cause of the malfunction cannot be clearly identified.

Operation

Do not remain in the operating room when the product is running unless absolutely necessary. Keep your stay as short as possible.

Keep a safe distance away from the product if possible. Do not touch the product unless expressly instructed to do so following a written procedure.

Do not inhale the exhaust gases of the product.

The following requirements must be fulfilled before the product is started:

- Wear hearing protection.
- Mop up any leaked or spilled fluids and lubricants immediately or soak up with a suitable binding agent.

Operation of electrical equipment

When electrical equipment is in operation, certain components of these appliances are electrically live.

Follow the applicable operating and safety instructions when operating the devices and heed warnings at all times.

1.5 Safety regulations for commissioning and operation, specific information for gaseous fuel supply or and dual fuel applications

Gas system, general requirements

Operating company requirements: When putting the product into operation, always check the gas control units.

The temperature of the gas during operation must not fall below 5 °C in any section.

The plant manufacturer / operating company must make the connection to the gas supply according to the respectively applicable official regulations, e.g. DVGW, G490/I, G491/I, DIN EN 12186, NFPA37.

Shut-off for the gas supply: The plant manufacturer / operating company must design the gas shut-off device according to local regulations.

Work on lines and components carrying fuel gas must only be carried out gas specialist companies with specially qualified personnel.

In case pressure is exceeded, the gas pressure regulator must be equipped at the pressure regulator outlet with a certified safety shut-off valve (SAV) and a safety blow-off valve (SBV). The gas must be directed into a ventilated safe zone (to the atmosphere).

Gas engine (Loose engine)

The fuel supplied to the gas engine is exclusively fuel gas.

For the gas supply to the product and connection to a gas supply network, the plant manufacturer/operating company must use inspected gas control units. The connection conditions and dimensions must be coordinated with the manufacturer.

Depending on the country of use and usage conditions, further control and/or safety devices may be demanded and required.

If the gas supply is connected to a vessel or if gases containing oxygen are used, the gas control unit must be equipped with a temperature-monitored flame arrestor.

The gas shut-off valves are activated via two different paths from the engine control system, whereby one gas shut-off valve respectively is activated via one of the paths.

The gas control unit must be equipped with a minimum pressure monitor.

In flow direction, gas control units have:

- One manual shut-off fitting
- One gas filter
- Two gas shut-off valves
- One pressure regulating device

The gas control unit must be equipped with an automatic leak monitor.

Additional equipment for the gas control unit, e.g. a maximum pressure monitor, may be necessary

- at a pressure in the gas supply above 100 mbar
- at a gas volume flow higher than 200 m³/h
- a fuel output higher than 600 KW

The plant manufacturer/operating company is responsible for positioning the gas control unit directly before the engine, but a maximum of 3 meter line length before the engine interface. The interface is the flange of the gas volume controller or the connection of the gas-air mixer of the engine.

Series 400 and 500: The gas control unit must be positioned directly before the engine, but a maximum of 2 meter line length before the engine interface.

Freedom of movement of the flexible line connection must be guaranteed in accordance with the installation instructions.