



Installation and Commissioning Instructions

Gas engine-generator sets
Series 500

with MMC500 Version 1.0

MS65055/00E

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

Table of Contents

1	Safety		3.11	Safety concept	52
1.1	Important provisions for all products	6	3.12	Check of water systems	54
1.2	Intended use of gas systems	7	3.12.1	Water systems - Check	54
1.3	Personnel and organizational requirements	9	3.12.2	Expansion tank	55
1.4	Safety regulations for commissioning and operation	10	3.12.3	Coolant pressure for Series 500 - Setting	58
1.5	Safety regulations for commissioning and operation, specific information for gaseous fuel supply or and dual fuel applications	12	3.13	Connections for lube oil	59
1.6	Safety regulations for assembly, maintenance, and repair work	14	4	Initial operation of switch cabinets	
1.7	Safety regulations for assembly, maintenance and servicing work, specific information for gaseous fuel and dual fuel supply or applications	18	4.1	General information	62
1.8	Fire and environmental protection, indirect materials	19	4.2	Control cabinets - Electrical check	63
1.9	Fire prevention and environmental protection, fluids and lubricants, auxiliary materials, specific information for gaseous fuel supply in gaseous-fuel or dual-fuel applications	22	4.3	Voltage supply and measurement of rotary fields	64
1.10	Standards for warning messages in the text and highlighted information	23	4.4	Grid measurement voltage	65
2	Preparations for Operation		4.5	List of plant data	66
2.1	General information	24	4.6	Motor protection switch - Setting	67
2.2	Handover discussion	25	4.7	Battery chargers	68
2.3	Documents required for commissioning	26	4.8	Starter batteries - Check	71
2.4	Pre-commissioning record	27	4.9	24 VDC power supply	72
3	Check of installation on site		4.10	PLC voltage supply - Switching on	73
3.1	General information	28	4.11	Industrial PC - Switching on	75
3.2	General Provisions	29	4.12	Project name - Change	77
3.2.1	Water systems	29	4.13	Date and time for RPS - Setting	79
3.2.2	Gas systems	30	4.14	Remote access - Testing	80
3.2.3	Electrical hazards	32	4.15	PLC / UPS - Battery change intervals	81
3.2.4	Exhaust systems	34	4.16	Remaining 24 V voltage supply - Activation	82
3.2.5	Mechanical dangers	35	5	Check of engine peripherals	
3.3	Taking stock of delivery	36	5.1	General information	84
3.4	Installation situation of the engine-generator set / module	37	5.2	Safety chains - Activation	85
3.5	Taking stock of external devices	38	5.3	Frequency converter - Programming	86
3.6	Grounding - Check	39	5.4	Water temperature controller - Test	98
3.7	Power cabling	44	5.5	Mixture coolant temperature controller - Test	99
3.8	Connections for gas	45	5.6	Emergency coolant controller - Test	100
3.9	Connections for exhaust gas	46	5.7	Operation of heating water pump - Test	101
3.10	Air system - Check	48	5.8	Operation of coolant pump - Test	102
			5.9	Mixture coolant blower and pump - Test	103
			5.10	Emergency cooler blower and pump - Test	104
			5.11	Supply and exhaust air flaps - Test	105
			5.12	Room fan - Test	106
			5.13	Room temperature sensor / exhaust air temperature sensor - Test	107
			5.14	Room temperature controller - Test	108
			5.15	Gas compressor (only with biogas) - Test	109
			5.16	Preheating - Test	110
			5.17	External analog sensors - Check and calibration	114
			5.18	External analog values - Calibration	115

5.19	External signals - Check	117	9	Preliminary check of engine	
5.20	External communication - Test	118	9.1	Performing overspeed test	188
5.21	Messages - Check	119	9.2	Service Menu - Calling	191
5.22	Plant-specific parameters	120	9.3	Ignition time - Calibration	195
5.23	Plant malfunction - Test	121	9.4	Settings - Check	196
5.24	Technical safety equipment - Check after completion of work	122	9.5	All connectors for the electric engine components - Retighten and check	198
6	Initial operation of gas train		9.6	Coolant system - Venting	199
6.1	Safety shut-off valve	123	9.7	Engine - Filling with oil and priming until oil pressure is displayed in the MMC	200
6.2	Safety blow-off valve	124	9.8	Gas warning / fire alarm - Test	205
6.3	Technical safety necessity of an SAV / SBV	125	10	Energy measurement module	
6.4	Gas pressure sensors - Setting	126	10.1	Power measurement module parameters 1	206
6.5	Settings	127	10.2	Power measurement module parameters 2	209
6.6	Gas train - Check	128	10.3	Power measurement module parameters 3	211
6.7	Gas filter	134	10.4	Mains busbar-generator voltage at energy measurement module - Connection	219
6.8	Double solenoid valve	135	10.5	Connection of current transformers to energy measurement module	221
6.9	Operation of safety pressure monitor min. (SPM min) - Check	136	10.6	Connection of current transformers in generator	222
6.10	Safety pressure monitor "max." - Function check	137	11	Engine Start	
6.11	Gas leak test VPS 504	139	11.1	Module in manual mode - Starting	224
6.12	Deflagration flame arrestor / Thermal fuse cut-off	142	11.2	Gas train - Check	225
6.13	Gas pressure regulator	143	11.3	Ignition time - Check and adjustment	226
6.14	Gas hose to gas mixer	145	11.4	EMERGENCY-STOP button - Test	229
7	Initial operation of generator circuit breaker		11.5	Visual inspection for leaks and engine behavior	230
7.1	General information	146	12	Measurement of generator rotary field	
7.2	Safety functions of generator circuit breaker - Check	147	12.1	Rotary field at generator - Measurement	231
7.3	Generator circuit breaker - Setting	148	13	Functional test of automatic voltage regulator AVR	
7.4	Undervoltage circuit breaker	151	13.1	AVR function - Test	233
7.5	Generator circuit breaker / grid coupling switch - Test	152	14	Synchronization	
7.6	Switch-on contact to mains - Disconnection	154	14.1	Measuring points on container for synchronization	234
7.7	Generator circuit breaker - Move to test position	158	14.2	Preventing cut-in to the mains	235
8	Initial operation of generator		14.3	Synchronization - Check	237
8.1	General information	159	14.4	Floating voltage - Check	239
8.2	Generator - Commissioning	160	14.5	Switch-on contact - Connection	240
8.3	Generator - Electrical check	163	14.6	Engine - Synchronization	241
8.4	Generator power cables - Check	165	14.7	Mains failure test	242
8.5	Leroy Somer generators - Insulation measurement	167			
8.6	Automatic voltage regulator D510C	172			
8.7	Diodes in the generator - Check	184			

15 Engine setting		19 Setting and test of power control at the MMC	
15.1 Engine – Running-in procedure	243	19.1 MMC power control – Setting and testing	289
15.2 Filling systems – Check	245	20 Parameters	
15.3 Ventilation systems – Adjustment	246	20.1 Backing up data and parameters	291
15.4 Water systems – Setting	247	21 Final Steps	
15.5 Settings	248	21.1 Final steps	293
15.5.1 Emission values – Calibration	248	22 Following startup	
15.5.2 Explanation of calibrating emissions	252	22.1 Following startup	295
15.6 Automatic oil replenishment – Test	254	23 Appendix A	
15.7 Recording measured values and preparing acceptance report	255	23.1 List of abbreviations	296
15.8 Full load shedding (isolated operation / standby power operation) – Test	256	23.2 Contact person/Service partner	298
16 Isolated Operation		24 Appendix B	
16.1 Isolated operation	257	24.1 Index	299
17 Option parameters in the Service menu			
17.1 Option parameters in the Service Menu	258		
18 Optional functions			
18.1 Standby power operation – Test	287		

1 Safety

1.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at:<http://www.mtu-solutions.com>

1.2 Intended use of gas systems

Intended use

The machine is intended to be used exclusively for electrical power generation and waste heat utilization in stationary operation, either in sufficiently ventilated rooms or in container solutions.

A gas/air mixture is fed to the internal combustion reciprocating piston engine. This is converted into mechanical work in the individual cylinders through combustion. The flywheel of the engine drives the synchronous generator connected via an elastic coupling, resulting in a conversion to electric energy. The engine and the generator are joined to the base frame with resilient, vibration-damped elements.

For mains frequency 60 Hz, depending on the series either a gearbox is used between the engine and generator or the engine speed is increased accordingly. The waste heat generated during the combustion process is dissipated to the surroundings via coolers (power generator) and/or made available to the customer via heat exchangers (combined heat and power plant).

Area of application	Applicable	Comment
Industry	Yes	–
Business/Service	Yes	In some individual cases, however, such as with swimming pool facilities, schools, heating stations for apartment buildings and the like, no end user in the classic sense is involved
Household	No	Operation is excluded
Potentially explosive area	No	Operation is not permitted in potentially explosive areas
Underground	No	Operation is excluded
Mobile use	No	Operation is excluded

Table 1: Area of application of machine

There are 3 operating modes of the machine:

- Mains parallel operation
- Mains failure operation
- Isolated operation

Foreseeable misuse

Any other use, particularly misuse or wrong parametrization, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

Operation

Operation is not permissible if the physical conditions specified on the technical data sheet or on/in other documents (concerning temperature, pressure, site altitude, etc.) are not complied with. Operation is not permissible without protective equipment, usage of approved spare parts, supplied accessory parts, exclusion of conversions, warning of foreseeable misuse.

Operation is only permissible with the use of fluids and lubricants (natural gas, biogas, quality-compliant gas, quality-compliant water, lubricants) in accordance with the (→ Fluids and Lubricants Specifications).

Operation is only permissible with preservation agents approved by Rolls-Royce Solutions in accordance with the (→ Preservation and Represervation Specifications).

Operation is only permissible after proper integration/installation.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Surroundings, climate, temperature

The weather plays no role with regard to the intended use of the engine-generator set/module provided that operation takes place inside an installation room. For container applications, however, the permissible outdoor temperatures at the installation site play a decisive role. The product-specific ambient conditions such as climate and temperature are indicated in the technical description.

Prerequisite for proper use

Fulfillment of all the requirements set out in the “Installation conditions” document.

Any use that does not fall within the described limits for use is regarded as improper.

Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

1.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.

1.4 Safety regulations for commissioning and operation

Safety regulations for commissioning

Install the product correctly and carry out acceptance in accordance with the manufacturer's specifications before commissioning the product. All necessary approvals must be granted by the relevant authorities and all requirements for commissioning must be fulfilled.

Whenever the product is subsequently put into operation ensure that:

- All personnel is clear of the danger zone surrounding moving parts of the machine.
Electrically-actuated linkages may be set in motion when the Engine Control Unit (governor) is switched on.
- All maintenance and repair work has been completed.
- All loose parts have been removed from rotating machine components.
- All protective devices are in place.
- All lines bearing media are ready for operation.
- The walkways in the operating room are unobstructed and safe.
- No persons wearing pacemakers or any other technical body aids are present.
- Adequate ventilation of the operating room is ensured for any operating status.
- In the first few hours of operation, the product emits gases as a result of smoldering e.g. lacquers or oil.
These gases may be hazardous to health. Always wear respiratory protection in the operating room during this period.
- The exhaust system is leak-tight and the gases are vented to atmosphere.
- The product is free of any damage, this applies in particular to lines and cabling.
- All components are properly grounded. Ground separately by means of a grounding stake as necessary.
- The power supply (mains plug) is always freely accessible to facilitate disconnecting the device or system from the power supply at any time.
- Battery terminals, generator terminals or cables are protected against accidental contact.
- All connections have been correctly allocated e.g. +/- polarity, fuel line/reducing agent line, supply/return.

Immediately after putting the product into operation, make sure that all control and display instruments as well as the monitoring, signaling and alarm systems work properly.

Smoking is prohibited in the area of the product.

Safety regulations during operation

The operator must be familiar with the control and display elements.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be observed with regard to present operating status, violation of limit values and warning or alarm messages.

Malfunctions and emergency stop

Practice emergency procedures, especially emergency stopping, at regular intervals.

Take the following steps if any system malfunctions are detected or signaled by the system:

- Inform supervisor(s) in charge.
- Analyze the message.
- Respond by taking any necessary emergency action, e.g. emergency stop.

After a safety shutdown, the engine may only be started after the cause of the shutdown has been eliminated.

Contact Service if the root cause of the malfunction cannot be clearly identified.

Operation

Do not remain in the operating room when the product is running unless absolutely necessary. Keep your stay as short as possible.