

Instructions for Exchange of Sub-assemblies

Gas Engine

8V4000L62

12V4000L62

16V4000L62

20V4000L62

8V4000L63

12V4000L63

16V4000L63

20V4000L63

MS22022/02E



Power. Passion. Partnership.

Engine model	kW/cyl.	Application group
8V4000L62	100 kW/cyl.	3A, continuous operation, unrestricted
12V4000L62	100 kW/cyl.	3A, continuous operation, unrestricted
16V4000L62	100 kW/cyl.	3A, continuous operation, unrestricted
20V4000L62	100 kW/cyl.	3A, continuous operation, unrestricted
8V4000L63	110 kW/cyl.	3A, continuous operation, unrestricted
12V4000L63	110 kW/cyl.	3A, continuous operation, unrestricted
16V4000L63	110 kW/cyl.	3A, continuous operation, unrestricted
20V4000L63	110 kW/cyl.	3A, continuous operation, unrestricted

Table 1: Applicability

Table of Contents

1	Safety		4.1.15	Cylinder liner – Final steps	45
1.1	Important provisions for all products	6	4.2	Running Gear	46
1.2	Correct use of all products	8	4.2.1	Crankshaft PTO, free end – Overview	46
1.3	Personnel and organizational requirements	9	4.2.2	Vibration damper, 12/16 V engines – Removal	51
1.4	Initial start-up and operation – Safety regulations	10	4.2.3	Vibration damper, 12/16 V – Installation	54
1.5	Safety regulations for startup and operation, specific information for gaseous fuel or dual fuel supply applications	12	4.2.4	Vibration damper, 20V engines – Removal	58
1.6	Assembly, maintenance, and repair work – Safety regulations	14	4.2.5	Vibration damper, 20V – Installation	61
1.7	Safety regulations for assembly, maintenance and servicing work, specific information for gaseous fuel and dual fuel supply or applications	18	4.2.6	Piston and conrod – Overview	66
1.8	Fire and environmental protection, fluids and lubricants	19	4.2.7	Piston and conrod – Preparatory steps	69
1.9	Fire prevention and environmental protection, fluids and lubricants, auxiliary materials, specific information for gaseous fuel supply in gaseous-fuel or dual-fuel applications	21	4.2.8	Piston and conrod – Removal	70
1.10	Standards for warning notices in the text and highlighted information	22	4.2.9	Piston and conrod – Disassembly	72
2	General Information		4.2.10	Piston – Cleaning	74
2.1	Engine side and cylinder designations	23	4.2.11	Piston – Check	76
3	Technical Data		4.2.12	Piston – Tolerances	78
3.1	Settings	24	4.2.13	Conrod – Check	81
4	Task Description		4.2.14	Conrod – Tolerances	83
4.1	Crankcase and Attachments	26	4.2.15	Conrod – Assembly	87
4.1.1	Inspection port cover – Overview	26	4.2.16	Piston – Assembly	90
4.1.2	Inspection port cover – Preparatory steps	28	4.2.17	Piston and conrod – Installation	93
4.1.3	Inspection port cover – Removal	29	4.2.18	Piston and conrod – Final steps	98
4.1.4	Inspection port cover sealing surfaces – Cleaning	30	4.3	Cylinder Head	99
4.1.5	Inspection port cover – Check	31	4.3.1	Cylinder head with add-on components – Overview	99
4.1.6	Inspection port cover – Installation	32	4.3.2	Cylinder head – Preparatory steps	101
4.1.7	Inspection port cover – Final steps	33	4.3.3	Cylinder head – Removal	102
4.1.8	Cylinder liner – Overview	34	4.3.4	Cylinder head – Cleaning	105
4.1.9	Cylinder liner – Preparatory steps	36	4.3.5	Cylinder head – Installation	107
4.1.10	Cylinder liner – Removal	37	4.3.6	Cylinder head – Final steps	111
4.1.11	Cylinder liner – Cleaning	39	4.4	Valve Gear	112
4.1.12	Cylinder liner – Check	40	4.4.1	Valve gear – Overview	112
4.1.13	Cylinder liner – Tolerances	41	4.4.2	Valve drive – Overview	113
4.1.14	Cylinder liner – Installation	43	4.4.3	Valve drive – Preparatory steps	118
			4.4.4	Valve gear – Removal	119
			4.4.5	Valve drive – Cleaning	120
			4.4.6	Valve drive – Check	121
			4.4.7	Valve gear – Installation	122
			4.4.8	Valve drive – Final steps	125
			4.4.9	Cylinder head cover – Overview	126
			4.4.10	Cylinder head cover – Removal	127
			4.4.11	Cylinder head cover – Installation	128
			4.5	Ignition System	129
			4.5.1	Spark plug – Removal	129
			4.5.2	Spark plug – Installation	130
			4.5.3	Spark plug connector – Removal	132
			4.5.4	Spark plug connector – Installation	133
			4.6	Gas System	135
			4.6.1	Gas system – Overview	135
			4.6.2	Gas control valve (TecJet) – Preparatory steps	137
			4.6.3	Gas control valve (TecJet) – Removal	138
			4.6.4	Gas control valve (TecJet) – Check	139
			4.6.5	Gas control valve (TecJet) – Installation	140
			4.6.6	Gas control valve (TecJet) – Final steps	141

4.7 Exhaust Turbocharger	142	4.10.5 Exhaust pipework after cylinder head - Installation	194
4.7.1 Exhaust turbocharger - Overview	142	4.10.6 Exhaust pipework after cylinder head - Final steps	195
4.7.2 Exhaust turbocharger - Preparatory steps	145	4.10.7 Exhaust pipework after exhaust turbocharger - Overview	196
4.7.3 Exhaust turbocharger - Removal	146	4.10.8 Exhaust pipework after turbocharger - Removal	201
4.7.4 Exhaust turbocharger - Cleaning	147	4.10.9 Exhaust pipework after exhaust turbocharger - Installation	202
4.7.5 Exhaust turbocharger - Check	148	4.11 Starting Equipment	203
4.7.6 Exhaust turbocharger - Installation	149	4.11.1 Starter - Overview	203
4.7.7 Exhaust turbocharger - Final steps	151	4.11.2 Starter - Preparatory steps	205
4.8 Mixture Cooling	152	4.11.3 Starter - Removal	206
4.8.1 Mixture cooler - Overview	152	4.11.4 Starter - Cleaning	207
4.8.2 Mixture cooler - Preparatory steps	154	4.11.5 Starter - Check	208
4.8.3 Mixture cooler - Removal	155	4.11.6 Starter - Installation	209
4.8.4 Mixture cooler - Cleaning	156	4.11.7 Starter - Final steps	211
4.8.5 Mixture cooler - Check	157	4.12 Lube Oil System, Lube Oil Circuit	212
4.8.6 Mixture cooler - Installation	158	4.12.1 Oil heat exchanger - Overview	212
4.8.7 Mixture cooler - Final steps	159	4.12.2 Oil heat exchanger - Preparatory steps	213
4.9 Air Intake / Air Supply	160	4.12.3 Oil heat exchanger - Removal	214
4.9.1 Air intake / mixture supply - Overview	160	4.12.4 Oil heat exchanger - Cleaning	215
4.9.2 Air filter and air intake - Overview	162	4.12.5 Oil heat exchanger - Installation	216
4.9.3 Air filter and air intake - Removal	163	4.12.6 Oil heat exchanger - Final steps	217
4.9.4 Air filter and air intake - Installation	164	4.12.7 Exhaust turbocharger oil supply, 16V - Overview	218
4.9.5 Mixture pipework upstream of mixture cooler - Overview	165	4.12.8 Exhaust turbocharger oil supply, 16V - Removal	219
4.9.6 Mixture pipe upstream of mixture cooler - Preparatory steps	167	4.12.9 Exhaust turbocharger oil supply, 16V - Installation	220
4.9.7 Mixture line upstream of mixture cooler - Removal	168	4.13 Coolant System	221
4.9.8 Mixture line before mixture cooler - Installation	169	4.13.1 Coolant pipework, HT circuit - Overview	221
4.9.9 Mixture pipe upstream of mixture cooler - Final steps	172	4.13.2 Coolant pipework, HT circuit - Preparatory steps	222
4.9.10 Mixture pipework downstream of mixture cooler - Overview	173	4.13.3 Coolant pipework, HT circuit - Removal	223
4.9.11 Mixture pipe downstream of mixture cooler - Preparatory steps	176	4.13.4 Coolant pipework, HT circuit - Installation	224
4.9.12 Mixture pipework downstream of mixture cooler - Removal	177	4.13.5 Coolant pipework, HT circuit - Final steps	226
4.9.13 Mixture line downstream of mixture cooler - Installation	178	4.13.6 Coolant pipework from/to mixture cooler (HT-circuit) - Overview	227
4.9.14 Mixture pipe downstream of mixture cooler - Final steps	179	4.13.7 Coolant pipework from/to mixture cooler (HT system) - Preparatory steps	229
4.9.15 Heat shield for mixture line - Overview	180	4.13.8 Coolant pipework from/to mixture cooler (HT circuit) - Removal	230
4.9.16 Heat shield for mixture line - Removal	181	4.13.9 Coolant pipework from/to mixture cooler (HT circuit) - Installation	231
4.9.17 Heat shield for mixture line - Installation	182	4.13.10 Coolant pipework from/to mixture cooler (HT system) - Final steps	232
4.9.18 Bypass line - Overview	183	4.13.11 Coolant ventilation - Overview	233
4.9.19 Bypass line - Removal	185	4.13.12 Coolant ventilation - Preparatory steps	237
4.9.20 Bypass line - Installation	186	4.13.13 Coolant ventilation - Removal	238
4.10 Exhaust Pipework	187	4.13.14 Coolant ventilation - Installation	239
4.10.1 Exhaust pipework - Overview	187	4.13.15 Coolant ventilation - Final steps	240
4.10.2 Exhaust pipework downstream of cylinder head - Overview	189	4.13.16 Coolant pipework from/to exhaust turbochargers - Overview	241
4.10.3 Exhaust pipework downstream of cylinder head - Preparatory steps	192		
4.10.4 Exhaust pipework after cylinder head - Removal	193		

4.13.17	Coolant pipework from/to exhaust turbochargers - Preparatory steps	243	4.15.4	Sensors - Removal	269
4.13.18	Coolant pipework from/to exhaust turbochargers - Removal	244	4.15.5	Sensors - Check	274
4.13.19	Coolant pipework from/to exhaust turbochargers - Installation	245	4.15.6	Sensors - Installation	275
4.13.20	Coolant pipework from/to exhaust turbochargers - Final steps	246	4.15.7	Sensors - Final steps	283
4.13.21	Coolant pipework from/to mixture cooler (LT circuit) - Overview	247	4.15.8	ADEC engine governor, EMU engine monitoring unit and knock module - Overview	284
4.13.22	Coolant pipework from/to mixture cooler (LT system) - Preparatory steps	248	4.15.9	ADEC engine governor, EMU engine monitoring unit and knock module - Removal	288
4.13.23	Coolant pipework from/to mixture cooler (LT circuit) - Removal	249	4.15.10	ADEC engine governor, EMU engine monitoring unit and knock module - Installation	289
4.13.24	Coolant pipework from/to mixture cooler (LT circuit) - Installation	250			
4.13.25	Coolant pipework from/to mixture cooler (LT system) - Final steps	251	5	Appendix A	
4.14	Mounting / Support	252	5.1	Tightening specifications for screws, nuts and bolts	290
4.14.1	Engine mounting - Overview	252	5.2	Conversion tables	303
4.14.2	Engine mounting - Removal	253	5.3	Tolerances and wear limits list - General information	307
4.14.3	Engine mounting - Installation	254	5.4	Abbreviations	308
4.15	Monitoring, Control and Regulation Equipment	255	5.5	MTU Onsite Energy contact person / service partner	310
4.15.1	Engine wiring - Overview	255	6	Appendix B	
4.15.2	Sensors - Overview	260	6.1	Special Tools	311
4.15.3	Sensors - Preparatory steps	268	6.2	Index	328

1 Safety

1.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by MTU come with a second nameplate. When operating the machine in the EU: The second nameplate must be affixed in a prominent position as described in the accompanying specifications.

Emission regulations and emission labels

Responsibility for compliance with emission regulations

Modification or removal of any mechanical/electronic components or the installation of additional components including the execution of calibration processes that might affect the emission characteristics of the product are prohibited by emission regulations. Emission-related components must only be serviced, exchanged or repaired if the components used for this purpose are approved by the manufacturer.

Noncompliance with these specifications will invalidate the design type approval or certification issued by the emissions regulation authorities. The manufacturer does not accept any liability for violations of the emission regulations.

The product must be operated over its entire life cycle according to the conditions defined as "Intended use" (→ Page 8).

Emission certification applicable to engines with EPA Nonroad Tier 4 emission certification in accordance with 40 CFR 1039

Extract from the standard:

Failing to follow these instructions when installing a certified engine in a piece of nonroad equipment violates federal law (40 CFR 1068.105(b)), subject to fines or other penalties as described in the Clean Air Act.

Extract from the standard:

If you install the engine in a way that makes the engine's emission control information label hard to read during normal engine maintenance, you must place a duplicate label on the equipment, as described in 40 CFR 1068.105.

When fitting the second label, the requirements of 40 CFR 1068.105(c) must be followed and observed. This paragraph describes the process for requesting and fitting the label, the documentation obligations and storage obligations for the required documents.

Replacing components with emission labels

On all MTU engines fitted with emission labels, these labels must remain on the engine throughout its operational life.

Exception: Engines used exclusively in land-based, military applications other than by US government agencies.

Please note the following when replacing components with emission labels:

- The relevant emission labels must be affixed to the spare part.
- Emission labels shall not be transferred from the replaced part to the spare part.
- The emission labels must be removed from the replaced part and destroyed.

1.2 Correct use of all products

Correct use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/MTU contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found on the websites:

- For drive systems: <http://www.mtu-online.com>
- For power generation: <http://www.mtuonsiteenergy.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

1.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the descriptions of the individual activities.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorisation and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.

1.4 Initial start-up and operation – Safety regulations

Safety regulations for initial start-up

Install the product correctly and carry out acceptance in accordance with the manufacturer's specifications before putting the product into service. All necessary approvals must be granted by the relevant authorities and all requirements for initial startup must be fulfilled.

Whenever the product is subsequently taken into operation ensure that:

- All personnel is clear of the danger zone surrounding moving parts of the machine.
Electrically-actuated linkages may be set in motion when the Engine Control Unit (governor) is switched on.
- All maintenance and repair work has been completed.
- All loose parts have been removed from rotating machine components.
- All safeguards are in place.
- All components must be properly grounded. Ground separately by means of a grounding stake as necessary.
- No persons wearing pacemakers or any other technical body aids are present.
- The service room is adequately ventilated.
- In the first few hours of operation, the product emits gases as a result of smoldering e.g. lacquers or oil. These gases may be hazardous to health. Always wear respiratory protection in the operating room during this period.
- The exhaust system is leak-tight and that the gases are vented to atmosphere.
- The product must be free of any damage, this applies in particular to lines and cabling.
- Protect battery terminals, generator terminals or cables against accidental contact.
- Check that all connections have been correctly allocated e.g. +/- polarity, fuel line/reduction agent line, supply/return.

Immediately after putting the product into operation, make sure that all control and display instruments as well as the monitoring, signaling and alarm systems work properly.

Smoking is prohibited in the area of the product.

Safety regulations during operation

The operator must be familiar with the control and display elements.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be permanently observed with regard to present operating status, violation of limit values and warning or alarm messages.

Malfunctions and emergency stop

Practice emergency procedures, especially emergency stopping, at regular intervals.

Take the following steps if any system malfunctions are detected or signaled by the system:

- Inform supervisor(s) in charge.
- Analyze the message.
- Respond by taking any necessary emergency action, e.g. emergency stop.

After a safety shutdown, the engine must only be started after the cause of the shutdown has been eliminated.

Contact Service if the root cause of the malfunction cannot be clearly identified.

Operation

Do not remain in the operating room when the product is running unless absolutely necessary. Keep your stay as short as possible.

Keep a safe distance away from the product if possible. Do not touch the product unless expressly instructed to do so following a written procedure.