



Instructions for Exchange of Sub-assemblies

Gas engine
8V4000L32FB
12V4000L32FB
16V4000L32FB
20V4000L32FB

MS22069/02E

Engine model	kW/cyl.	Application group
8V4000L32FB	100/103 kW/cyl.	3A, continuous operation, unrestricted
12V4000L32FB	100 kW/cyl.	3A, continuous operation, unrestricted
16V4000L32FB	100 kW/cyl.	3A, continuous operation, unrestricted
20V4000L32FB	100 kW/cyl.	3A, continuous operation, unrestricted

Table 1: Applicability

Table of Contents

1	Preface			
1.1	Preface	6		
2	Safety			
2.1	Important provisions for all products	7		
2.2	Intended use of all products	9		
2.3	Personnel and organizational requirements	10		
2.4	Safety regulations for initial start-up and operation	11		
2.5	Safety regulations for commissioning and operation, specific information for gaseous fuel supply or and dual fuel applications	13		
2.6	Safety regulations for assembly, maintenance, and repair work	15		
2.7	Safety regulations for assembly, maintenance and servicing work, specific information for gaseous fuel and dual fuel supply or applications	19		
2.8	Fire and environmental protection, indirect materials	20		
2.9	Fire prevention and environmental protection, fluids and lubricants, auxiliary materials, specific information for gaseous fuel supply in gaseous-fuel or dual-fuel applications	23		
2.10	Standards for warning notices in the text and highlighted information	24		
3	General Information			
3.1	Engine side and cylinder designations	25		
4	Technical Data			
4.1	Settings	26		
5	Task Description			
5.1	Crankcase and Attachments	28		
5.1.1	Inspection port cover - Overview	28		
5.1.2	Inspection port cover - Preparatory steps	30		
5.1.3	Inspection port cover - Removal	31		
5.1.4	Inspection port cover sealing surfaces - Cleaning	32		
5.1.5	Inspection port cover - Check	33		
5.1.6	Inspection port cover - Installation	34		
5.1.7	Inspection port cover - Final steps	35		
5.1.8	Cylinder liner - Overview	36		
5.1.9	Cylinder liner - Preparatory steps	38		
5.1.10	Cylinder liner - Removal	39		
5.1.11	Cylinder liner - Cleaning	40		
5.1.12	Cylinder liner - Check	41		
5.1.13	Cylinder liner - Tolerances	42		
5.1.14	Cylinder liner - Installation	44		
5.1.15	Cylinder liner - Final steps	46		
5.2	Running Gear	47		
5.2.1	Crankshaft PTO, free end - Overview	47		
5.2.2	Vibration damper on PTO, free end - Removal	52		
5.2.3	Vibration damper on PTO, free end - Installation	57		
5.2.4	Piston and conrod - Overview	66		
5.2.5	Pistons and conrods - Preparatory steps	69		
5.2.6	Piston and conrod - Removal	70		
5.2.7	Piston and conrod - Disassembly	72		
5.2.8	Piston - Cleaning	74		
5.2.9	Piston - Check	76		
5.2.10	Piston - Tolerances	78		
5.2.11	Conrod - Check	81		
5.2.12	Conrod - Tolerances	83		
5.2.13	Conrod - Assembly	87		
5.2.14	Piston - Assembly	90		
5.2.15	Piston and conrod - Installation	93		
5.2.16	Piston and conrod - Final steps	99		
5.3	Cylinder Head	100		
5.3.1	Cylinder head with add-on components - Overview	100		
5.3.2	Cylinder head - Preparatory operations	102		
5.3.3	Cylinder head - Removal	103		
5.3.4	Cylinder head - Disassembly	106		
5.3.5	Cylinder head - Cleaning	108		
5.3.6	Cylinder head - Assembly	110		
5.3.7	Cylinder head - Installation	115		
5.3.8	Cylinder head - Final steps	120		
5.4	Valve Gear	121		
5.4.1	Valve gear - Overview	121		
5.4.2	Valve drive - Overview	123		
5.4.3	Valve drive - Preparatory steps	128		
5.4.4	Valve gear - Removal	129		
5.4.5	Valve drive - Cleaning	130		
5.4.6	Valve drive - Check	131		
5.4.7	Valve drive - Installation	132		
5.4.8	Valve drive - Final steps	135		
5.5	Gas System	136		
5.5.1	Gas system - Overview	136		
5.5.2	Gas control valve (TecJet) - Preparatory steps	138		
5.5.3	Gas control valve (TecJet) - Removal	139		
5.5.4	Gas control valve (TecJet) - Check	140		
5.5.5	Gas control valve (TecJet) - Installation	141		
5.5.6	Gas control valve (TecJet) - Final steps	143		
5.6	Exhaust Turbocharger	144		
5.6.1	Exhaust turbocharger - Overview	144		
5.6.2	Exhaust turbocharger - Preparatory steps	148		

5.6.3 Exhaust turbocharger - Removal	149	5.9.7 Exhaust pipework after exhaust turbocharger - Overview	208
5.6.4 Exhaust turbocharger - Cleaning	150	5.9.8 Exhaust pipework after turbocharger - Removal	212
5.6.5 Exhaust turbocharger - Check	151	5.9.9 Exhaust pipework after exhaust turbocharger - Installation	213
5.6.6 Exhaust turbocharger - Installation	152		
5.6.7 Exhaust turbocharger - Final steps	155		
5.7 Mixture Cooling	156	5.10 Starting Equipment	214
5.7.1 Mixture cooler - Overview	156	5.10.1 Starter - Overview	214
5.7.2 Mixture cooler - Preparatory steps	158	5.10.2 Starter - Preparatory steps	216
5.7.3 Mixture cooler - Removal	159	5.10.3 Starter - Removal	217
5.7.4 Mixture cooler - Cleaning	160	5.10.4 Starter - Cleaning	218
5.7.5 Mixture cooler - Check	161	5.10.5 Starter - Check	219
5.7.6 Mixture cooler - Installation	162	5.10.6 Starter - Installation	220
5.7.7 Mixture cooler - Final steps	163	5.10.7 Starter - Final steps	222
5.8 Air Intake / Mixture Supply	164	5.11 Lube Oil System, Lube Oil Circuit	223
5.8.1 Air intake / mixture supply - Overview	164	5.11.1 Oil heat exchanger - Overview	223
5.8.2 Air filter and air intake - Overview	168	5.11.2 Oil heat exchanger - Preparatory steps	225
5.8.3 Air filter and air intake - Removal	169	5.11.3 Oil heat exchanger - Removal	226
5.8.4 Air filter and air intake - Installation	170	5.11.4 Oil heat exchanger - Cleaning	227
5.8.5 Mixture line before mixture cooler - Overview	171	5.11.5 Oil heat exchanger - Installation	228
5.8.6 Mixture pipe upstream of mixture cooler - Preparatory steps	175	5.11.6 Oil heat exchanger - Final steps	229
5.8.7 Mixture line upstream of mixture cooler - Removal	176	5.11.7 Exhaust turbocharger oil supply, 16V - Overview	230
5.8.8 Mixture line before mixture cooler - Installation	177	5.11.8 Exhaust turbocharger oil supply, 16V - Removal	231
5.8.9 Mixture pipe upstream of mixture cooler - Final steps	181	5.11.9 Exhaust turbocharger oil supply, 16V - Installation	232
5.8.10 Mixture line downstream of mixture cooler - Overview	182	5.12 Coolant System	233
5.8.11 Mixture pipe downstream of mixture cooler - Preparatory steps	185	5.12.1 Coolant pipework, HT circuit - Overview	233
5.8.12 Mixture pipework downstream of mixture cooler - Removal	186	5.12.2 Coolant pipework, HT circuit - Preparatory steps	236
5.8.13 Mixture line after mixture cooler - Cleaning	187	5.12.3 Coolant pipework, HT circuit - Removal	237
5.8.14 Mixture line downstream of mixture cooler - Installation	188	5.12.4 Coolant pipework, HT circuit - Installation	238
5.8.15 Mixture pipe downstream of mixture cooler - Final steps	189	5.12.5 Coolant pipework, HT circuit - Final steps	240
5.8.16 Heat shield for mixture line - Overview	190	5.12.6 Coolant pipework from/to mixture cooler (HT- circuit) - Overview	241
5.8.17 Jacket for mixture line - Removal	191	5.12.7 Coolant pipework from/to mixture cooler (HT system) - Preparatory steps	243
5.8.18 Heat shield for mixture line - Installation	192	5.12.8 Coolant pipework from/to mixture cooler (HT circuit) - Removal	244
5.8.19 Bypass line - Overview	193	5.12.9 Coolant pipework from/to mixture cooler (HT circuit) - Installation	245
5.8.20 Bypass line - Removal	195	5.12.10 Coolant pipework from/to mixture cooler (HT system) - Final steps	246
5.8.21 Bypass line - Installation	196	5.12.11 Coolant ventilation - Overview	247
5.9 Exhaust Pipework	197	5.12.12 Coolant ventilation - Preparatory steps	251
5.9.1 Exhaust pipework - Overview	197	5.12.13 Coolant ventilation - Removal	252
5.9.2 Exhaust pipework downstream of cylinder head - Overview	201	5.12.14 Coolant ventilation - Installation	253
5.9.3 Exhaust pipework downstream of cylinder head - Preparatory steps	204	5.12.15 Coolant ventilation - Final steps	254
5.9.4 Exhaust pipework after cylinder head - Removal	205	5.12.16 Coolant pipework from/to exhaust turbochargers - Overview	255
5.9.5 Exhaust pipework after cylinder head - Installation	206	5.12.17 Coolant pipework from/to exhaust turbochargers - Preparatory steps	258
5.9.6 Exhaust pipework after cylinder head - Final steps	207	5.12.18 Coolant pipework from/to exhaust turbochargers - Removal	259

5.12.19	Coolant pipework from/to exhaust turbochargers - Installation	260	5.13.8	Engine Control Unit ECU, Engine Monitoring Unit EMU, knock module - Overview	307
5.12.20	Coolant pipework from/to exhaust turbochargers - Final steps	261	5.13.9	Engine Control Unit ECU, Engine Monitoring Unit EMU and knock module - Removal	311
5.12.21	Coolant pipework from/to mixture cooler (LT circuit) - Overview	262	5.13.10	Engine Control Unit ECU, Engine Monitoring Unit EMU and knock module - Installation	312
5.12.22	Coolant pipework from/to mixture cooler (LT system) - Preparatory steps	263			
5.12.23	Coolant pipework from/to mixture cooler (LT circuit) - Removal	264	6	Appendix A	
5.12.24	Coolant pipework from/to mixture cooler (LT circuit) - Installation	265	6.1	Tightening specifications for screws, nuts and bolts	313
5.12.25	Coolant pipework from/to mixture cooler (LT system) - Final steps	266	6.2	Conversion tables	326
5.13	Monitoring, Control and Regulation Equipment	267	6.3	Tolerances and wear limits list - General information	330
5.13.1	Engine wiring - Overview	267	6.4	Abbreviations	331
5.13.2	Sensors - Overview	275	6.5	Repairing tapped holes with thread inserts (Helicoil)	333
5.13.3	Sensors - Preparatory steps	287	6.6	Contact person/Service partner	335
5.13.4	Sensors - Removal	288			
5.13.5	Sensors - Check	295	7	Appendix B	
5.13.6	Sensors - Installation	296	7.1	Special Tools	336
5.13.7	Sensors - Final steps	306	7.2	Index	354

1 Preface

1.1 Preface

This manual provides instructions for your product from the manufacturer MTU.

Definition of MTU

MTU refers to Rolls-Royce Power Systems AG and MTU Friedrichshafen GmbH or an affiliated company pursuant to Section § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture).

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by MTU come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations and emissions label

Responsibility for compliance with emissions regulations

Modification or removal of any mechanical/electronic components or the installation of additional components including the execution of calibration processes that might affect the emissions characteristics of the product are prohibited by emissions regulations. Emissions-related components must only be serviced, exchanged or repaired if the components used for this purpose are approved by the manufacturer.

Noncompliance with these specifications will invalidate the design type approval or certification issued by the emissions regulation authorities. The manufacturer does not accept any liability for violations of the emissions regulations.

The product must be operated over its entire life cycle according to the conditions defined as "Intended use" (→ Page 9).

Emissions certification applicable to engines with EPA Nonroad Tier 4 emissions certification in accordance with 40 CFR 1039 and with EPA Locomotive emissions certification in accordance with 40 CFR 1033

Extract from the standard:

Failing to follow these instructions when installing a certified engine in a piece of nonroad equipment violates federal law (40 CFR 1068.105(b)), subject to fines or other penalties as described in the Clean Air Act.

Extract from the standard:

If you install the engine in a way that makes the engine's emission control information label hard to read during normal engine maintenance, you must place a duplicate label on the equipment, as described in 40 CFR 1068.105.

When fitting the second label, the requirements of 40 CFR 1068.105(c) must be followed and observed. This paragraph describes the process for requesting and fitting the label, the documentation obligations and storage obligations for the required documents.

Replacing components with emissions labels

On all engines from MTU fitted with emissions labels, these labels must remain on the engine throughout its operational life.

Exception: Engines used exclusively in land-based, military applications other than by US government agencies.

Please note the following when replacing components with emissions labels:

- The relevant emissions labels must be affixed to the spare part.
- Emissions labels shall not be transferred from the replaced part to the spare part.
- The emissions labels must be removed from the replaced part and destroyed.

2.2 Intended use of all products

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/MTU contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all safety and warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

2.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.