



Operating Instructions

Gas engine-generator sets

MTU 8V4000 GS – GG08V4000A1/A2 with engines 8V4000L32/
L32FB/L33

MTU 12V4000 GS – GG12V4000A1/A2 with engines 12V4000L32/
L32FB/L33

MTU 16V4000 GS – GG16V4000A1/A2 with engines 16V4000L32/
L32FB/L33

MTU 20V4000 GS – GG20V4000A1/A2 with engines 20V4000L32/
L32FB/L33

SS180135/02E



A Rolls-Royce
solution

Product name	Model number	Engine model	Application group
MTU 8V4000 GS	GG08V4000A1	8V4000L32 8V4000L32FB 8V4000L33	3A, continuous operation, unrestricted
MTU 8V4000 GS	GG08V4000A2	8V4000L32 8V4000L32FB 8V4000L33	3A, continuous operation, unrestricted
MTU 12V4000 GS	GG12V4000A1	12V4000L32 12V4000L32FB 12V4000L33	3A, continuous operation, unrestricted
MTU 12V4000 GS	GG12V4000A2	12V4000L32 12V4000L32FB 12V4000L33	3A, continuous operation, unrestricted
MTU 16V4000 GS	GG16V4000A1	16V4000L32 16V4000L32FB 16V4000L33	3A, continuous operation, unrestricted
MTU 16V4000 GS	GG16V4000A2	16V4000L32 16V4000L32FB 16V4000L33	3A, continuous operation, unrestricted
MTU 20V4000 GS	GG20V4000A1	20V4000L32 20V4000L32FB 20V4000L33	3A, continuous operation, unrestricted
MTU 20V4000 GS	GG20V4000A2	20V4000L32 20V4000L32FB 20V4000L33	3A, continuous operation, unrestricted

Table of Contents

1	Preface		4.2.2	Engine-generator set - Application group	48
1.1	Preface	6	4.2.3	Engine-generator set - Nameplate and designation	49
2	Safety		4.2.4	Engine-generator set - Standard scope of delivery	52
2.1	Important provisions for all products	7	4.2.5	Engine-generator set - Optional scope of supply	60
2.2	Gas systems - Intended use	9	4.3	Engine	61
2.3	Personnel and organizational requirements	11	4.3.1	Engine - Overview	61
2.4	Safety regulations for initial start-up and operation	12	4.3.2	Engine side and cylinder designations	68
2.5	Safety regulations for commissioning and operation, specific information for gaseous fuel supply or and dual fuel applications	14	4.3.3	Sensors - Overview	69
2.6	Safety regulations for assembly, maintenance, and repair work	16	4.3.4	Mixture formation, turbocharging and exhaust system	73
2.7	Safety regulations for assembly, maintenance and servicing work, specific information for gaseous fuel and dual fuel supply or applications	20	4.3.5	Lube oil system	76
2.8	Fire and environmental protection, indirect materials	21	4.3.6	Cooling system	78
2.9	Fire prevention and environmental protection, fluids and lubricants, auxiliary materials, specific information for gaseous fuel supply in gaseous-fuel or dual-fuel applications	24	4.4	Gearbox / Transmission	83
2.10	Standards for warning notices in the text and highlighted information	25	4.4.1	Gearbox	83
2.11	Conventions for warning notices on safety signs on the engine-generator set	26	4.5	Generator	85
2.12	Safety signs on engine-generator set - Overview	28	4.5.1	Generator - General information	85
2.13	Overview of protective devices on the engine-generator set	30	4.5.2	Coupling	86
3	Transport		4.6	Monitoring and Control	87
3.1	Transport	32	4.6.1	MIP and MMC control system	87
3.2	Transport locking device for engine mounting	39	4.7	Charge-air System and Gas System	88
3.3	Transport locking device - Generator mounting	40	4.7.1	Compressor	88
3.4	Crankshaft transport locking device	42	4.7.2	Gas train	89
3.5	Tie-down instructions	44	4.7.3	Air filter	91
4	Functional Description		4.8	Exhaust System	93
4.1	Chapter overview	46	4.8.1	Exhaust gas heat exchanger	93
4.2	Engine-Generator Set	47	4.8.2	Catalytic converter	95
4.2.1	General description	47	4.8.3	Exhaust silencer	96
			4.9	Lube Oil System	97
			4.9.1	Lube oil system - Engine-generator set	97
			4.9.2	Oil priming pump	99
			4.10	Cooling System and Heating Water System	100
			4.10.1	Cooling system - Engine-generator set	100
			4.10.2	Heat recovery module	103
			4.11	Base Frame	106
			4.11.1	Mounting	106
			4.12	Monitoring, Control and Regulation Equipment	107
			4.12.1	Gas engine phase 4 system - Overview	107
			4.12.2	Purpose of the units	109
			4.13	Electrical System	111
			4.13.1	Starter battery	111
			4.13.2	Battery charger	112
			4.14	Gas Alarm and Fire Alarm	113
			4.14.1	Gas alarm system	113
			4.14.2	Fire detector	114

5	Technical Data	
5.1	Technical data	116
6	Operation	
6.1	Chapter overview	117
6.2	Conduct in case of activated gas alarm	118
6.3	Conduct in case of activated fire alarm	119
6.4	Conduct in case of activation of safety functions	120
6.5	Operating room - Check for smell of gas	121
6.6	Emission values - Check	122
6.7	Lockout/tagout procedure	124
6.8	Unlocking procedure	126
6.9	Control, starting and stopping sequences	128
6.10	Runtimes at partial load	130
6.11	Automatic start and shutdown	131
6.12	Engine-generator set - Starting in Manual mode	132
6.13	Status signals	134
6.14	Operational monitoring	148
6.15	Engine-generator set - Shutdown in Manual mode	150
6.16	Emergency shutdown	151
6.17	After shutdown	152
6.18	Re-starting the engine following an automatic safety shutdown	153
6.19	Putting the engine-generator set into operation after extended out-of-service-period	154
7	Troubleshooting	
7.1	Chapter overview	157
7.2	MMC controller - Fault messages	158
7.3	Engine Control Unit - Fault messages	320
8	Maintenance	
8.1	Maintenance task reference table [QL1] for natural gas	362
8.2	Maintenance task reference table [QL1], biogas	365
9	Task Description	
9.1	Chapter overview	367
9.2	Engine-Generator Set	368
9.2.1	Performing test run	368
9.2.2	Starting sequence - Monitoring	369

9.2.3	Operating data check after 3000 hours (natural gas)	370
9.2.4	Operating data check after 3000 hours (biogas)	372
9.2.5	Shutdown criteria - Check	374
9.3	Engine	375
9.3.1	Work with special qualifications	375
9.3.2	Engine - Barring manually	376
9.3.3	Oil separator - Filter replacement	377
9.3.4	Spark plug - Replacement	379
9.3.5	Spark plug - Removal	380
9.3.6	Spark plug - Installation	381
9.3.7	Spark plug connector - Replacement	383
9.3.8	Spark plug connector - Removal	384
9.3.9	Spark plug connector - Cleaning and check	385
9.3.10	Spark plug connector - Installation	386
9.3.11	Ignition system - Ignition timing check	388
9.3.12	Crankcase breather - Pressure control check and adjustment	389
9.3.13	Valve protrusion - Measurement	390
9.3.14	Valve gear - Lubrication	393
9.3.15	Valve clearance - Check and adjustment	394
9.3.16	Cylinder head cover - Removal	397
9.3.17	Cylinder head cover - Installation	398
9.3.18	Engine oil level - Check	399
9.3.19	Engine oil - Change	400
9.3.20	Engine oil - Sample extraction and analysis	401
9.3.21	Engine oil filter - Replacement	403
9.3.22	Coolant and antifreeze - Check	405
9.3.23	Engine coolant level - Check	406
9.3.24	Engine coolant - Change	407
9.3.25	Engine coolant - Draining	408
9.3.26	Engine coolant - Filling	410
9.3.27	Coolant vent line (engine coolant circuit) - Replacement	411
9.3.28	Mixture cooler - Check	412
9.3.29	Mixture coolant level - Check	413
9.3.30	Mixture coolant - Change	414
9.3.31	Mixture coolant - Draining	415
9.3.32	Mixture coolant - Filling	416
9.3.33	Starter - Replacement	417
9.3.34	Engine cabling - Check	420
9.3.35	Sensors - Removal	421
9.3.36	Sensors - Installation	423
9.3.37	Engine mounting - Checking resilient element	424
9.3.38	Engine mounting - Checking securing screws for firm seating	425
9.4	Gearbox / Transmission	426
9.4.1	Gearbox and oil circulation system - Check	426
9.4.2	Gear oil - Check	427
9.4.3	Gear oil - Sample extraction	428
9.4.4	Gear oil - Change	430
9.4.5	Gearbox - Cleaning	432
9.4.6	Oil filter - Cleaning	433
9.4.7	Bearing and housing temperature - Check	434
9.5	Generator	435
9.5.1	Cummins Generator	435

9.5.1.1	Bearing and winding temperature - Check	435	9.9.1	Exhaust temperature before/after exhaust gas heat exchanger - Check	480
9.5.1.2	Intake grill - Cleaning	436	9.9.2	Exhaust back pressure before/after exhaust gas heat exchanger - Check	482
9.5.1.3	Air filter - Replacement	437	9.9.3	Exhaust back pressure before/after catalytic converter - Check	484
9.5.1.4	Antifriction bearings - Lubrication	438	9.9.4	Condensate and neutralization system - Check	485
9.5.1.5	Antifriction bearings - Replacement	440	9.9.5	Exhaust flap - Check	486
9.5.1.6	Oil separator - Cleaning	441	9.9.6	Coolant flow rate - Check	487
9.5.1.7	Coupling element - Check	443	9.10	Cooling System and Heating Water System	488
9.5.1.8	Windings - Check	445	9.10.1	Rubber bellows and hoses - Check	488
9.5.1.9	Windings - Drying	447	9.10.2	Coolant pump - Engine mount lubrication	489
9.5.2	Leroy-Somer Generator	449	9.10.3	Coolant pump - Check	490
9.5.2.1	Bearing and winding temperature - Check	449	9.11	Electrical System	492
9.5.2.2	Intake grill - Cleaning	450	9.11.1	Working in the control cabinet	492
9.5.2.3	Antifriction bearings - Lubrication	452	9.11.2	Starter battery - Check	493
9.5.2.4	Coupling element - Check	454	9.11.3	Control cabinet - Filter fan contamination check	494
9.5.2.5	Windings - Check	456	9.11.4	Control cabinet - Filter mat replacement	495
9.5.2.6	Windings - Drying	458	9.11.5	Control cabinet - Filter fan and noise generation check	496
9.6	Air Intake / Mixture Supply	460	9.11.6	Control cabinet - Cooling unit noise generation check	497
9.6.1	Air filter - Replacement	460	9.11.7	Control cabinet - Cooling unit cooling function check	498
9.6.2	Air filter - Removal and installation	461	9.11.8	Control cabinet - Checking cooling louvers on cooling unit	499
9.7	Gas System	462	9.11.9	Control cabinet - Cleaning cooling louvers on cooling unit	500
9.7.1	Gas filter differential pressure - Check	462	10	Appendix A	
9.7.2	Gas filter - Replacement	464	10.1	Abbreviations	501
9.7.3	Valve leak control - Function check	466	10.2	Conversion tables	503
9.7.4	Shut-off device - Check	468	10.3	Contact person/Service partner	507
9.7.5	Gas supply - Checking gas lines for leaks	469	11	Appendix B	
9.7.6	Deflagration arrester and flame arrester - Check	470	11.1	Special Tools	508
9.7.7	Deflagration arrester (without test opening) - Check	471	11.2	Consumables	514
9.7.8	Deflagration arrester (with test opening) - Check	472	11.3	Index	516
9.7.9	Flame arrester - Replacement	474			
9.7.10	Deflagration arrester and flame arrester - Removal	475			
9.7.11	Deflagration arrester and flame arrester - Installation	477			
9.7.12	Flame arrestor filter - Cleaning	478			
9.8	Lube Oil System, Lube Oil Circuit	479			
9.8.1	Lube oil tank - Removing water and oil sludge	479			
9.9	Exhaust System	480			

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper operation of your engine-generator set from the manufacturer MTU. It is vitally important that all persons working on or with the engine-generator set are familiar with all the contents of this manual and follow the instructions provided carefully at all times.

In some cases, it may prove necessary to depart from the guidelines specified in this manual in response to extraneous circumstances. Any such departure must comply with locally applicable directives and standards. All relevant safety directives and safety precautions shall be duly considered and respected.

Following these Operating Instructions will ensure that the plant operates efficiently and reliably.

All procedural instructions and safety precautions shall be followed closely to ensure that the plant operates as intended and to avoid injury or harm. Read and follow the instructions in the "Safety" section at the beginning of this manual.

All the instructions and diagrams have been checked to ensure accuracy and user-friendliness, however the skills and qualification of the operating personnel remain the most significant factor nevertheless. MTU cannot give any assurances for the actual results of any work performed according to the descriptions provided in this manual, nor shall MTU be held liable for any resultant personal injury or material damage. Personnel charged with running and operating the plant do so entirely at their own risk.

Other documents included in the scope of supply shall also be given due consideration in addition to these Operating Instructions.

All documents required by Machinery Directive 2006/42/EC are included in the standard scope of documentation for the engine-generator set. The following documents are supplied in addition:

- Test records
- Spare parts catalog
- Wiring diagrams

Definition of MTU

MTU refers to Rolls-Royce Power Systems AG and MTU Friedrichshafen GmbH or an affiliated company pursuant to Section § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture).

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by MTU come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations and emissions label

Responsibility for compliance with emissions regulations

Modification or removal of any mechanical/electronic components or the installation of additional components including the execution of calibration processes that might affect the emissions characteristics of the product are prohibited by emissions regulations. Emissions-related components must only be serviced, exchanged or repaired if the components used for this purpose are approved by the manufacturer.

Noncompliance with these specifications will invalidate the design type approval or certification issued by the emissions regulation authorities. The manufacturer does not accept any liability for violations of the emissions regulations.

The product must be operated over its entire life cycle according to the conditions defined as "Intended use" (→ Page 9).

Emissions certification applicable to engines with EPA Nonroad Tier 4 emissions certification in accordance with 40 CFR 1039 and with EPA Locomotive emissions certification in accordance with 40 CFR 1033

Extract from the standard:

Failing to follow these instructions when installing a certified engine in a piece of nonroad equipment violates federal law (40 CFR 1068.105(b)), subject to fines or other penalties as described in the Clean Air Act.

Extract from the standard:

If you install the engine in a way that makes the engine's emission control information label hard to read during normal engine maintenance, you must place a duplicate label on the equipment, as described in 40 CFR 1068.105.

When fitting the second label, the requirements of 40 CFR 1068.105(c) must be followed and observed. This paragraph describes the process for requesting and fitting the label, the documentation obligations and storage obligations for the required documents.

Replacing components with emissions labels

On all engines from MTU fitted with emissions labels, these labels must remain on the engine throughout its operational life.

Exception: Engines used exclusively in land-based, military applications other than by US government agencies.

Please note the following when replacing components with emissions labels:

- The relevant emissions labels must be affixed to the spare part.
- Emissions labels shall not be transferred from the replaced part to the spare part.
- The emissions labels must be removed from the replaced part and destroyed.

2.2 Gas systems – Intended use

Intended use

The machine is intended to be used exclusively for electrical power generation and waste heat utilization in stationary operation, either in sufficiently ventilated rooms or in container solutions.

A gas/air mixture is fed to the internal combustion reciprocating piston engine. This is converted into mechanical work in the individual cylinders through combustion. The flywheel of the engine drives the synchronous generator connected via an elastic coupling, resulting in a conversion to electric energy. The engine and the generator are joined to the base frame with resilient, vibration-damped elements. For mains frequency 60 Hz, depending on the series either a gearbox is used between the engine and generator (Series 4000) or the engine speed is increased accordingly (Series 400). The waste heat generated during the combustion process is dissipated to the surroundings via coolers (power generator) and/or made available to the customer via heat exchangers (combined heat and power plant).

Area of application	Applicable	Comment
Industry	Yes	–
Business/Service	Yes	In some individual cases, however, such as with swimming pool facilities, schools, heating stations for apartment buildings and the like, no end user in the classic sense is involved
Household	No	Operation is excluded
Potentially explosive area	No	Operation is not permitted in potentially explosive areas
Underground	No	Operation is excluded
Mobile use	No	Operation is excluded

Table 1: Area of application of machine

There are 3 operating modes of the machine:

- Mains parallel operation
- Mains failure operation
- Isolated operation

Foreseeable misuse

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper use.

Operation

Operation is not permissible if the physical conditions specified on the technical data sheet or on/in other documents (concerning temperature, pressure, site altitude, etc.) are not complied with. Operation is not permissible without protective equipment, usage of approved spare parts, exclusion of conversions, warning of foreseeable misuse.

Operation is only permissible with the use of fluids and lubricants (natural gas, biogas, quality-compliant gas, quality-compliant water, lubricants) in accordance with the (→ Fluids and Lubricants Specifications).

Operation is only permissible with preservation agents approved by MTU in accordance with the (→ Preservation and Represervation Specifications).

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version of these are adopted. The latest version can be found at:

- <http://www.mtu-solutions.com>

Surroundings, climate, temperature

The weather plays no role with regard to the intended use of the engine-generator set/module provided that operation takes place inside an installation room. For container applications, however, the permissible outdoor temperatures at the installation site play a decisive role. The product-specific ambient conditions such as climate and temperature are indicated in the technical description.

Prerequisite for proper use

Fulfillment of all the requirements set out in the “Installation conditions” document.

Any use that does not fall within the described limits for use is regarded as improper.

Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.

Modifications or conversions

Unauthorized changes to the product breach the conditions concerning its intended use and compromise safety.

Only modifications or conversions expressly authorized by the manufacturer are regarded as compliant in this sense. The manufacturer shall not be held liable for any damage resulting from unauthorized modifications or conversions.